

Kollmorgen Automation Suite

KAS Reference Manual - Motion Library



Document Edition: V, December 2022

Valid for KAS Software Revision 4.00

Part Number: 959716



For safe and proper use, follow these instructions. Keep for future use.

1 Trademarks and Copyrights

Copyrights

Copyright © 2009-2022 Kollmorgen

Information in this document is subject to change without notice. The software package described in this document is furnished under a license agreement. The software package may be used or copied only in accordance with the terms of the license agreement.

This document is the intellectual property of Kollmorgen and contains proprietary and confidential information. The reproduction, modification, translation or disclosure to third parties of this document (in whole or in part) is strictly prohibited without the prior written permission of Kollmorgen.

Trademarks

- KAS and AKD are registered trademarks of [Kollmorgen](#).
- [Kollmorgen](#) is part of the [Altra Industrial Motion](#) Company.
- EnDat is a registered trademark of Dr. Johannes Heidenhain GmbH
- EtherCAT is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH
- Ethernet/IP is a registered trademark of ODVA, Inc.
- Ethernet/IP Communication Stack: copyright (c) 2009, Rockwell Automation
- HIPERFACE is a registered trademark of Max Stegmann GmbH
- PROFINET is a registered trademark of PROFIBUS and PROFINET International (PI)
- SIMATIC is a registered trademark of SIEMENS AG
- Windows is a registered trademark of Microsoft Corporation
- [PLCopen](#) is an independent association providing efficiency in industrial automation.
- Codemeter is a registered trademark of [WIBU-Systems AG](#).
- SyCon® is a registered trademark of [Hilscher GmbH](#).

Kollmorgen Automation Suite is based on the work of:

- [7-zip](#) (distributed under the terms of the LGPL and the BSD 3-clause licenses - [see terms](#))
- The [C++ Mathematical Expression Library](#) (distributed under [the MIT License](#))
- [curl](#) software library
- [JsonCpp](#) software (distributed under the MIT License - [see terms](#))
- [Mongoose](#) software (distributed under the MIT License - [see terms](#))
- [Qt](#) cross-platform SDK (distributed under the terms of the LGPL3; Qt source is available on KDN)
- [Qwt](#) project (distributed under the terms of the [Qwt License](#))
- [U-Boot](#), a universal boot loader is used by the AKD PDMM and PCMM (distributed under the [terms](#) of the GNU General Public License). The U-Boot source files, copyright notice, and readme are available on the distribution disk that is included with the AKD PDMM and PCMM.
- [Zlib](#) software library

All other product and brand names listed in this document may be trademarks or registered trademarks of their respective owners.

Disclaimer

The information in this document (Version V published on 12/7/2022) is believed to be accurate and reliable at the time of its release. Notwithstanding the foregoing, Kollmorgen assumes no responsibility for any damage or loss resulting from the use of this help, and expressly disclaims any liability or damages for loss of data, loss of use, and property damage of any kind, direct, incidental or consequential, in regard to or arising out of the performance or form of the materials presented herein or in any software programs that accompany this document.

All timing diagrams, whether produced by Kollmorgen or included by courtesy of the PLCopen organization, are provided with accuracy on a best-effort basis with no warranty, explicit or implied, by Kollmorgen. The user releases Kollmorgen from any liability arising out of the use of these timing diagrams.

2 Table of Contents

1 Trademarks and Copyrights	2
2 Table of Contents	3
3 Motion Library	20
3.1 Motion Library - PipeNetwork	20
3.1.1 Motion Library - Adder	20
3.1.1.1 MlAddInit	21
3.1.1.2 MlAddReadOff1	22
3.1.1.3 MlAddReadOff2	24
3.1.1.4 MlAddReadRatio1	25
3.1.1.5 MlAddReadRatio2	26
3.1.1.6 MlAddWriteInput	27
3.1.1.7 MlAddWriteOff1	28
3.1.1.8 MlAddWriteOff2	29
3.1.1.9 MlAddWriteRat1	31
3.1.1.10 MlAddWriteRat2	32
3.1.2 Motion Library - Block	33
3.1.2.1 MlBlkCreate	33
3.1.2.2 MlBlkIsReady	34
3.1.2.3 MlBlkReadModPos	35
3.1.2.4 MlBlkReadOutVal	36
3.1.2.5 MlBlkWriteModPos	37
3.1.3 Motion Library - Pipe Network	38
3.1.3.1 MlPipeAct	39
3.1.3.2 MlPipeAddBlock	40
3.1.3.3 MlPipeCreate	42
3.1.3.4 MlPipeDeact	43
3.1.4 Motion Library - Axis	45
3.1.4.1 Function by Types	45
3.1.4.2 Functions in Alphabetical Order	45
3.1.4.3 MlAxisAbs	47
3.1.4.4 Position with Modulo On	48
3.1.4.5 Forcing the direction of rotation	49
3.1.4.6 Travel Speed Update with MlAxisAbs	50
3.1.4.7 MlAxisAdd	51
3.1.4.8 MlAxisAddress	52
3.1.4.9 MlAxisAddTq	53
3.1.4.10 MlAxisCfgFastIn	55
3.1.4.11 MlAxisCmdPos	56
3.1.4.12 MlAxisDriveNumber	57
3.1.4.13 MlAxisFBackPos	59
3.1.4.14 MlAxisGenEN	60
3.1.4.15 MlAxisGenIsEN	61
3.1.4.16 MlAxisGenIsRdy	62
3.1.4.17 MlAxisGenPos	63

3.1.4.18	MLAxisGenReadAcc	64
3.1.4.19	MLAxisGenReadDec	66
3.1.4.20	MLAxisGenReadSpd	67
3.1.4.21	MLAxisGenWriteAcc	68
3.1.4.22	MLAxisGenWriteDec	69
3.1.4.23	MLAxisGenWriteSpd	70
3.1.4.24	MLAxisInit	71
3.1.4.25	MLAxisIsCnctd	74
3.1.4.26	MLAxisIsTriggered	74
3.1.4.27	MLAxisMoveVel	76
3.1.4.28	MLAxisPipePos	77
3.1.4.29	MLAxisPower	78
3.1.4.30	MLAxisPowerDOff	79
3.1.4.31	MLAxisRatedTq	80
3.1.4.32	MLAxisReadActPos	81
3.1.4.33	MLAxisReadFBUnit	82
3.1.4.34	MLAxisReadFEUU	83
3.1.4.35	MLAxisReadGenStatus	84
3.1.4.36	MLAxisReadModPos	85
3.1.4.37	MLAxisReadTq	86
3.1.4.38	MLAxisReadUUnits	87
3.1.4.39	MLAxisReadVel	88
3.1.4.40	MLAxisReAlgnRdy	89
3.1.4.41	MLAxisReAlign	90
3.1.4.42	MLAxisRel	92
3.1.4.43	MLAxisResetErrors	94
3.1.4.44	MLAxisRstFastIn	95
3.1.4.45	MLAxisStatus	96
3.1.4.46	MLAxisStop	98
3.1.4.47	MLAxisTimeStamp	100
3.1.4.48	MLAxisWriteModPos	102
3.1.4.49	MLAxisWritePipPos	103
3.1.4.50	MLAxisWritePos	104
3.1.4.51	MLAxisWriteUUnits	106
3.1.4.52	MLPNAxisCreate	107
3.1.4.53	Examples of Axis Functions	109
3.1.5	Motion Library - Cam Profile	110
3.1.5.1	MLCamInit	111
3.1.5.2	MLCamSwitch	113
3.1.5.3	MLPrfReadIOffset	114
3.1.5.4	MLPrfReadIScale	115
3.1.5.5	MLPrfReadOOffset	117
3.1.5.6	MLPrfReadOScale	118
3.1.5.7	MLPrfWriteIOffset	119
3.1.5.8	MLPrfWriteIScale	120
3.1.5.9	MLPrfWriteOOffset	122
3.1.5.10	MLPrfWriteOScale	123

3.1.6 Motion Library - Comparator	125
3.1.6.1 Usage Example of Comparator Functions	125
3.1.6.2 MLCompCheck	128
3.1.6.3 MLCompInit	129
3.1.6.4 MLCompReadRef	131
3.1.6.5 MLCompReset	132
3.1.6.6 MLCompWriteRef	133
3.1.7 Motion Library - Convertor	134
3.1.7.1 MLCNVConECAT	135
3.1.7.2 MLCNVConnect	137
3.1.7.3 MLCNVConnectEx	138
3.1.7.4 MLCNVDisconnect	141
3.1.7.5 MLCNVInit	142
3.1.8 Motion Library - Delay	143
3.1.8.1 MLDelayInit	143
3.1.9 Motion Library - Derivator	144
3.1.9.1 MLDerInit	144
3.1.9.2 MLDerReadInModPos	146
3.1.9.3 MLDerWriteInModPos	147
3.1.10 Motion Library - Gear	149
3.1.10.1 Usage example of Gear Functions	149
3.1.10.2 MLGearInit	151
3.1.10.3 MLGearReadOffset	155
3.1.10.4 MLGearReadOffSlp	155
3.1.10.5 MLGearReadRatio	156
3.1.10.6 MLGearReadRatSlp	157
3.1.10.7 MLGearWriteOff	158
3.1.10.8 MLGearWriteOSlp	160
3.1.10.9 MLGearWriteRatio	161
3.1.10.10 MLGearWriteRatSlp	162
3.1.11 Motion Library - Integrator	164
3.1.11.1 MLIntWriteOutVal	164
3.1.11.2 MLIntInit	165
3.1.12 Motion Library - Master	167
3.1.12.1 Examples of Master Functions	168
3.1.12.2 MLMstAbs	169
3.1.12.3 Position with Modulo On	169
3.1.12.4 Forcing the direction of rotation	170
3.1.12.5 Travel Speed Update with MLAxisAbs	171
3.1.12.6 MLMstAdd	173
3.1.12.7 MLMstForcePos	174
3.1.12.8 MLMstInit	176
3.1.12.9 MLMstReadAccel	179
3.1.12.10 Function Block Diagram	180
3.1.12.11 MLMstReadDecel	180
3.1.12.12 MLMstReadInitPos	181
3.1.12.13 MLMstReadSpeed	182

3.1.12.14	MLMstRel	183
3.1.12.15	MLMstRun	184
3.1.12.16	MLMstStatus	186
3.1.12.17	MLMstWriteAccel	187
3.1.12.18	MLMstWriteDecel	189
3.1.12.19	MLMstWriteInitPos	190
3.1.12.20	MLMstWriteSpeed	191
3.1.13	Motion Library - Phaser	193
3.1.13.1	Example: Phaser Functions	193
3.1.13.2	MLPhaInit	194
3.1.13.3	MLPhaReadActPhase	196
3.1.13.4	MLPhaReadPhase	197
3.1.13.5	MLPhaReadSlope	198
3.1.13.6	MLPhaWritePhase	199
3.1.13.7	MLPhaWriteSlope	200
3.1.14	Motion Library - PMP	201
3.1.14.1	MLPmpAbs	202
3.1.14.2	MLPmpForcePos	203
3.1.14.3	MLPmpInit	205
3.1.14.4	MLPmpReadAccel	208
3.1.14.5	MLPmpReadFstSpd	209
3.1.14.6	MLPmpReadInitPos	210
3.1.14.7	MLPmpReadJerk	211
3.1.14.8	MLPmpReadLstSpd	212
3.1.14.9	MLPmpRel	213
3.1.14.10	MLPmpRun	215
3.1.14.11	MLPmpStatus	216
3.1.14.12	MLPmpWriteAccel	218
3.1.14.13	MLPmpWriteFstSpd	219
3.1.14.14	MLPmpWriteJerk	220
3.1.14.15	MLPmpWriteLstSpd	221
3.1.15	Motion Library - Sampler	223
3.1.15.1	MLSmpConECAT	223
3.1.15.2	MLSmpConnect	226
3.1.15.3	MLSmpConPLCAxis	227
3.1.15.4	MLSmpConPNAxis	228
3.1.15.5	MLSmpInit	230
3.1.16	Motion Library - Synchronizer	233
3.1.16.1	Usage Example of Synchronizer Functions	233
3.1.16.2	MLSyncInit	234
3.1.16.3	MLSyncReadDeltaS	236
3.1.16.4	MLSyncStart	238
3.1.16.5	MLSyncStop	239
3.1.16.6	MLSyncWriteDeltaS	240
3.1.17	Motion Library - Trigger	242
3.1.17.1	Usage Example of Trigger Functions	243
3.1.17.2	MLTrigClearFlag	244

3.1.17.3	MLTrigInit	245
3.1.17.4	MLTrigIsTriggered	248
3.1.17.5	MLTrigReadDelay	250
3.1.17.6	MLTrigReadPos	250
3.1.17.7	MLTrigReadTime	252
3.1.17.8	MLTrigSetEdge	254
3.1.17.9	MLTrigWriteDelay	255
3.2	Motion Library - PLCopen	256
3.2.1	Control Functions	258
3.2.1.1	MC_ClearFaults	258
3.2.1.2	MC_CreatePLCAxis	259
3.2.1.3	MC_EStop	263
3.2.1.4	MC_InitAxis	264
3.2.1.5	MC_InitAxisFeedback	267
3.2.1.6	MC_Power	269
3.2.1.7	MC_ErrorDescription	271
3.2.1.8	MC_ResetError	273
3.2.1.9	MC_Stop	274
3.2.2	I/O Functions	277
3.2.2.1	MC_AbortTrigger	277
3.2.2.2	MC_TouchProbe	279
3.2.3	Information Functions	286
3.2.3.1	MC_ReadActPos	286
3.2.3.2	MC_ReadActVel	288
3.2.3.3	MC_ReadAxisErr	290
3.2.3.4	MC_ReadBoolPar	292
3.2.3.5	MC_ReadParam	293
3.2.3.6	MC_ReadStatus	295
3.2.3.7	MC_WriteBoolPar	297
3.2.3.8	MC_WriteParam	299
3.2.4	PLCOpenMotion Functions	301
3.2.4.1	MC_Halt	301
3.2.4.2	MC_MoveAbsolute	304
3.2.4.3	MC_MoveAdditive	309
3.2.4.4	MC_MoveRelative	313
3.2.4.5	MC_MoveSuperimp	317
3.2.4.6	MC_MoveVelocity	321
3.2.4.7	MC_MoveContVel	324
3.2.4.8	MC_SetOverride	328
3.2.5	Profile Functions	330
3.2.5.1	MC_CamIn	330
3.2.5.2	MC_CamOut	338
3.2.5.3	MC_CamResumePos	341
3.2.5.4	MC_CamStartPos	343
3.2.5.5	MC_CamTblSelect	347
3.2.5.6	MC_GearIn	350
3.2.5.7	MC_GearInPos	354

3.2.5.8 MC_GearOut	360
3.2.5.9 MC_Phasing	362
3.2.5.10 MC_SyncSlaves	366
3.2.6 Reference Functions	368
3.2.6.1 MC_Reference	368
3.2.6.2 MC_SetPos	373
3.2.6.3 MC_SetPosition	376
3.2.7 Registration Function Blocks	376
3.2.7.1 MC_MachRegist	376
3.2.7.2 Description	376
3.2.7.3 MC_MarkRegist	384
3.2.7.4 MC_StopRegist	390
3.2.8 Superimposed Axes	392
3.2.8.1 MC_AddSuperAxis	392
3.2.8.2 MC_RemSuperAxis	394
3.3 Motion Library- Common	395
3.3.1 Motion Library - Common - Info	396
3.3.1.1 MC_ErrorDescription	396
3.3.2 Motion Library - Common - Profiles	398
3.3.2.1 MLProfileBuild	398
3.3.2.2 MLProfileCreate	406
3.3.2.3 MLProfileInit	408
3.3.2.4 MLProfileRelease	410
3.3.3 Motion Library	413
3.3.3.1 State Machine	413
3.3.3.2 MLMotionCycleTime	414
3.3.3.3 MLMotionInit	414
3.3.3.4 MLMotionRstErr	416
3.3.3.5 MLMotionStart	417
3.3.3.6 MLMotionStatus	418
3.3.3.7 MLMotionStop	420
3.3.4 Coordinated Motion Function Blocks	421
3.3.4.1 Group Control	421
3.3.4.2 Info	422
3.3.4.3 Motion	422
3.3.4.4 Reference	423
3.3.4.5 Coordinated Motion Group Control Library	424
3.3.5 Related Functions	425
3.3.6 Input	425
3.3.7 Output	426
3.3.8 Structured Text	426
3.3.9 IL	427
3.3.10 FBD	427
3.3.11 Ladder Diagram	427
3.3.12 Related Function Blocks	428
3.3.13 Structured Text	430
3.3.14 Instruction List	430

3.3.15 Function Block Diagram	430
3.3.16 Ladder Diagram	430
3.3.17 Related Functions	431
3.3.18 Input	431
3.3.19 Output	431
3.3.20 ST	432
3.3.21 IL	432
3.3.22 FBD	432
3.3.23 FFLD	432
3.3.24 Related Function Blocks	434
3.3.25 Input	434
3.3.26 Output	435
3.3.27 ST	435
3.3.28 IL	436
3.3.29 FBD	436
3.3.30 FFLD	436
3.3.31 Input	437
3.3.32 Output	437
3.3.33 ST	437
3.3.34 FBD	438
3.3.35 FFLD	438
3.3.36 Related Functions	438
3.3.37 Input	439
3.3.38 Output	439
3.3.39 ST	439
3.3.40 FBD	439
3.3.41 IL	440
3.3.42 FFLD	440
3.3.43 Related Functions	441
3.3.44 Input	441
3.3.45 Output	441
3.3.46 Structured Text	442
3.3.47 IL	442
3.3.48 FBD	442
3.3.49 FFLD	442
3.3.50 Related Function Blocks	443
3.3.51 Input	443
3.3.52 Output	444
3.3.53 ST	444
3.3.54 IL	444
3.3.55 FBD	445
3.3.56 FFLD	445
3.3.57 Input	445
3.3.58 Output	446
3.3.59 ST	446
3.3.60 FBD	447
3.3.61 FFLD	447

3.3.62 Related Function Blocks	447
3.3.63 Inputs	447
3.3.64 Outputs	449
3.3.65 Structured Text	449
3.3.66 IL	449
3.3.67 FBD	449
3.3.68 FFLD	449
3.3.69 Related Functions	450
3.3.70 Input	450
3.3.71 Output	451
3.3.72 ST	451
3.3.73 IL	451
3.3.74 FBD	452
3.3.75 FFLD	452
3.3.76 Input	452
3.3.77 Output	453
3.3.78 Structured Text	453
3.3.79 Function Block Diagram	454
3.3.80 Ladder Diagram	454
3.3.81 Related Functions	455
3.3.82 Input	456
3.3.83 Output	456
3.3.84 ST	456
3.3.85 IL	456
3.3.86 FBD	456
3.3.87 FFLD	457
3.3.87.1 Coordinated Motion Info Library	460
3.3.88 Related Functions	462
3.3.89 Input	462
3.3.90 Output	463
3.3.91 Structured Text	463
3.3.92 IL	463
3.3.93 FBD	463
3.3.94 Ladder Diagram	463
3.3.95 Related Functions	464
3.3.96 Input	464
3.3.97 Output	465
3.3.98 Structured Text	465
3.3.99 IL	466
3.3.100 FBD	466
3.3.101 Ladder Diagram	466
3.3.102 Related Functions	467
3.3.103 Input	467
3.3.104 Output	468
3.3.105 Structured Text	468
3.3.106 IL	468
3.3.107 FBD	468

3.3.108 FFLD	469
3.3.109 Related Function Blocks	469
3.3.110 Input	470
3.3.111 Output	470
3.3.112 Structured Text	471
3.3.113 IL	471
3.3.114 FBD	471
3.3.115 FFLD	471
3.3.116 Related Function Blocks	472
3.3.117 Input	472
3.3.118 Output	473
3.3.119 Structured Text	473
3.3.120 IL	474
3.3.121 FBD	474
3.3.122 FFLD	474
3.3.123 Related Functions	474
3.3.124 Input	475
3.3.125 Output	475
3.3.126 Structured Text	475
3.3.127 FBD	475
3.3.128 FFLD	475
3.3.129 Related Functions	476
3.3.130 Structured Text	478
3.3.131 IL	478
3.3.132 FBD	479
3.3.133 FFLD	479
3.3.133.1 Coordinated Motion Motion Library	479
3.3.134 Related Functions	480
3.3.135 Input	481
3.3.136 Output	482
3.3.137 Structured Text	482
3.3.138 Instruction List	482
3.3.139 Function Block Diagram	483
3.3.140 Ladder Diagram	483
3.3.141 Related Functions	484
3.3.142 Input	484
3.3.143 Output	484
3.3.144 Structured Text	485
3.3.145 IL	485
3.3.146 FBD	485
3.3.147 FFLD	485
3.3.148 Related Functions	486
3.3.149 Input	486
3.3.150 Output	487
3.3.151 ST	487
3.3.152 IL	487
3.3.153 FBD	487

3.3.154 FFLD	488
3.3.155 Related Functions	488
3.3.156 Input	489
3.3.157 Output	492
3.3.158 ST	493
3.3.159 IL	493
3.3.160 FBD	493
3.3.161 FFLD	494
3.3.162 Related Functions	495
3.3.163 Input	495
3.3.164 Output	499
3.3.165 ST	499
3.3.166 IL	499
3.3.167 FBD	500
3.3.168 FFLD	500
3.3.169 Related Functions	501
3.3.170 Input	501
3.3.171 Output	502
3.3.172 Structure Text	503
3.3.173 IL	503
3.3.174 Function Block Diagram	503
3.3.175 Ladder Diagram	503
3.3.176 Related Functions	504
3.3.177 Input	504
3.3.178 Output	505
3.3.179 Structure Text	505
3.3.180 IL	506
3.3.181 Function Block Diagram	506
3.3.182 Ladder Diagram	506
3.3.183 Related Functions	507
3.3.184 Input	507
3.3.185 Output	510
3.3.186 Structured Text	510
3.3.187 IL	510
3.3.188 FBD	511
3.3.189 FFLD	511
3.3.190 Related Functions	512
3.3.191 Input	512
3.3.192 Output	515
3.3.193 Structured Text	515
3.3.194 IL	515
3.3.195 FBD	516
3.3.196 FFLD	516
3.3.196.1 Coordinated Motion Reference Library	516
3.3.197 Related Functions	517
3.3.198 Input	517
3.3.199 Output	518

3.3.200 ST	519
3.3.201 FBD	519
3.3.202 IL	519
3.3.203 FFLD	519
4 Fieldbus Library	520
4.1 EtherCAT Library	520
4.1.1 Why use ECATReadSdo and ECATWriteSdo FBs?	520
4.1.2 Why use the DriveParam FBs?	520
4.1.3 EtherCAT Function Blocks That Work With Drive Parameters	521
4.1.3.1 Execution Time	521
4.1.4 EtherCAT Function Blocks That Work With SDOs	522
4.1.5 DriveParamRead	522
4.1.5.1 Inputs	523
4.1.5.2 Outputs	523
4.1.5.3 Remarks	523
4.1.5.4 FBD Language	526
4.1.5.5 FFLD Language	526
4.1.5.6 IL Language	526
4.1.5.7 ST Language	526
4.1.6 DriveParamStrRead	527
4.1.6.1 Inputs	527
4.1.6.2 Outputs	527
4.1.6.3 Remarks	527
4.1.6.4 FBD Language	530
4.1.6.5 FFLD Language	530
4.1.6.6 IL Language	530
4.1.6.7 ST Language	530
4.1.7 DriveParamWrite	530
4.1.7.1 Inputs	530
4.1.7.2 Outputs	531
4.1.7.3 Remarks	531
4.1.7.4 FBD Language	534
4.1.7.5 FFLD Language	534
4.1.7.6 IL Language	534
4.1.7.7 ST Language	534
4.1.8 ECATCommErrors	534
4.1.8.1 Inputs	534
4.1.8.2 Outputs	535
4.1.8.3 Remarks	535
4.1.8.4 FBD Language	536
4.1.8.5 FFLD Language	536
4.1.8.6 IL Language	536
4.1.8.7 ST Language	536
4.1.9 ECATDeviceAction	537
4.1.9.1 Inputs	537
4.1.9.2 Outputs	537
4.1.9.3 Remarks	538

4.1.9.4 Usage	538
4.1.9.5 Error Codes	538
4.1.10 ECATDeviceStatus	539
4.1.10.1 Arguments	540
4.1.10.2 Related Functions	542
4.1.10.3 Example	542
4.1.11 ECATDevReadParam	542
4.1.11.1 Arguments	543
4.1.11.2 Example	545
4.1.12 ECATGetObjVal	546
4.1.13 ECATMasterStatus	547
4.1.13.1 Arguments	547
4.1.13.2 Related Functions	548
4.1.13.3 Examples	548
4.1.14 ECATReadData	549
4.1.14.1 Arguments	549
4.1.14.2 Related Functions	550
4.1.14.3 Example	550
4.1.15 ECATReadSDO	551
4.1.15.1 Arguments	552
4.1.15.2 Related Functions	554
4.1.15.3 Example	554
4.1.16 ECATWCStatus	555
4.1.16.1 Arguments	555
4.1.16.2 Related Functions	556
4.1.16.3 Example	556
4.1.17 ECATWriteData	556
4.1.17.1 Arguments	557
4.1.17.2 Related Functions	558
4.1.17.3 Example	558
4.1.18 ECATWriteSDO	558
4.1.18.1 Arguments	559
4.1.18.2 Related Functions	561
4.1.18.3 Example	561
4.1.19 FSoEParamsInit	562
4.1.19.1 Description	562
4.1.19.2 Arguments	563
4.1.19.3 EtherCAT Error Codes	564
4.1.19.4 Examples	565
4.2 EtherNet/IP (ODVA)	566
4.2.1 eipAdapter	566
4.2.1.1 Inputs	566
4.2.1.2 Outputs	566
4.2.1.3 Remarks	566
4.2.1.4 Example	566
4.2.2 eipReadAttr	567
4.2.2.1 Inputs	567

4.2.2.2	Outputs	567
4.2.2.3	Remarks	567
4.2.2.4	FBD Language	568
4.2.2.5	FFLD Language	568
4.2.2.6	IL Language	568
4.2.2.7	ST Language	568
4.2.3	eipWriteAttr	569
4.2.3.1	Inputs	569
4.2.3.2	Outputs	569
4.2.3.3	Remarks	570
4.2.3.4	FBD Language	570
4.2.3.5	FFLD Language	570
4.2.3.6	IL Language	570
4.2.3.7	ST Language	570
5	System Library	572
5.1	Controller Functions	572
5.1.1	ClearCtrlErrors	572
5.1.1.1	Inputs	572
5.1.1.2	Outputs	572
5.1.1.3	Remarks	572
5.1.2	GetCtrlErrors	573
5.1.2.1	Arguments	573
5.1.2.2	Examples	574
5.1.3	GetCtrlInfo	574
5.1.3.1	Arguments	575
5.1.3.2	Examples	577
5.1.4	GetCtrlPerf	577
5.1.4.1	Arguments	578
5.1.4.2	Example	580
5.2	File Tools Function Blocks	582
5.2.1	FileClose	582
5.2.1.1	Description	582
5.2.1.2	Arguments	582
5.2.1.3	Example	583
5.2.2	FileCopy	583
5.2.2.1	Description	583
5.2.2.2	Arguments	584
5.2.2.3	Example	585
5.2.3	FileDelete	585
5.2.3.1	Description	585
5.2.3.2	Arguments	585
5.2.3.3	Example	586
5.2.4	FileEOF	586
5.2.4.1	Description	586
5.2.4.2	Arguments	587
5.2.4.3	Example	588
5.2.5	FileExists	588

5.2.5.1 Description	588
5.2.5.2 Arguments	588
5.2.5.3 Example	589
5.2.6 FileOpenA	589
5.2.6.1 Description	589
5.2.6.2 Arguments	590
5.2.6.3 Example	591
5.2.7 FileOpenR	591
5.2.7.1 Description	591
5.2.7.2 Arguments	591
5.2.7.3 Example	592
5.2.8 FileOpenW	592
5.2.8.1 Description	592
5.2.8.2 Arguments	593
5.2.8.3 Example	594
5.2.9 FileReadBinData	594
5.2.9.1 Description	594
5.2.9.2 Arguments	594
5.2.9.3 Example	595
5.2.10 FileReadLine	596
5.2.10.1 Description	596
5.2.10.2 Arguments	596
5.2.10.3 Example	597
5.2.11 FileRename	597
5.2.11.1 Description	597
5.2.11.2 Arguments	598
5.2.11.3 Example	598
5.2.12 FileSeek	599
5.2.12.1 Description	599
5.2.12.2 Arguments	599
5.2.12.3 Example	600
5.2.13 FileSize	601
5.2.13.1 Description	601
5.2.13.2 Arguments	601
5.2.13.3 Example	602
5.2.14 FileWriteBinData	602
5.2.14.1 Description	602
5.2.14.2 Arguments	602
5.2.14.3 Example	603
5.2.15 FileWriteLine	604
5.2.15.1 Description	604
5.2.15.2 Arguments	605
5.2.15.3 Example	605
5.3 TCP/IP Function Blocks	606
5.3.1 TcpAccept	606
5.3.1.1 Arguments	607
5.3.1.2 Example	608


5.3.2 TcpBinReceive	608
5.3.2.1 Arguments	609
5.3.2.2 Example	610
5.3.3 TcpBinSend	610
5.3.3.1 Arguments	610
5.3.3.2 Example	611
5.3.4 TcpClose	612
5.3.4.1 Arguments	612
5.3.4.2 Example	613
5.3.5 TcpConnect	613
5.3.5.1 Arguments	614
5.3.5.2 Example	615
5.3.6 TcpIsConnected	615
5.3.6.1 Arguments	616
5.3.6.2 Example	616
5.3.7 TcpIsValid	617
5.3.7.1 Arguments	617
5.3.7.2 Example	618
5.3.8 TcpListen	618
5.3.8.1 Arguments	619
5.3.8.2 Example	620
5.3.9 TcpSend	620
5.3.9.1 Arguments	620
5.3.9.2 Example	621
5.4 UDP Functions for PxMM and Simulator	622
5.4.1 udpAddrMake	622
5.4.1.1 Description	623
5.4.1.2 Arguments	623
5.4.1.3 Examples	623
5.4.2 udpClose	624
5.4.2.1 Description	624
5.4.2.2 Arguments	624
5.4.2.3 Examples	625
5.4.3 udpCreate	625
5.4.3.1 Description	625
5.4.3.2 Arguments	625
5.4.3.3 Examples	626
5.4.4 udpIsValid	626
5.4.4.1 Description	626
5.4.4.2 Arguments	626
5.4.4.3 Examples	627
5.4.5 udpRcvFrom	627
5.4.5.1 Description	627
5.4.5.2 Arguments	627
5.4.5.3 Examples	628
5.4.6 udpRcvFromArray	629
5.4.6.1 Description	629

5.4.6.2 Arguments	629
5.4.6.3 Examples	630
5.4.7 udpRcvFromVar	631
5.4.7.1 Arguments	631
5.4.7.2 Examples	632
5.4.8 udpSendTo	633
5.4.8.1 Description	633
5.4.8.2 Arguments	633
5.4.8.3 Examples	634
5.4.9 udpSendToArray	634
5.4.9.1 Description	634
5.4.9.2 Arguments	634
5.4.9.3 Examples	635
5.4.10 udpSendToVar	636
5.4.10.1 Arguments	637
5.4.10.2 Examples	638
5.5 PrintMessage	638
5.5.1 Input	638
5.5.2 Output	639
5.5.3 Remarks	639
5.5.3.1 Source	639
5.5.3.2 Level	639
5.5.4 Usage	639
5.5.5 Structured Text	639
5.5.6 FBD Language	640
5.5.7 FFLD Language	640
5.6 File and TCP/IP Function Block ErrorID Output	640
6 Kollmorgen UDFBs	642
6.1 Create an Instance	642
6.2 Working with Kollmorgen UDFBs	643
6.2.0.1 FB_FirstOrderDigitalFilter	643
6.2.0.2 FB_PWDutyOutput	650
6.2.0.3 FB_ScaleInput	653
6.2.0.4 FB_ScaleOutput	656
6.2.0.5 FB_ElapseTime	658
6.2.0.6 PipeNetwork_FFLD	660
6.2.0.7 ProfilesCode_FFLD	661
6.2.0.8 FB_TemperaturePID	663
6.2.0.9 MLFB_DriveFault	666
6.2.0.10 MLFB_ECATRestart	669
6.2.0.11 MLFB_HomeFindHomeInput	671
6.2.0.12 MLFB_HomeFindHomeInputThenZeroAngle	674
6.2.0.13 MLFB_HomeFindLimitInput	676
6.2.0.14 MLFB_HomeFindLimitInputThenZeroAngle	678
6.2.0.15 MLFB_HomeFindZeroAngle	680
6.2.0.16 MLFB_HomeMoveUntilPosErrExceeded	682
6.2.0.17 MLFB_HomeMoveUntilPosErrExceededThenZeroAngle	684

6.2.0.18	MLFB_HomeUsingCurrentPosition	687
6.2.0.19	MLFB_HomeFindHomeFastInput	688
6.2.0.20	MLFB_HomeFindHomeFastInputModulo	694
6.2.0.21	MLFB_HomeFindLimitFastInput	700
6.2.0.22	MLFB_HomeFindLimitFastInputModulo	705
6.2.0.23	MLFB_Jog	710
6.2.0.24	MLFB_PlSPosFw	712
6.2.0.25	MLFB_PlSPosFwBw	713
6.2.0.26	MLFB_PlSTimeFw	715
6.2.0.27	MCFB_AKDFault	717
6.2.0.28	MCFB_AKDFaultLookup	719
6.2.0.29	MCFB_DriveFault	720
6.2.0.30	MCFB_ECATRestart	723
6.2.0.31	MCFB_StepAbsolutes	725
6.2.0.32	MCFB_StepAbsSwitch	728
6.2.0.33	MCFB_StepBlock	735
6.2.0.34	MCFB_StepLimitSwitch	741
6.2.0.35	MCFB_StepRefPulse	747
6.2.0.36	MCFB_StepAbsSwitchFastInput	753
6.2.0.37	MCFB_StepLimitSwitchFastInput	760
6.2.0.38	MCFB_Jog	766
6.2.0.39	MCFB_GearedWebTension	768
6.2.0.40	Example 1	774
6.2.0.41	Example 2	774
6.2.0.42	FB_Cylinder	776
6.2.0.43	FB_AKDFltRpt	778
6.2.0.44	FB_S700FltRpt	781
6.2.0.45	FB_AxisPlSPosModulo	785
6.2.0.46	FB_AxisPlSPosNoModulo	787
Appendix A: Index		790
7 Support and Services		798

3 Motion Library

This section covers the Motion Library (for [PipeNetwork Concept](#) and [PLCopen®](#)) in the function blocks tab of the Library toolbox.



KAS function library contains ML function blocks that are used to integrate motion in a PLC program. ML function blocks can be used in four of the IEC 61131-3 languages: ST, FBD, FFLD and IL.

Regarding SFCSFC programs, ML function blocks (like any other function blocks from the library) are used as part of a stepstep or transitiontransition which are defined with ST, FBD, FFLD, or IL languages.

3.1 Motion Library - PipeNetwork

The KAS IDE function library contains Motion Library (ML) function blocks (FBs) used to integrate motion from a PipeNetwork in a PLC program.

ML function blocks are of these types:

List of Pipe Network FBs

Function	Description
Motion	Prepare the physical motion part: init, reset, start, stop.
Pipe Network	Manage the PipeNetwork: Create / activate.
Block	Manage the blocks: Create / activate.
Pipe Block	Manage each specific Pipe Block: Read / write parameters.

⚠ IMPORTANT

PipeNetwork code is generated automatically by the compiler.
Do not try to modify it.

3.1.1 Motion Library - Adder

Name	Description	Return Type
"MLAddInit" (→ p. 21)	Initializes an Adder Pipe Block with user-defined settings.	BOOL
"MLAddReadOff1" (→ p. 22)	Returns the offset value of the first entry of an Adder block.	None
"MLAddReadOff2" (→ p. 24)	Returns the offset value of the second entry of an Adder block.	None

Name	Description	Return Type
"MLAddReadRatio1" (→ p. 25)	Returns the ratio value of the first entry of an Adder block.	None
"MLAddReadRatio2" (→ p. 26)	Returns the ratio value of the second entry of an Adder block.	None
"MLAddWriteInput" (→ p. 27)	Sets the source of an input of an adder Pipe Block.	BOOL
"MLAddWriteOff1" (→ p. 28)	Sets the offset value of the first entry of the Adder block.	BOOL
"MLAddWriteOff2" (→ p. 29)	Sets the offset value of the second entry of the Adder block.	BOOL
"MLAddWriteRat1" (→ p. 31)	Sets the ratio value of the first entry of the Adder block.	BOOL
"MLAddWriteRat2" (→ p. 32)	Sets the ratio value of the second entry of the Adder block.	BOOL

3.1.1.1 MLAddInit

 Pipe Network ✓

 **Function** - Initializes an Adder Pipe Block for use in a PLC Program.

3.1.1.1.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of a created Pipe Block.
Offset1	LREAL	No range	N/A	No default	Sets the Offset value of the first entry of an Adder object.
Offset2	LREAL	No range	N/A	No default	Sets the Offset value of the second entry of an Adder object.
Ratio1	LREAL	No range	N/A	No default	Sets the Ratio value of the first entry of an Adder object.
Ratio2	LREAL	No range	N/A	No default	Sets the Ratio value of the second entry of an Adder object.

3.1.1.1.2 Outputs

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2

Output	Data Type	Range	Unit	Description
Default (.Q)	BOOL	N/A	N/A	Returns TRUE if the Adder Pipe Block is initialized.

3.1.1.1.3 Remarks

NOTE

Adder objects are normally created in the PipeNetwork using the graphical engine. You do not have to add **MLAddInit** function blocks to their programs.

Parameters are entered directly in pop-up windows and the code is automatically added to the current project.

- Function block is automatically called if an Adder Block is added to the Pipe Network.
 - User-defined settings are entered in the **Pipe Blocks Properties** screen.
- The Pipe Block is assigned ratios and offsets for both inputs.
 - After an Adder block is initialized, the inputs need to be selected using the "MLAddWriteInput" (→ p. 27) function block or graphically using the PipeNetwork.






Figure 1-1: MlAddInit

3.1.1.1.4 FBD Language



3.1.1.1.5 FFLD Language



3.1.1.1.6 IL Language

Not available.

3.1.1.1.7 ST Language

```
//Create and Initiate a Trigger object
MyAdder := MlBlkCreate( 'MyAdder', 'ADDER' );
MlAddInit( MyAdder, 1.0, 0.0, 1.0, 0.0 );
```

See Also

- "MLAddReadOff1" (→ p. 22)
- "MLAddReadRatio1" (→ p. 25)
- "MLAddWriteInput" (→ p. 27)
- "MlBlkCreate" (→ p. 33)

3.1.1.2 MlAddReadOff1

Pipe Network ✓

Function - Returns the offset value of the first entry of an Adder block.

3.1.1.2.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Adder object.

3.1.1.2.2 Outputs

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2

Output	Data Type	Range	Unit	Description
Offset	LREAL	No range	N/A	Returns the offset value of the first entry of an Adder object.

3.1.1.2.3 Remarks

- Offset1 shifts the value of the first input to the block before its added to the second input.
- Can change the offset value with "MLAddWriteOff1" (→ p. 28) function block.






Figure 1-2: MLCAddReadOff1

3.1.1.2.4 FBD Language



3.1.1.2.5 FFLD Language



3.1.1.2.6 IL Language

Not available.

3.1.1.2.7 ST Language

```
//Save the offset value of first entry to the Adder block
AdderOffset := MLCAddReadOff1 ( PipeNetwork.MyAdder );
```

See Also

- "MLAddReadOff2" (→ p. 24)
- "MLAddReadRatio1" (→ p. 25)
- "MLAddWriteOff1" (→ p. 28)
- "MLAddWriteRat1" (→ p. 31)

3.1.1.3 MLAddReadOff2



Function - Returns the offset value of the second entry of an Adder block.

3.1.1.3.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Adder object.

3.1.1.3.2 Outputs

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2

Output	Data Type	Range	Unit	Description
Offset	LREAL	No range	N/A	Returns the offset value of the second entry of an Adder object.

3.1.1.3.3 Remarks

- Offset2 shifts the value of the second input to the block before its added to the first input.
- Can change the offset value with "MLAddWriteOff2" (→ p. 29) function block.





Figure 1-3: MLAddReadOff2

3.1.1.3.4 FBD Language



3.1.1.3.5 FFLD Language



3.1.1.3.6 IL Language

Not available.

3.1.1.3.7 ST Language


```
//Save the offset value of second entry to the Adder block
AdderOffset := MLAddReadOff2( PipeNetwork.MyAdder );
```

See Also

- "MLAddReadOff1" (→ p. 22)
- "MLAddReadRatio2" (→ p. 26)
- "MLAddWriteOff2" (→ p. 29)
- "MLAddWriteRat2" (→ p. 32)

3.1.1.4 MLAddReadRatio1



Function - Returns the ratio value of the first entry of an Adder block.

3.1.1.4.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Adder object.

3.1.1.4.2 Outputs

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2

Output	Data Type	Range	Unit	Description
Ratio	LREAL	No range	N/A	Returns the Ratio value of the first entry of an Adder object.

3.1.1.4.3 Remarks

- Ratio1 amplifies the value of the first input to the block before its added to the second input.
- Can change the ratio value with "MLAddWriteRat1" (→ p. 31) function block.





Figure 1-4: MLAddReadRatio1

3.1.1.4.4 FBD Language



3.1.1.4.5 FFLD Language



3.1.1.4.6 IL Language

Not available.

3.1.1.4.7 ST Language

```
//Save the ratio value of first entry to the Adder block
AdderRatio := MLAddReadRatio1( PipeNetwork.MyAdder );
```

See Also

- "MLAddReadOff1" (→ p. 22)
- "MLAddReadOff2" (→ p. 24)
- "MLAddReadRatio2" (→ p. 26)
- "MLAddWriteRat1" (→ p. 31)

3.1.1.5 MLAddReadRatio2



Function - Returns the ratio value of the second entry of an Adder block.

3.1.1.5.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Adder object.

3.1.1.5.2 Outputs

$$\text{Adder Block Output} = \text{Ratio1} * \text{Input1} + \text{Offset1} + \text{Ratio2} * \text{Input2} + \text{Offset2}$$

Output	Data Type	Range	Unit	Description
Ratio	LREAL	No range	N/A	Returns the Ratio value of the second entry of an Adder object.

3.1.1.5.3 Remarks

- Ratio2 amplifies the value of the second input to the block before its added to the first input.
- Can change the ratio value with "MLAddWriteRat2" (→ p. 32) function block.






Figure 1-5: MLAddReadRatio2

3.1.1.5.4 FBD Language



3.1.1.5.5 FFLD Language



3.1.1.5.6 IL Language

Not available.

3.1.1.5.7 ST Language

```
//Save the ratio value of second entry to the Adder block
AdderRatio := MLAddReadRatio2( PipeNetwork.MyAdder );
```

See Also

- "MLAddReadOff1" (→ p. 22)
- "MLAddReadOff2" (→ p. 24)
- "MLAddReadRatio1" (→ p. 25)
- "MLAddWriteRat2" (→ p. 32)

3.1.1.6 MLAddWriteInput



Function - Sets the source of an input of an adder Pipe Block.

3.1.1.6.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Adder object.
InputID	DINT	1, 2	N/A	No default	Select first or second input to the Adder object.
InputBlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Pipe Block. This is an input to the Adder object.

3.1.1.6.2 Outputs

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2

Output	Data Type	Range	Unit	Description
Default (.Q)	BOOL	N/A	N/A	Returns TRUE if the input to the Adder object is set.

3.1.1.6.3 Remarks

- Function block is automatically called if an Adder Block is connected to other blocks in the PipeNetwork.





Figure 1-6: MlAddWriteInput


NOTE

Adder objects are normally created in the Pipe Network using the graphical engine. You do not have to add **MlAddWriteInput** function blocks to their programs. Blocks are connected with lines in the PipeNetwork. The code is automatically added to the current project.

3.1.1.6.4 FBD Language



3.1.1.6.5 FFLD Language



3.1.1.6.6 IL Language

Not available.

3.1.1.6.7 ST Language

```
//Set the first input of an Adder pipeblock to be connected to the output
of GEAR1 pipeblock
MlAddWriteInput( PipeNetwork.ADDER, 1, PipeNetwork.GEAR1 );
```

See Also

- "MlAddInit" (→ p. 21)
- "MlAddReadOff1" (→ p. 22)
- "MlAddReadRatio1" (→ p. 25)
- "MlBlkCreate" (→ p. 33)

3.1.1.7 MlAddWriteOff1



Function - Set the offset value of the first entry of the Adder block.

3.1.1.7.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Adder object.
InputID	LREAL	No range	N/A	No default	Desired new value for the Adder Object's Offset1.

3.1.1.7.2 Outputs

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2

Output	Data Type	Range	Unit	Description
Default (.Q)	BOOL	N/A	N/A	Returns TRUE if the Offset value for input one is set.

3.1.1.7.3 Remarks

! IMPORTANT

Changes made to the Offset of an Adder block are executed immediately and can cause an axis position to jump.

- Offset1 shifts the value of the first input to the block before its added to the second input.






Figure 1-7: MAddWriteOff1

3.1.1.7.4 FBD Language



3.1.1.7.5 FFLD Language



3.1.1.7.6 IL Language

Not available.

3.1.1.7.7 ST Language

```
//Change the offset value of first entry to the Adder block to 10
MLAddWriteOff1( PipeNetwork.MyAdder, 10 );
```

See Also

- "MLAddReadOff1" (→ p. 22)
- "MLAddReadRatio1" (→ p. 25)
- "MLAddWriteOff2" (→ p. 29)
- "MLAddWriteRat1" (→ p. 31)

3.1.1.8 MAddWriteOff2



Function - Set the offset value of the second entry of the Adder block.

3.1.1.8.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Adder object.
InputID	LREAL	No range	N/A	No default	Desired new value for the Adder Object's Offset2.

3.1.1.8.2 Outputs

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2

Output	Data Type	Range	Unit	Description
Default (.Q)	BOOL	N/A	N/A	Returns TRUE if the Offset value for input two is set.

3.1.1.8.3 Remarks

! IMPORTANT

Changes made to the Offset of an Adder block are executed immediately and can cause an axis position to jump.

- Offset2 shifts the value of the second input to the block before its added to the first input.






Figure 1-8: MlAddWriteOff2

3.1.1.8.4 FBD Language



3.1.1.8.5 FFLD Language



3.1.1.8.6 IL Language

Not available.

3.1.1.8.7 ST Language

```
//Change the offset value of second entry to the Adder block to 10
MlAddWriteOff2 ( PipeNetwork.MyAdder, 10 );
```

See Also

- "MLAddReadOff2" (→ p. 24)
- "MLAddReadRatio2" (→ p. 26)
- "MLAddWriteOff1" (→ p. 28)
- "MLAddWriteRat2" (→ p. 32)

3.1.1.9 MLAddWriteRat1



Function - Set the ratio value of the first entry of the Adder block.

3.1.1.9.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Adder object.
Ratio	LREAL	No range	N/A	No default	Desired new value for the Adder Object's Ratio1.

3.1.1.9.2 Outputs

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2

Output	Data Type	Range	Unit	Description
Default (.Q)	BOOL	N/A	N/A	Returns TRUE if the Ratio value for input one is set.

3.1.1.9.3 Remarks

IMPORTANT

Changes made to the Ratio of an Adder block are executed immediately and can cause an axis position to jump.

- Ratio1 amplifies the value of the first input to the block before its added to the second input.






Figure 1-9: MLAddWriteRat1

3.1.1.9.4 FBD Language



3.1.1.9.5 FFLD Language



3.1.1.9.6 IL Language

Not available.

3.1.1.9.7 ST Language

```
//Change the ratio value of first entry to the Adder block to 2
MLAddWriteRat1 ( PipeNetwork.MyAdder, 2 );
```

See Also

- "MLAddReadOff1" (→ p. 22)
- "MLAddReadRatio1" (→ p. 25)
- "MLAddWriteOff1" (→ p. 28)
- "MLAddWriteRat2" (→ p. 32)

3.1.1.10 MLAddWriteRat2



Function - Set the ratio value of the second entry of the Adder block.

3.1.1.10.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Adder object.
Ratio	LREAL	No range	N/A	No default	Desired new value for the Adder Object's Ratio2.

3.1.1.10.2 Outputs

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2

Output	Data Type	Range	Unit	Description
Default (.Q)	BOOL	N/A	N/A	Returns TRUE if the Ratio value for input two is set.

3.1.1.10.3 Remarks

IMPORTANT

Changes made to the Ratio of an Adder block are executed immediately and can cause an axis position to jump.

- Ratio2 amplifies the value of the second input to the block before its added to the first input.






Figure 1-10: MLAddWriteRat2\

3.1.1.10.4 FBD Language



3.1.1.10.5 FFLD Language



3.1.1.10.6 IL Language

Not available.

3.1.1.10.7 ST Language

```
//Change the ratio value of second entry to the Adder block to 2
MAddWriteRat2 ( PipeNetwork.MyAdder, 2 );
```

See Also

- "MAddReadOff2" (→ p. 24)
- "MAddReadRatio2" (→ p. 26)
- "MAddWriteOff2" (→ p. 29)
- "MAddWriteRat1" (→ p. 31)

3.1.2 Motion Library - Block

Name	Description	Return Type
"MLBlkCreate" (→ p. 33)	Creates a new Pipe Block object.	None
"MLBlkIsReady" (→ p. 34)	Checks if a Pipe Block currently has a function running.	BOOL
"MLBlkReadModPos" (→ p. 35)	Gets the value of the period of a block in user units.	None
"MLBlkReadOutVal" (→ p. 36)	Gets the output value of a selected Pipe Block.	None
"MLBlkWriteModPos" (→ p. 37)	Sets the value of the period of a block in user units.	BOOL

3.1.2.1 MLBlkCreate



Function - Creates a new Pipe Block object.
is this a function or function block?

3.1.2.1.1 Inputs

Input	Data Type	Range	Unit	Default	Description
Name	String	No range	N/A	No default	Designated name for the newly created Pipe Block.
Type	String	No range	N/A	No default	The type of Pipe Block to create. Examples: MASTER, GEAR, PHASER, etc.

3.1.2.1.2 Outputs

Output	Data Type	Range	Unit	Description
ID	DINT	N/A	N/A	Assigned ID number of the created Block.

3.1.2.1.3 Remarks

- Before a Pipe Block is Initialized, the function needs to be created and assigned an ID number.
- The **MLBlkCreate** function is automatically called if a Block is added to the PipeNetwork.

NOTE

Pipe Blocks are normally created in the PipeNetwork using the graphical engine. You do not have to add **MLBlkCreate** function blocks to their programs. The code with **MLBlkCreate** commands are automatically generated and called in a program with **Pipe Network(MLPN_CREATE_OBJECTS)**.


TIP

This function should be called after "MLMotionInit" (→ p. 414) is called and before "MLMotionStart" (→ p. 417) is called.

3.1.2.1.4 FBD Language



3.1.2.1.5 FFLD Language



3.1.2.1.6 IL Language

Not available.

3.1.2.1.7 ST Language

```
//Create a new GEAR Pipe Block named "MyGear"
MyGear := MLBlkCreate( 'MyGear', 'GEAR' );
```

See Also

- "MLAxisInit" (→ p. 71)
- See Step 3 in [Initialize and Start a Pipe Network](#).

3.1.2.2 MLBlkIsReady

Pipe Network ✓

Function - Check if a block is ready.

3.1.2.2.1 Input

Input	Data Type	Range	Unit	Default	Description
ID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of a created Pipe Block.

3.1.2.2.2 Output


Output	Data Type	Range	Unit	Description
Default (.Q)	BOOL	N/A	N/A	Returns TRUE if no function of a specified Pipe Block is running.

3.1.2.2.3 Remarks


- Returns TRUE if **no function** of a specified Pipe Block is running.
- Returns FALSE if the selected Pipe Block has a function running.
- Same return value as the .Q output of a specific function itself.

NOTE
 This function or function block returns cached data.
 See [Programming a Dual Core Controller](#) for more information.

3.1.2.2.4 FBD Language



3.1.2.2.5 FFLD Language



3.1.2.2.6 IL Language

Not available.

3.1.2.2.7 ST Language

```
//Check if the MST Pipe Block named "MASTER" has a function running
IsReady := MLBlkIsReady( PipeNetwork.MASTER );
```

See Also

- "MLBlkReadModPos" (→ p. 35)
- "MLBlkReadOutVal" (→ p. 36)

3.1.2.3 MLBlkReadModPos

Pipe Network ✓

Function - Get the value of the period of a block in user units.

3.1.2.3.1 Inputs


Input	Data Type	Range	Unit	Default	Description
ID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of a created Pipe Block.

3.1.2.3.2 Outputs


Output	Data Type	Range	Unit	Description
ModuloPosition	LREAL	N/A	User units	Current period value for selected Pipe Block.

3.1.2.3.3 Remarks


- The output value of a block is reset each time it reaches its period value.



3.1.2.3.4 FBD Language



3.1.2.3.5 FFLD Language



3.1.2.3.6 IL Language

Not available.

3.1.2.3.7 ST Language

```
//Return and save the Period of a Pipe Block
GearPeriod := MLBlkReadModPos ( PipeNetwork.MyGear );
```

See Also

- "MLBlkCreate" (→ p. 33)
- "MLBlkReadOutVal" (→ p. 36)
- "MLBlkWriteModPos" (→ p. 37)

3.1.2.4 MLBlkReadOutVal

Pipe Network ✓

Function - Gets the output value of a selected Pipe Block.

3.1.2.4.1 Inputs

Input	Data Type	Range	Unit	Default	Description
ID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of a created Pipe Block.


3.1.2.4.2 Outputs

Output	Data Type	Range	Unit	Description
Value	LREAL	N/A	N/A	Current output value of the selected Pipe Block.


3.1.2.4.3 Remarks

NOTE
 This function or function block returns cached data.
 See [Programming a Dual Core Controller](#) for more information.

3.1.2.4.4 FBD Language



3.1.2.4.5 FFLD Language



3.1.2.4.6 IL Language

Not available.

3.1.2.4.7 ST Language

```
//Save the output of a Gear Pipe Block
BlockOutput := MLBkReadOutVal( PipeNetwork.MyGear );
```

See Also

- "MLBkCreate" (→ p. 33)
- "MLBkReadModPos" (→ p. 35)

3.1.2.5 MLBkWriteModPos

Pipe Network ✓

Function - Sets the value of the period of a block in user units.

3.1.2.5.1 Inputs


Input	Data Type	Range	Unit	Default	Description
ID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of a created Pipe Block.
ModuloPosition	LREAL	No range	User units	No default	Designated new Period Value for selected Pipe Block.

3.1.2.5.2 Outputs


Output	Data Type	Range	Unit	Description
Default (.Q)	BOOL	N/A	N/A	Returns TRUE if the function block executes.

3.1.2.5.3 Remarks


- The output value of a block is reset each time it reaches its period value.



3.1.2.5.4 FBD Language



3.1.2.5.5 FFLD Language



3.1.2.5.6 IL Language

Not available.

3.1.2.5.7 ST Language

```
//Set the Period of a Pipe Block to 300
MLBlkWriteModPos ( PipeNetwork.MyGear, 300 );
```

See Also

- "MLBlkCreate" (→ p. 33)
- "MLBlkReadModPos" (→ p. 35)
- "MLBlkReadOutVal" (→ p. 36)

3.1.3 Motion Library - Pipe Network

Name	Description	Return type
MLPipeAct	Activates a pipe	BOOL
MLPipeAddBlock	Adds a Pipe Block to a pipe	BOOL
MLPipeCreate	Creates a new pipe object	None
MLPipeDeact	Deactivates a pipe	BOOL

3.1.3.1 MLPipeAct Pipe Network

3.1.3.1.1 Description

Activates a pipe. A Pipe contains an Input Pipe Block (Master, PMP, or Sampler), a Converter Output Pipe Block, and any Transformation Pipe Block that can be in between. The figure below shows two Pipes, both with the same Master Input Pipe Block. The first ends with the first converter, and has a Gear Pipe Block to transform the input values from the Master. The second pipe ends with the second converter, and has a CAM Pipe Block to modify the input values from the Master.

Once a Pipe is activated then history on the values in the Pipe's Blocks are saved and updated each program cycle. A Converter object connected to a destination Axis object cannot send updated position values unless its Pipe is activated.




Figure 1-11: MLPipeAct

NOTE
 All Pipes in the Pipe Network can be activated at once with the command PipeNetwork(MLPN_ACTIVATE). This calls automatically generated code with MLPipeAct commands for each Pipe object. Therefore, in a multi-pipe program only one command can be used to activate Pipes instead of writing code for each Pipe separately.

3.1.3.1.2 Arguments

3.1.3.1.2.1 Input

PipeID	Description
	ID number of a created Pipe object
	Data type DINT
	Range [-2147483648, 2147483648]
	Unit N/A
	Default —

3.1.3.1.2.2 Output

Default (.Q)	Description
	Returns TRUE if the Pipe is activated
	Data type BOOL

Unit	N/A
-------------	-----

3.1.3.1.2.3 Return Type

BOOL

3.1.3.1.3 Related Functions

[MLPipeDeact](#)

"MLCNVConnect" (→ p. 137)

[PipeNetwork\(MLPN_ACTIVATE\)](#)


[MLPipeAddBlock](#)

3.1.3.1.4 Example

3.1.3.1.4.1 Structured Text

```
//Activate a Pipe
MLPipeAct( PipeAXIS1 );
```

3.1.3.1.4.2 Ladder Diagram



3.1.3.1.4.3 Function Block Diagram



3.1.3.2 MLPipeAddBlock Pipe Network ✓

3.1.3.2.1 Description

Add a Pipe Block to a pipe. A Pipe contains an Input Pipe Block (Master, PMP, or Sampler), a Converter Output Pipe Block, and any Transformation Pipe Block that can be in between.

The figure below shows two Pipes, both with the same Master Input Pipe Block. If a user were to create the Pipe 1 below without using the Graphical Engine, they would use the following commands once a Pipe and the Pipe Blocks have been created.

```
MLPipeAddBlock( PipeAXIS1, MASTER);
```

```
MLPipeAddBlock( PipeAXIS1, MyGear);
```

```
MLPipeAddBlock( PipeAXIS1, CNV1);
```





Figure 1-12: MLPipeAddBlock

NOTE

All Blocks in the Pipe Network are added to a Pipe automatically. Code with MLPipeAddBlock commands are automatically generated and called in a program with PipeNetwork(MLPN_CREATE_OBJECTS). Therefore, when using the Pipe Network graphical engine to create Pipe Blocks the user does not have to manually add MLPipeAddBlock commands to the Project.

3.1.3.2.2 Arguments

3.1.3.2.2.1 Input

PipeID	Description	ID number of a created Pipe
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
BlockID	Description	ID number of a created Pipe object to add to the selected Pipe
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.3.2.2.2 Output

Default (.Q)	Description	Returns TRUE if the Pipe Block is added to the Pipe
	Data type	BOOL
	Unit	N/A

3.1.3.2.2.3 Return Type

BOOL

3.1.3.2.3 Related Functions

[PipeNetwork\(MLPN_CREATE_OBJECTS\)](#)

[MLPipeAct](#)

[MLPipeCreate](#)


[MLPipeDeact](#)

3.1.3.2.4 Example


3.1.3.2.4.1 Structured Text

```
//Add a block to a pipe
MLPipeAddBlock( PipeAXIS1, MyGear );
```

3.1.3.2.4.2 Ladder Diagram



3.1.3.2.4.3 Function Block Diagram



3.1.3.3 MLPipeCreate Pipe Network ✓

3.1.3.3.1 Description

Create a new pipe object. A Pipe contains an Input Pipe Block (Master, PMP, or Sampler), a Converter Output Pipe Block, and any Transformation Pipe Block that can be in between. The figure below shows two Pipes, both with the same Master Input Pipe Block.

NOTE

Pipes are normally created in the Pipe Network using the graphical engine. Then you do not have to add MLPipeCreate function blocks to their programs. Pipes are created graphically, and the code with MLPipeCreate commands are automatically generated and called in a program with PipeNetwork(MLPN_CREATE_OBJECTS).

3.1.3.3.2 Arguments

3.1.3.3.2.1 Input

Name	Description	Desired name for the newly created Pipe
	Data type	String
	Range	—
	Unit	N/A
	Default	—

3.1.3.3.2.2 Output

ID	Description	Assigned ID number of the created Pipe
	Data type	DINT
	Unit	N/A

Default —

3.1.3.3.3 Related Functions

[PipeNetwork\(MLPN_CREATE_OBJECTS\)](#)

[MLPipeAddBlock](#)

[MLPipeAct](#)


[MLPipeDeact](#)

3.1.3.3.4 Example

3.1.3.3.4.1 Structured Text

```
//Create a new pipe
PipeAXIS1 := MLPipeCreate( 'PipeAXIS1' );
```

3.1.3.3.4.2 Ladder Diagram



3.1.3.3.4.3 Function Block Diagram



3.1.3.4 MLPipeDeact Pipe Network ✓

3.1.3.4.1 Description

Deactivates a pipe. A Pipe contains an Input Pipe Block (Master, PMP, or Sampler), a Converter Output Pipe Block, and any Transformation Pipe Block that can be in between. The figure below shows two Pipes, both with the same Master Input Pipe Block. The first ends with the first converter, and has a Gear Pipe Block to transform the input values from the Master. The second pipe ends with the second converter, and has a CAM Pipe Block to modify the input values from the Master.

Once a Pipe is activated then history on the values in the Pipe's Blocks are lost and no longer updated. A Converter object connected to a destination Axis object cannot send updated position values once its Pipe is deactivated.




Figure 1-13: MLPipeDeact

NOTE

All Pipes in the Pipe Network can be deactivated at once with the command PipeNetwork(MLPN_DEACTIVATE). This calls automatically generated code with MLPipeDeact commands for each Pipe object. Therefore, in a multi-pipe program only one command can be used to deactivate Pipes instead of writing code for each Pipe separately.

3.1.3.4.2 Arguments**3.1.3.4.2.1 Input**

PipeID	Description	ID number of a created Pipe object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.3.4.2.2 Output

Default (.Q)	Description	Returns TRUE if the Pipe is deactivated
	Data type	BOOL
	Unit	N/A

3.1.3.4.2.3 Return Type

BOOL

3.1.3.4.3 Related Functions

[MLPipeAct](#)


["MLCNVDisconnect" \(→ p. 141\)](#)

[PipeNetwork\(MLPN_DEACTIVATE\)](#)

[MLPipeAddBlock](#)

3.1.3.4.4 Example**3.1.3.4.4.1 Structured Text**

```
//Deactivate a Pipe
MLPipeDeact( PipeAXIS1 );
```

3.1.3.4.4.2 Ladder Diagram**3.1.3.4.4.3 Function Block Diagram**



3.1.4 Motion Library - Axis

TIP

For an Axis function example, see ["Examples of Axis Functions"](#) (→ p. 109).

3.1.4.1 Function by Types

Power Stage	Motion Control	Inquiry Functions	Position setting
"MLAxisPower" (→ p. 78)	"MLAxisAbs" (→ p. 47)	"MLAxisGenPos" (→ p. 63)	"MLAxisWritePos" (→ p. 104)
"MLAxisPowerDOff" (→ p. 79)	"MLAxisAdd" (→ p. 51)	"MLAxisPipePos" (→ p. 77)	"MLAxisReAlign" (→ p. 90)
	"MLAxisMoveVel" (→ p. 76)	"MLAxisCmdPos" (→ p. 56)	
	"MLAxisRel" (→ p. 92)	"MLAxisReadActPos" (→ p. 81)	
	"MLAxisStop" (→ p. 98)	"MLAxisFBackPos" (→ p. 59)	
		"MLAxisStatus" (→ p. 96)	
		"MLAxisReadGenStatus" (→ p. 84)	
		"MLAxisGenIsRdy" (→ p. 62)	
		"MLAxisTimeStamp" (→ p. 100)	
		"MLAxisDriveNumber" (→ p. 57)	

3.1.4.2 Functions in Alphabetical Order


Name	Description	Return type
"MLAxisAbs" (→ p. 47)	Performs a move to an absolute position	BOOL
"MLAxisAdd" (→ p. 51)	Performs an additive move relative for a specified distance from the endpoint of the previous move	BOOL
"MLAxisAddress" (→ p. 52)	Returns the motion bus address of the axis	DINT
"MLAxisAddTq" (→ p. 53)	Sets additive torque	BOOL
"MLAxisCfgFastIn" (→ p. 55)	Initializes the Fast Input capability for the axis	BOOL
"MLAxisCmdPos" (→ p. 56)	Returns the reference position of the axis	None
"MLAxisDriveNumber" (→ p. 57)	Read the DriveAxisNumber from a PipeNetwork axis	

Name	Description	Return type
"MLAxisFBackPos" (→ p. 59)	Returns the feedback position of the axis	None
"MLAxisGenEN" (→ p. 60)	Enables or disables the internal TMP generator of the axis	BOOL
"MLAxisGenIsEN" (→ p. 61)	Checks if the internal TMP generator of the axis is enabled	BOOL
"MLAxisGenIsRdy" (→ p. 62)	Checks if an axis is ready	BOOL
"MLAxisGenPos" (→ p. 63)	Returns the generator position of the axis	None
"MLAxisGenReadAcc" (→ p. 64)	Gets the acceleration of the internal generator of an axis	None
"MLAxisGenReadDec" (→ p. 66)	Gets the deceleration of the internal generator of an axis	None
"MLAxisGenReadSpd" (→ p. 67)	Gets the speed of the internal generator of an axis	None
"MLAxisGenWriteAcc" (→ p. 68)	Sets the acceleration of the internal generator of an axis	BOOL
"MLAxisGenWriteDec" (→ p. 69)	Sets the deceleration of the internal generator of an axis	BOOL
"MLAxisGenWriteSpd" (→ p. 70)	Sets the speed of the internal generator of an axis	BOOL
"MLAxisInit" (→ p. 71)	Initializes an axis object	BOOL
"MLAxisIsCnctd" (→ p. 74)	Checks if a pipe is currently connected to the axis	BOOL
"MLAxisIsTrigged" (→ p. 74)	Checks if the axis got a trigger event	BOOL
"MLAxisMoveVel" (→ p. 76)	Jogs at the specified speed	BOOL
"MLAxisPipePos" (→ p. 77)	Returns the pipe position of the axis	None
"MLAxisPower" (→ p. 78)	Powers up the axis. Enables a Servo drive or Stepper drive mapped to the axis..	BOOL
"MLAxisPowerDOff" (→ p. 79)	Returns the adjustment of position done by the last power on to avoid bumps	None
"MLAxisRatedTq" (→ p. 80)	Sets rated motor torque	BOOL
"MLAxisReadActPos" (→ p. 81)	Returns the actual position of the axis	None
"MLAxisReadFBUnit" (→ p. 82)	Gets the feedback units per revolution value of the axis	None
"MLAxisReadFEUU" (→ p. 83)	Read following error in user units	None

Name	Description	Return type
"MLAxisReadGenStatus" (→ p. 84)	Returns the status of the internal generator of the axis	DINT
"MLAxisReadModPos" (→ p. 85)	Get the value period of the axis	None
"MLAxisReadTq" (→ p. 86)	Read actual torque	None
"MLAxisReadUUnits" (→ p. 87)	Get the user units per revolution value of the axis	None
"MLAxisReadVel" (→ p. 88)	Read actual velocity	None
"MLAxisReAlgnRdy" (→ p. 89)	Checks if an axis is ready. Returns TRUE if the internal realignment axis is ready.	BOOL
"MLAxisReAlign" (→ p. 90)	Realigns the actual position with the reference position by moving the axis by the specified delta position	BOOL
"MLAxisRel" (→ p. 92)	Performs a relative move for a specified distance from the current position	BOOL
"MLAxisResetErrors" (→ p. 94)	Clears errors of the specified axis	BOOL
"MLAxisRstFastIn" (→ p. 95)	Resets the Fast Input	BOOL
"MLAxisStatus" (→ p. 96)	Returns the status of the axis	DINT
"MLAxisStop" (→ p. 98)	Stop with the specified deceleration	None
"MLAxisTimeStamp" (→ p. 100)	Returns the timestamp of the triggered axis	DINT
"MLAxisWriteModPos" (→ p. 102)	Sets the value period of the axis	BOOL
"MLAxisWritePipPos" (→ p. 103)	Forces the pipe position internal value. This function is working only when no pipe is connected.	BOOL
"MLAxisWritePos" (→ p. 104)	Sets the logical zero position of an axis	BOOL
"MLAxisWriteUUnits" (→ p. 106)	Sets the user units per revolution value of the axis	BOOL
"MLPNAxisCreate" (→ p. 107)	Creates a new axis object	None

3.1.4.3 MLAxisAbs



 **Function** - Performs a move to an absolute position. Returns TRUE if the function succeeded.

3.1.4.3.1 Arguments

3.1.4.3.1.1 Input

ID	Description	ID name of the Axis Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Position	Description	Sets the value of the absolute destination position. When the Modulo is turned on, see more explanations below.
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
Default (.Q)	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A


3.1.4.4 Position with Modulo On

NOTE

This information applies to both "MLMstAbs" (→ p. 169) and "MLAxisAbs" (→ p. 47). For simplicity, the term Axis Block also refers to Master Block.

When the Modulo is turned on, the Axis Block moves to the targeted position during the corresponding period, calculated as follows:

- If the Position input is between 0 and the Modulo Position, then the Axis Block moves within the **current** period (no position rollover).
- If the Position input is greater than the Modulo Position, then the Axis Block moves during one of the **next** period (positive position rollover).




The Axis Block works similarly for negative positions: if the Position input is less than zero, then the Axis Block moves during one of the **previous** period (negative position rollover).

3.1.4.5 Forcing the direction of rotation


In some applications, the direction of rotation for the axis is forced in one direction only. As a consequence, the motor movement goes to the next or previous modulo in the following situations:

- If the **End Position** is less than the **Start Position** and the direction of rotation for the axis is forced to be clockwise (the red point shows when the modulo position is reached).



(see an example in row#2 of the table below)

- If the **End Position** is greater than the **Start Position** and the direction of rotation for the axis is forced to be counter clockwise.



(see an example in row#4 of the table below)

Examples

Start Position	End Position	Direction of rotation	Cross Modulo	Position Input to MLAxisAbs (1)	RelativeDistance Moved (2)
60	200	clockwise	No	200	140 (i.e. 200 - 60 + 0)
60	30	clockwise	Yes	390	330 (i.e. 30 - 60 + 360)
60	30	counter clockwise	No	30	-30 (i.e. 30 - 60 - 0)
60	200	counter clockwise	Yes	-160	-220 (i.e. 200 - 60 - 360)

With:

(1) **Position Input** = End Position (+ Modulo * *Direction of rotation*)

(2) **Relative Distance Moved** = End Position - Start Position (+ Modulo * *Direction of rotation*)

Where:

Direction of rotation = 1 when clockwise and -1 when anti-clockwise

3.1.4.6 Travel Speed Update with MLAxisAbs

The travel speed of the generator can be updated using the function block "MLAxisGenWriteSpd" (→ p. 70). Depending on the state of the generator, this speed is directly reflected on the current move or a future move.

- If MLAxisAbs is not currently being executed, the new travel speed will be applied for the trajectory calculation for a future MLAxisAbs command.
- If MLAxisAbs is currently being executed and a new MLAxisAbs with the same target position is called, the new travel speed will be taken into account only if the current state of the TMP profile is the constant velocity or acceleration. If the axis was decelerating to stop at the goal position the new travel speed will not be taken into account.
- If a MLAxisAbs is currently being executed and a new MLAxisAbs with a different target position is called, the new travel speed is taken into account.

Following are several examples.




Figure 1-14: Initial speed is smaller than the new speed




Figure 1-15: Initial speed is bigger than the new speed




Figure 1-16: The speed update is taken into account only if the second MLAxisAbs is triggered during acceleration or constant velocity

3.1.4.6.1 Related Functions

[MLAxisGenWriteSpd](#)

[MLAxisGenWriteDec](#)

[MLAxisGenWriteAcc](#)

3.1.4.6.2 Example

See "Examples of Axis Functions" (→ p. 109) for additional examples.

3.1.4.6.2.1 Structured Text

```
MLAxisAbs ( PipeNetwork.Axis1, 2000 ) ;
```

3.1.4.6.2.2 Ladder Diagram



3.1.4.6.2.3 Function Block Diagram



3.1.4.7 MLAxisAdd



Function - A selected Axis performs a move for a specified distance relative to the endpoint of the previous move.

The DeltaPosition input is signed so that the move can be in the positive or negative direction, and the Axis moves this distance in user units. The travel speed, acceleration, deceleration, and User Units of the move are values inherited from the selected Axis. The default settings are entered when an Axis is created and initiated, and can be changed with other MLAxis commands such as [MLAxisGenWriteSpd](#), [MLAxisGenWriteAcc](#), and [MLAxisWriteUUnits](#).

3.1.4.7.1 Arguments

3.1.4.7.1.1 Input

ID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
DeltaPosition	Description	Sets the Axis Delta Position to add to the endpoint of the previous move
	Data type	LREAL
	Range	—

Unit	User unit
Default	—

3.1.4.7.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes, after the motion profile is complete.
	Data type	BOOL
	Unit	N/A

3.1.4.7.2 Related Functions

[MLAxisGenWriteAcc](#)

[MLAxisGenWriteDec](#)


[MLAxisGenWriteSpd](#)

3.1.4.7.3 Example

3.1.4.7.3.1 Structured Text

```
MLAxisAdd (PipeNetwork.Axis1, LREAL#750.0 ) ;
```

3.1.4.7.3.2 Ladder Diagram



NOTE
You must use a [pulse contact](#) to start the FB

3.1.4.7.3.3 Function Block Diagram



3.1.4.8 MLAxisAddress


Pipe Network ✓

Function - Returns the motion bus address of the axis.

It is possible that two or more axes have the same address if the axis is mapped to a multi-axis drive, such as the dual-axis AKD2G drive.

NOTE
Axes will have the same address when they are mapped to the same multi-axis drive. For example if Axis1 is mapped to an AKD2G's Drive Axis Number 1 and Axis2 is mapped to the AKD2G's Drive

Axis Number 2, both axes will return the same address.



3.1.4.8.1 Arguments

3.1.4.8.1.1 Input

ID	Description	ID name of the Axis Block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.8.1.2 Output


OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A
Default (.Q)	Description	Returns the motion bus address of the axis
	Data type	DINT
	Unit	N/A

3.1.4.8.2 Example

3.1.4.8.2.1 Structured Text

```
Axis1_Address := MLAxisAddress(PipeNetwork.AXIS1);
```

3.1.4.8.2.2 Ladder Diagram



3.1.4.8.2.3 Function Block Diagram



3.1.4.9 MLAxisAddTq

Pipe Network ✓

3.1.4.9.1 Description

Function - Allows the application to set the additive torque value to the drive output (Torque feed-forward).

This function is only active after the "MLAxisRatedTq" (→ p. 80) function has been invoked. Using the PDO, it also requires IL.KBUSFF value to be set to 1 in the drive.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.4.9.2 Arguments

3.1.4.9.2.1 Input

ID	Description	Pipe network identifier of the axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
Torque	Description	Requested additive torque value in N.m (Newton meter).
	Data type	LREAL
	Unit	Rated torque units as used in the drive (i.e. rated motor continuous torque x the Torque factor).

3.1.4.9.2.2 Output

Default (.Q)	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

3.1.4.9.3 Related Functions


"MLAxisRatedTq" (→ p. 80)

3.1.4.9.4 Example


3.1.4.9.4.1 Structured Text

```
MLAxisAddTq(PipeNetwork.Axis1, LREAL#10 ) ;
```

3.1.4.9.4.2 Ladder Diagram



3.1.4.9.4.3 Function Block Diagram



3.1.4.10 MLAxisCfgFastIn

Pipe Network ✓



Function - Configures the Fast Input for the axis by writing the expected settings in the Latch Control Word.

Fast input can be armed on falling or rising edge.

3.1.4.10.1 Arguments

3.1.4.10.1.1 Input

En	Description	Enables execution
	Data type	BOOL
	Unit	N/A
	Default	-
AxisID	Description	ID name of the Axis Block
	Data type	DINT
	Range	—
	Unit	N/A
InputID	Description	ID of the FastInput of an axis, (i.e., IN1 and IN2 on S300) <ul style="list-style-type: none"> • InputIDDINT <ul style="list-style-type: none"> • 0 = Touch Probe 1 / Capture Engine 0 • 1 = Touch Probe 2 / Capture Engine 1 • Range is [0,1]
	Data type	DINT
	Range	[0, 1]
	Unit	N/A
Mode	Description	Configures the Fast Inputs as: <ul style="list-style-type: none"> • 0= Disabled • 1=Rising edge • 2=Falling edge
	Data type	DINT
	Range	[0, 2]
	Unit	N/A
	Default	—

3.1.4.10.1.2 Output

Q	Description	<ul style="list-style-type: none"> • Returns true when the function successfully executes. • Returns false if the fast input could not be configured due to an invalid PDO mapping in the .XML file.
	Data type	BOOL
	Unit	N/A

3.1.4.10.2 Related Functions

"MLAxisIsTriggered" (→ p. 74)

"MLAxisRstFastIn" (→ p. 95)

3.1.4.10.3 See Also


- [Fast Inputs with Pipe Network Motion](#)
- [Fast Homing Example with the Pipe Network Motion Engine Axis Pipe Block](#)
- [Fast Homing Example with the PLCopen Motion Engine](#)
- [Pipe Network Registration and Fast Homing](#)
- [Registration Position Capture Example with Pipe Network Trigger Block](#)

3.1.4.10.4 Example

3.1.4.10.4.1 Structured Text

```
MLAxisCfgFastIn( PipeNetwork.Axis1, 0, 1 ) ;
```

3.1.4.10.4.2 Ladder Diagram



3.1.4.10.4.3 Function Block Diagram



3.1.4.11 MLAxisCmdPos

Pipe Network ✓

Function - Returns the reference position of the axis.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.4.11.1 Arguments

3.1.4.11.1.1 Input

ID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.11.1.2 Output

OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A
Position	Description	Returns the Axis reference position
	Data type	LREAL
	Unit	User unit

3.1.4.11.2 Related Functions

[MLAxisReadActPos](#)

[MLAxisFBackPos](#)

[MLAxisGenPos](#)

[MLAxisPipePos](#)

[MLAxisWritePipPos](#)

3.1.4.11.3 Previous Function Name


MLAxisRefPos

3.1.4.11.4 Example


3.1.4.11.4.1 Structured Text

```
Axis1_ReferencePosition := MLAxisCmdPos (PipeNetwork.AXIS1);
```

3.1.4.11.4.2 Ladder Diagram



3.1.4.11.4.3 Function Block Diagram



3.1.4.12 MLAxisDriveNumber Pipe Network ✓

3.1.4.12.1 Description

This function block returns the drive number that is associated with the axis, or -1 if the function block failed.




Figure 1-17: ML_AxisDriveNumber

TIP

"MLPNAxisCreate" (→ p. 107) assigns the drive axis number.

3.1.4.12.2 Arguments

3.1.4.12.2.1 Input

AxisID	Description	ID name of the Axis
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.12.2.2 Output

OK	Description	Returns true when the function successfully executes
	Data type	BOOL
	Range	N/A
	Unit	N/A
DriveAxisNumber	Description	Drive number that is associated with the axis, or -1 if the function block failed.
	Data type	INT
	Range	-1 or [1,32767]
	Unit	N/A

3.1.4.12.3 Related Functions


3.1.4.12.4 Example

3.1.4.12.4.1 Structured Text


```

Inst_MLAxisDriveNumber( AxisID)
IF Inst_MLAxisDriveNumber.OK Then
    Axis1DriveNumber := Inst_MLAxisDriveNumber.DriveAxisNumber
End_IF;
    
```

3.1.4.12.4.2 Ladder Diagram



3.1.4.12.4.3 Function Block Diagram



3.1.4.13 MLAxisFBackPos



Function - Returns the Feedback Position of the axis

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.4.13.1 Arguments

3.1.4.13.1.1 Input

ID	Description	ID name of the Axis Block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.13.1.2 Output

OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A
Position	Description	Returns the Feedback Position of the axis
	Data type	LREAL
	Unit	User unit

3.1.4.13.2 Related Functions

[MLAxisReadActPos](#)

[MLAxisGenPos](#)

[MLAxisPipePos](#)

[MLAxisCmdPos](#)

[MLAxisWritePipPos](#)

3.1.4.13.3 Example


3.1.4.13.3.1 Structured Text

```
Axis1_Position := MlAxisFBackPos( PipeNetwork.Axis1 ) ;
```

3.1.4.13.3.2 Ladder Diagram



3.1.4.13.3.3 Function Block Diagram



3.1.4.14 MlAxisGenEN



Function - Enables or disables the internal TMP generator of the axis.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.4.14.1 Arguments

3.1.4.14.1.1 Input

ID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
Enable	Description	Boolean switch to activate the generator
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—

3.1.4.14.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

3.1.4.14.2 Related Functions


MLAxisGenIsEN

3.1.4.14.3 Example

3.1.4.14.3.1 Structured Text

```
MLAxisGenEN( PipeNetwork.Axis1, true) ;
```

3.1.4.14.3.2 Ladder Diagram



3.1.4.14.3.3 Function Block Diagram



3.1.4.15 MLAxisGenIsEN

Pipe Network ✓

Function - Check if the internal TMP generator of the axis is enable. Returns TRUE if the internal generator is enabled.

3.1.4.15.1 Arguments

3.1.4.15.1.1 Input

ID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.15.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

3.1.4.15.2 Related Functions


[MLAxisGenIsRdy](#)

3.1.4.15.3 Example

3.1.4.15.3.1 Structured Text

```
MLAxisGenIsEN(PipeNetwork.Axis1 ) ;
```

3.1.4.15.3.2 Ladder Diagram



3.1.4.15.3.3 Function Block Diagram



3.1.4.16 MLAxisGenIsRdy



Function - Check if an axis is ready. Returns TRUE if the internal generator axis is ready.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.4.16.1 Arguments

3.1.4.16.1.1 Input

ID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.16.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

3.1.4.16.2 Related Functions

[MLAxisGenIsEN](#)

[MLAxisStatus](#)


3.1.4.16.3 Example

See "Examples of Axis Functions" (→ p. 109) for additional examples.

3.1.4.16.3.1 Structured Text

```
MLAxisGenIsRdy(PipeNetwork.Axis1 );
```

3.1.4.16.3.2 Ladder Diagram



3.1.4.16.3.3 Function Block Diagram



3.1.4.17 MLAxisGenPos



Function - Returns the generator position of the axis Returns TRUE if the internal generator axis is ready.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.4.17.1 Arguments

3.1.4.17.1.1 Input

ID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.17.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A
Position	Description	Returns Axis generator position value
	Data type	LREAL
	Unit	User unit

3.1.4.17.2 Related Functions

[MLAxisReadActPos](#)

[MLAxisFBackPos](#)

[MLAxisPipePos](#)

[MLAxisCmdPos](#)

[MLAxisWritePipPos](#)

3.1.4.17.3 Example

3.1.4.17.3.1 Structured Text

```
Axis1_Generator_Position := MLAxisGenPos (PipeNetwork.Axis1 ) ;
```

3.1.4.17.3.2 Ladder Diagram



3.1.4.17.3.3 Function Block Diagram



3.1.4.18 MLAxisGenReadAcc



Function - Get the acceleration of the internal generator of an axis.

3.1.4.18.1 Arguments

3.1.4.18.1.1 Input

AxisID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.18.1.2 Output

OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A
Acceleration	Description	Returns Axis Acceleration value
	Data type	LREAL

UnitUser unit/sec²**3.1.4.18.2 Related Functions**[MLAxisGenReadDec](#)[MLAxisGenReadSpd](#)**3.1.4.18.3 Example****3.1.4.18.3.1 Structured Text**

```
Axis1_Acceleration := MLAxisGenReadAcc( PipeNetwork.Axis1 );
```

3.1.4.18.3.2 Ladder Diagram

3.1.4.18.3.3 Function Block Diagram



3.1.4.19 MLAxisGenReadDec



Function - Get the Deceleration of the internal generator of an axis.

3.1.4.19.1 Arguments

3.1.4.19.1.1 Input

AxisID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.19.1.2 Output

OK	Description	
	Data type	BOOL
	Unit	N/A
Deceleration	Description	Returns Axis Deceleration value
	Data type	LREAL
	Unit	User unit/sec ²

3.1.4.19.2 Related Functions

[MLAxisGenReadAcc](#)

[MLAxisGenReadSpd](#)

3.1.4.19.3 Example


3.1.4.19.3.1 Structured Text

```
Axis1_Deceleration := MLAxisGenReadDec ( PipeNetwork.Axis1 );
```

3.1.4.19.3.2 Ladder Diagram



3.1.4.19.3.3 Function Block Diagram



3.1.4.20 MLAxisGenReadSpd



Function - Get the speed of the internal generator of an axis.

3.1.4.20.1 Arguments

3.1.4.20.1.1 Input

AxisID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.20.1.2 Output

OK	Description	
	Data type	BOOL
	Unit	N/A
Speed	Description	Returns Axis Speed value
	Data type	LREAL
	Unit	User unit/sec

3.1.4.20.2 Related Functions

[MLAxisGenReadDec](#)

[MLAxisGenReadAcc](#)

3.1.4.20.3 Example

3.1.4.20.3.1 Structured Text

```
Axis1_Speed := MLAxisGenReadSpd( PipeNetwork.Axis1 ) ;
```

3.1.4.20.3.2 Ladder Diagram



3.1.4.20.3.3 Function Block Diagram



3.1.4.21 MLAxisGenWriteAcc



Function - Set the acceleration of the internal generator of an axis.
Returns TRUE if the internal generator axis is ready.

3.1.4.21.1 Arguments

3.1.4.21.1.1 Input

AxisID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
Acceleration	Description	Sets the generator Acceleration value
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—

3.1.4.21.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

3.1.4.21.2 Related Functions

[MLAxisGenWriteDec](#)


[MLAxisGenWriteSpd](#)

3.1.4.21.3 Example

3.1.4.21.3.1 Structured Text

```
MLAxisGenWriteAcc(PipeNetwork.Axis1, 100000 ) ;
```

3.1.4.21.3.2 Ladder Diagram



3.1.4.21.3.3 Function Block Diagram



3.1.4.22 MLAxisGenWriteDec



Function - Set the Deceleration of the internal generator of an axis.
Returns TRUE if the internal generator axis is ready.

3.1.4.22.1 Arguments

3.1.4.22.1.1 Input

AxisID	Description	ID Name of the Axis block.
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
Deceleration	Description	Sets the generator Deceleration value. The axis deceleration rate is limited such that the velocity cannot change by more than the value of the declared velocity limit in a single iteration. The Pipe Network Axis block uses the TRAVEL_SPEED parameter to scale this limit. The maximum deceleration is therefore affected by the Pipe Network Axis Block parameter "TRAVEL_SPEED", as well as the axis update rate.
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—

3.1.4.22.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

3.1.4.22.2 Related Functions

[MLAxisGenWriteAcc](#)


[MLAxisGenWriteSpd](#)

3.1.4.22.3 Example

3.1.4.22.3.1 Structured Text

```
MLAxisGenWriteDec (PipeNetwork.Axis1, 100000 ) ;
```

3.1.4.22.3.2 Ladder Diagram



3.1.4.22.3.3 Function Block Diagram



3.1.4.23 MLAxisGenWriteSpd

Pipe Network ✓

Function - Set the speed of the internal generator of an axis.
Returns TRUE if the function succeeded. This function does not generate any motion.

3.1.4.23.1 Arguments

3.1.4.23.1.1 Input

AxisID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
Speed	Description	Sets the generator Speed value
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.1.4.23.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

3.1.4.23.2 Related Functions

[MLAxisGenWriteAcc](#)


[MLAxisGenWriteDec](#)

3.1.4.23.3 Example

3.1.4.23.3.1 Structured Text

```
MLAxisGenWriteSpd(PipeNetwork.Axis1, 500 ) ;
```

3.1.4.23.3.2 Ladder Diagram



3.1.4.23.3.3 Function Block Diagram



3.1.4.24 MLAxisInit



Function - Initializes an axis object.

3.1.4.24.1 Input

AxisID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
ModuloPosition	Description	Value of the period of a cyclic system expressed in user units. The parameter is defined to correctly manage the periodicity (modulo) of the input values.
	Data type	LREAL
	Range	—

	Unit	User unit
	Default	—
UserUnitPerTurn	Description	Define the unit which is equivalent to one revolution of the physical motor.
	Data type	LREAL
	Range	—
	Unit	N/A
	Default	—
FeedbackUnitPerTurn	Description	
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
Speed	Description	Sets the Axis Speed
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
Acceleration	Description	Sets the Axis Acceleration value
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Sets the Axis Deceleration value
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
InitialPosition	Description	Initial position value expressed in user logical units. Used only at the pipe activation to initialize the position starting point
	Data type	LREAL
	Range	—

	Unit	User unit
	Default	—
Modulo	Description	Define the mode which can be Modulo (True) or not (False)
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—


3.1.4.24.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A


3.1.4.24.3 Remarks

- Returns TRUE if the function succeeded.
- The axis object can be mapped to servo or stepper drives.

3.1.4.24.4 FBD Language



3.1.4.24.5 FFLD Language



3.1.4.24.6 ST Language

```
MLAxisInit( PipeNetwork.Axis1, 360.0, 360.0, SHL(1,20), 500.0, 100000.0,
100000.0, 0.0, true ) ;
```

3.1.4.25 MLAxisIsCnctd



Function - Check if a pipe is currently connected to the axis. Returns TRUE if a pipe is connected.

3.1.4.25.1 Arguments

3.1.4.25.1.1 Input

ID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.25.1.2 Output


Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

3.1.4.25.2 Example

3.1.4.25.2.1 Structured Text

```
MLAxisIsCnctd(PipeNetwork.Axis1 ) ;
```

3.1.4.25.2.2 Ladder Diagram



3.1.4.25.2.3 Function Block Diagram



3.1.4.26 MLAxisIsTriggered



Function - Checks if the axis got a trigger event.

Returns TRUE if the Fast Input event has been **triggered** and not yet been reset.

3.1.4.26.1 Arguments

3.1.4.26.1.1 Input

ID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
InputID	Description	ID of the triggered Fast input of an axis (ie IN1 and IN2 on S300). <ul style="list-style-type: none"> • InputIDINT <ul style="list-style-type: none"> • 0 = Touch Probe 1 / Capture Engine 0 • 1 = Touch Probe 2 / Capture Engine 1 • Range is [0,1]
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
edge	Description	Configures the Inputs as 0= Disabled, 1=Rising Edge, 2=Falling edge
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.26.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

3.1.4.26.2 Related Functions


[MLAxisRstFastIn](#)

3.1.4.26.3 Example

3.1.4.26.3.1 Structured Text

```
MLAxisIsTriggered (PipeNetwork.Axis1, 0,1 ) ;
```

3.1.4.26.3.2 Ladder Diagram



3.1.4.26.3.3 Function Block Diagram



3.1.4.27 MLAxisMoveVel



Function - Jog at the specified speed.
Returns TRUE if the function succeeded.

3.1.4.27.1 Arguments

3.1.4.27.1.1 Input

ID	Description	ID Name of the Axis block.
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
Speed	Description	Sets the Axis Speed.
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—

3.1.4.27.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes after the motion has reached jog speed.
	Data type	BOOL
	Unit	N/A

3.1.4.27.2 Related Functions

[MLAxisGenWriteSpd](#)

[MLAxisGenWriteDec](#)

[MLAxisGenWriteAcc](#)

3.1.4.27.3 Previous Function Name

MLAxisRun


3.1.4.27.4 Example

See "Examples of Axis Functions" (→ p. 109) for additional examples.

3.1.4.27.4.1 Structured Text

```
MLAxisMoveVel(PipeNetwork.Axis1, 500 ) ;
```

3.1.4.27.4.2 Ladder Diagram




3.1.4.27.4.3 Function Block Diagram



3.1.4.28 MLAxisPipePos

Pipe Network ✓

 **Function** - Returns the pipe position of the axis.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.4.28.1 Arguments

3.1.4.28.1.1 Input

ID	Description	ID Name of the Axis block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.4.28.1.2 Output

OK	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

Position	Description
	Data type LREAL
	Range —
	Unit User unit

3.1.4.28.2 Related Functions

[MLAxisReadActPos](#)

[MLAxisFBackPos](#)

[MLAxisGenPos](#)

[MLAxisCmdPos](#)

[MLAxisWritePipPos](#)

3.1.4.28.3 Example

3.1.4.28.3.1 Structured Text

```
Axis1_Pipe_Position := MLAxisPipePos (PipeNetwork.Axis1 ) ;
```

3.1.4.28.3.2 Ladder Diagram



3.1.4.28.3.3 Function Block Diagram



3.1.4.29 MLAxisPower



Function - Powers up or down the axis.

Enables or disables a Servo drive or Stepper drive mapped to the axis.

When the axis is powered up, the **ReferencePosition** is modified to equal the **ActualPosition**. For that, KAS updates the **GeneratorPosition**.

⚠ IMPORTANT

Powering on an axis affects the position and motion state of an axis. MLAxisPower should not be called with the **On** input flag set to **True** while the axis is in motion.

3.1.4.29.1 Arguments

3.1.4.29.1.1 Input

ID	Description
ID	ID Name of the Axis block

	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
On	Description	Flag to power up (True) or down (False) the Axis
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—

3.1.4.29.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

3.1.4.29.2 Related Functions

[MLAxisPowerDOff](#)

3.1.4.29.3 Previous Function Name

MLAxisPowerOn


MLAxisPowerOff

3.1.4.29.4 Example

3.1.4.29.4.1 Structured Text

```
(* If Power_OnOff is TRUE then power in ON, otherwise OFF*)
MLAxisPower( PipeNetwork.Axis1, Power_OnOff) ;
```

3.1.4.29.4.2 Ladder Diagram



3.1.4.29.4.3 Function Block Diagram



3.1.4.30 MLAxisPowerDOff




Function - This function has been deprecated.

3.1.4.31 MLAxisRatedTq



Function - Allows conversion of drive torque values from rated torque units (1000 = rated motor continuous torque) to N.m (Newton meter).



3.1.4.31.1 Arguments

3.1.4.31.1.1 Input

ID	Description	Pipe network identifier of the axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
Torque	Description	Actual torque applied by the drive associated to the axis Rated torque = Nominal Drive Current * Torque factor = <code>DRV.ICONT</code> * <code>MOTOR.KT</code>
	About SDO	<p><code>DRV.ICONT</code> is obtained by SDO parameter: index 5083h (sub-index 0) <code>MOTOR.KT</code> is obtained by SDO parameter: index 3593h (sub-index 0) For more details, refer to:</p> <ul style="list-style-type: none"> • Communication SDOs • Manufacturer specific SDOs • Profile specific SDOs <p>To read/write an SDO object with an index greater than 16#7FFF (32767), the value must be entered in the form <code>any_to_int(index # in hex format)</code>. For example <code>any_to_int(16#8321)</code>. The actual units of <code>DRV.ICONT</code> and <code>MOTOR.KT</code> are 1/1000 of the actual values if obtained by SDO. So the formula, if using the SDO values, is: Rated Torque = Torque = $(\text{SDO}(\text{DRV.ICONT})/1000) * (\text{SDO}(\text{MOTOR.KT})/1000)$</p>
	Data type	LREAL
	Unit	N.m (Newton meter)

3.1.4.31.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

3.1.4.31.2 Related Functions


[MLAxisReadTq](#)

3.1.4.31.3 Example


3.1.4.31.3.1 Structured Text

```
MLAxisRatedTq(PipeNetwork.Axis1, Axis1_Torque ) ;
```

3.1.4.31.3.2 Ladder Diagram



3.1.4.31.3.3 Function Block Diagram



3.1.4.32 MLAxisReadActPos



Function - Returns the Actual Position of the axis

NOTE
 This function or function block returns cached data.
 See [Programming a Dual Core Controller](#) for more information.

3.1.4.32.1 Arguments

3.1.4.32.1.1 Input

ID	Description	ID name of the Axis Block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.32.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes
---------------------	--------------------	--

	Data type	BOOL
	Unit	N/A
Position	Description	Returns the absolute position of the axis
	Data type	LREAL
	Unit	User unit

3.1.4.32.2 Related Functions

[MLAxisFBackPos](#)

[MLAxisGenPos](#)

[MLAxisPipePos](#)

[MLAxisCmdPos](#)

[MLAxisWritePipPos](#)

3.1.4.32.3 Previous Function Name


MLAxisActualPos

3.1.4.32.4 Example

3.1.4.32.4.1 Structured Text

```
Axis1_Position := MLAxisReadActPos( PipeNetwork.Axis1 ) ;
```

3.1.4.32.4.2 Ladder Diagram



3.1.4.32.4.3 Function Block Diagram



3.1.4.33 MLAxisReadFBUnit



Function - Get the feedback units per revolution value of the axis

3.1.4.33.1 Arguments

3.1.4.33.1.1 Input

AxisID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—

Unit	N/A
Default	—

3.1.4.33.1.2 Output

OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A
FBUnitsPerRev	Description	Returns the Axis Feedback Units per revolution
	Data type	LREAL
	Unit	N/A

3.1.4.33.2 Example

3.1.4.33.2.1 Structured Text

```
Axis1_Feedback_Units := MAxisReadFBUnit(PipeNetwork.Axis1 ) ;
```

3.1.4.33.2.2 Ladder Diagram



3.1.4.33.2.3 Function Block Diagram



3.1.4.34 MAxisReadFEUU

Pipe Network ✓



Function - Return the difference between the reference position and the actual position of the drive mapped to the specified axis

3.1.4.34.1 Arguments

3.1.4.34.1.1 Input

ID	Description	Pipe network identifier of the axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.34.1.2 Output

Error	Description	Difference between the reference position and the actual position of the drive associated to the axis
	Data type	LREAL
	Unit	User unit

3.1.4.34.2 Related Functions


[MLAxisReadActPos](#)

3.1.4.34.3 Example

3.1.4.34.3.1 Structured Text

```
Axis1_Error := MLAxisReadFEUU(PipeNetwork.Axis1 ) ;
```

3.1.4.34.3.2 Ladder Diagram



3.1.4.34.3.3 Function Block Diagram



3.1.4.35 MLAxisReadGenStatus



Function - Returns the status of the internal generator of the axis.

0	RUN mode (acceleration)
1	RUNNING or STOPPED
2	MOVE: Changing move destination
3	MOVE: Changing move destination
4	MOVE: Acceleration
5	MOVE: Constant speed (travel speed)
6	MOVE: Deceleration
7	MOVE: Single step (micro movement)

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.4.35.1 Arguments

3.1.4.35.1.1 Input

ID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.35.1.2 Output

OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A
Default (.Q)	Description	Shows the status of the internal generator based on the table at the top of this topic
	Data type	DINT
	Unit	N/A

3.1.4.35.2 Related Functions

[MLAxisGenIsRdy](#)

[MLAxisStatus](#)

3.1.4.35.3 Previous Function Name

MLAxisGenStatus

3.1.4.35.4 Example

3.1.4.35.4.1 Structured Text

```
MLAxisReadGenStatus(PipeNetwork.Axis1 ) ;
```

3.1.4.35.4.2 Ladder Diagram



3.1.4.35.4.3 Function Block Diagram



3.1.4.36 MLAxisReadModPos

Pipe Network ✓

 **Function** - Get the value period of the axis.

3.1.4.36.1 Arguments

3.1.4.36.1.1 Input

AxisID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.36.1.2 Output

OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A
ModuloPosition	Description	Returns the Axis Value Period
	Data type	LREAL
	Unit	User unit

3.1.4.36.2 Example

3.1.4.36.2.1 Structured Text

```
Axis1_Value_Period := MAxisReadModPos (PipeNetwork.Axis1 ) ;
```

3.1.4.36.2.2 Ladder Diagram



3.1.4.36.2.3 Function Block Diagram



3.1.4.37 MAxisReadTq

Pipe Network ✓

Function - Return the actual torque applied by the drive which is mapped to the specified axis.



NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.4.37.1 Arguments**3.1.4.37.1.1 Input**

ID	Description	Pipe network identifier of the axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.37.1.2 Output

Torque	Description	Actual torque applied by the drive associated to the axis in N.m (Newton meter). If you have not previously invoked the " MLAxisRatedTq " (→ p. 80) function, the Output value is rated motor continuous torque (where 1000.0 = rated torque)
	Data type	LREAL
	Unit	N.m (Newton meter)

3.1.4.37.2 Related Functions



[MLAxisRatedTq](#)

[MLAxisReadActPos](#)

[MLAxisReadVel](#)

3.1.4.37.3 Example**3.1.4.37.3.1 Structured Text**

```
Axis1_Torque := MLAxisReadTq(PipeNetwork.Axis1 ) ;
```

3.1.4.37.3.2 Ladder Diagram**3.1.4.37.3.3 Function Block Diagram****3.1.4.38 MLAxisReadUUnits**

Pipe Network ✓



Function - Get the User units per revolution value of the axis.

3.1.4.38.1 Arguments

3.1.4.38.1.1 Input

AxisID	Description	ID Name of the Axis block.
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.38.1.2 Output

OK	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A
UserUnitsPerRev	Description	Returns the Axis User Units per revolution.
	Data type	LREAL
	Unit	N/A

3.1.4.38.2 Example


3.1.4.38.2.1 Structured Text

```
Axis1_User_Units := MAxisReadUUnits (PipeNetwork.Axis1 ) ;
```

3.1.4.38.2.2 Ladder Diagram



3.1.4.38.2.3 Function Block Diagram



3.1.4.39 MAxisReadVel



Function - Return the actual velocity of the axis, based on the data provided by the drive's feedback device.

AKD, S300, S700 drives: The actual velocity is calculated internally by the drive. The 'Velocity Actual Value' object (CoE object 0x606C, subindex 0) must be included in the drive's Input (Tx) PDO data for the controller to read the axis actual velocity from the drives. This can be added via the [PDO Editor Tab](#). The 'Velocity Actual Value' object is included by default in the AKD PDOs 0x1B20, 0x1B22, and 0x1B23.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.4.39.1 Arguments**3.1.4.39.1.1 Input**

ID	Description	Pipe network identifier of the axis block.
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.39.1.2 Output

Velocity	Description	The actual velocity of the axis.
	Data type	LREAL
	Unit	User unit/sec


3.1.4.39.2 Related Functions

[MLAxisReadActPos](#)


[MLAxisReadTq](#)

3.1.4.39.3 Example**3.1.4.39.3.1 Structured Text**

```
Axis1_Velocity := MLAxisReadVel(PipeNetwork.Axis1 ) ;
```

3.1.4.39.3.2 Ladder Diagram**3.1.4.39.3.3 Function Block Diagram****3.1.4.40 MLAxisReAlignRdy**

Pipe Network ✓

 **Function** - Check if an axis is ready.
Returns TRUE if the internal realignment axis is ready.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.4.40.1 Arguments

3.1.4.40.1.1 Input

ID	Description	ID Name of the Axis block.
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.40.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

3.1.4.40.2 Related Functions

[MLAxisReAlign](#)

3.1.4.40.3 Example

3.1.4.40.3.1 Structured Text

```
MLAxisReAlignRdy (PipeNetwork.Axis1 ) ;
```

3.1.4.40.3.2 Ladder Diagram



3.1.4.40.3.3 Function Block Diagram



3.1.4.41 MLAxisReAlign



Function

When stopping the drive a motion profile is applied to decelerate. During the deceleration, the Reference position changes. Calling MLAxisReAlign realigns the actual position with the reference position by moving the axis by the specified delta position, which is typically calculated by the

application code. After a [MLAxisStop](#) is executed, a [MLAxisReAlign](#) is required for the Pipe Position to be used again.

The function returns TRUE if it succeeds.

NOTE

The realign function do not work properly if the [MLAxisStop](#) function is continuously executed via its Start input

3.1.4.41.1 Arguments

3.1.4.41.1.1 Input

ID	Description	ID Name of the Axis block.
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
Acceleration	Description	Sets the Realign Acceleration.
	Data type	LREAL
	Range	—
	Unit	User unit /sec ²
	Default	—
Deceleration	Description	Sets the Realign Deceleration rate.
	Data type	LREAL
	Range	—
	Unit	User unit /sec ²
	Default	—
Speed	Description	Sets the Axis Speed.
	Data type	LREAL
	Range	—
	Unit	User unit /sec
	Default	—
DeltaPos	Description	Sets the Axis Delta Position, or the relative distance to be moved.
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.1.4.41.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

3.1.4.41.2 Related Functions


[MLAxisReAlignRdy](#)

3.1.4.41.3 Example


3.1.4.41.3.1 Structured Text

```
MLAxisReAlign(PipeNetwork.Axis1, 100000, 100000, 500, 20 ) ;
```

3.1.4.41.3.2 Ladder Diagram



3.1.4.41.3.3 Function Block Diagram



3.1.4.42 MLAxisRel



Function

A selected Axis performs a move for a specified distance relative to the current position. The DeltaPosition input is signed so that the move can be in the positive or negative direction, and the Axis moves this distance in user units. The travel speed, acceleration, deceleration, and User Units of the move are values inherited from the selected Axis. The default settings are entered when an Axis is created and initiated, and can be changed with other MLAxis commands such as [MLAxisGenWriteSpd](#), [MLAxisGenWriteAcc](#), and [MLAxisWriteUUnits](#).

NOTE

If you wish to know when a move has completed, we recommend using [MLAxisGenIsRdy](#). The output of MLAxisRel can occur before moves have finished.

3.1.4.42.1 Arguments

3.1.4.42.1.1 Input

ID	Description	ID Name of the Axis block.
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
DeltaPosition	Description	Sets the Axis Delta Position, or the relative distance to be moved.
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.1.4.42.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes. This occurs immediately after the function is called; the function does not wait for the motion profile to be completed.
	Data type	BOOL
	Unit	N/A

3.1.4.42.2 Related Functions

[MLAxisGenWriteAcc](#)

[MLAxisGenWriteDec](#)

[MLAxisGenWriteSpd](#)


3.1.4.42.3 Example

See "Examples of Axis Functions" (→ p. 109) for additional examples.

3.1.4.42.3.1 Structured Text

```
MLAxisRel (PipeNetwork.Axis1, 2500 ) ;
```

3.1.4.42.3.2 Ladder Diagram



NOTE

You must use a [pulse contact](#) to start the FB

3.1.4.42.3.3 Function Block Diagram



3.1.4.43 MLAxisResetErrors



Function - Clears errors of the specified axis

3.1.4.43.1 Arguments

3.1.4.43.1.1 Input

ID	Description	ID name of the Axis Block.
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.43.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

3.1.4.43.2 Previous Function Name


MLAxisClrErrors

3.1.4.43.3 Example

3.1.4.43.3.1 Structured Text

```
MLAxisResetErrors( PipeNetwork.Axis1 ) ;
```

3.1.4.43.3.2 Ladder Diagram



3.1.4.43.3.3 Function Block Diagram



3.1.4.44 MLAxisRstFastIn

 Pipe Network ✓



Function - Write in the Latch Control Word to reset the Fast Input.

3.1.4.44.1 Arguments

3.1.4.44.1.1 Input

AxisID	Description	ID Name of the Axis block.
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
InputID	Description	ID name of the Fast input to be reset on an axis, (ie IN1 and IN2 on S300). <ul style="list-style-type: none"> • InputIDDINT <ul style="list-style-type: none"> • 0 = Touch Probe 1 / Capture Engine 0 • 1 = Touch Probe 2 / Capture Engine 1 • Range is [0,1]
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.44.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

3.1.4.44.2 Related Functions

[MLAxisCfgFastIn](#)


[MLAxisIsTriggered](#)

3.1.4.44.3 Example

3.1.4.44.3.1 Structured Text

```
MLAxisRstFastIn(PipeNetwork.Axis1, 0 ) ;
```

3.1.4.44.3.2 Ladder Diagram



3.1.4.44.3.3 Function Block Diagram



3.1.4.45 MLAxisStatus



Function - Returns the status of the axis.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.4.45.1 Arguments

3.1.4.45.1.1 Input

ID	Description	ID Name of the Axis block.
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.45.1.2 Output

OK	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

Default (.Q)	Description	Returns the status of the axis																												
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Initialized (1 if initialized)</td> </tr> <tr> <td>1</td> <td>Power (1 if power is on) Is linked to bit 1 (Switched on) of the Status Word For more information on the status machine</td> </tr> <tr> <td>2</td> <td>Enabled (1 if enabled) Is linked to bit 0 (Ready to switch on) of the Status Word</td> </tr> <tr> <td>3</td> <td>Found (1 if found on the network). EtherCAT state is Pre-Operational, see EtherCAT State Machine.</td> </tr> <tr> <td>4</td> <td>Configured (1 if configured) EtherCAT state is Safe-Operational, see EtherCAT State Machine.</td> </tr> <tr> <td>5</td> <td>Running (1 if running) EtherCAT state is Operational, see EtherCAT State Machine.</td> </tr> <tr> <td>6</td> <td>Error (1 if in error)</td> </tr> <tr> <td>7</td> <td>Simulated (1 if working with a simulated axis)</td> </tr> <tr> <td>8</td> <td>Connected (1 if a pipe is connected)</td> </tr> <tr> <td>9</td> <td>Warning (1 if the drive signals a warning)</td> </tr> <tr> <td>10</td> <td>Stopping (1 if the drive is performing a Stop)</td> </tr> <tr> <td>11</td> <td>Stopped (1 if the drive has finished the Stop)</td> </tr> <tr> <td>12 to 31</td> <td>Reserved</td> </tr> </tbody> </table>	Bit	Description	0	Initialized (1 if initialized)	1	Power (1 if power is on) Is linked to bit 1 (Switched on) of the Status Word For more information on the status machine	2	Enabled (1 if enabled) Is linked to bit 0 (Ready to switch on) of the Status Word	3	Found (1 if found on the network). EtherCAT state is Pre-Operational, see EtherCAT State Machine .	4	Configured (1 if configured) EtherCAT state is Safe-Operational, see EtherCAT State Machine .	5	Running (1 if running) EtherCAT state is Operational, see EtherCAT State Machine .	6	Error (1 if in error)	7	Simulated (1 if working with a simulated axis)	8	Connected (1 if a pipe is connected)	9	Warning (1 if the drive signals a warning)	10	Stopping (1 if the drive is performing a Stop)	11	Stopped (1 if the drive has finished the Stop)	12 to 31	Reserved
Bit	Description																													
0	Initialized (1 if initialized)																													
1	Power (1 if power is on) Is linked to bit 1 (Switched on) of the Status Word For more information on the status machine																													
2	Enabled (1 if enabled) Is linked to bit 0 (Ready to switch on) of the Status Word																													
3	Found (1 if found on the network). EtherCAT state is Pre-Operational, see EtherCAT State Machine .																													
4	Configured (1 if configured) EtherCAT state is Safe-Operational, see EtherCAT State Machine .																													
5	Running (1 if running) EtherCAT state is Operational, see EtherCAT State Machine .																													
6	Error (1 if in error)																													
7	Simulated (1 if working with a simulated axis)																													
8	Connected (1 if a pipe is connected)																													
9	Warning (1 if the drive signals a warning)																													
10	Stopping (1 if the drive is performing a Stop)																													
11	Stopped (1 if the drive has finished the Stop)																													
12 to 31	Reserved																													
	Data type	DINT																												
	Unit	N/A																												

3.1.4.45.2 Example

3.1.4.45.2.1 Structured Text


```
AxisStatus := MAxisStatus(PipeNetwork.AXI_A1_Axis) ;
IF AxisStatus.11 THEN
    MAxisStop(PipeNetwork.AXI_A1_Axis, FALSE, DEF_A1_StopDec) ;
END_IF;
```

```
AxisStatus := MAxisStatus(PipeNetwork.AXI1);
If AxisStatus.0 Then
    (*Axis is initialized*)
ElsIf AxisStatus.1 Then
    (*Axis' power is ON*)
```

```

ElsIf AxisStatus.2 Then
  (*Axis is READY to be enabled*)
End_If;
    
```

3.1.4.45.2 Ladder Diagram



3.1.4.45.2.3 Function Block Diagram



3.1.4.46 MLAxisStop Pipe Network

3.1.4.46.1 Description

Stop with the specified deceleration.

After stopping the drive, you need to restart the motion by realigning the actual position with the reference position.

The purpose of the MLAxisStop Command is not to remove the input source, but to stop the drive from continuing to move.

When the stop occurs, the master keeps moving and the axis starts ignoring the Pipe Position value and begins a controlled stop based on the input parameters. Also at that point, any Axis Block level profile (issued from FB like MLAxisAbs, MLAxisRel...) are aborted. When the stop is complete, it is up to the application to decide how to move the axis, master, or both to a position where they can be realigned, and the master restarted.

The **realign** function is used to move the axis to a restart position in order to enable synchronized machine motion to start again. Once the realign function is successfully completed, the Pipe Position is again summed with the Generator Position to create the Reference Position.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.4.46.2 Arguments

3.1.4.46.2.1 Input

ID	Description	ID Name of the Axis block.
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
Start	Description	
	Data type	BOOL

	Range	0, 1
	Unit	N/A
	Default	—
Deceleration	Description	
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—

3.1.4.46.2.2 Output

Default (.Q)	Description	Comes true when the Axis is completely stopped.
	Data type	BOOL
	Unit	N/A
PipePos	Description	Corresponds to the Pipe Position input to the axis at the time the stop is triggered.
	Data type	LREAL
	Unit	User unit
GenPos	Description	Corresponds to the Generator Position input to the axis at the time the stop is triggered.
	Data type	LREAL
	Unit	User unit
RealignPos	Description	Realign Position is the Reference Position at which the stop is triggered. The Realign Position is obtained by converting the last value sent to the drive from drive interface units into user units. The Realign Position is useful if you want to return to the point at which the trajectory was abandoned, or in case you need to realign the master to the slave.
	Data type	LREAL
	Unit	User unit
StopPos	Description	Corresponds to the last Reference Position sent to the drive at the time when the Axis is completely stopped. It is functionally different than the Actual Position because that position is the drive position converted to user units. The correct delta for the realign move to get in sync with the trajectory in order to realign the slave to the master is the current Reference Position minus the Stop Position for the realign move. After stopping, if the axis is disabled and the motor position is manually altered, this distance must be taken into account when performing the realign.

Data type	LREAL
Unit	User unit

3.1.4.46.3 Related Functions

[MLAxisReAlign](#)


3.1.4.46.4 Example

3.1.4.46.4.1 Structured Text

```

Inst_MLAxisStop(PipeNetwork.AXIS1, bStop, 200000);
If Inst_MLAxisStop.Done Then
  Axis1_PipePosition      := Inst_MLAxisStop.PipePos;
  Axis1_GeneratorPosition := Inst_MLAxisStop.GenPos;
  Axis1_RealignPosition  := Inst_MLAxisStop.RealignPos;
  Axis1_StopPosition     := Inst_MLAxisStop.StopPos;
End_if;
    
```

3.1.4.46.4.2 Ladder Diagram



3.1.4.46.4.3 Function Block Diagram



3.1.4.47 MLAxisTimeStamp



Function - Returns the timestamp of the triggered axis.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.4.47.1 Arguments

3.1.4.47.1.1 Input

En	Description	Enables execution
	Data type	BOOL

	Unit	N/A
	Default	—
ID	Description	ID Name of the Axis block.
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
InputID	Description	ID of the triggered Fast input of an axis, 0=first , 1=second (ie IN1 and IN2 on S300).
	Data type	DINT
	Range	[0, 1]
	Unit	N/A
	Default	—
edge	Description	Configures the Inputs as 0= Disabled, 1=Rising Edge, 2=Falling edge
	Data type	DINT
	Range	[0, 2]
	Unit	N/A
	Default	—

3.1.4.47.1.2 Output

OK	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A
Q	Description	Returns the time stamp value. This value is explained in How To Interpret a Timestamp .
	Data type	DINT
	Unit	microseconds

3.1.4.47.2 Related Functions

[MLAxisCfgFastIn](#)

[MLAxisRstFastIn](#)


[MLAxisIsTriggered](#)

3.1.4.47.3 Example

3.1.4.47.3.1 Structured Text

```
MLAxisTimeStamp (PipeNetwork.Axis1, 0, 1 ) ;
```

3.1.4.47.3.2 Ladder Diagram



3.1.4.47.3.3 Function Block Diagram



3.1.4.48 MLAxisWriteModPos



Function - Set the value period of the axis.
Returns TRUE if the function succeeded.

3.1.4.48.1 Arguments

3.1.4.48.1.1 Input

AxisID	Description	ID Name of the Axis block
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
ModuloPosition	Description	Sets the Axis Period Value when Mode is set to Modulo.
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.1.4.48.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

3.1.4.48.2 Example

3.1.4.48.2.1 Structured Text

```
MLAxisWriteModPos (PipeNetwork.Axis1, 360) ) ;
```

3.1.4.48.2.2 Ladder Diagram



3.1.4.48.2.3 Function Block Diagram



3.1.4.49 MLAxisWritePipPos

Pipe Network ✓



Function - Force the pipe position internal value.

This function is working only when no pipe is connected.

3.1.4.49.1 Arguments

3.1.4.49.1.1 Input

AxisID	Description	ID Name of the Axis block.
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
PipePosition	Description	Sets the Axis Pipe Position.
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.1.4.49.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL

Unit	N/A
-------------	-----

3.1.4.49.2 Related Functions

- [MLAxisReadActPos](#)
- [MLAxisFBackPos](#)
- [MLAxisGenPos](#)
- [MLAxisPipePos](#)
- [MLAxisCmdPos](#)

3.1.4.49.3 Example

3.1.4.49.3.1 Structured Text

```
MLAxisWritePipPos (PipeNetwork.Axis1, 3000 ) ;
```

3.1.4.49.3.2 Ladder Diagram



3.1.4.49.3.3 Function Block Diagram



3.1.4.50 MLAxisWritePos



Function - Sets a new value to an axis' current location.

After this function is called, the axis' current location will have a value equal to the **Position** argument.


About associated data on Positions

This data are illustrated in the figure below.

NOTE

All positions are in user units with modulo applied if active, unless specified.

Position / Offset	Description
Actual Position	<p>Actual Position is the actual position of the underlying axis as reported by the drive.</p> <p>It is the sum of the feedback value (Position actual value) returned from the communication link to the drive and any zero-offset due to an MLWritePos function block ("MLAxisWritePipPos" (→ p. 103), "MLAxisWritePos" (→ p. 104)).</p> <pre>ActualPos := FeedbackPos + ZeroOffset</pre>
Feedback Position	<p>Feedback Position is the current position the drive reports for an axis, scaled to user units.</p> <p>It does not take into account the value of the Zero Offset or axis modulo.</p>
Generator Position	<p>Generator Position is the summation of all previous commands (i.e., calls to functions which perform motion such as "MLAxisAbs" (→ p. 47), "MLAxisMoveVel" (→ p. 76), and "MLAxisRel" (→ p. 92)) to the Axis internal motion generator.</p> <ul style="list-style-type: none"> • It is modified by "MLAxisWritePos" (→ p. 104) to insure no jumps in the Reference Position command. • It accumulates changes in pipe position due to activate and deactivation of the pipe the Axis block is associated with.
Pipe Position	<p>The output of the convertor block is written into the Pipe Position value whenever the Convertor block is connected to the axis and the pipe is active.</p>
Reference Position	<p>Reference Position is the commanded axis position sent to the drive.</p> <p>It is the summation of Pipe Position and Generator Position.</p> <pre>ReferencePosition = Pipe Position + Generator Position</pre>
Zero Offset	<p>The Zero Offset adjusts the coordinate system so the Actual Position reports correct values after homing or using "MLAxisWritePos" (→ p. 104).</p>



3.1.4.50.1 Arguments

3.1.4.50.1.1 Input

ID	Description	ID Name of the Axis block.
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
Position	Description	The new value for the axis' current location.
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.1.4.50.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

3.1.4.50.2 Previous Function Name


MLAxisSetZero

3.1.4.50.3 Example

3.1.4.50.3.1 Structured Text

```
MLAxisWritePos(PipeNetwork.Axis1, 0) ;
```

3.1.4.50.3.2 Ladder Diagram



3.1.4.50.3.3 Function Block Diagram



3.1.4.51 MLAxisWriteUUnits

Pipe Network ✓

Function - Set the user units per revolution value of the axis.
Returns TRUE if the function succeeded.

User units are user-defined position units used within the KAS application. Selected units must be as natural as possible and must make sense for the machine. It must be related to the final moving object (e.g. the driven belt rather than the axis shaft). The same unit must be used for all related axes for simplicity reasons. Speeds are defined in [user units / second] and accelerations in [user units / second²].

3.1.4.51.1 Arguments

3.1.4.51.1.1 Input

AxisID	Description	ID Name of the Axis block.
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.51.1.2 Output


Default (.Q)	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A
UserUnitsPerRev	Description	Sets the Axis User Units per revolution.
	Data type	LREAL
	Unit	N/A

3.1.4.51.2 Example


3.1.4.51.2.1 Structured Text

```
MLAxisWriteUUnits (PipeNetwork.Axis1, 360 ) ;
```

3.1.4.51.2.2 Ladder Diagram



3.1.4.51.2.3 Function Block Diagram




3.1.4.52 MLPNAxisCreate Pipe Network ✓

3.1.4.52.1 Description

Creates a new axis object. Returns the ID of the newly created axis object or 0 if the function failed.

TIP

This function should be called after "MLMotionInit" (→ p. 414) is called and before "MLMotionStart" (→ p. 417) is called.



3.1.4.52.2 Arguments

3.1.4.52.2.1 Input

Name	Description	Name of the created Axis.
	Data type	STRING
	Range	—
	Unit	N/A
	Default	—
DriverName	Description	Is the Motion bus driver name or Simulated.
	Data type	STRING
	Range	—
	Unit	N/A
	Default	—
DriveAxisNumber	Description	This one-based number specifies the axis on the drive. For a single-axis drive, this number should be 1.
	Data type	UINT
	Range	[1,256]
	Unit	N/A
	Default	—
Address	Description	Axis motion bus address
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

3.1.4.52.2.2 Output


OK	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

3.1.4.52.3 Example


3.1.4.52.3.1 Structured Text

```
PipeNetwork.AXIS1 := MLPNAxisCreate('AXIS1','SercosDriver',0,1001);
```


3.1.4.52.3.2 Ladder Diagram




3.1.4.52.3.3 Function Block Diagram



3.1.4.53 Examples of Axis Functions



MLAxisMoveVel(Speed) starts to run the axis. Then **MLAxisGenIsRdy** returns TRUE when the Speed is reached.



MLAxisMoveVel(0.0) reduces the speed down to 0. Then **MLAxisGenIsRdy** returns TRUE once the axis is ready.




Figure 1-18: Axis Functions Usage

3.1.5 Motion Library - Cam Profile

Name	Description	Return type
"MLCamInit" (→ p. 111)	Initializes a cam Pipe Block with user-defined settings.	BOOL
"MLCamSwitch" (→ p. 113)	Switches profiles of the selected cam object.	BOOL
"MLPrfReadIOffset" (→ p. 114)	Returns the Input Offset value of a selected cam profile.	None
"MLPrfReadIScale" (→ p. 115)	Returns the Input Ratio value of a selected cam profile.	None
"MLPrfReadOOffset" (→ p. 117)	Returns the Output Offset value of a selected cam profile.	None
"MLPrfReadOScale" (→ p. 118)	Returns the Output Ratio value of a selected cam profile.	None
"MLPrfWriteIOffset" (→ p. 119)	Sets the Input Offset value of a selected cam profile.	BOOL
"MLPrfWriteIScale" (→ p. 120)	Sets the Input Ratio value of a selected cam profile	BOOL
"MLPrfWriteOOffset" (→ p. 122)	Sets the Output Offset value of a selected cam profile.	BOOL

Name	Description	Return type
"MLPrfWriteOScale" (→ p. 123)	Sets the Output Ratio value of a selected cam profile.	BOOL
"MLProfileBuild" (→ p. 398)	Builds a cam profile from application data.	See "Output" (→ p. 401).
"MLProfileCreate" (→ p. 406)	Creates a new cam profile object.	None
"MLProfileInit" (→ p. 408)	Initializes a previously created cam profile object.	BOOL
"MLProfileRelease" (→ p. 410)	Removes a Profile so the Profile ID may be used by a different or new Profile.	See "Output" (→ p. 411).

3.1.5.1 MLCamInit

Pipe Network

 **Function** - Initializes a Cam Pipe Block for use in a PLC Program.

Function block is automatically called if a Cam Block is added to the Pipe Network, with user-defined settings then entered in the Pipe Blocks Properties screen.

The Cam Pipe Block is used to generate motion profiles of any shape. These profiles are created and initiated separately and the shape is modified with the Cam Editor. With the Editor profiles can be changed graphically or by manually changing values in a numeric table relating input and output values with specific slopes. The Cam Editor software tool provides the capability to visualize, analyze, edit, and smooth profiles.

With the PipeNetwork (PN) Cam block:

- the Cam block's profile is in reference to the input positions coming into the PN Cam block (Master Absolute)
- the PN Cam block output positions are in reference to PN Cam block's output position at the end of the last cam cycle (Slave Relative)

Profile switching can be done on the fly, without losing synchronization and without dead time. In addition, the offsets and ratios of Cam Profiles can be changed on the fly. See [Cam Profile Switching](#) for more information.

NOTE

CAM objects are normally created in the Pipe Network using the graphical engine. Then you do not have to add MLCamInit function blocks to their programs. Parameters are entered directly in pop-up windows, and the code is then automatically added to the current project.

3.1.5.1.1 Arguments

3.1.5.1.1.1 Input

BlockID	Description	ID number of a created Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	CAM

ProfileName	Description	Name of the current profile assigned to the cam. It must be a declared profile object
	Data type	STRING
	Range	—
	Unit	N/A
	Default	—
ModuloPosition	Description	Value of the period of the cam output values expressed in user units, for a cyclic system
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	360.0

3.1.5.1.1.2 Output

Default (.Q)	Description	Returns TRUE if the CAM Pipe Block is initialized
	Data type	BOOL
	Unit	N/A

3.1.5.1.1.3 Return Type

BOOL

3.1.5.1.2 Related Functions

"MLProfileCreate" (→ p. 406)


"MLProfileInit" (→ p. 408)

3.1.5.1.3 Example


3.1.5.1.3.1 Structured Text

```
//Initialize a Pipe Network block named "CAM" with a profile named
"Profile_A", set the cam modulo position to 360
CAM := MLBlkCreate( 'CAM', 'CAM' );
MLCamInit( CAM, 'Profile_A', 360.0 );
```

3.1.5.1.3.2 Ladder Diagram



3.1.5.1.3.3 Function Block Diagram



3.1.5.2 MLCamSwitch

Pipe Network

Function - Switches the CAM Profile in a selected CAM object.

Can be used in combination with a comparator to check that profiles are switched at a time where the input and output values of both the old and new profiles are equal, so an Axis receives continuous position values and does not jump.

These profiles are created and initiated separately and the shape is created with the CAM Editor. With the Editor profiles can be changed graphically or by manually changing values in a numeric table relating input and output values with specific slopes. The Cam Editor software tool provides the capability to visualize, analyze, edit, and smooth profiles.

See [Cam Profile Switching](#) for more information.

3.1.5.2.1 Arguments

3.1.5.2.1.1 Input

BlockID	Description	ID number of an initialized CAM Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
ProfileID	Description	Name of the new CAM profile which is assigned to the CAM Pipe Block. It must be a declared profile object.
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.5.2.1.2 Output

Default (.Q)	Description	Returns TRUE if the CAM Profile is changed
	Data type	BOOL
	Unit	N/A

3.1.5.2.1.3 Return Type

BOOL

3.1.5.2.2 Related Functions

"MLProfileCreate" (→ p. 406)

"MLProfileInit" (→ p. 408)

"MLPrfWriteIOffset" (→ p. 119)


"MLPrfWriteOScale" (→ p. 123)

3.1.5.2.3 Example


3.1.5.2.3.1 Structured Text

```
//Switch CAM Profile
MLCamSwitch(PipeNetwork.CAM, Profiles.Profile_B);
```

3.1.5.2.3.2 Ladder Diagram



3.1.5.2.3.3 Function Block Diagram



3.1.5.3 MLPrfReadIOffset

Pipe Network ✓

Function - Returns the Input Offset value of a selected CAM Profile.

Offsets can be changed on the fly to modify the CAM Profile while maintaining its shape. A change in input offset is equivalent to shifting the CAM Profile on the x or Input Axis.




Figure 1-19: MLPrfReadIOffset

3.1.5.3.1 Arguments

3.1.5.3.1.1 Input

ProfileID	Description	Name of an initialized CAM Profile
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.5.3.1.2 Output

OK	Description	Returns true when function successfully executes
	Data type	BOOL
Offset	Description	Returns the Input Offset of the selected CAM Profile
	Data type	LREAL
	Unit	N/A

3.1.5.3.2 Related Functions

"MLPrfWriteIOffset" (→ p. 119)

"MLProfileCreate" (→ p. 406)


"MLProfileInit" (→ p. 408)

3.1.5.3.3 Example

3.1.5.3.3.1 Structured Text

```
//Save value of input offset
CamOffset := MLPrfReadIOffset( Profiles.Profile_A );
```

3.1.5.3.3.2 Ladder Diagram



3.1.5.3.3.3 Function Block Diagram



3.1.5.4 MLPrfReadIScale



Function - Returns the Input Ratio value of a selected CAM Profile.

Ratios can be changed on the fly to modify the CAM Profile while maintaining its basic shape. A change in input ratio is equivalent to stretching the CAM Profile on the X (or Input) Axis. A negative value is not allowed.




Figure 1-20: MLPrfReadIScale

3.1.5.4.1 Arguments

3.1.5.4.1.1 Input

ProfileID	Description	ID number of an initialized CAM Profile
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.5.4.1.2 Output

Ratio	Description	Returns the Input Ratio of the selected CAM Profile
	Data type	LREAL
	Unit	N/A

3.1.5.4.2 Related Functions

["MLPrfWriteIScale" \(→ p. 120\)](#)

["MLProfileCreate" \(→ p. 406\)](#)

["MLProfileInit" \(→ p. 408\)](#)

3.1.5.4.3 Previous Function Name


MLPrfGetIRatio

3.1.5.4.4 Example

3.1.5.4.4.1 Structured Text

```
//Save value of input ratio
CamRatio := MLPrfReadIScale( Profiles.Profile_A );
```

3.1.5.4.4.2 Ladder Diagram



3.1.5.4.4.3 Function Block Diagram



3.1.5.5 MLPrfReadOOffset

Pipe Network ✓



Function - Returns the Output Offset value of a selected CAM Profile.

Offsets can be changed on the fly to modify the CAM Profile while maintaining its shape. A change in output offset is equivalent to shifting the CAM Profile on the Y (or Output) Axis.




Figure 1-21: MLPrfReadOOffset

3.1.5.5.1 Arguments

3.1.5.5.1.1 Input

ProfileID	Description	ID number of an initialized CAM Profile
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.5.5.1.2 Output

Offset	Description	Returns the Output Offset of the selected CAM Profile
	Data type	LREAL
	Unit	N/A

3.1.5.5.2 Related Functions

"MLPrfWriteOOffset" (→ p. 122)

"MLProfileCreate" (→ p. 406)


"MLProfileInit" (→ p. 408)

3.1.5.5.3 Example

3.1.5.5.3.1 Structured Text

```
//Save value of output offset
CamOffset := MLPrfReadOOffset ( Profiles.Profile_A );
```

3.1.5.5.3.2 Ladder Diagram



3.1.5.5.3.3 Function Block Diagram



3.1.5.6 MLPrfReadOScale



Function - Returns the Output Ratio value of a selected CAM Profile.

Ratios can be changed on the fly to modify the CAM Profile while maintaining its basic shape. A change in output ratio is equivalent to stretching, and flipping if negative, the CAM Profile on the Y (or Output) Axis.




Figure 1-22: MLPrfReadOScale

3.1.5.6.1 Arguments

3.1.5.6.1.1 Input

ProfileID	Description	ID number of an initialized CAM Profile
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.5.6.1.2 Output

Ratio	Description	Returns the Output Ratio of the selected CAM Profile
	Data type	LREAL
	Unit	N/A

3.1.5.6.2 Related Functions

"MLPrfWriteOScale" (→ p. 123)

"MLProfileCreate" (→ p. 406)

"MLProfileInit" (→ p. 408)

3.1.5.6.3 Previous Function Name


MLPrfGetORatio

3.1.5.6.4 Example

3.1.5.6.4.1 Structured Text

```
//Save value of output ratio
CamRatio := MLPrfReadOScale( Profiles.Profile_A );
```

3.1.5.6.4.2 Ladder Diagram



3.1.5.6.4.3 Function Block Diagram



3.1.5.7 MLPrfWriteIOffset

Pipe Network ✓

Function - Set the Input Offset value of a selected CAM Profile.

Offsets are changed on the fly to modify the CAM Profile while maintaining its shape. A change in input offset is equivalent to shifting the CAM Profile on the X (or Input) Axis.




Figure 1-23: MLPrfWriteIOffset

3.1.5.7.1 Arguments

3.1.5.7.1.1 Input

ProfileID	Description	ID number of an initialized CAM Profile
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Offset	Description	Desired new value of Input Offset
	Data type	LREAL
	Range	—
	Unit	N/A
	Default	—

3.1.5.7.1.2 Output

Default (.Q)	Description	Returns TRUE if the Input Offset is changed to the new value
	Data type	BOOL
	Unit	N/A

3.1.5.7.1.3 Return Type

BOOL

3.1.5.7.2 Related Functions

"MLPrfReadIOffset" (→ p. 114)

"MLProfileCreate" (→ p. 406)


"MLProfileInit" (→ p. 408)

3.1.5.7.3 Example


3.1.5.7.3.1 Structured Text

```
//Change the value of input offset
MLPrfWriteIOffset( Profiles.Profile_A , 45 );
```

3.1.5.7.3.2 Ladder Diagram




3.1.5.7.3.3 Function Block Diagram



3.1.5.8 MLPrfWriteIScale

Pipe Network

 **Function** - Set the Input Ratio value of a selected CAM Profile.

Ratios are changed on the fly to modify the CAM Profile while maintaining its basic shape. A change in input ratio is equivalent to stretching the CAM Profile on the X (or Input) Axis.




Figure 1-24: MLPrfWriteIScale

3.1.5.8.1 Arguments

3.1.5.8.1.1 Input

ProfileID	Description	ID number of initialized CAM Profile
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Ratio	Description	Desired new value for Input Ratio
	Data type	LREAL
	Range	Positive
	Unit	N/A
	Default	—

3.1.5.8.1.2 Output

Default (.Q)	Description	Returns TRUE if the Input Ratio is changed
	Data type	BOOL
	Unit	N/A

3.1.5.8.1.3 Return Type

BOOL

3.1.5.8.2 Related Functions

["MLPrfReadIScale" \(→ p. 115\)](#)

["MLProfileCreate" \(→ p. 406\)](#)

["MLProfileInit" \(→ p. 408\)](#)

3.1.5.8.3 Previous Function Name


MLPrfSetIRatio

3.1.5.8.4 Example


3.1.5.8.4.1 Structured Text

```
//Change value of input ratio
MLPrfWriteIScale( Profiles.Profile_A, 360 );
```

3.1.5.8.4.2 Ladder Diagram



3.1.5.8.4.3 Function Block Diagram



3.1.5.9 MLPrfWriteOOffset



Function - Changes the Output Offset value of a selected CAM Profile.

Offsets are changed on the fly to modify the CAM Profile while maintaining its shape. A change in output offset is equivalent to shifting the CAM Profile on the Y (or Output) Axis.




Figure 1-25: MLPrfWriteOOffset

3.1.5.9.1 Arguments

3.1.5.9.1.1 Input

Argument	Description	Default
ProfileID	ID number of an initialized CAM Profile	—
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

Offset	Description	Desired new value of Output Offset
	Data type	LREAL
	Range	—
	Unit	N/A
	Default	—

3.1.5.9.1.2 Output

Default (.Q)	Description	Returns TRUE if the Output Offset value is changed
	Data type	BOOL
	Unit	N/A

3.1.5.9.1.3 Return Type

BOOL

3.1.5.9.2 Related Functions

"MLPrfReadOOffset" (→ p. 117)

"MLProfileCreate" (→ p. 406)


"MLProfileInit" (→ p. 408)

3.1.5.9.3 Example


3.1.5.9.3.1 Structured Text

```
//Change value of output offset
MLPrfWriteOOffset( Profiles.Profile_A , 45 );
```

3.1.5.9.3.2 Ladder Diagram



3.1.5.9.3.3 Function Block Diagram



3.1.5.10 MLPrfWriteOScale



Function - Set the Output Ratio value of a selected CAM Profile.

Ratios are changed on the fly to modify the CAM Profile while maintaining its basic shape. A change in output ratio is equivalent to stretching, and flipping if negative (as shown on figure below), the CAM Profile on the Y (or Output) Axis.




Figure 1-26: MLPrfWriteOScale

3.1.5.10.1 Arguments

3.1.5.10.1.1 Input

ProfileID	Description	ID number of an initialized CAM Profile
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Ratio	Description	Desired new value of Output Ratio
	Data type	LREAL
	Range	—
	Unit	N/A
	Default	—

3.1.5.10.1.2 Output

Default (.Q)	Description	Returns TRUE if the Output Ratio is changed
	Data type	BOOL
	Unit	N/A

3.1.5.10.1.3 Return Type

BOOL

3.1.5.10.2 Related Functions

["MLPrfReadOScale" \(→ p. 118\)](#)

["MLProfileCreate" \(→ p. 406\)](#)

["MLProfileInit" \(→ p. 408\)](#)

3.1.5.10.3 Previous Function Name


MLPrfSetORatio

3.1.5.10.4 Example


3.1.5.10.4.1 Structured Text

```
//Change value of output ratio
MLPrfWriteOScale( Profiles.Profile_A , -180 );
```

3.1.5.10.4.2 Ladder Diagram



3.1.5.10.4.3 Function Block Diagram



3.1.6 Motion Library - Comparator

TIP



- See "Usage Example of Comparator Functions" (→ p. 125) for a Comparator function example.

Name	Description	Return Type
"MLCompCheck" (→ p. 128)	Checks if the reference of a comparator Pipe Block has been crossed. Returns TRUE if the reference has been crossed.	BOOL
"MLComplnit" (→ p. 129)	Initializes a comparator Pipe Block with user-defined settings.	BOOL
"MLCompReadRef" (→ p. 131)	Returns the reference position of a comparator block.	None
"MLCompReset" (→ p. 132)	Clears the Transition Flag of a comparator Pipe Block.	BOOL
"MLCompWriteRef" (→ p. 133)	Sets the reference position of a comparator block.	BOOL


3.1.6.1 Usage Example of Comparator Functions


When you call the "MLCompWriteRef" (→ p. 133) function, the output for "MLCompCheck" (→ p. 128)

becomes TRUE as soon as the input value reaches the reference.




The same function can also be called for a cyclic input value.





When the THROUGH_ZERO parameter is set to YES, the output for "MLCompCheck" (→ p. 128) becomes TRUE as soon as the input value reaches the reference, but not before it has passed through zero.






Figure 1-27: Comparator Functions Usage

3.1.6.2 MLCompCheck



Function - Check if the reference of a comparator Pipe Block has been crossed.

3.1.6.2.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Comparator object.

3.1.6.2.2 Outputs


Output	Data Type	Range	Unit	Description
Default (.Q)	BOOL	N/A	N/A	Returns TRUE if reference position of the Comparator object has been crossed.

3.1.6.2.3 Remarks


NOTE

This function or function block returns cached data. See [Programming a Dual Core Controller](#) for more information.


- Returns the Transition Flag of a comparator object, which turns TRUE if the input position to the comparator is greater or equal to the reference.
 - The Comparator Transition Flag stays TRUE until it is reset.



3.1.6.2.4 FBD Language



3.1.6.2.5 FFLD Language



3.1.6.2.6 IL Language

Not available.

3.1.6.2.7 ST Language

```
//Check if Comparator Reference has been reached
bCrossed := MLCompCheck( PipeNetwork.MyComp );
```

See Also

- "MLCompReadRef" (→ p. 131)
- "MLCompReset" (→ p. 132)
- "MLCompWriteRef" (→ p. 133)

3.1.6.3 MLCompInit



Function - Initializes a comparator Pipe Block for use in a PLC Program.

3.1.6.3.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of a created Comparator Pipe Block.

Input	Data Type	Range	Unit	Default	Description
ModuloPosition	LREAL	No range	User units	No default	Value of the period of a cyclic system.
ThroughZero	BOOL	0, 1	N/A	No default	<ul style="list-style-type: none"> When TRUE, the system must cross zero and then the reference position before the Transition Flag is set. When FALSE, the Transition Flag is set immediately if the input pipe position is greater then or equal to the Reference value.
Reference	LREAL	No range	User units	No default	Set the reference position in the new Comparator object.

3.1.6.3.2 Outputs

Output	Data Type	Range	Unit	Description
Default (.Q)	BOOL	No range	N/A	Returns TRUE when function starts to execute.


3.1.6.3.3 Remarks

- Function block is automatically called if a Comparator Block is added to the Pipe Network, with user-defined settings entered in the Pipe Blocks Properties screen.
- The Transition Flag of a comparator object turns TRUE if the input position to the comparator is greater or equal to the reference.
- The Comparator Transition Flag stays TRUE until it is reset.
- If the input **ThroughZero** is set to TRUE, the system must cross zero and then the reference position before the Transition Flag is set.
- If **ThroughZero** is FALSE, the Transition Flag is set immediately if the input pipe position is greater or equal to the Reference value.


NOTE

Comparator objects are normally created in the Pipe Network using the graphical engine. Then you do not have to add MLCompInit function blocks to their programs. Parameters are entered directly in pop-up windows, and the code is then automatically added to the current project.

3.1.6.3.4 FBD Language



3.1.6.3.5 FFLD Language



3.1.6.3.6 IL Language

Not available.

3.1.6.3.7 ST Language

```

//Initiate a created Comparator Block named "MyComp" to:
// Modulo of 360
// Require the input position to first cross 0 before the
//   MLCompCheck output is triggered
// Input compared position to 45

MyComp := MLBlkCreate( 'MyComp', 'COMPARATOR' );
MLCompInit( MyComp, 360.0, TRUE, 45.0 );
    
```

See Also

- "MLBlkCreate" (→ p. 33)
- "MLCompCheck" (→ p. 128)
- "MLCompReset" (→ p. 132)
- "MLCompWriteRef" (→ p. 133)

3.1.6.4 MLCompReadRef



Function - Returns the reference position of a comparator block.

3.1.6.4.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Comparator object.

3.1.6.4.2 Outputs

Output	Data Type	Range	Unit	Description
Reference	LREAL	No range	User units	Returns the current reference position of the Comparator object.


3.1.6.4.3 Remarks

- The Transition Flag of a comparator object turns TRUE if the input position to the comparator is greater or equal to the reference.
- The Comparator Transition Flag stays TRUE until it is reset.

3.1.6.4.4 FBD Language



3.1.6.4.5 FFLD Language



3.1.6.4.6 IL Language

Not available.

3.1.6.4.7 ST Language

```
//Return the Comparator Reference value
CompRef := MLCompReadRef( PipeNetwork.MyComp );
```

See Also

- "MLCompCheck" (→ p. 128)
- "MLCompReset" (→ p. 132)
- "MLCompWriteRef" (→ p. 133)

3.1.6.5 MLCompReset



Function - Clear the Transition Flag of a comparator Pipe Block.

3.1.6.5.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Comparator object.

3.1.6.5.2 Outputs

Output	Data Type	Range	Unit	Description
Default (.Q)	BOOL	No range	N/A	Returns TRUE when function starts to execute.


3.1.6.5.3 Remarks

- The Transition Flag of a comparator object turns TRUE if the input position to the comparator is greater or equal to the reference.
- The Comparator Transition Flag stays TRUE until it is reset.

3.1.6.5.4 FBD Language



3.1.6.5.5 FFLD Language



3.1.6.5.6 IL Language

Not available.

3.1.6.5.7 ST Language

```
//Clear the Transition Flag of a Comparator object
MLCompReset ( PipeNetwork.MyComp );
```

See Also

- "MLCompCheck" (→ p. 128)
- "MLCompReadRef" (→ p. 131)
- "MLCompWriteRef" (→ p. 133)

3.1.6.6 MLCompWriteRef



Function - Set the reference position of a comparator block.

3.1.6.6.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Comparator object.
ThroughZero	BOOL	0, 1	N/A	No default	<ul style="list-style-type: none"> • When TRUE, the system must cross zero and then the reference position before the Transition Flag is set. • When FALSE, the Transition Flag is set immediately if the input pipe position is greater then or equal to the Reference value.
Reference	LREAL	No range	User units	No default	New reference position to set in the selected Comparator object.


3.1.6.6.2 Outputs

Output	Data Type	Range	Unit	Description
Default (.Q)	BOOL	No range	N/A	Returns TRUE when function starts to execute.


3.1.6.6.3 Remarks

- The Transition Flag of a comparator object turns TRUE if the input position to the comparator is greater or equal to the reference.
- The Comparator Transition Flag stays TRUE until it is reset.


- If the input ThroughZero is set to TRUE, system must cross zero and then the reference position before the Transition Flag is set.
- If ThroughZero is FALSE, Transition Flag is set immediately if the input pipe position is greater than or equal to the Reference value.



3.1.6.6.4 FBD Language



3.1.6.6.5 FFLD Language



3.1.6.6.6 IL Language

Not available.

3.1.6.6.7 ST Language

```
//Set the Comparator Reference value
MLCompWriteRef( PipeNetwork.MyComp , TRUE , 45 );
```

See Also

- "MLCompCheck" (→ p. 128)
- "MLCompReadRef" (→ p. 131)
- "MLCompReset" (→ p. 132)

3.1.7 Motion Library - Convertor

Name	Description	Return Type
"MLCNVConECAT" (→ p. 135)	Connect the output of a pipe convertor block to an EtherCAT Output (Rx) PDO object.	
"MLCNVConnect" (→ p. 137)	Connects a converter Pipe Block to the specified axis.	BOOL
"MLCNVConnectEx" (→ p. 138)	Connects an extra converter Pipe Block to the specified axis. This function connects the output of a pipe to an axis data other than the control position.	BOOL
"MLCNVDisconnect" (→ p. 141)	Disconnects a converter Pipe Block from its associated axis.	BOOL
"MLCNVInit" (→ p. 142)	Initializes a converter Pipe Block in Position or Speed mode.	BOOL

3.1.7.1 MLCNVConECAT



Function - connects the output of a pipe convertor block to an EtherCAT Output (Rx) PDO object.

The output value of the convertor block will then be written to the PDO object every update of the convertor block. The pipe block is specified by the BlockID input and the PDO object is specified by the DeviceAddr, Index, and SubIndex inputs.

3.1.7.1.1 Arguments

3.1.7.1.1.1 Input

BlockID	Description	The convertor block whose output value will be written to the PDO object. For example: PipeNetwork:CNV1
	Data type	DINT
	Range	N/A
	Unit	N/A
	Default	—
DeviceAddr	Description	The device address of the PDO object to be written. EtherCAT devices are numbered in order with the first device being 1001, the second 1002, etc.
	Data type	INT
	Range	N/A
	Unit	N/A
	Default	—
Index	Description	The index of the PDO object to be written. The index can be determined from the table located in the "PDO Selection/Mapping" tab of the EtherCAT device page. (In Project Explorer, under EtherCAT, select the device, then select the PDO Selection/Mapping tab.)

	Data type	UINT
	Range	N/A
	Unit	N/A
	Default	—
SubIndex	Description	The sub index of the PDO object to be written. The sub index can be determined from the table located in the “PDO Selection/Mapping” tab of the EtherCAT device page. (In Project Explorer, under EtherCAT, select the device, then select the PDO Selection/Mapping tab.)
	Data type	USINT
	Range	N/A
	Unit	N/A
	Default	—

3.1.7.1.1.2 Output

Default (.Q)	Description	Returns TRUE if this function has successfully connected the output of the pipe convertor block to the EtherCAT Output (Rx) PDO Object.
	Data type	BOOL
	Unit	N/A

3.1.7.1.2 Related Functions

"MLCNVDisconnect" (→ p. 141)


"MLCNVInit" (→ p. 142)

3.1.7.1.3 Example


3.1.7.1.3.1 Structured Text

```
//Connect a converter Pipe Block named "CNV2" to PDO 16#60B2 (Accel FF)
on ECAT address 1002.
MLCNVConECAT( PipeNetwork.CNV2, 1002, 16#60B2, 0 );
```

3.1.7.1.3.2 Ladder Diagram



3.1.7.1.3.3 Function Block Diagram



3.1.7.2 MLCNVConnect

Function - Connect a converter Pipe Block to the specified axis.

When using the Pipe Network for coordinated motion, Pipe Blocks have to be Activated, Connected, and then Powered On before move commands work.

The Converter block changes the incoming flow of values to continuous position output with no periodicity. If a converter block is not connected to an Axis, it does not send position output values to its assigned Axis. Every pipe branch must end in a converter, whether or not it is connected to a destination Axis object, as seen in Figure 1 below.




Figure 1-28: MLCNVConnect

NOTE
 All converters in the Pipe Network can be connected at once with the command PipeNetwork (MLPN_Connect). This calls automatically generated code with MLCNVConnect commands for each Converter block. Therefore, in a multi-axis program only one command can be used to connect Pipe Blocks instead of writing code for each Axis separately.

TIP
 The converter block has the ability to control the analog output on the AKD. See for information on the parameters.

3.1.7.2.1 Arguments

3.1.7.2.1.1 Input

BlockID	Description	ID number of an initiated Converter object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
AxisID	Description	ID number of an initiated Axis object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A

Default	—
----------------	---

3.1.7.2.1.2 Output

Default (.Q)	Description	Returns TRUE if the converter is connected to the Axis object
	Data type	BOOL
	Unit	N/A

3.1.7.2.1.3 Return Type

BOOL

3.1.7.2.2 Related Functions

"MLCNVConnectEx" (→ p. 138)

"MLCNVDisconnect" (→ p. 141)


"MLCNVInit" (→ p. 142)

3.1.7.2.3 Example


3.1.7.2.3.1 Structured Text

```
//Connect a converter Pipe Block named "CNV1" to Pipe Block AXIS1
MLCNVConnect( PipeNetwork.CNV1, AXIS1 );
```

3.1.7.2.3.2 Ladder Diagram



3.1.7.2.3.3 Function Block Diagram



3.1.7.3 MLCNVConnectEx

Function - connects the output of a pipe to an axis data other than the control position.

Connect a converter Pipe Block to the specified axis.

With this function, several converter Pipe Blocks can connect to the same axis and acts on different data.

Normally a Converter block sends position values to an Axis. However, some cases exist that require additional information such as torque feed-forward (IDN 3056) that needs to be provided by a second converter.

NOTE

This FB does not work when you choose to [simulate](#) the device. In such a case, the FB continuously generates error messages displayed in the Controller log window.

NOTE

Need to add 16#8000 to desired IDN number for ValueID input. 8000 in hexadecimal signals a vendor-specific IDN value.

3.1.7.3.1 Arguments**3.1.7.3.1.1 Input**

BlockID	Description	ID number of an initiated Converter object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
AxisID	Description	ID number of an initiated Axis object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
ValueID	Description	Specify the following constant: <ul style="list-style-type: none"> • EC_ADDITIVE_TORQUE_VALUE (for torque feed-forward) • EC_ANALOG_OUTPUT (for control of Analog Output: AKD parameter: "AOUT.VALUEU") <p>If the Analog Output is mapped to a PLC variable, the connection to the analog output by EC_ANALOG_OUTPUT will not work as the output value will be overwritten by the PLC mapped variable data. In order to function properly the AOUT.MODE must be set to "User Mode (mode = 0)". See the TIP below for more information.</p>
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
ValueInfo	Description	This value is ignored and must be set to zero
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A

Default —

TIP

The PDO values will be overwritten by Mapped PLC variables including a possible link to the mapping of variables or the section on MLCParamWrite() warning indicating that the function block write of Analog output will be overwritten by the MLCnvConnectEx function.

Precedence rules:

1. A PLC variable mapped to Analog Output takes precedence.
2. If MLCNVConnect assigns a Pipe output to Analog Output it will take precedence over a DriveParamWrite function call.
3. DriveParamWrite will modify the Analog Output but get overwritten by the higher precedent options if they are present.

3.1.7.3.1.2 Output

Default (.Q)	Description	Returns TRUE if the converter is connected to the Axis object
	Data type	BOOL
	Unit	N/A

3.1.7.3.1.3 Return Type

BOOL

3.1.7.3.2 Related Functions

"MLCNVConnect" (→ p. 137)

"MLCNVDisconnect" (→ p. 141)


"MLCNVInit" (→ p. 142)

3.1.7.3.3 Example


3.1.7.3.3.1 Structured Text

```
//Connect a converter Pipe Block named "CNV1" to the pipe block named
//AXIS1, And send feed-forward (EC_ADDITIVE_TORQUE_VALUE) to the drive
MLCNVConnectEx( PipeNetwork.CNV1, PipeNetwork.AXIS1, EC_ADDITIVE_TORQUE_
VALUE, 0 );
```

3.1.7.3.3.2 Ladder Diagram



3.1.7.3.3.3 Function Block Diagram



3.1.7.4 MLCNVDisconnect

Function - Disconnect a converter Pipe Block from its associated axis.

If a converter block is not connected to an Axis, it does not send position output values to its assigned Axis. Can disconnect one or multiple Axis from the Pipe Network and still send single-axis motion commands. Axis can be disconnected while the Pipe Positions are reset to different values or if coordinated motion is only not needed with every axis in the project in a certain state.

3.1.7.4.1 Arguments

3.1.7.4.1.1 Input

BlockID	Description	ID number of an initiated Converter object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.7.4.1.2 Output

Default (.Q)	Description	Returns TRUE if the converter is disconnected from the Axis object
	Data type	BOOL
	Unit	N/A

3.1.7.4.1.3 Return Type

BOOL

3.1.7.4.2 Related Functions

"MLCNVConnect" (→ p. 137)


"MLCNVInit" (→ p. 142)

3.1.7.4.3 Example


3.1.7.4.3.1 Structured Text

```
//Disconnect a converter Pipe Block name " CNV1" from its present
connection
MLCNVDisconnect( PipeNetwork.CNV1);
```

3.1.7.4.3.2 Ladder Diagram



3.1.7.4.3.3 Function Block Diagram



3.1.7.5 MLCNVInit

Function - Initializes a converter Pipe Block.

Function block is automatically called if a Converter Block is added to the Pipe Network, with the input mode (position or speed) entered in the Pipe Blocks Properties screen. The Converter block changes the incoming flow of speed or position values to continuous position output with no periodicity.

NOTE

Converter objects are normally created in the Pipe Network using the graphical engine. Then you do not have to add MLCNVInit function blocks to their programs. Parameters are entered directly in pop-up windows, and the code is then automatically added to the current project.

3.1.7.5.1 Arguments

3.1.7.5.1.1 Input

BlockID	Description	ID number of a created Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Mode	Description	1 for Position mode, 2 for Speed mode. Determines the type of input to the Converter Object.
	Data type	DINT
	Range	[1, 2]
	Unit	N/A
	Default	—

3.1.7.5.1.2 Output

Default (.Q)	Description	Returns TRUE if the Converter Pipe Block is initialized
	Data type	BOOL
	Unit	N/A

3.1.7.5.1.3 Return Type

BOOL

3.1.7.5.2 Related Functions

"MLBlkCreate" (→ p. 33)


"MLCNVConnect" (→ p. 137)

3.1.7.5.3 Example


3.1.7.5.3.1 Structured Text

```
// Initiate a created convertor block named "CNV1"
CNV1 := MLBlkCreate( 'CNV1', 'CONVERTOR' );
MLCNVInit( CNV1, 1 );
```

3.1.7.5.3.2 Function Block Diagram



3.1.7.5.3.3 Ladder Diagram



3.1.8 Motion Library - Delay

Name	Description	Return Type
"MLDelayInit" (→ p. 143)	Initializes a delay object.	BOOL

3.1.8.1 MLDelayInit

Pipe Network ✓

Function - Initializes a delay object.

3.1.8.1.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of a created Pipe Block.
CycleDelay	DINT	0, 9	Cycle	0 (zero)	Number of delay cycles.

3.1.8.1.2 Remarks


is this a function or function block?

- This FB is automatically created in the compiled code of a Pipe Network.
 - It is included in the MLPN_CREATE_OBJECT (created in ST) which is typically executed in a project as part of the startup sequence of the Pipe Network.
- Returns TRUE if the function succeeded.

3.1.8.1.3 FBD Language



3.1.8.1.4 FFLD Language



3.1.8.1.5 IL Language

Not available. - IS THIS TRUE?

3.1.8.1.6 ST Language

```
MLDelayInit (PipeNetwork.DELAY1, 2 );
```

3.1.9 Motion Library - Derivator

See Also

- "MLDerInit" (→ p. 144)
- "MLDerReadInModPos" (→ p. 146)
- "MLDerWriteInModPos" (→ p. 147)

3.1.9.1 MLDerInit



Function - Initializes an derivator object.

3.1.9.1.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of a created Pipe Block.
ModuloPosition	LREAL	No range	User units	360.0	Input ModuloPosition of Derivator object.

3.1.9.1.2 Outputs

Output	Data Type	Range	Unit	Default	Description
Default (.Q)	BOOL	No range	N/A	No default	Returns TRUE if the Derivator object is initialized.

3.1.9.1.3 Remarks

is this a function or function block?

Function block is automatically called if a Derivator Block is added to the Pipe Network, with user-defined settings entered in the Pipe Blocks Properties screen. Input ModuloPosition is defined to manage the periodicity (modulo) of the input values.

NOTE

Derivator objects are normally created in the PipeNetwork using the graphical engine. You do not have to add MLDerInit function blocks to their programs. Parameters are entered directly in pop-up windows and the code is automatically added to the current project.






Figure 1-29: MLDerInit

3.1.9.1.4 FBD Language



3.1.9.1.5 FFLD Language



3.1.9.1.6 IL Language

Not available. - IS THIS TRUE?

3.1.9.1.7 ST Language

```
//Create and Initiate a Derivator object
MyDerivator := MlBlkCreate( 'MyDerivator', 'DERIVATOR' );
MLDerInit( MyDerivator, 360.0 );
```

See Also

- "MlBlkCreate" (→ p. 33)
- "MLDerReadInModPos" (→ p. 146)
- "MLDerReadInModPos" (→ p. 146)

3.1.9.2 MLDerReadInModPos



Function - Returns the Input ModuloPosition of the derivator block.

3.1.9.2.1 Inputs

Input	Data Type	Range	Unit	Default	Description
ID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Derivator object.

3.1.9.2.2 Outputs

Output	Data Type	Range	Unit	Default	Description
ModuloPosition	LREAL	No range	User units	No default	Current Input ModuloPosition of the selected Derivator object.

3.1.9.2.3 Remarks

Input ModuloPosition is defined to manage the periodicity (modulo) of the input values.

Example

If the input value increases each millisecond by one degree then the output value is 1000 degrees per second.

Suddenly, the input value skips from 359 to 0 (zero).

- Input ModuloPosition = 360, the output continues to indicate 1000 degrees per second.
 - This indicates that rollover into the next period has been properly handled
- Input ModuloPosition = 1000, the output then indicates 359,000 degrees per second.
 - This indicates that the input has incorrectly interpreted roll-over as a 359 degree move in one millisecond.





Figure 1-30: MLDerReadInModPos


NOTE

The first calculation of a Derivator Pipe Block just after the pipe installation indicates 0 (zero) regardless of the initial input value.

3.1.9.2.4 FBD Language



3.1.9.2.5 FFLD Language



3.1.9.2.6 IL Language

Not available. - IS THIS TRUE?

3.1.9.2.7 ST Language

```
//save the current input MODULO_POSITION of a Derivator object
DerInputPeriod := MLDerReadInModPos ( PipeNetwork.MyDerivator );
```

See Also

- "MLDerInit" (→ p. 144)
- "MLDerWriteInModPos" (→ p. 147)

3.1.9.3 MLDerWriteInModPos



Function - Sets the Input ModuloPosition of the Derivator block.

3.1.9.3.1 Inputs

Input	Data Type	Range	Unit	Default	Description
ID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Derivator object.
ModuloPosition	LREAL	No range	User units	No default	Designated new value of Input ModuloPosition of the selected Derivator object.

3.1.9.3.2 Outputs

Output	Data Type	Range	Unit	Default	Description
Default (.Q)	BOOL	No range	N/A	No default	Returns TRUE if the Input ModuloPosition value is changed.

3.1.9.3.3 Remarks

Input ModuloPosition is defined to manage the periodicity (modulo) of the input values.

Example

If the input value increases each millisecond by one degree then the output value is 1000 degrees per second.

Suddenly, the input value skips from 359 to 0 (zero).

- Input ModuloPosition = 360, the output continues to indicate 1000 degrees per second.
 - This indicates that rollover into the next period has been properly handled
- Input ModuloPosition = 1000, the output then indicates 359,000 degrees per second.
 - This indicates that the input has incorrectly interpreted roll-over as a 359 degree move in one millisecond.





Figure 1-31: MLDerWriteInModPos


NOTE

The first calculation of a Derivator Pipe Block just after the pipe installation indicates 0 (zero) regardless of the initial input value.

3.1.9.3.4 FBD Language



3.1.9.3.5 FFLD Language



3.1.9.3.6 IL Language

Not available. - IS THIS TRUE?

3.1.9.3.7 ST Language

```
//change the input MODULO_POSITION of a Derivator object to 720
MLDerWriteInModPos ( PipeNetwork.MyDerivator, 720 );
```

See Also


- "MLDerInit" (→ p. 144)
- "MLDerReadInModPos" (→ p. 146)

3.1.10 Motion Library - Gear


Name	Description	Return type
"MLGearInit" (→ p. 151)	Initializes a Gear Pipe Block with user-defined settings	BOOL
"MLGearReadOffset" (→ p. 155)	Returns the offset value of selected Gear Block	None
"MLGearReadOffSlp" (→ p. 155)	Returns the Offset Slope value of selected Gear Block	None
"MLGearReadRatio" (→ p. 156)	Returns the ratio value of a gear block	None
"MLGearReadRatSlp" (→ p. 157)	Returns the ratio slope value of a gear block	None
"MLGearWriteOff" (→ p. 158)	Sets the Offset value of a selected Gear Pipe Block	BOOL
"MLGearWriteOSlp" (→ p. 160)	Sets the Offset Slope value of a selected Gear Pipe Block	BOOL
"MLGearWriteRatio" (→ p. 161)	Sets the Ratio value of a selected Gear Pipe Block	BOOL
"MLGearWriteRatSlp" (→ p. 162)	Sets the Ratio Slope value of a selected Gear Pipe Block	BOOL

3.1.10.1 Usage example of Gear Functions


The output value starts with offset = 0 and gain = 1 (blue line)




You can call the **MLGearWriteOff** function to modify the Offset (where Offset_Slope is set with the **MLGearWriteOSlp** function).



After setting the Offset (Q=TRUE in the previous figure), you can call the **MLGearWriteRatio** function to modify the gear Ratio (where Gain_Slope is set with the **MLGearWriteRatSlp** function).



The output value is finally adapted with the gear offset and ratio (blue line).



Gear Functions Usage

3.1.10.2 MLGearInit



is this a function or function block?

Function - Initializes a Gear Pipe Block for use in a PLC Program. This function block is automatically called if a Gear Block is added to the Pipe Network, with user-defined settings entered in the Pipe Blocks Properties screen.

The Pipe Block is assigned a **Name**, **Ratio**, **Offset**, and **Slopes** for changes in Ratio and Offset values. You can also choose between Modulo or Not modulo mode. Slopes set the limit at which step changes in Ratio and Offset are implemented.

The output of a Gear Block = Input value * Ratio + Offset

⚠ IMPORTANT

Be sure to set $\text{RatioSlope} < (\text{Ratio} * \text{EtherCAT Update Rate})$. The Gear block will make a jump (without a ramp) from one gear to the next when the RatioSlope is greater than the Ratio change factor multiplied by the update rate scale factor.

NOTE

If the Gear block's input is a modulo value, and the position delta is greater than $\frac{1}{2}$ the modulo value within one sample period in the opposite direction, then the Gear block cannot detect the change in the direction of motion. As an example, suppose the sample period is 1 msec and the Master is configured for a 360 degree modulo and the Master position is changed by >180 degrees within 1 msec. In this case the Gear block cannot determine whether the direction is in the same or opposite direction.

To avoid modulo calculation problems, either deactivate and reactivate the PipeNetwork when forcing the Master position with "MLMstForcePos" (→ p. 174), or use a "MLMstAbs" (→ p. 169) or "MLMstRel" (→ p. 183) move to force the Master's position value. For example, to force the Master position to zero you could do the following:

```
PipeNetwork(MLPN_DEACTIVATE);
MLMstForcePos(PipeNetwork.MASTER, 0);
PipeNetwork(MLPN_ACTIVATE);
```

👉 TIP

Gear objects are normally created in the Pipe Network using the graphical engine. Then you do not have to add MLGearInit function blocks to their programs. Parameters are entered directly in pop-up windows, and the code is then automatically added to the current project.

3.1.10.2.1 Arguments**3.1.10.2.1.1 Input**

BlockID	Description	ID number of a created Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	GEAR
Ratio	Description	Ratio of new Gear Pipe Block. Values lower than 1.0 can be entered, but require a leading zero (for example 0.8 instead of .8)
	Data type	LREAL
	Range	—
	Unit	N/A
	Default	1.0
Offset	Description	Offset of new Gear Pipe Block. Values lower than 1.0 can be entered, but require a leading zero (for example 0.8 instead of .8)
	Data type	LREAL

	Range	—
	Unit	N/A
	Default	0.0
UseUserRatioSlope	Description	FALSE to use the maximum Slope, causing an instantaneous gear change within one cycle. TRUE to use user-defined RatioSlope
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	FALSE
RatioSlope	Description	User-defined limit at which step changes in Ratio are implemented. Values lower than 1.0 can be entered, but require a leading zero (for example 0.8 instead of .8)
	Data type	LREAL
	Range	—
	Unit	1/sec
	Default	0.0
UseUserOffsetSlope	Description	FALSE to use the maximum Slope, causing an instantaneous gear change within one cycle. TRUE to use user-defined OffsetSlope
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	FALSE
OffsetSlope	Description	User-defined limit at which step changes in Offset are implemented. Values lower than 1.0 can be entered, but require a leading zero (for example 0.8 instead of .8)
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	0.0
Modulo	Description	TRUE when mode is modulo. Modulo mode adapts the output values according to the ModuloPosition (modulo)
	Data type	BOOL
	Range	0, 1
	Unit	N/A

Default	FALSE
----------------	-------

3.1.10.2.1.2 Output

Default (.Q)	Description	Returns TRUE if the Gear Pipe Block is initialized
	Data type	BOOL
	Unit	N/A

3.1.10.2.1.3 Return Type

BOOL

3.1.10.2.2 Related Functions

"MLBlkCreate" (→ p. 33)

"MLGearWriteRatio" (→ p. 161)


3.1.10.2.3 Example

3.1.10.2.3.1 Structured Text


```

//Initialize a Gear Pipe Block named GEAR1 with:
// Ratio = 1,Offset = 0, User Ratio Slope OFF, User Ratio
// Slope = 0, Offset Slope = 0, and no Modulo
GEAR1 := MLBlkCreate( 'GEAR1', 'GEAR' );
MLGearInit( GEAR1, 1.0, 0.0, false, 0.0, false, 0.0, false);
    
```

3.1.10.2.3.2 Ladder Diagram



3.1.10.2.3.3 Function Block Diagram



3.1.10.3 MLGearReadOffset



Function - Returns the Offset value of a selected Gear Block from the Pipe Network.

The output of a Gear Block = Input value * Ratio + Offset

3.1.10.3.1 Arguments

3.1.10.3.1.1 Input

BlockID	Description	ID number of an initiated an initialized Gear object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.10.3.1.2 Output

Offset	Description	The offset value currently assigned to the selected Gear Pipe Block
	Data type	LREAL
	Unit	User unit

3.1.10.3.2 Related Functions

"MLGearWriteOff" (→ p. 158)


"MLGearInit" (→ p. 151)

3.1.10.3.3 Example

3.1.10.3.3.1 Structured Text

```
//Find the Offset value of Gear1 Pipe Block
Gear1Offset := MLGearReadOffset( PipeNetwork.GEAR1 );
```

3.1.10.3.3.2 Ladder Diagram




3.1.10.3.3.3 Function Block Diagram



3.1.10.4 MLGearReadOffSlp



 **Function** - Returns the Offset Slope value of a selected Gear Block from the Pipe Network. Offset Slope sets the limit in User Units per Second at which step changes in offset are implemented. The default value when creating a Gear Block is OFFSET_SLOPE_MAX or infinite.

3.1.10.4.1 Arguments

3.1.10.4.1.1 Input

BlockID	Description	ID number of an initiated an initialized Gear object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.10.4.1.2 Output

Slope	Description	The offset slope value currently assigned to the selected Gear Pipe Block, which may be a different sign than what is programmed with MLGearWriteOSlp.
	Data type	LREAL
	Unit	User unit/sec

3.1.10.4.2 Related Functions

"MLGearWriteOSlp" (→ p. 160)


"MLGearInit" (→ p. 151)

3.1.10.4.3 Example

3.1.10.4.3.1 Structured Text

```
//Find the Offset Slope value of Gear1 Pipe Block
Gear1OffsetSlope := MLGearReadOffSlp(PipeNetwork.GEAR1);
```

3.1.10.4.3.2 Ladder Diagram




3.1.10.4.3.3 Function Block Diagram



3.1.10.5 MLGearReadRatio



 **Function** - Returns the Ratio value of a selected Gear Block from the Pipe Network.

The output of a Gear Block = Input value * Ratio + Offset

3.1.10.5.1 Arguments

3.1.10.5.1.1 Input

BlockID	Description	ID number of an initialized Gear Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.10.5.1.2 Output

Ratio	Description	The Ratio value currently assigned to the selected Gear Pipe Block
	Data type	LREAL
	Unit	N/A

3.1.10.5.2 Related Functions

"MLGearWriteRatio" (→ p. 161)


"MLGearInit" (→ p. 151)

3.1.10.5.3 Example

3.1.10.5.3.1 Structured Text

```
//Find the Ratio value of Gear1 Pipe Block
Gear1Ratio := MLGearReadRatio(PipeNetwork.GEAR1);
```

3.1.10.5.3.2 Ladder Diagram



3.1.10.5.3.3 Function Block Diagram



3.1.10.6 MLGearReadRatSlp

Pipe Network ✓

Function - Returns the Ratio Slope value of a selected Gear Block from the Pipe Network. Ratio Slope sets the limit in 1/Seconds (or s⁻¹) at which step changes in Ratio are implemented.

3.1.10.6.1 Arguments

3.1.10.6.1.1 Input

BlockID	Description	ID number of an initialized Gear Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.10.6.1.2 Output

Slope	Description	The Ratio Slope value currently assigned to the selected Gear Pipe Block, , which may be a different sign than what is programmed with MLGearWriteRatSlp.
	Data type	LREAL
	Unit	1/sec (or s ⁻¹)

3.1.10.6.2 Related Functions

"MLGearWriteRatSlp" (→ p. 162)


"MLGearInit" (→ p. 151)

3.1.10.6.3 Example

3.1.10.6.3.1 Structured Text

```
//Find the Ratio Slope value of Gear1 Pipe Block
Gear1RatioSlope := MLGearReadRatSlp(PipeNetwork.GEAR1);
```

3.1.10.6.3.2 Ladder Diagram



3.1.10.6.3.3 Function Block Diagram



3.1.10.7 MLGearWriteOff



Function - Sets the Offset value of a selected Gear Pipe Block.

The output of a Gear Block = Input value * Ratio + Offset



Values lower than 1.0 can be entered, but require a leading zero (for example 0.8 instead of .8)

3.1.10.7.1 Arguments

3.1.10.7.1.1 Input

BlockID	Description	ID number of an initialized Gear Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Offset	Description	New Offset value to be assigned to selected Gear Pipe Block. Values lower than 1.0 can be entered, but require a leading zero (for example 0.8 instead of .8)
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.1.10.7.1.2 Output

Default (.Q)	Description	Returns TRUE if Offset value is changed in the selected Gear Pipe Block
	Data type	BOOL
	Unit	N/A

3.1.10.7.1.3 Return Type

BOOL

3.1.10.7.2 Related Functions

"MLGearReadOffset" (→ p. 155)


"MLGearInit" (→ p. 151)

3.1.10.7.3 Example


3.1.10.7.3.1 Structured Text

```
//Set the Offset value of Gear1 Pipe Block to 5 User Units
MLGearWriteOff(PipeNetwork.GEAR1, 5.0);
```

3.1.10.7.3.2 Ladder Diagram



3.1.10.7.3.3 Function Block Diagram



3.1.10.8 MLGearWriteOSlp



Function - Sets the Offset Slope value of a selected Gear Pipe Block.

Offset Slope sets the limit in User Units per Second at which step changes in offset are implemented. The default value when creating a Gear Block is OFFSET_SLOPE_MAX or infinite.

TIP

Values lower than 1.0 can be entered, but require a leading zero (for example 0.8 instead of .8)

3.1.10.8.1 Arguments

3.1.10.8.1.1 Input

BlockID	Description	ID number of an initialized Gear Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Slope	Description	New Offset Slope value to be assigned to selected Gear Pipe Block. Values lower than 1.0 can be entered, but require a leading zero (for example 0.8 instead of .8)
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—

3.1.10.8.1.2 Output

Default (.Q)	Description	Returns TRUE if Offset Slope value is changed in the selected Gear Pipe Block
	Data type	BOOL
	Unit	N/A

3.1.10.8.1.3 Return Type

BOOL

3.1.10.8.2 Related Functions

"MLGearReadOffSlp" (→ p. 155)


"MLGearInit" (→ p. 151)

3.1.10.8.3 Example


3.1.10.8.3.1 Structured Text

```
//Set the Offset Slope value of Gear1 Pipe Block to 100
MLGearWriteOSlp(PipeNetwork.GEAR1, 100.0);
```

3.1.10.8.3.2 Ladder Diagram



3.1.10.8.3.3 Function Block Diagram



3.1.10.9 MLGearWriteRatio



Function - Set the Ratio value of a selected Gear Pipe Block.

The output of a Gear Block = Input value * Ratio + Offset



Values lower than 1.0 can be entered, but require a leading zero (for example 0.8 instead of .8)

3.1.10.9.1 Arguments

3.1.10.9.1.1 Input

BlockID	Description	ID number of an initialized Gear Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Ratio	Description	New Ratio value to be assigned to selected Gear Pipe Block. Values lower than 1.0 can be entered, but require a leading zero (for example 0.8 instead of .8)
	Data type	LREAL
	Range	—
	Unit	N/A
	Default	—

3.1.10.9.1.2 Output

Default (.Q)	Description	Returns TRUE if Ratio value is changed in the selected Gear Pipe Block
	Data type	BOOL
	Unit	N/A

3.1.10.9.1.3 Return Type

BOOL

3.1.10.9.2 Related Functions

"MLGearReadRatio" (→ p. 156)


"MLGearInit" (→ p. 151)

3.1.10.9.3 Example


3.1.10.9.3.1 Structured Text

```
//Set the Ratio value of Gear1 Pipe Block to 5
MLGearWriteRatio(PipeNetwork.GEAR1, 5.0);
```

3.1.10.9.3.2 Ladder Diagram



3.1.10.9.3.3 Function Block Diagram



3.1.10.10 MLGearWriteRatSlp



Function - Set the Ratio Slope value of a selected Gear Pipe Block. Ratio Slope sets the limit at which step changes in ratio are implemented.

IMPORTANT

Be sure to set $RatioSlope < (Ratio * EtherCAT\ Update\ Rate)$. The Gear block will make a jump (without a ramp) from one gear to the next when the RatioSlope is greater than the Ratio change factor multiplied by the update rate scale factor.

TIP

Values lower than 1.0 can be entered, but require a leading zero (for example 0.8 instead of .8)

NOTE

The GEAR block output will add a position offset to the GEAR block input when using a RatioSlope. See "RatioSlope Offset" (→ p. 164) in the Examples below.

3.1.10.10.1 Arguments**3.1.10.10.1.1 Input**

BlockID	Description	ID number of an initialized Gear Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Slope	Description	New Ratio Slope value to be assigned to selected Gear Pipe Block. Values lower than 1.0 can be entered, but require a leading zero (for example 0.8 instead of .8)
	Data type	LREAL
	Range	—
	Unit	1/sec
	Default	—

3.1.10.10.1.2 Output

Default (.Q)	Description	Returns TRUE if Ratio Slope value is changed in the selected Gear Pipe Block
	Data type	BOOL
	Unit	N/A

3.1.10.10.1.3 Return Type

BOOL

3.1.10.10.2 Related Functions


"MLGearReadOffSlp" (→ p. 155)

"MLGearInit" (→ p. 151)


3.1.10.10.3 Example**3.1.10.10.3.1 Structured Text**

```
//Set the Ratio Slope value of Gear1 Pipe Block to 100
MLGearWriteRatSlp(PipeNetwork.GEAR1, 100.0);
```

3.1.10.10.3.2 Ladder Diagram



3.1.10.10.3.3 Function Block Diagram



3.1.10.10.3.4 RatioSlope Offset

If MLGearWriteRatSlp is set as `MLGearWriteRatSlp(PipeNetwork.GEAR1 12 , Gear1RatioSlope 500.0);` to generate a ramp (instead of a step) when going from a gear ratio of 1 to 2, then there will be a position offset when the gear ratio settles as 2. In the image below the ratio goes from 1.0 to 2.0; Green is PN Gear Block Output and Red is Gearbox Input.



1. Green line: PN Gear Block Output
2. Red line: PN Gearbox Input
3. When the ratio is changed
4. Phase difference

If MLGearWriteRatSlp is set without a ramp,

`MLGearWriteRatSlp(PipeNetwork.GEAR1 12 , Gear1RatioSlope 1e+301);` , then there will not be an offset.



1. Green line: PN Gear Block Output
2. Red line: PN Gearbox Input
3. When the ratio changes
4. Synced

3.1.11 Motion Library - Integrator

Name	Description	Return Type
"MLIntInit" (→ p. 165)	Initializes an integrator object.	BOOL
"MLIntWriteOutVal" (→ p. 164)	Sets the output value of an integrator object.	BOOL

3.1.11.1 MLIntWriteOutVal



Function - Sets the output value of an integrator object.

3.1.11.1.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of an initiated Integrator object.
Value	LREAL	No range	User units	No default	Designated new output value of the selected Integrator object.

3.1.11.1.2 Outputs


Output	Data Type	Range	Unit	Description
Default (.Q)	BOOL	No range	N/A	Returns TRUE if the output value if the Integrator object is changed.

3.1.11.1.3 Remarks


- This function can force the output to an entered value not dependent on the input value from the Pipe Network.
- Output value can jump to another value instantly after the function is executed if the Pipe Network is running

NOTE
 This function or function block returns cached data.
 See [Programming a Dual Core Controller](#) for more information.

3.1.11.1.4 FBD Language



3.1.11.1.5 FFLD Language



3.1.11.1.6 IL Language

Not available.

3.1.11.1.7 ST Language


```
//change the output value of an integrator object to 35
MLIntWriteOutVal ( PipeNetwork.MyIntegrator, 35.0 );
```

See Also

"MLIntInit" (→ p. 165)

3.1.11.2 MLIntInit



 **Function** - Initializes an integrator object.

3.1.11.2.1 Inputs

Input	Data Type	Range	Unit	Default	Description
BlockID	DINT	-2147483648 to 2147483648	N/A	No default	ID number of a created Pipe Block.
ModuloPosition	LREAL	No range	User units	360.0	Output ModuloPosition of Integrator object.
Modulo	BOOL	0, 1	N/A	TRUE	TRUE when mode is modulo. Modulo mode adapts the output values according to the ModuloPosition (modulo).


3.1.11.2.2 Outputs

Output	Data Type	Range	Unit	Description
Default (.Q)	BOOL	No range	N/A	Returns TRUE if the Integrator object is initialized.

3.1.11.2.3 Remarks

is this a function or function block?


- The function block is automatically called if an Integrator Block is added to the Pipe Network.
 - User-defined settings are entered in the **Pipe Blocks Properties** screen.
- The Integrator object can operate in modulo or not modulo mode.
 - While in modulo mode, the output values are adapted according to the entered **ModuloPosition** value.




NOTE

Integrator objects are normally created in the Pipe Network using the graphical engine. You do not have to add **MLIntInit** function blocks to their programs. Parameters are entered directly in pop-up windows. The code is automatically added to the current project.

3.1.11.2.4 FBD Language



3.1.11.2.5 FFLD Language



3.1.11.2.6 IL Language

Not available.

3.1.11.2.7 ST Language

```
//Initiate an Integrator Pipe Block named "MyIntegrator" with a Modulo of 360
MLIntInit(MyIntegrator, 360.0, true );
```

See Also

- "MLBlkCreate" (→ p. 33)
- "MLIntWriteOutVal" (→ p. 164)

3.1.12 Motion Library - Master

✎ TIP

- For an example of Master Functions, see "Examples of Master Functions" (→ p. 168).

Functions sorted by types:


Motion Control	Inquiry Functions	Position setting
"MLMstInit" (→ p. 176)	"MLMstReadAccel" (→ p. 179)	"MLMstAbs" (→ p. 169)
"MLMstRun" (→ p. 184)	"MLMstReadDecel" (→ p. 180)	"MLMstAdd" (→ p. 173)
"MLMstWriteAccel" (→ p. 187)	"MLMstReadInitPos" (→ p. 181)	"MLMstForcePos" (→ p. 174)
"MLMstWriteDecel" (→ p. 189)	"MLMstReadSpeed" (→ p. 182)	"MLMstRel" (→ p. 183)
"MLMstWriteSpeed" (→ p. 191)	"MLMstStatus" (→ p. 186)	

Functions sorted in alphabetical order:


Name	Description	Return type
"MLMstAbs" (→ p. 169)	Does an absolute move	BOOL
"MLMstAdd" (→ p. 173)	Does an additive move relative for a specified distance from the endpoint of the previous move	BOOL
"MLMstForcePos" (→ p. 174)	Forces the specified position. Possible only when the block is not moving.	BOOL

Name	Description	Return type
"MLMstInit" (→ p. 176)	Initializes a master object (TMP generator)	BOOL
"MLMstReadAccel" (→ p. 179)	Gets the present acceleration value of a master block	None
"MLMstReadDecel" (→ p. 180)	Gets the present deceleration value of a master block	None
"MLMstReadInitPos" (→ p. 181)	Gets the initial position of a master block	None
"MLMstReadSpeed" (→ p. 182)	Gets the speed of a master block	None
"MLMstRel" (→ p. 183)	Does an Relative move for a specified distance from the current position	BOOL
"MLMstRun" (→ p. 184)	Jogs at the specified speed. Returns TRUE if the function succeeded	BOOL
"MLMstStatus" (→ p. 186)	Returns the status of the generator	DINT
"MLMstWriteAccel" (→ p. 187)	Sets the acceleration of a master block	BOOL
"MLMstWriteDecel" (→ p. 189)	Sets the deceleration of a master block	BOOL
"MLMstWriteInitPos" (→ p. 190)	Sets the initial position of a master block	BOOL
"MLMstWriteSpeed" (→ p. 191)	Sets the speed of a master block	BOOL

3.1.12.1 Examples of Master Functions



MLMstRun(0.0) reduce the speed down to 0.



Master Functions Usage

3.1.12.2 MLMstAbs

Pipe Network ✓



Function - Performs a move to an absolute position.

Returns TRUE if the function succeeded.

3.1.12.2.1 Arguments

3.1.12.2.1.1 Input

BlockID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Position	Description	Sets the value of the absolute destination position. When the Modulo is turned on, see more explanations below.
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—


3.1.12.3 Position with Modulo On

NOTE

This information applies to both "MLMstAbs" (→ p. 169) and "MLAxisAbs" (→ p. 47). For simplicity, the term Axis Block also refers to Master Block.

When the Modulo is turned on, the Axis Block moves to the targeted position during the corresponding period, calculated as follows:

- If the Position input is between 0 and the Modulo Position, then the Axis Block moves within the **current** period (no position rollover).
- If the Position input is greater than the Modulo Position, then the Axis Block moves during one of the **next** period (positive position rollover).




The Axis Block works similarly for negative positions: if the Position input is less than zero, then the Axis Block moves during one of the **previous** period (negative position rollover).

3.1.12.4 Forcing the direction of rotation


In some applications, the direction of rotation for the axis is forced in one direction only. As a consequence, the motor movement goes to the next or previous modulo in the following situations:

- If the **End Position** is less than the **Start Position** and the direction of rotation for the axis is forced to be clockwise (the **red point** shows when the modulo position is reached).



(see an example in row#2 of the table below)

- If the **End Position** is greater than the **Start Position** and the direction of rotation for the axis is forced to be counter clockwise.



(see an example in row#4 of the table below)

Examples

Start Position	End Position	Direction of rotation	Cross Modulo	Position Input to MLAxisAbs (1)	RelativeDistance Moved (2)	
60	200	clockwise	No	200	140	(i.e. 200 - 60 + 0)
60	30	clockwise	Yes	390	330	(i.e. 30 - 60 + 360)
60	30	counter clockwise	No	30	-30	(i.e. 30 - 60 - 0)
60	200	counter clockwise	Yes	-160	-220	(i.e. 200 - 60 - 360)

With:

(1) **Position Input** = End Position (+ Modulo * *Direction of rotation*)

(2) **Relative Distance Moved** = End Position - Start Position (+ Modulo * *Direction of rotation*)

Where:

Direction of rotation = 1 when clockwise and -1 when anti-clockwise

3.1.12.5 Travel Speed Update with MLAxisAbs

The travel speed of the generator can be updated using the function block "MLAxisGenWriteSpd" (→ p. 70). Depending on the state of the generator, this speed is directly reflected on the current move or a future move.

- If MLAxisAbs is not currently being executed, the new travel speed will be applied for the trajectory calculation for a future MLAxisAbs command.
- If MLAxisAbs is currently being executed and a new MLAxisAbs with the same target position is called, the new travel speed will be taken into account only if the current state of the TMP profile is the constant velocity or acceleration. If the axis was decelerating to stop at the goal position the new travel speed will not be taken into account.
- If a MLAxisAbs is currently being executed and a new MLAxisAbs with a different target position is called, the new travel speed is taken into account.

Following are several examples.




Figure 1-32: Initial speed is smaller than the new speed




Figure 1-33: Initial speed is bigger than the new speed




Figure 1-34: The speed update is taken into account only if the second MLAxisAbs is triggered during acceleration or constant velocity

3.1.12.5.0.1 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

TIP

To reduce the load on the CPU, call MLMstAbs only once for each move. This can be achieved by adding a control variable, which is illustrated below.

```

// Master: modulo is on and modulo range is 0 - 360 with
rollover at 360

If Not MoveStarted Then
    Position := 500;
    MLMstAbs( PipeNetwork.MASTER, Position);
    MovesStarted := TRUE;
End_if;
    
```

NOTE

Perform one of the following to prevent undesired axis movement if modulo is turned on.

- Verify that the **Position** value is within the modulo range.
- If the **Position** value is outside of the modulo range, call MLMstAbs function only once. See the **TIP** above for an example of how to do this.

3.1.12.5.1 Related Functions

"MLMstWriteSpeed" (→ p. 191)


"MLMstWriteDecel" (→ p. 189)

3.1.12.5.2 Examples

3.1.12.5.2.1 Structured Text

```
//Make an absolute positon move with a Master block called "MASTER" to
position 1000.0
MLMstAbs( PipeNetwork.MASTER, 1000.0 );
```

3.1.12.5.2.2 Ladder Diagram



3.1.12.5.2.3 Function Block Diagram



3.1.12.6 MLMstAdd



Function - Performs a move for a specified distance relative to the endpoint of the previous move.

Returns TRUE if the function succeeded.

3.1.12.6.1 Arguments

3.1.12.6.1.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
DeltaPos	Description	Relative distance to move
	Data type	LREAL

Range	—
Unit	User unit
Default	—

3.1.12.6.1.2 Output

Default (Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

3.1.12.6.2 Related Functions

"MLMstWriteSpeed" (→ p. 191)


"MLMstWriteDecel" (→ p. 189)

3.1.12.6.3 Example

3.1.12.6.3.1 Structured Text

```
//At the endpoint of the previous move, with the Master pipe block named
"MASTER", make a move of 750.0
MLMstAdd( PipeNetwork.MASTER, 750.0 );
```

3.1.12.6.3.2 Ladder Diagram



NOTE
You must use a **pulse contact** to start the FB

3.1.12.6.3.3 Function Block Diagram



3.1.12.7 MLMstForcePos



Function - Forces the position of a Master Block to a specified position.

This block can only be executed when motion is not occurring. It can be used to force the master starting position to the desired values from which to start motion.

3.1.12.7.1 Arguments

3.1.12.7.1.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Position	Description	Defines the Master starting position when the motion starts
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.1.12.7.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

3.1.12.7.2 Related Functions


"MLMstReadInitPos" (→ p. 181)

3.1.12.7.3 Example

3.1.12.7.3.1 Structured Text

```
//Reset the output position of the Master Pipe Block named "Master" to
2500.0
MLMstForcePos(PipeNetwork.Master, 2500.0);
```


3.1.12.7.3.2 Ladder Diagram



NOTE

You must use a [pulse contact](#) to start the FB

3.1.12.7.3.3 Function Block Diagram



3.1.12.8 MLMstInit



Function - Initializes a Master TMP (trapezoidal motion profile) generator block.

This function is automatically created when the MLMaster Block is included in the Pipe Network Editor. Based on the parameters defined in the pipe block (see figure below), the Inputs for this function are initialized by default.




Figure 1-35: TMP Initialization

3.1.12.8.1 Arguments

3.1.12.8.1.1 Input

Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
ModuloPosition	Description	Modulo Position for cyclic motion systems expressed in user logical units (Position Rollover Value)
	Data type	LREAL
	Range	—

	Unit	User unit
	Default	—
Period	Description	Sampling period of the generator expressed according to the update cycle (e.g. 2.0 means the sampling is done once every 2 cycles)
	Data type	LREAL
	Range	—
	Unit	Cycles
	Default	—
Speed	Description	Travel speed value expressed in user logical units per second. The travel speed value is used to set the constant speed part of the trapezoidal motion profile
	Data type	LREAL
	Range	—
	Unit	User unit / sec
	Default	—
Acceleration	Description	Acceleration value expressed in user logical units per second squared. The acceleration value is always used to generate the first part of the trapezoidal motion profile
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Deceleration value expressed in user logical units per second squared. The deceleration value is always used to generate the last part of the trapezoidal motion profile
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Initial Position	Description	Initial position value expressed in user logical units. Used only at the pipe activation to initialize the position starting point
	Data type	LREAL
	Range	—
	Unit	User unit

	Default	—
Modulo	Description	The available modes are Modulo (True) or No modulo (False)
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—

3.1.12.8.1.2 Output


Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

3.1.12.8.2 Example


3.1.12.8.2.1 Structured Text

```
//Initialize a Master Pipe Block named "MASTER" to a Modulo of 360,
motion generator sample period of 1,Speed of 1000.0, Accel and Decel of
10000.0, Initial position of 0.0,
MLMstInit( PipeNetwork.MASTER, 360.0, 1.0, 1000.0, 10000.0, 10000.0, 0.0,
true );
```

3.1.12.8.2.2 Ladder Diagram




3.1.12.8.2.3 Function Block Diagram



3.1.12.9 MLMstReadAccel

Pipe Network ✓

 **Function** - Get the presently used value for acceleration of a master block.

3.1.12.9.1 Arguments

3.1.12.9.1.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.12.9.1.2 Output

OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A
Acceleration	Description	Returns Acceleration value
	Data type	LREAL
	Unit	User unit/sec ²

3.1.12.9.2 Related Functions

"MLMstReadSpeed" (→ p. 182)


"MLMstReadDecel" (→ p. 180)

3.1.12.9.3 Example


3.1.12.9.3.1 Structured Text

```
// Read the present acceleration of a Pipe Block named "MASTER"
MLMstReadAccel( PipeNetwork.MASTER );
```

3.1.12.9.3.2 Ladder Diagram



3.1.12.10 Function Block Diagram



3.1.12.11 MLMstReadDecel



Function - Get the presently used value for deceleration of a master block.

3.1.12.11.1 Arguments

3.1.12.11.1.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.12.11.1.2 Output

OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A
Deceleration	Description	Returns Deceleration value
	Data type	LREAL
	Unit	User unit/sec ²

3.1.12.11.2 Example


3.1.12.11.2.1 Structured Text

```
// Read the present deceleration of a Pipe Block named "MASTER"
MLMstReadDecel( PipeNetwork.MASTER );
```

3.1.12.11.2.2 Ladder Diagram



3.1.12.11.2.3 Function Block Diagram



3.1.12.12 MLMstReadInitPos



Function - Get the presently used value for initial position of a master block.

3.1.12.12.1 Arguments

3.1.12.12.1.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Block ID	Description	PipeNetwork Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.12.12.1.2 Output


OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A
Position	Description	Returns Intial Postion
	Data type	LREAL
	Unit	User unit

3.1.12.12.2 Example

3.1.12.12.2.1 Structured Text

```
MstInitPos := MLMstReadInitPos ( PipeNetwork.MASTER );
```

3.1.12.12.2.2 Ladder Diagram



3.1.12.12.2.3 Function Block Diagram



3.1.12.13 MLMstReadSpeed



Function - Get the presently used value for speed of a master block.

3.1.12.13.1 Arguments

3.1.12.13.1.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.12.13.1.2 Output

OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

Speed	Description	Returns current Speed
	Data type	LREAL
	Unit	User unit/sec

3.1.12.13.2 Related Functions

"MLMstReadAccel" (→ p. 179)


"MLMstReadDecel" (→ p. 180)

3.1.12.13.3 Example

3.1.12.13.3.1 Structured Text

```
MstSpeed := MLMstReadSpeed( PipeNetwork.MASTER );
```

3.1.12.13.3.2 Ladder Diagram



3.1.12.13.3.3 Function Block Diagram



3.1.12.14 MLMstRel



Function - Performs a move for a specified distance relative to the current position. Returns TRUE if the function succeeded.

3.1.12.14.1 Arguments

3.1.12.14.1.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT

	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
DeltaPos	Description	Relative distance to move
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.1.12.14.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

3.1.12.14.2 Related Functions

"MLMstWriteSpeed" (→ p. 191)


"MLMstWriteDecel" (→ p. 189)

3.1.12.14.3 Example

3.1.12.14.3.1 Structured Text

```
MLMstRel ( PipeNetwork.MASTER, 750.0 );
```

3.1.12.14.3.2 Ladder Diagram



NOTE


You must use a [pulse contact](#) to start the FB

3.1.12.14.3.3 Function Block Diagram



3.1.12.15 MLMstRun

Pipe Network ✓

 **Function** - Jog at the specified speed.
Returns TRUE if the function succeeded.

3.1.12.15.1 Arguments

3.1.12.15.1.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Speed	Description	Speed to jog motor
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—

3.1.12.15.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

3.1.12.15.2 Related Functions

"MLMstWriteSpeed" (→ p. 191)


"MLMstWriteDecel" (→ p. 189)

3.1.12.15.3 Example


3.1.12.15.3.1 Structured Text

```
MLMstRun( PipeNetwork.MASTER, 1250.0 );
```

3.1.12.15.3.2 Ladder Diagram



3.1.12.15.3.3 Function Block Diagram



3.1.12.16 MLMstStatus



Function - The value returned is the state being executed by the TMP generator as it processes the various motion commands.

Some states are transitory, others are stable until the next event takes place. These terms are relevant to the returned values.

Term	Definition
Running	Speed is non-zero
Stopped	Speed is zero
Positioning	A target position has been programmed with a relative, additive or absolute command.
Status	Definition
0	(New speed programmed) is entered when a jog move (MLMstRun) is commanded and the current speed is not at the commanded speed.
1	(Stable state Running or Stopped) is entered when a jog move (MLMstRun) is commanded and the current speed is at the commanded speed. (Stable state Running or Stopped) is entered when a position move is programmed and motion is completed.
2	(Speed change) is entered when the current speed is greater than the commanded speed.
3	(Speed reversal while positioning) is entered when a position move is programmed and the distance to go requires a speed reversal.
4	(Acceleration while positioning) current speed is below the travel speed
5	(Constant Speed while positioning) is entered when a positioning move is commanded and the current speed is at the commanded speed.
6	(Deceleration while positioning) is entered when a positioning move is commanded and the current speed is changing to achieve the target position at zero speed.
7	(Micro step) is entered when a small change in position is required and the current speed is zero.

3.1.12.16.1 Arguments

3.1.12.16.1.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.12.16.1.2 Output


OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A
Default (.Q)	Description	Returns the status of the generator
	Data type	DINT
	Unit	N/A

3.1.12.16.2 Example

3.1.12.16.2.1 Structured Text

```
MasterStatus := MLMstStatus( PipeNetwork.MASTER );
```

3.1.12.16.2.2 Ladder Diagram



3.1.12.16.2.3 Function Block Diagram



3.1.12.17 MLMstWriteAccel

Pipe Network ✓

 **Function** - Set the acceleration of a master block.

Returns TRUE if the function succeeded.

3.1.12.17.1 Arguments

3.1.12.17.1.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Acceleration	Description	Acceleration value expressed in user logical units per second squared
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—

3.1.12.17.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

3.1.12.17.2 Related Functions

"MLMstAbs" ([→ p. 169](#))

"MLMstRel" ([→ p. 183](#))

"MLMstWriteSpeed" ([→ p. 191](#))


"MLMstWriteDecel" ([→ p. 189](#))

3.1.12.17.3 Example


3.1.12.17.3.1 Structured Text

```
MLMstWriteAccel( PipeNetwork.MASTER, 40000.0 );
```

3.1.12.17.3.2 Ladder Diagram



3.1.12.17.3.3 Function Block Diagram



3.1.12.18 MLMstWriteDecel



Function - Set the deceleration of a master block.

Returns TRUE if the function succeeded.

3.1.12.18.1 Arguments

3.1.12.18.1.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Deceleration	Description	Deceleration value
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—

3.1.12.18.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes
---------------------	--------------------	--

Data type	BOOL
Unit	N/A

3.1.12.18.2 Related Functions


"MLMstWriteSpeed" (→ p. 191)

3.1.12.18.3 Example

3.1.12.18.3.1 Structured Text

```
MLMstWriteDecel( PipeNetwork.MASTER, 40000.0 );
```

3.1.12.18.3.2 Ladder Diagram



3.1.12.18.3.3 Function Block Diagram



3.1.12.19 MLMstWriteInitPos



Function - Set the initial position of a master block.
Returns TRUE if the function succeeded.

3.1.12.19.1 Arguments

3.1.12.19.1.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]

	Unit	N/A
	Default	—
Position	Description	Initial position
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.1.12.19.1.2 Output


Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

3.1.12.19.2 Example


3.1.12.19.2.1 Structured Text

```
MLMstWriteInitPos ( PipeNetwork.MASTER, 120.0 );
```

3.1.12.19.2.2 Ladder Diagram



3.1.12.19.2.3 Function Block Diagram



3.1.12.20 MLMstWriteSpeed

Pipe Network ✓

Function - Set the speed of motion for the "MLMstAbs" (→ p. 169) and "MLMstRel" (→ p. 183) blocks.

- Returns TRUE if the function succeeded.
- This function does not generate any motion.

3.1.12.20.1 Arguments

3.1.12.20.1.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Speed	Description	Speed of the motion
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—

3.1.12.20.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

3.1.12.20.2 Related Functions


"MLMstWriteDecel" (→ p. 189)

3.1.12.20.3 Example

3.1.12.20.3.1 Structured Text

```
MLMstWriteSpeed( PipeNetwork.MASTER, 400.0 );
```

3.1.12.20.3.2 Ladder Diagram



3.1.12.20.3.3 Function Block Diagram



3.1.13 Motion Library - Phaser

TIP

- See "Example: Phaser Functions" (→ p. 193) for an example of Phaser functions.

Names	Description	Return type
"MLPhaInit" (→ p. 194)	Initializes a phaser Pipe Block.	BOOL
"MLPhaReadPhase" (→ p. 197)	Gets the phase value of a phaser block.	None
"MLPhaReadSlope" (→ p. 198)	Gets the phase slope value of a phaser block.	None
"MLPhaWritePhase" (→ p. 199)	Sets the phase value of a phaser block.	BOOL
"MLPhaWriteSlope" (→ p. 200)	Sets the phase slope value of a phaser block.	BOOL
"MLPhaReadActPhase" (→ p. 196)	Get the actual phase value of a phaser block.	LREAL

TIP

There is a delay when using an external encoder.
 The delay is five cycles:
 2 cycles to read the encoder from the AKD via EtherCAT,
 1 cycle for computing,
 2 cycles for sending the new position set point to the AKD).
 This lag error is speed proportional (5 cycles * speed).
 A Phaser block can be used to compensate for this lag.

When executing, the phaser block is in one of these states:

State	Description
Applying Phase	<ul style="list-style-type: none"> • Entered when the programmed Phase value is reached. • Exits to the Changing phase state whenever a new value is programmed via the "MLPhaWritePhase" (→ p. 199) function changes the Phase Offset target.
Changing Phase	<ul style="list-style-type: none"> • Entered when a new value is programmed. • Exits to the Applying Phase state when the programmed phase offset is reached. • The current Phase offset value is slewed to the new phase offset by the amount of the slew value.
Standby	<ul style="list-style-type: none"> • Entered when the Block is initialized. • Exits to the Changing Phase state when the Phase value is changed via the "MLPhaWritePhase" (→ p. 199) command.

3.1.13.1 Example: Phaser Functions

- Call "MLPhaWritePhase" (→ p. 199) function to modify the Phase value..
- Call "MLPhaWriteSlope" (→ p. 200) to modify the rate of change of phase, or slope, applied when the Phase value is changed.




Figure 1-36: Phaser Functions Usage

NOTE

% MODULO_POSITION is in the equation to take into account the modulo (periodicity) of the value.

3.1.13.2 MLPhaInit



Function - Initializes a phaser Pipe Block.

Returns TRUE if the function succeeded.

is this a function or function block?

This function block is automatically called by the Function PipeNetwork(MLPN_CREATE_OBJECTS) if a Phaser Block is added to the Pipe Network, with user-defined settings entered in the Pipe Blocks Properties screen.

The Phaser Pipe Block is assigned a Name, OUTPUT_PERIOD, PHASE, PHASE_SLOPE_TYPE, and STANDBY_VALUE.

3.1.13.2.1 Arguments

3.1.13.2.1.1 Input

BlockID	Description	ID Name of a Phaser function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
ModuloPosition	Description	Rollover Position of the Phaser block
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	360.0
Phase	Description	Amount of Phase adjustment
	Data type	LREAL
	Range	—
	Unit	N/A
	Default	0.0
UseUserSlope	Description	Setting determines if Max Slope or user-defined slope is used
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	Max Slope
PhaseSlope	Description	User-defined slope for making the phase adjustment
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	0.0
StandbyValue	Description	This value is output from the Phaser Block, when the pipe is active, until the " MLPhaWritePhase " (→ p. 199) function is executed.
	Data type	LREAL
	Range	—
	Unit	N/A
	Default	0.0

3.1.13.2.1.2 Output

Default (.Q)	Description	Returns True if the function block is successfully executing
	Data type	BOOL
	Unit	N/A

3.1.13.2.2 Related Functions

"MLPhaReadPhase" (→ p. 197)

"MLPhaReadSlope" (→ p. 198)

MLPhaInit


"MLPhaWritePhase" (→ p. 199)

3.1.13.2.3 Example


3.1.13.2.3.1 Structured Text

```
//Initialize a Phaser Pipe Block named "PhaseAdjust" to a Modulo of 720, phase offset value of 30, use the Max Slope
MLPhaInit( PipeNetwork.PhaseAdjust , 720, 30, false, 30 , 10 );
```

3.1.13.2.3.2 Ladder Diagram



3.1.13.2.3.3 Function Block Diagram



3.1.13.3 MLPhaReadActPhase



Function - Get the actual phase value of a phaser block.

If a "PHASE_SLOPE_USER" (refer to "MLPhaReadSlope" (→ p. 198) and "MLPhaWriteSlope" (→ p. 200)) value is being used, the new phase (refer to "MLPhaWritePhase" (→ p. 199)) isn't set immediately; the phase will be ramped with the slope value from the old phase value to the new phase value. MLPhaReadActPhase returns this ramping value.

"MLPhaReadPhase" (→ p. 197) returns the new value and this also when the phaser is still ramping. If using max slope means no ramping MLPhaReadActPhase and MLPhaReadPhase return always the same value.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.13.3.1 Arguments**3.1.13.3.1.1 Input**

Enable	Description	
	Data type	
	Range	
	Unit	
	Default	
BlockID	Description	ID Name of a Phaser function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.13.3.1.2 Output

OK	Description	
	Data type	
	Unit	
Phase	Description	
	Data type	LREAL
	Unit	

3.1.13.3.2 Related Functions

MLPhaReadPhase, MLPhaWritePhase, MLPhaReadSlope, MLPhaWriteSlope

3.1.13.4 MLPhaReadPhase

 Pipe Network ✓

 **Function** - Get the phase value of a phaser block.

3.1.13.4.1 Arguments**3.1.13.4.1.1 Input**

BlockID	Description	ID Name of a Phaser function block in the Pipe Network
----------------	--------------------	--

Data type	DINT
Range	[-2147483648, 2147483648]
Unit	N/A
Default	—

3.1.13.4.1.2 Output

Phase	Data type	LREAL
--------------	------------------	-------

3.1.13.4.2 Example


3.1.13.4.2.1 Structured Text

```
PresentPhase := MLPhaReadPhase ( PipeNetwork.PhaseAdjust );
```

3.1.13.4.2.2 Ladder Diagram



3.1.13.4.2.3 Function Block Diagram



3.1.13.5 MLPhaReadSlope



Function - Get the phase slope value of a phaser block.

3.1.13.5.1 Arguments

3.1.13.5.1.1 Input

BlockID	Description	ID Name of a Phaser function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.13.5.1.2 Output

Slope	Description	Present Slope value
--------------	--------------------	---------------------

Data type	LREAL
Unit	User unit/sec
Default	Value defined in the setup of a Phaser Block within a Pipe Network. Depending on the phase slope type setting, it is the VALUE in "PHASE_SLOPE_USER", "PHASE" or the max slope.

3.1.13.5.2 Related Functions

[MLPhaReadSlope](#)

3.1.13.5.3 Example

3.1.13.5.3.1 Structured Text

```
PresentSlope :=MLPhaReadSlope( PipeNetwork.PhaseAdjust );
```

3.1.13.5.3.2 Ladder Diagram



3.1.13.5.3.3 Function Block Diagram



3.1.13.6 MLPhaWritePhase



Function - Set the phase value of a phaser block.

3.1.13.6.1 Arguments

3.1.13.6.1.1 Input

BlockID	Description	ID Name of a Phaser function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Phase	Description	Phase value
	Data type	LREAL

Range	—
Unit	User unit/sec
Default	Value defined in the setup of a phaser Block within a Pipe Network. It is in the "PHASE" field in the parameter tab

3.1.13.6.1.2 Output

Default (.Q)	Description	Returns True if the function block is successfully executing
	Data type	BOOL
	Unit	N/A

3.1.13.6.2 Related Functions

"MLPhaReadPhase" (→ p. 197)

3.1.13.6.3 Example


3.1.13.6.3.1 Structured Text

```
MLPhaWritePhase( PipeNetwork.PhaseAdjust , 30 );
```

3.1.13.6.3.2 Ladder Diagram



3.1.13.6.3.3 Function Block Diagram



3.1.13.7 MLPhaWriteSlope



Function - Set the phase value of a phaser block.
Returns TRUE if the function succeeded.

3.1.13.7.1 Arguments

3.1.13.7.1.1 Input

BlockID	Description	ID Name of a Phaser function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]

Unit	N/A
Default	—
Description	Set slope of phase adjust
Data type	LREAL
Range	—
Unit	User unit/sec
Default	Value defined in the setup of a Phaser Block within a Pipe Network. Depending on the phase slope type setting, it is the VALUE in "PHASE_SLOPE_USER", "PHASE" or the max slope.

3.1.13.7.1.2 Output

Default (.Q)	Description	Returns True if the function block is successfully executing
	Data type	BOOL
	Unit	N/A

3.1.13.7.2 Related Functions


"MLPhaReadSlope" (→ p. 198)

3.1.13.7.3 Example


3.1.13.7.3.1 Structured Text

```
MLPhaWriteSlope( PipeNetwork.PhaseAdjust , 10 );
```

3.1.13.7.3.2 Ladder Diagram



3.1.13.7.3.3 Function Block Diagram



3.1.14 Motion Library - PMP

Name	Description	Return type
"MLPmpAbs" (→ p. 202)	Moves to an Absolute Position.	BOOL
"MLPmpForcePos" (→ p. 203)	Forces the specified position. Possible only when the block is not moving.	BOOL
"MLPmpInit" (→ p. 205)	Initializes a PMP object (Parabolic Motion Profile generator) with user-defined settings.	BOOL
"MLPmpReadAccel" (→ p. 208)	Gets the Acceleration parameter of a PMP block.	None
"MLPmpReadFstSpd" (→ p. 209)	Gets the FirstTravelSpeed parameter of a PMP block.	None
"MLPmpReadInitPos" (→ p. 210)	Gets the InitialPosition parameter of a PMP block.	None
"MLPmpReadJerk" (→ p. 211)	Gets the Jerk parameter of a PMP block	None
"MLPmpReadLstSpd" (→ p. 212)	Gets the LastTravelSpeed parameter of a PMP block.	None
"MLPmpRel" (→ p. 213)	Does two subsequent relative moves.	BOOL
"MLPmpRun" (→ p. 215)	Jog the generator at the specified speed.	BOOL
"MLPmpStatus" (→ p. 216)	Returns the status of the PMP block generator.	None
"MLPmpWriteAccel" (→ p. 218)	Sets the acceleration parameter of a PMP block.	BOOL
"MLPmpWriteFstSpd" (→ p. 219)	Sets the FirstTravelSpeed parameter of a PMP block.	BOOL
"MLPmpWriteJerk" (→ p. 220)	Sets the jerk parameter of a PMP block.	BOOL
"MLPmpWriteLstSpd" (→ p. 221)	Sets the LastTravelSpeed parameter of a PMP block.	BOOL

3.1.14.1 MLPmpAbs



Function - Move to an Absolute Position using a parabolic acceleration profile.

- The FIRST_TRAVEL_SPEED is used as the velocity for the motion.
- JERK determines the level of parabolic acceleration.
- Returns TRUE if the function succeeded.

3.1.14.1.1 Arguments

3.1.14.1.1.1 Input

BlockID	Description
	ID Name of the PMP function block in the Pipe Network
	Data type DINT
	Range [-2147483648, 2147483648]
	Unit N/A

	Default	—
Position	Description	Absolute Position of motor/load to be at after this FB is complete
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.1.14.1.1.2 Output

Default (.Q)	Description	Returns True if the function block is successfully executing
	Data type	BOOL
	Unit	N/A

3.1.14.1.2 Related Functions

"MLPmpWriteAccel" (→ p. 218)

"MLPmpWriteJerk" (→ p. 220)


"MLPmpWriteFstSpd" (→ p. 219)

3.1.14.1.3 Example


3.1.14.1.3.1 Structured Text

```
MLPmpAbs ( PipeNetwork.PmpMaster, 1000.0 ) ;
```

3.1.14.1.3.2 Ladder Diagram



3.1.14.1.3.3 Function Block Diagram



3.1.14.2 MLPmpForcePos

Pipe Network ✓

Function - Forces the position of a PMP Block to a specified position.
is this a function or function block?

This block can only be executed when motion is not occurring. It can be used to force the PMP starting position to the desired values from which to start motion.

3.1.14.2.1 Arguments

3.1.14.2.1.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Block ID	Description	ID name of the PMP Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Position	Description	Defines the PMP starting position when the motion starts
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.1.14.2.1.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	N/A

3.1.14.2.2 Related Functions


"MLPmpReadInitPos" ([→ p. 210](#))

3.1.14.2.3 Example

3.1.14.2.3.1 Structured Text

```
MLPmpForcePos( PipeNetwork.PMP, 2500.0 );
```

3.1.14.2.3.2 Ladder Diagram



NOTE
 You must use a **pulse contact** to start the FB

3.1.14.2.3.3 Function Block Diagram



3.1.14.3 MLPmpInit



Function - Initializes a Pmp Block for use in a PLC Program.

is this a function or function block?

This function block is automatically called by the Function PipeNetwork(MLPN_CREATE_OBJECTS) if a Pmp Block is added to the Pipe Network, with user-defined settings entered in the Pipe Blocks Properties screen.

The Pmp Pipe Block is assigned a Name, SAMPLING_PERIOD, MODULO_POSITION, FIRST_TRAVEL_SPEED, LAST_TRAVEL_SPEED, ACCELERATION, JERK, and INITIAL Position. Some of these parameters can be changes in an application program using other MLPmp function blocks

A MLPmpRel function block is used to make a bi directional motion. First movement in one direction, then a return motion back to the initial position. A MLPmpAbs function block is use to move one direction to an absolute position.

NOTE
 Pmp objects are normally created in the Pipe Network using the graphical engine. Then you do not have to add MLPmpInit function blocks to their programs. Parameters are entered directly in pop-up windows, and the code is then automatically added to the current project.

3.1.14.3.1 Arguments

3.1.14.3.1.1 Input

BlockID	Description	ID Name of a PMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
ModuloPosition	Description	Modulo Position for cyclic motion systems expressed in user logical units (Position Rollover Value)
	Data type	LREAL

	Range	—
	Unit	User unit
	Default	360.0
Period	Description	Sampling period of the generator expressed according to the update cycle (e.g. 2.0 means the sampling is done once every 2 cycles)
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	1.0
FirstTravelSpeed	Description	First Travel Speed of the motion
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	100.0
LastTravelSpeed	Description	Last Travel Speed of the motion
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	100.0
Acceleration	Description	Acceleration of the Pmp block motion
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	1000.0
Jerk	Description	Jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	0
InitialPosition	Description	Initial Position of the Pmp block when the Pipe Network is start up
	Data type	LREAL
	Range	—

	Unit	User unit
	Default	0
Modulo	Description	The available modes are Modulo (True) or No modulo (False)
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—

3.1.14.3.1.2 Output

Default (.Q)	Description	Returns True if the function block is successfully executing
	Data type	BOOL
	Unit	N/A

3.1.14.3.2 Related Functions

"MLPmpReadAccel" (→ p. 208)

"MLPmpReadFstSpd" (→ p. 209)

"MLPmpReadInitPos" (→ p. 210)

"MLPmpReadJerk" (→ p. 211)


"MLPmpReadLstSpd" (→ p. 212)

3.1.14.3.3 Example


3.1.14.3.3.1 Structured Text

```
//Initialize a PMP Pipe Block named "PMP" to a modulo roll over of 360,
motion generator sample period of 1,First Travel Speed of 800.0, Second
Travel Speed of 20000.0, Accel of 20000.0,Jerk of 520.0, Initial position
of 0.0
MLPmpInit( PipeNetwork.Pmp , 360.0, 1.0, 800.0, 20000.0, 20000.0, 520.0,
0, true ) ;
```

3.1.14.3.3.2 Ladder Diagram



3.1.14.3.3 Function Block Diagram



3.1.14.4 MLPmpReadAccel



Function - Get the Acceleration parameter of a PMP block used in both the MLPmpAbs and MLPmpRel function block.

3.1.14.4.1 Arguments

3.1.14.4.1.1 Input

BlockID	Description	ID Name of the PMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.14.4.1.2 Output

Acceleration	Description	Present Acceleration of the PMP PipeNetwork Function Block
	Data type	LREAL
	Unit	User unit/sec ²

Default	Value defined PMP Block when creating a Pipe Network. It is in the "ACCELERATION" field in the parameter tab.
----------------	---

3.1.14.4.2 Related Functions

"MLPmpReadFstSpd" (→ p. 209)

"MLPmpReadInitPos" (→ p. 210)

"MLPmpReadJerk" (→ p. 211)

"MLPmpReadLstSpd" (→ p. 212)

3.1.14.4.3 Example

3.1.14.4.3.1 Structured Text

```
PmpAccelValue := MLPmpReadAccel ( PipeNetwork.PmpMaster ) ;
```

3.1.14.4.3.2 Ladder Diagram



3.1.14.4.3.3 Function Block Diagram



3.1.14.5 MLPmpReadFstSpd

Pipe Network ✓

Function - Get the FirstTravelSpeed parameter of a PMP block.

This parameter is used as the first of 2 speeds in an MLPmpRel Motion Block. It is also used as the speed in an MLPmpAbs Motion Block.

3.1.14.5.1 Arguments

3.1.14.5.1.1 Input

BlockID	Description	ID Name of a PMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.14.5.1.2 Output

FirstTravelSpeed	Description	Present first travel velocity of the PMP PipeNetwork Function Block
-------------------------	--------------------	---

Data type	LREAL
Unit	User unit/sec
Default	Value defined in the setup of a PMP Block within a Pipe Network. It is in the "FIRST_TRAVEL_SPEED" field in the parameter tab

3.1.14.5.2 Related Functions

"MLPmpReadAccel" (→ p. 208)

MLPmpReadFstSpd

"MLPmpReadInitPos" (→ p. 210)

"MLPmpReadJerk" (→ p. 211)

"MLPmpReadLstSpd" (→ p. 212)

"MLPmpWriteLstSpd" (→ p. 221)

3.1.14.5.3 Example

3.1.14.5.3.1 Structured Text

```
FirstSpeedValue := MLPmpReadFstSpd( PipeNetwork.PmpMaster ) ;
```

3.1.14.5.3.2 Ladder Diagram



3.1.14.5.3.3 Function Block Diagram



3.1.14.6 MLPmpReadInitPos



Function - Get the Initial Position parameter of a PMP block.

This value is the position the Pmpblock starts at when the Pipe Network is enabled. This position can be set when adding a Pmp Block to a Pipe Network and defining the parameters for that block.

3.1.14.6.1 Arguments

3.1.14.6.1.1 Input

BlockID	Description	ID Name of a PMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]

Unit	N/A
Default	—

3.1.14.6.1.2 Output

InitialPosition	Description	Present Initial Position of the PMP PipeNetwork Function Block
	Data type	LREAL
	Unit	User unit
	Default	Value defined in the setup of a PMP Block within a Pipe Network. It is in the "INITIAL_POSITION" field in the parameter tab.

3.1.14.6.2 Related Functions


"MLPmpInit" (→ p. 205)

3.1.14.6.3 Example


3.1.14.6.3.1 Structured Text

```
PmpInitPos := MLPmpReadInitPos ( PipeNetwork.PmpMaster ) ;
```

3.1.14.6.3.2 Ladder Diagram



3.1.14.6.3.3 Function Block Diagram



3.1.14.7 MLPmpReadJerk



Function - Get the Jerk parameter of a PMP block used in both the MLPmpAbs and MLPmpRel function block.

3.1.14.7.1 Arguments

3.1.14.7.1.1 Input

BlockID	Description	ID Name of a PMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.14.7.1.2 Output


Jerk	Description	Jerk of the PMP PipeNetwork Function Block
	Data type	LREAL
	Unit	User unit/sec ³
	Default	Value defined in the setup of a PMP Block within a Pipe Network. It is in the "JERK" field in the parameter tab.

3.1.14.7.2 Example


3.1.14.7.2.1 Structured Text

```
PmpJerkValue := MLPmpReadJerk( PipeNetwork.PmpMaster ) ;
```

3.1.14.7.2.2 Ladder Diagram



3.1.14.7.2.3 Function Block Diagram



3.1.14.8 MLPmpReadLstSpd



Function - Get the LastTravelSpeed parameter of a PMP block used in the MLPmpRel function block.

3.1.14.8.1 Arguments

3.1.14.8.1.1 Input

BlockID	Description	ID Name of a PMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.14.8.1.2 Output

LastTravelSpeed	Description	Last Travel Speed of the PMP PipeNetwork Function Block
	Data type	LREAL
	Unit	User unit/sec
	Default	Value defined in the setup of a PMP Block within a Pipe Network. It is in the "LAST_TRAVEL_SPEED" field in the parameter tab.

3.1.14.8.2 Related Functions

"MLPmpReadAccel" (→ p. 208)

"MLPmpReadFstSpd" (→ p. 209)

"MLPmpReadInitPos" (→ p. 210)


"MLPmpReadJerk" (→ p. 211)

3.1.14.8.3 Example


3.1.14.8.3.1 Structured Text

```
PmpLastSpeed := MLPmpReadLstSpd( PipeNetwork.PmpMaster ) ;
```

3.1.14.8.3.2 Ladder Diagram



3.1.14.8.3.3 Function Block Diagram



3.1.14.9 MLPmpRel



Function - used to perform two subsequent relative moves.

Using the MLPmpRel function block, the PMP Generator is capable of producing forward-backward motions with a non-stop, jerk-free transition through zero speed (see Figure below). This feature is frequently useful for linear axes which must move back and forward without any pause at one end.

This function can also be used to do a single relative move, ending in zero speed, by setting the **DeltaSecond** argument to zero (0.0). If it is done, for the controlling speed to be the first move, the "Last_Travel_Speed" parameter has to be set equal to or greater than the "First_Travel_Speed" parameter.

In general, the slower of the two "Speeds" is utilized to optimize the S-curve behavior for the move whether it is a 2 or 1 delta move.

If the DeltaSecond argument is non-zero, it must have the opposite sign than the sign of the DeltaFirst argument.




Figure 1-37: PMP Generator Forward & Backward Motion Profile

3.1.14.9.1 Arguments

3.1.14.9.1.1 Input

BlockID	Description	ID Name of the PMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
DeltaFirst	Description	Length of first Move
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	Value defined in the setup of a PMP Block within a Pipe Network. It is the "FIRST_TRAVEL_SPEED" field in the parameter tab.
DeltaSecond	Description	Length of second (return) Move
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	Value defined in the setup of a PMP Block within a Pipe Network. It is the "LAST_TRAVEL_SPEED" field in the parameter tab.

3.1.14.9.1.2 Output

Default (.Q)	Description	Returns True if the MLPmlRel successfully completed
	Data type	BOOL
	Unit	N/A

3.1.14.9.2 Related Functions

"MLPmpWriteAccel" ([→ p. 218](#))

"MLPmpWriteFstSpd" ([→ p. 219](#))

"MLPmpWriteJerk" ([→ p. 220](#))


"MLPmpWriteLstSpd" ([→ p. 221](#))

3.1.14.9.3 Example

3.1.14.9.3.1 Structured Text

```
//Execute a Relative move on a PMP Block name "PmpMaster" with a First
Travel Speed of 750.0, Second Travel Speed of -500,
MLPmpRel( PipeNetwork.PmpMaster, 750 , -500);
```

3.1.14.9.3.2 Ladder Diagram



3.1.14.9.3.3 Function Block Diagram



3.1.14.10 MLPmpRun

Pipe Network

Function - Jog the generator at the requested speed.

3.1.14.10.1 Arguments

3.1.14.10.1.1 Input

EN	Description	Enables FB to be executed. Is only recognized if the PMP generator is Idle or at constant velocity as determined from the " MLPmpStatus " (→ p. 216) function.
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
BlockID	Description	ID Name of the PMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Speed	Description	The desired rate at which to Jog. If the speed is 0.0 User Units / second the PMP block decelerates to zero speed and switches to the Idle state (0).
	Data type	LREAL
	Range	—
	Unit	User unit /sec
	Default	—

3.1.14.10.1.2 Output

Default (.Q)	Description	Returns True if the MLPmpRun successfully completed.
	Data type	BOOL
	Unit	N/A

3.1.14.10.2 Related Functions


"MLPmpStatus" (→ p. 216)

3.1.14.10.3 Example

3.1.14.10.3.1 Structured Text

```
//Execute a Relative move on a PMP Block name "PmpMaster" with a Jog speed of 1000.0
MLPmpRun( PipeNetwork.PmpMaster, 1000.0 ) ;
```

3.1.14.10.3.2 Ladder Diagram



3.1.14.10.3.3 Function Block Diagram



3.1.14.11 MLPmpStatus



Function - Returns the status of the PMP block generator.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.14.11.1 Arguments

3.1.14.11.1.1 Input

EN	Description	Enables FB to be executed.
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—

BlockID	Description	ID Name of the PMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.14.11.1.2 Output


OK	Description	Returns true when function successfully executes								
	Data type	BOOL								
	Unit	N/A								
Default (.Q)	Description	Returns the status of the PMP block generator								
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Indicates that the PMP block is idle. No command is currently running in the generator. It can be used to determine that a previous move is complete.</td> </tr> <tr> <td>1</td> <td>Indicates that the PMP block is either accelerating to a position or speed, or is decelerating to a position or speed.</td> </tr> <tr> <td>2</td> <td>Indicates that the PMP block is running at a constant speed.</td> </tr> </tbody> </table>	Value	Description	0	Indicates that the PMP block is idle. No command is currently running in the generator. It can be used to determine that a previous move is complete.	1	Indicates that the PMP block is either accelerating to a position or speed, or is decelerating to a position or speed.	2	Indicates that the PMP block is running at a constant speed.
Value	Description									
0	Indicates that the PMP block is idle. No command is currently running in the generator. It can be used to determine that a previous move is complete.									
1	Indicates that the PMP block is either accelerating to a position or speed, or is decelerating to a position or speed.									
2	Indicates that the PMP block is running at a constant speed.									
	Data type	DINT								
	Unit	N/A								

3.1.14.11.2 Example

3.1.14.11.2.1 Structured Text

```
PMP_Status := MLPmpStatus ( PipeNetwork.PmpMaster ) ;
Done := TRUE;
```

3.1.14.11.2.2 Ladder Diagram



3.1.14.11.2.3 Function Block Diagram



3.1.14.12 MLPmpWriteAccel

Pipe Network ✓

Function - Set the acceleration parameter of a PMP block.

Returns TRUE if the function succeeded.

Acceleration can also be set when adding a Pmp Block to a Pipe Network and defining the parameters for that block.

3.1.14.12.1 Arguments

3.1.14.12.1.1 Input

BlockID	Description	ID Name of the PMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Acceleration	Description	Acceleration Value
	Data type	LREAL
	Range	> 0
	Unit	User unit/sec ²
	Default	Value defined in the setup of a PMP Block within a Pipe Network. It is the "ACCELERATION" field the parameter tab.

3.1.14.12.1.2 Output

Default (.Q)	Description	Returns True if the function block is successfully executing
	Data type	BOOL
	Unit	N/A

3.1.14.12.2 Related Functions

"MLPmpAbs" (→ p. 202)

"MLPmpRel" (→ p. 213)

"MLPmpWriteFstSpd" (→ p. 219)

"MLPmpWriteJerk" (→ p. 220)


"MLPmpWriteLstSpd" (→ p. 221)

3.1.14.12.3 Example


3.1.14.12.3.1 Structured Text

```
MLPmpWriteAccel( PipeNetwork.PmpMaster, 40000.0 ) ;
```

3.1.14.12.3.2 Ladder Diagram



3.1.14.12.3.3 Function Block Diagram



3.1.14.13 MLPmpWriteFstSpd



Function - Set the FirstTravelSpeed parameter of a PMP block.

- Returns TRUE if the function succeeded.
- FirstTravelSpeed can also be set when adding a Pmp Block to a Pipe Network and defining the parameters for that block.

3.1.14.13.1 Arguments

3.1.14.13.1.1 Input

BlockID	Description	ID Name of the PMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
First Travel Speed	Description	First Travel Speed Value
	Data type	LREAL
	Range	> 0
	Unit	User unit/sec
	Default	Value defined in the setup of a PMP Block within a Pipe Network. It is the "FIRST_TRAVEL_SPEED" field in the parameter tab.

3.1.14.13.1.2 Output

Default (.Q)	Description	Returns True if the function block is successfully executing
---------------------	--------------------	--

Data type	BOOL
Unit	N/A

3.1.14.13.2 Related Functions

"MLPmpAbs" (→ p. 202)

"MLPmpRel" (→ p. 213)

"MLPmpWriteAccel" (→ p. 218)

"MLPmpWriteJerk" (→ p. 220)


"MLPmpWriteLstSpd" (→ p. 221)

3.1.14.13.3 Example


3.1.14.13.3.1 Structured Text

```
MLPmpWriteFstSpd( PipeNetwork.PmpMaster, 300.0 ) ;
```

3.1.14.13.3.2 Ladder Diagram



3.1.14.13.3.3 Function Block Diagram



3.1.14.14 MLPmpWriteJerk



Function - Set the jerk parameter of a PMP block.

- Returns TRUE if the function succeeded.
- Jerk can also be set when adding a Pmp Block to a Pipe Network and defining the parameters for that block.

3.1.14.14.1 Arguments

3.1.14.14.1.1 Input

BlockID	Description	ID Name of the PMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A

	Default	—
Jerk	Description	Jerk Value
	Data type	LREAL
	Range	> 0
	Unit	User unit/sec3
	Default	Value defined in the setup of a PMP Block within a Pipe Network. It is the "JERK" field in the parameter tab.

3.1.14.14.1.2 Output

Default (.Q)	Description	Returns True if the function block is successfully executing
	Data type	BOOL
	Unit	N/A

3.1.14.14.2 Related Functions

"MLPmpAbs" (→ p. 202)

"MLPmpReadJerk" (→ p. 211)

"MLPmpRel" (→ p. 213)

"MLPmpWriteAccel" (→ p. 218)

"MLPmpWriteFstSpd" (→ p. 219)

"MLPmpWriteLstSpd" (→ p. 221)

3.1.14.14.3 Example


3.1.14.14.3.1 Structured Text

```
MLPmpWriteJerk( PipeNetwork.PmpMaster, 15.0 ) ;
```

3.1.14.14.3.2 Ladder Diagram



3.1.14.14.3.3 Function Block Diagram



3.1.14.15 MLPmpWriteLstSpd

Pipe Network

 **Function** - Set the LastTravelSpeed parameter of a PMP block.

- Returns TRUE if the function succeeded.
- Last Travel Speed can also be set when adding a Pmp Block to a Pipe Network and defining the parameters for that block.

3.1.14.15.1 Arguments

3.1.14.15.1.1 Input

BlockID	Description	ID Name of the PMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Last Speed	Description	Last Travel Speed Value
	Data type	LREAL
	Range	> 0
	Unit	User unit/sec
	Default	Value defined in the setup of a PMP Block within a Pipe Network. It is in the "LAST_TRAVEL_SPEED" field in the parameter tab.

3.1.14.15.1.2 Output

Default (.Q)	Description	Returns True if the function block is successfully executing
	Data type	BOOL
	Unit	N/A

3.1.14.15.2 Related Functions

"MLPmpAbs" (→ p. 202)

"MLPmpReadLstSpd" (→ p. 212)

"MLPmpRel" (→ p. 213)

"MLPmpWriteAccel" (→ p. 218)

"MLPmpWriteFstSpd" (→ p. 219)


"MLPmpWriteJerk" (→ p. 220)

3.1.14.15.3 Example


3.1.14.15.3.1 Structured Text

```
MLPmpWriteLstSpd( PipeNetwork.PmpMaster, 650 ) ;
```

3.1.14.15.3.2 Ladder Diagram



3.1.14.15.3.3 Function Block Diagram



3.1.15 Motion Library - Sampler

Name	Description	Return type
"MLSmpConECAT" (→ p. 223)	Connects a sampler block to the specified CoE object in a PDO.	BOOL
"MLSmpConnect" (→ p. 226)	Connects a sampler block to a pipe network axis or pipe block.	BOOL
"MLSmpConPLCAxis" (→ p. 227)	Connects a sampler block to a PLCopen axis variable.	BOOL
"MLSmpConPNAxis" (→ p. 228)	Connects a sampler block to a Pipe Network axis variable.	BOOL
"MLSmpInit" (→ p. 230)	Initializes a sampler object.	BOOL

TIP

There is a delay when using an external encoder.
 The delay is five cycles:
 2 cycles to read the encoder from the AKD via EtherCAT,
 1 cycle for computing,
 2 cycles for sending the new position set point to the AKD).
 This lag error is speed proportional (5 cycles * speed).
 A Phaser block can be used to compensate for this lag.

3.1.15.1 MLSmpConECAT



Function - Connects a sampler block to the specified CoE object.

The CoE object must be included in a PDO for the specified EtherCAT device.

Using this function, you can use any EtherCAT data source as input for the specified sampler block.

What happens when the device providing the CoE Object for the Sampler block is removed?

The CoE object value will become zero if the EtherCAT device providing the CoE object for the Sampler block is removed using the "ECATDeviceAction" (→ p. 537) function block. The CoE object will automatically connect to the sampler block when the device is reconnected to the EtherCAT network.





Figure 1-38: MLSmpConECAT function

This function can also be programmed from within the PipeNetwork block. Simply right-click on the block and select **Properties**.



3.1.15.1.0.1 Related Function Blocks

"MLSmpConnect" (→ p. 226), "MLSmpInit" (→ p. 230)

3.1.15.1.1 Arguments

3.1.15.1.1.1 Input

BlockID	Description	ID Name of the Sampler function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
DeviceAddr	Description	The EtherCAT address of the slave device. The first node usually has the value '1001'. Alternately, you can use the members of the EtherCATCode structure to specify a device's address.
	Data type	INT
	Range	—
	Unit	N/A

	Default	—
Index	Description	The CoE index of the object to be connected with the Sampler block.
	Data Type	UINT
	Range	—
	Unit	N/A
	Default	—
SubIndex	Description	The CoE sub-index of the object to be connected with the Sampler block.
	Data Type	UINT
	Range	—
	Unit	N/A
	Default	—

3.1.15.1.1.2 Output

Default (.Q)	Description	Function block is operational
	Data type	BOOL
	Unit	N/A

3.1.15.1.1.3 Return Type


BOOL

3.1.15.1.2 Example


3.1.15.1.2.1 Structured Text

```
//Connect a Sampler pipe block named "EncoderMaster" to an ECAT Index
Object defined by variable "CoE_SubIndex" with the SubIndex defined by
variable "CoE_SubIndex", from a device with Ethercat Address defined by
"ECAT_Addr"
MLSmpConECAT(PipeNetwork.EncoderMaster, ECAT_Addr, CoE_Index, CoE_
SubIndex );
```

3.1.15.1.2.2 Ladder Diagram



3.1.15.1.2.3 Function Block Diagram



3.1.15.2 MLSmpConnect



Function - Connect a sampler to an axis or pipe block as a value source.
Returns TRUE if the function succeeded.

See Also

"MLSmpConECAT" (→ p. 223), "MLSmpInit" (→ p. 230), "MLSmpConPNAxis" (→ p. 228),
"MLSmpConPLCAxis" (→ p. 227)

3.1.15.2.1 Arguments

3.1.15.2.1.1 Input

BlockID	Description	ID Name of the SMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
PipeBlockID	Description	ID Name of the Pipe Block the sampler is connected to
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.15.2.1.2 Output

Default (.Q)	Description	Returns True if the Sampler is connected.
	Data type	BOOL
	Unit	N/A

3.1.15.2.1.3 Return Type


BOOL

3.1.15.2.2 Example

3.1.15.2.2.1 Structured Text

```
//Connect a Sampler pipe block named "EncoderMaster1" to a PipeNetwork
Axis block named AXIS1
MLSmpConnect( PipeNetwork.EncoderMaster1, PipeNetwork.AXIS1 ) ;
```

3.1.15.2.2.2 Ladder Diagram



3.1.15.2.2.3 Function Block Diagram



3.1.15.3 MLSmpConPLCAxis



Function - connects a sampler block to a specific variable from a PLCOpen Axis.




Figure 1-39: MLSmpConPLCAxis function

3.1.15.3.1 Arguments

3.1.15.3.1.1 Input

BlockID	Description	ID Name of the SMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
AxisID	Description	Name of a declared instance of the AXIS_REF library function (for more details, click here....)
	Data Type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—

Variable	Description	Variable to be connected to. You need to use one of the following Internal Defines : <ul style="list-style-type: none"> • MC_ACTUAL_POSITION • MC_COMMAND_POSITION • MC_NORMAL_COMMAND_POSITION • MC_SUPERIMPOSED_COMMAND_POSITION • MC_PHASE_COMMAND_POSITION
	Data Type	UINT
	Range	N/A (use available macros)
	Unit	N/A
	Default	—

3.1.15.3.1.2 Output

Default (.Q)	Description	Function block is operational
	Data type	BOOL
	Unit	N/A

3.1.15.3.1.3 Return Type


BOOL

3.1.15.3.2 Example

3.1.15.3.2.1 Structured Text

```
//Connect a Sampler pipe block named "SAMPLER" to a variable named "MC_ACTUAL_POSITION" from a PLCOpen Axis named Axis1.
MLSmpConPLCAxis( PipeNetwork.SAMPLER, Axis1, MC_ACTUAL_POSITION);
```

3.1.15.3.2.2 Ladder Diagram



3.1.15.3.2.3 Function Block Diagram



3.1.15.4 MLSmpConPNAxis



Function - connects a sampler block to a specific variable from a PipeNetwork Axis.




Figure 1-40: MLSmpConPNAxis function

3.1.15.4.1 Arguments

3.1.15.4.1.1 Input

BlockID	Description	ID Name of the SMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
AxisID	Description	ID Name of the Axis the sampler is connected to
	Data Type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Variable	Description	Variable to be connected to. You need to use one of the following Internal Defines : <ul style="list-style-type: none"> • ML_PIPE_POSITION • ML_REFERENCE_POSITION • ML_GENERATOR_POSITION • ML_ACTUAL_POSITION • ML_FEEDBACK_POSITION • ML_ACTUAL_VELOCITY • ML_ACTUAL_TORQUE • ML_FOLLOWING_ERROR • ML_CURRENT_POSITION
	Data Type	UINT
	Range	N/A (use available macros)
	Unit	N/A
	Default	—

3.1.15.4.1.2 Output

Default (.Q)	Description	Function block is operational
	Data type	BOOL
	Unit	N/A

3.1.15.4.1.3 Return Type


BOOL

3.1.15.4.2 Example

3.1.15.4.2.1 Structured Text

```
//Connect a sampler block named "SAMPLER" to a variable named ML_PIPE_POSITION from a Pipe Network Axis named PipeNetwork.AXIS1
MLSmpConPNAxis( PipeNetwork.SAMPLER , PipeNetwork.AXIS1, ML_PIPE_POSITION );
```

3.1.15.4.2.2 Ladder Diagram



3.1.15.4.2.3 Function Block Diagram



3.1.15.5 MLSmplnit



Function

is this a function or function block?


The purpose of the sampler block is to periodically sample and place into a pipe some output of a source object. The sampled output can typically be the POSITION or SPEED of a source object measured by a resolver, an encoder or some other types of sensor.

The sampler implements the logical connection between an encoder on a physical master axis (the source object) and one or more pipes and performs the function of periodically sampling the source and placing the sampled values into the pipe.

This function block is automatically called by the Function PipeNetwork(MLPN_CREATE_OBJECTS) if a Smp Block is added to the Pipe Network, with user-defined settings entered in the Pipe Blocks Properties screen.


The Smp Pipe Block is assigned a Name, SAMPLING_PERIOD, MODE, INPUT_VALUE_PERIOD and OUTPUT_VALUE_PERIOD.

This function can also be programmed from within the PipeNetwork block. Simply right-click on the block and select **Properties**.



Using AKD Secondary Feedback	Using AKD2G Additional Feedback
<ul style="list-style-type: none"> • The Sampler can be connected to the secondary feedback on the AKD using "MLSmpConPNAxis" (→ p. 228). • The scaling for the AKD Secondary Feedback is setup using AKD Parameters: DRV.HANDWHEEL and FB2.ENCRES. • The feedback signal comes through EtherCAT in object 0x2050. • The scaling for this position signal is 0 to 4294967296 = 0 to FB2.ENCRES. <ul style="list-style-type: none"> • Object 0x2050 rolls over to 0 when reaching 4294967296. 	<ul style="list-style-type: none"> • The Sampler can be connected to the additional feedback (1-5) on the AKD2G using "MLSmpConPNAxis" (→ p. 228). <ul style="list-style-type: none"> • See the AKD2G Feedback Settings section for setting up the additional feedback type and resolution. • The default feed constant value in the KAS IDE is scaled to 65536. <ul style="list-style-type: none"> • This feed constant value can be changed using EtherCAT object 0x60E9 subindex 1-5. • The feedback signal comes through EtherCAT in object 0x60E4 subindex 1-5.

Place a Phaser Block (and write "MLPhaWritePhase" (→ p. 199) in the application code) or Gear Block (and write "MLGearWriteOff" (→ p. 158)) after the Sampler Block to offset the Sampler Block Output Position in the PipeNetwork.



3.1.15.5.0.1 Related Function Blocks

"MLSmpConnect" (→ p. 226), "MLSmpConECAT" (→ p. 223), "MLSmpConPLCAxis" (→ p. 227), "MLSmpConPNAxis" (→ p. 228)

3.1.15.5.1 Arguments

3.1.15.5.1.1 Input


BlockID	Description	ID Name of the SMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
SamplingPeriod	Description	period that the device is sampled
	Data type	LREAL

	Range	0.25 to ?
	Unit	millisecond
	Default	1.0
Mode	Description	Sampled output can be either position or velocity
	Data type	DINT
	Range	[1 , 2] Position or Speed
	Unit	N/A
	Default	position
InputModuloPosition	Description	Period of the input signal. The value set depends upon the device used. <ul style="list-style-type: none"> • AKD: This should be set equal to 232 (4294967296.0) • AKD2G: The value should be set based on the feed constant value assigned in the EtherCAT object 0x60E4 subindex 1-5. The default feed constant value is 216 (65536)
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	360.0
OutputModuloPosition	Description	Period of the output signal
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	360.0


3.1.15.5.1.2 Output

Default (.Q)	Description	Smp Block successfully initiated
	Data type	BOOL
	Unit	N/A

3.1.15.5.2 FBD Language



3.1.15.5.3 FFLD Language



3.1.15.5.4 ST Language

```
//Initialize a Sampler Pipe Block named "EncoderMaster1" to a Sample
Period of 1 millisecc, Mode of Operation to 2(Velocity), Input Modulo of
4294967296, and Output Modulo of 720
MLSmpInit( PipeNetwork.EncoderMaster1, 1.0,2,4294967296,720);
```

3.1.16 Motion Library - Synchronizer

TIP


- See "Usage Example of Synchronizer Functions" (→ p. 233) for a Synchronizer example.

Name	Description	Return Type
"MLSynclnit" (→ p. 234)	Initializes a synchronizer Pipe Block.	BOOL
"MLSyncReadDeltaS" (→ p. 236)	Gets the output phasing value of a synchronizer block.	None
"MLSyncStart" (→ p. 238)	Starts a synchronization of a synchronizer Pipe Block.	BOOL
"MLSyncStop" (→ p. 239)	De-synchronizes a synchronizer Pipe Block.	BOOL
"MLSyncWriteDeltaS" (→ p. 240)	Sets the output phasing value of a synchronizer block.	BOOL

3.1.16.1 Usage Example of Synchronizer Functions

When you call the **MLSyncStop** function, the output value is adapted according to the specified Stop-Position (point B).

The OUTPUT_PHASING parameter is used to define point A, where the flow follows a curve in order to smooth the output value.



When you call the **MLSyncStart** function, the output value is adapted to catch up with the input value.

The **OUTPUT_PHASING** parameter is also used to define a curve in order to smooth the output value.




Figure 1-41: Synchronizer Functions Usage

3.1.16.2 MLSyncInit

Pipe Network ✓

Function - Initializes a synchronizer Pipe Block.
Returns TRUE if the function succeeded.

is this a function or function block?

This FB is automatically created in the compiled code of a Pipe Network.

This function block is part of the **MLPN_CREATE_OBJECT** to initialize the Pipe Network. It is called at the beginning of an application program with the function call:

```
PipeNetwork (MLPN_CREATE_OBJECTS) ;
```

3.1.16.2.1 Arguments

3.1.16.2.1.1 Input

BlockID	Description	Name of the Pipe Network Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
ModuloPosition	Description	The modulo distance
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
CurveType	Description	The curve type to the motion when starting and stopping synchronization. Option are Parabolic or Polynomial
	Data type	DINT
	Range	[1 , 2] (1 = Parabolic, 2 = Polynomial)
	Unit	n/a
	Default	—
DeltaS	Description	The Distance to get in or out of synchronization. This parameter is used in the MLSyncStart and MLSyncStop FunctionBlocks
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.1.16.2.1.2 Output

Default (.Q)	Description	Function Block Execute Successfully
	Data type	BOOL
	Unit	n/a

3.1.16.2.2 Related Functions

"MLSyncWriteDeltaS" ([→ p. 240](#))


3.1.16.2.3 Example

3.1.16.2.3.1 Structured Text

```
//Initialize a synchronizer Pipe Block named " SYN" with a modulo of
360, Curve Type of Parabolic, and a distance (DeltaS) of 30 to get in and
```

```
out of synchronization
MLSyncInit( PipeNetwork.SYN, 360, 1, 30 );
```

3.1.16.2.3.2 Ladder Diagram



3.1.16.2.3.3 Function Block Diagram



3.1.16.3 MLSyncReadDeltaS



Function - Gets the output phasing value of a synchronizer block.

Output phasing is the distance or the slope the output takes to synchronize with the input when MLSyncStart Block is executed (see "Get Output Phasing after MLSyncStart" (→ p. 236)). It also affects the distance or the slope the output takes to desynchronize with the input and come to a stop when MLSyncStop Block is executed (see "Get Output Phasing after MLSyncStop" (→ p. 237)).




Figure 1-42: Get Output Phasing after MLSyncStart




Figure 1-43: Get Output Phasing after MLSyncStop

3.1.16.3.1 Arguments

3.1.16.3.1.1 Input

BlockID	Description	Name of the Pipe Network Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

3.1.16.3.1.2 Output

DeltaS	Description	Present Delta Slope value
	Data type	LREAL
	Unit	User unit

3.1.16.3.2 Related Functions

"MLSyncWriteDeltaS" (→ p. 240)

3.1.16.3.3 Example


3.1.16.3.3.1 Structured Text

```
ActScope := MLSyncReadDeltaS( PipeNetwork.SYN );
```

3.1.16.3.3.2 Ladder Diagram



3.1.16.3.3 Function Block Diagram



3.1.16.4 MLSyncStart



Function - Start a synchronization of a synchronizer Pipe Block.
Returns TRUE if the function succeeded.




Figure 1-44: MLSyncStart

3.1.16.4.1 Arguments

3.1.16.4.1.1 Input

BlockID	Description	Name of the Pipe Network Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

3.1.16.4.1.2 Output

Default (.Q)	Description	Function Block Execute Successfully
	Data type	BOOL
	Unit	n/a

3.1.16.4.2 Example


3.1.16.4.2.1 Structured Text

```
MLSyncStart( PipeNetwork.SYN );
```

3.1.16.4.2.2 Ladder Diagram



3.1.16.4.2.3 Function Block Diagram



3.1.16.5 MLSyncStop



Function - De-synchronizes a synchronizer Pipe Block.
Returns TRUE if the function succeeded.




Figure 1-45: MLSyncStop

3.1.16.5.1 Arguments

3.1.16.5.1.1 Input

Position	Description	Motion Stop Position
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.1.16.5.1.2 Output


Default (.Q)	Description	Function Block Execute Successfully
	Data type	BOOL
	Unit	n/a

3.1.16.5.2 Example


3.1.16.5.2.1 Structured Text

```
MLSyncStop( PipeNetwork.SYN , 120 );
```

3.1.16.5.2.2 Ladder Diagram



3.1.16.5.2.3 Function Block Diagram



3.1.16.6 MLSyncWriteDeltaS



Function - Set the output phasing value of a synchronizer block.

Returns TRUE if the function succeeded.

Output phasing is the distance or the slope the output takes to synchronize with the input when MLSyncStart Block is executed. It also affects the distance or the slope the output takes to desynchronize with the input and come to a stop when MLSyncStop Block is executed.




Figure 1-46: Set output phasing after MLSyncStart




Figure 1-47: Set output phasing after MLSyncStop

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.16.6.1 Arguments

3.1.16.6.1.1 Input

BlockID	Description	Name of the Pipe Network Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
DeltaS	Description	Slope to be used during Start and stop of Synchronization

Data type	LREAL
Range	—
Unit	User unit
Default	—

3.1.16.6.1.2 Output


Default (.Q)	Description	Function Block Execute Successfully
	Data type	BOOL
	Unit	n/a

3.1.16.6.2 Example


3.1.16.6.2.1 Structured Text

```
MLSyncWriteDeltaS( PipeNetwork.SYN, 45 );
```

3.1.16.6.2.2 Ladder Diagram



3.1.16.6.2.3 Function Block Diagram



3.1.17 Motion Library - Trigger

TIP


- See "Usage Example of Trigger Functions" (→ p. 243) for an example of Trigger functions.

Name	Description	Return Type
"MLTrigClearFlag" (→ p. 244)	Clears the flag of an initiated Trigger block.	BOOL
"MLTrigInit" (→ p. 245)	Initializes a Trigger object.	BOOL
"MLTrigsTriggered" (→ p. 248)	Checks if the selected block has been triggered.	BOOL
"MLTrigReadDelay" (→ p. 250)	Returns the time that the trigger block uses to compensate the delay of the sensor that captures the triggering signal.	None
"MLTrigReadPos" (→ p. 250)	Returns the position of the block at the moment when it was triggered.	None


Name	Description	Return Type
"MLTrigReadTime" (→ p. 252)	Returns the time of the moment where the block was triggered in milliseconds.	None
"MLTrigSetEdge" (→ p. 254)	Sets the edge configuration for a Trigger object.	BOOL
"MLTrigWriteDelay" (→ p. 255)	Sets the time that the trigger block uses to compensate for the delay introduced by the sensor that captures the triggering signal.	BOOL

3.1.17.1 Usage Example of Trigger Functions

When you call the **MLTrigClearFlag** function, the flag for trigger is reset to False.



When a Fast Input is set, the **MLTrigIsTriggered** function returns TRUE.



Then you can call the **MLTrigReadPos** and **MLTrigReadTime** functions to get more details.




Figure 1-48: Trigger Functions Usage

⚠ IMPORTANT

The trigger delay must be calculated by **you** and set with the "MLTrigWriteDelay" (→ p. 255) function block. This delay belongs to the sensor and it is additional to the "MLTrigReadTime" (→ p. 252) / "MLTrigReadPos" (→ p. 250).

3.1.17.2 MLTrigClearFlag

Pipe Network ✓

Function - Clears the flag of an initiated Trigger block so the block can capture the position and time of the next event.

Once triggered, a block has to be reset with this command before it can be triggered again. All events that are sent to a block while in a triggered state are ignored and the position and time information is lost.

⚠ IMPORTANT

The Fast Input assigned to a Trigger block has to be reset as well before information on a new event can be captured. MLAxisRstFastIn is generally used at the same time as MLTrigClearFlag

NOTE

This function or function block returns cached data. See [Programming a Dual Core Controller](#) for more information.

3.1.17.2.1 Arguments

3.1.17.2.1.1 Input

BlockID	Description	ID number of an initiated Trigger object
	Data type	DINT
	Range	[-2147483648, 2147483648]

Unit	N/A
Default	—

3.1.17.2.1.2 Output

Default (.Q)	Description	Returns TRUE if function block is executed
	Data type	BOOL
	Unit	N/A

3.1.17.2.2 Return Type

BOOL

3.1.17.2.3 Related Functions

"MLAxisRstFastIn" (→ p. 95)

"MLTrigIsTriggered" (→ p. 248)

"MLTrigReadPos" (→ p. 250)

"MLTrigReadTime" (→ p. 252)

3.1.17.2.4 See Also


- [Fast Inputs with Pipe Network Motion](#)
- [Fast Homing Example with the Pipe Network Motion Engine Axis Pipe Block](#)
- [Fast Homing Example with the PLCopen Motion Engine](#)
- [Pipe Network Registration and Fast Homing](#)
- [Registration Position Capture Example with Pipe Network Trigger Block](#)

3.1.17.2.5 Example

3.1.17.2.5.1 Structured Text

```
//Clear Trigger Flag
MLTrigClearFlag( PipeNetwork.TRIGGER );
```

3.1.17.2.5.2 Ladder Diagram




3.1.17.2.5.3 Function Block Diagram



3.1.17.3 MLTrigInit

Pipe Network ✓

 **Function** - Initializes a Trigger object for use in a PLC Program.

Function block is automatically called if a Trigger Block is added to the Pipe Network, with user-defined settings entered in the Pipe Blocks Properties screen.

The Trigger object monitors a selected Fast Input and captures the time of a rising or falling edge event. With the time and pipe position information the Trigger object extrapolates the axis position when the Fast Input event occurred.

Parameters to enter include the name of the Pipe Block, the Axis where the Fast Input is located, the number of the desired Fast Input, and whether to trigger on the rising or falling edge of the input.

NOTE

Trigger objects are normally created in the Pipe Network using the graphical engine. Then you do not have to add MLTrigInit function blocks to their programs. Parameters are entered directly in pop-up windows, and the code is then automatically added to the current project.

3.1.17.3.1 Arguments

3.1.17.3.1.1 Input

BlockID	Description	ID number of a created Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Input_Axis	Description	Name of the axis where the Fast Input is located
	Data type	STRING
	Range	—
	Unit	N/A
	Default	—
InputID	Description	ID number of the Fast Input <ul style="list-style-type: none"> • InputIDDINT <ul style="list-style-type: none"> • 0 = Touch Probe 1 / Capture Engine 0 • 1 = Touch Probe 2 / Capture Engine 1 • Range is [0,1]
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

EdgeID	Description	Trigger at rising or falling edge of Fast Input. Enter 1 for rising edge, 2 for falling edge, and 0 disables the Fast Input
	Data type	DINT
	Range	[0 , 2]
	Unit	N/A
	Default	1 (Rising edge)

3.1.17.3.1.2 Output

Default (.Q)	Description	Returns TRUE if function block is executed
	Data type	BOOL
	Unit	N/A

3.1.17.3.1.3 Return Type

BOOL

3.1.17.3.2 Related Functions

"MLTrigIsTriggered" (→ p. 248)

"MLTrigReadPos" (→ p. 250)

"MLTrigClearFlag" (→ p. 244)

"MLAxisRstFastIn" (→ p. 95)

3.1.17.3.3 See Also


- [Fast Inputs with Pipe Network Motion](#)
- [Fast Homing Example with the Pipe Network Motion Engine Axis Pipe Block](#)
- [Fast Homing Example with the PLCopen Motion Engine](#)
- [Pipe Network Registration and Fast Homing](#)
- [Registration Position Capture Example with Pipe Network Trigger Block](#)

3.1.17.3.4 Example


3.1.17.3.4.1 Structured Text

```
//Create and Initiate a Trigger Pipe Block named "Trigger" and set it up
to receive the trigger signal from Axis1, capture engine 0, and the
rising edge of the signal
TRIGGER := MBlkCreate( 'TRIGGER', 'TRIGGER' );
MLTrigInit( TRIGGER, 'Axis1', 0, 1 );
```

3.1.17.3.4.2 Ladder Diagram



3.1.17.3.4.3 Function Block Diagram




3.1.17.4 MLTrigsTriggered

Pipe Network ✓

Function - Checks if the selected block has been triggered.

When a block has been triggered, it contains the time and position when a Fast Input event occurred. The application has to reset the block before the block can be triggered again. All trigger events that are sent to the block during its triggered state are lost.



NOTE

Once triggered, a block has to be reset before it can be triggered again. All events that are sent to a block while in a triggered state are ignored and the position and time information is lost.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.1.17.4.1 Arguments**3.1.17.4.1.1 Input**

BlockID	Description	ID number of an initiated Trigger object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.17.4.1.2 Output

Default (.Q)	Description	Returns TRUE if the selected Trigger Object has Triggered
	Data type	BOOL
	Unit	N/A

3.1.17.4.1.3 Return Type

BOOL

3.1.17.4.2 Related Functions

"MLTrigReadPos" (→ p. 250)

"MLTrigReadTime" (→ p. 252)

3.1.17.4.3 See Also

- [Fast Inputs with Pipe Network Motion](#)
- [Fast Homing Example with the Pipe Network Motion Engine Axis Pipe Block](#)
- [Fast Homing Example with the PLCopen Motion Engine](#)
- [Pipe Network Registration and Fast Homing](#)
- [Registration Position Capture Example with Pipe Network Trigger Block](#)


3.1.17.4.4 Example


```
//Check if a Trigger Block has been triggered, then save position
```

```
IF MLTrigIsTriggered( PipeNetwork.TRIGGER ) THEN
```

```
Trig_Position := MLTrigReadPos( PipeNetwork.TRIGGER );
```

```
END_IF
```

3.1.17.4.4.1 Ladder Diagram**3.1.17.4.4.2 Function Block Diagram**



3.1.17.5 MLTrigReadDelay



Function - returns the delay that has been programmed in a trigger block by the [MLTrigWriteDelay](#) function to compensate for this reaction time required by the sensor.

Electronic sensors are not able to respond immediately to a signal. Sensors usually require a certain amount of time to process a change of state in their input signal.

3.1.17.5.0.1 Input

BlockID	Description	Identifier of the trigger block whose delay is requested
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
En	Description	Enables execution
	Data type	BOOL
	Unit	N/A
	Default	-

3.1.17.5.0.2 Output

Delay	Description	Value of the delay compensation currently applied by the trigger block
	Data type	LREAL
	Unit	microseconds
OK	Description	Returns true when the function successfully executes
	Data type	BOOL
	Unit	N/A

3.1.17.5.1 Related Functions

["MLTrigWriteDelay"](#) (→ p. 255)

3.1.17.5.2 See Also

- [Fast Inputs with Pipe Network Motion](#)
- [Fast Homing Example with the Pipe Network Motion Engine Axis Pipe Block](#)
- [Fast Homing Example with the PLCopen Motion Engine](#)
- [Pipe Network Registration and Fast Homing](#)
- [Registration Position Capture Example with Pipe Network Trigger Block](#)


3.1.17.6 MLTrigReadPos

Pipe Network ✓

Function - Returns the modulo-applied position of the pipe at the moment it is triggered by the Trigger Block's selected Fast Input.

This value is only valid when TrigIsTriggered() returns TRUE. The Trigger block extrapolates the output value based on the timestamp of the Fast Input event to provide an accurate position even if the event occurs in the middle of a program cycle.

Once triggered, a block has to be reset before it can be triggered again. All events that are sent to a block while in a triggered state are ignored and the position and time information is lost.



Modulo Calculation: MLTrigReadPos uses the “Output Modulo Position” value of the previous block in the pipe, even if the previous pipe is configured for “No Modulo” mode. The previous block must specify a zero value for “Output Modulo Position” before setting the “Mode” to “No Modulo” to prevent a modulo operation for MLTrigReadPosPipe.

NOTE
 This function or function block returns cached data.
 See [Programming a Dual Core Controller](#) for more information.

3.1.17.6.1 Arguments

3.1.17.6.1.1 Input

BlockID	Description	ID number of an initiated Trigger object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.17.6.1.2 Output

Position	Description	Returns the position of the selected block's Axis at the moment when it was triggered
	Data type	LREAL
	Unit	User unit

3.1.17.6.2 Related Functions

"MLTrigIsTriggered" (→ p. 248)

"MLTrigReadTime" (→ p. 252)

"MLTrigClearFlag" (→ p. 244)

"MLAxisRstFastIn" (→ p. 95)

3.1.17.6.3 See Also

- [Fast Inputs with Pipe Network Motion](#)
- [Fast Homing Example with the Pipe Network Motion Engine Axis Pipe Block](#)
- [Fast Homing Example with the PLCopen Motion Engine](#)
- [Pipe Network Registration and Fast Homing](#)
- [Registration Position Capture Example with Pipe Network Trigger Block](#)

3.1.17.6.4 Previous Function Name


MLTrigGetPos

3.1.17.6.5 Example


3.1.17.6.5.1 Structured Text

```
//Save position of Axis when Fast Input event occurs
Trig_Position := MLTrigReadPos( PipeNetwork.TRIGGER );
```

3.1.17.6.5.2 Ladder Diagram



3.1.17.6.5.3 Function Block Diagram



3.1.17.7 MLTrigReadTime




Function - Returns the time of the moment where the block was triggered in milliseconds.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

This value is only valid when TrigIsTriggered() returns TRUE. The output is computed from the timestamp of a Fast Input time event

Once triggered, a block has to be reset before it can be triggered again. All events that are sent to a block while in a triggered state are ignored and the position and time information is lost.



3.1.17.7.1 Arguments

3.1.17.7.1.1 Input

BlockID	Description	ID number of an initiated Trigger object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

3.1.17.7.1.2 Output

Time	Description	Returns the time that the Trigger Block's selected Fast Input was triggered
	Data type	LREAL
	Unit	milliseconds

3.1.17.7.2 Related Functions

"MLTrigIsTriggered" (→ p. 248)

"MLTrigReadPos" (→ p. 250)

"MLTrigClearFlag" (→ p. 244)

"MLAxisRstFastIn" (→ p. 95)

3.1.17.7.3 See Also

- [Fast Inputs with Pipe Network Motion](#)
- [Fast Homing Example with the Pipe Network Motion Engine Axis Pipe Block](#)
- [Fast Homing Example with the PLCopen Motion Engine](#)
- [Pipe Network Registration and Fast Homing](#)
- [Registration Position Capture Example with Pipe Network Trigger Block](#)

3.1.17.7.4 Previous Function Name


MLTrigGetTime

3.1.17.7.5 Example


//Save time when Fast Input event occurs

Trig_Time := MLTrigReadTime(PipeNetwork.TRIGGER);

3.1.17.7.5.1 Ladder Diagram



3.1.17.7.5.2 Function Block Diagram



3.1.17.8 MLTrigSetEdge



Function - Sets the edge configuration (rising, falling, etc.) for a trigger block.

This block should be called prior to calling "MLAxisCfgFastIn" (→ p. 55). Also the value at the Edge input must match the value at MLAxisCfgFastIn's Mode input.

3.1.17.8.1 Arguments

3.1.17.8.1.1 Input

BlockID	Description	Identifier of the trigger block
	Data type	DINT
	Range	[-2147483648, 2147483647]
	Unit	N/A
	Default	—
Edge	Description	The edge on which to trigger 0 = disable the fast input 1 = rising edge 2 = falling edge
	Data type	DINT
	Range	[0,2]
	Unit	N/A
	Default	1 (rising edge)

3.1.17.8.1.2 Output

Q	Description	True if block executed successfully False if execution is not successful
	Data type	BOOL
	Unit	N/A

3.1.17.8.1.3 Return Type


BOOL

3.1.17.8.2 See Also


- [Fast Inputs with Pipe Network Motion](#)
- [Fast Homing Example with the Pipe Network Motion Engine Axis Pipe Block](#)
- [Fast Homing Example with the PLCopen Motion Engine](#)
- [Pipe Network Registration and Fast Homing](#)
- [Registration Position Capture Example with Pipe Network Trigger Block](#)

3.1.17.8.3 Examples

3.1.17.8.3.1 Function Block Diagram



3.1.17.8.3.2 Ladder Diagram



3.1.17.8.3.3 Structured Text

```
TrigEdgeChanged := MLTrigSetEdge(TrigBlockID,TrigEdge);
```

3.1.17.9 MLTrigWriteDelay



Function - allows the trigger block to calculate the exact moment at which a signal was triggered by letting you specify the compensation.

Electronic sensors are not able to respond immediately to a signal. Sensors usually require a certain amount of time to process a change of state in their input signal.

The delay compensation should include drive processing time, sensor delay, and the communication latency through the EtherCAT network.

3.1.17.9.1 Arguments

3.1.17.9.1.1 Input

BlockID	Description	Identifier of the trigger block
----------------	--------------------	---------------------------------

	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
Delay	Description	Reaction time of the sensor that the trigger block has to compensate
	Data type	LREAL
	Range	—
	Unit	microseconds
	Default	—

3.1.17.9.1.2 Output

Default (.Q)	Description	Returns TRUE if the delay is successfully set
	Data type	BOOL
	Unit	N/A

3.1.17.9.1.3 Return Type

BOOL

3.1.17.9.2 Related Functions

"MLTrigReadDelay" ([→ p. 250](#))

3.1.17.9.3 See Also

- [Fast Inputs with Pipe Network Motion](#)
- [Fast Homing Example with the Pipe Network Motion Engine Axis Pipe Block](#)
- [Fast Homing Example with the PLCopen Motion Engine](#)
- [Pipe Network Registration and Fast Homing](#)
- [Registration Position Capture Example with Pipe Network Trigger Block](#)

3.2 Motion Library - PLCopen

Name	Description
MC_AbortTrigger	Abort MC_TouchProbe
"MC_AddSuperAxis" (→ p. 392)	Add an axis to the axis's list of assigned, superimposed axes.
MC_CamIn	Performs a slave axis move based on the Cam Table
MC_CamOut	Disengages the slave axis from a MC_CamIn move
"MC_CamResumePos" (→ p. 341)	Returns the slave axis position for resuming an MC_CamIn move
"MC_CamStartPos" (→ p. 343)	Returns the slave axis position for starting an MC_CamIn move
MC_CamTblSelect	Defined to read and initialize the specified profile
MC_ClearFaults	Clear Drive Faults

Name	Description
"MC_CreatePLCAxis" (→ p. 259)	Creates a PLCopen Axis
MC_EStop	Performs a Emergency stop
"MC_ErrorDescription" (→ p. 396)	Converts the PLCopen error IDs into message strings.
MC_GearIn	Performs a slave axis move based on the ratio
MC_GearInPos	Performs a slave axis move based on the ratio
MC_GearOut	Disengages the slave axis from a MC_GearIn or MC_GearInPos move
MC_Halt	Decelerates an axis to zero velocity
MC_InitAxis	Initializes a PLCopen Axis' data
"MC_InitAxisFeedback" (→ p. 267)	Initializes a PLCopen Digitizing Axis' position data
MC_MachRegist	Runs Mark-to-Machine registration
MC_MarkRegist	Runs Mark-to-Mark registration
MC_MoveAbsolute	Performs a single-axis move to a specified endpoint position
MC_MoveAdditive	Performs a single-axis move for a specified distance from the endpoint of the previous move
"MC_MoveRelative" (→ p. 313)	Performs a single-axis move for a specified distance
MC_MoveSuperimp	Performs a single-axis move which is superimposed upon the active move
MC_MoveVelocity	Performs a single-axis non-ending move at a specified velocity
MC_Phasing	Performs a master position phase shift for the slave axis
MC_Power	Requests to enable the drive and close the loop, or disable the drive and open the loop
MC_ReadActPos	Reads the actual position of the axis
MC_ReadActVel	Reads the actual velocity of the axis
MC_ReadAxisErr	Returns the error status of the specified axis
MC_ReadBoolPar	Returns the value of the specified Boolean axis parameter
MC_ReadParam	Returns the value of the specified axis parameter
MC_ReadStatus	Returns the state of the specified axis
MC_Reference	Defines the position at the reference location for PLCopen Axis
"MC_RemSuperAxis" (→ p. 394)	Remove an axis from the axis's list of assigned, superimposed axes.
MC_ResetError	Resets the errors of the specified axis
MC_SetOverride	Writes velocity and acceleration override factors
MC_SetPosition	Deprecated by "MC_SetPos" (→ p. 373)

Name	Description
"MC_SetPos" (→ p. 373)	Sets a new axis position
MC_Stop	Aborts the active move, removes the next move from the queue, performs a controlled stop, and switches the axis to Stopping state
MC_StopRegist	Turns off registration for the specified axis
MC_SyncSlaves	Specifies synchronized slaves
MC_TouchProbe	Arm a Fast Input and capture an axis position
MC_WriteBoolPar	Writes the specified axis Boolean parameter
MC_WriteParam	Writes the specified axis parameter.

3.2.1 Control Functions

This set of functions provide general controls to drives and axes.

3.2.1.1 MC_ClearFaults




Function - sends a request to the drive to clear any drive faults that exists.

NOTE

The condition causing the drive fault has to be corrected before calling this function. If the fault condition still exists when this function is called, this function sends a request to the drive but the drive faults remain.

TIP

This function does **not** reset axis errors. [MC_ResetError](#) is required to reset axis errors and possibly to re-enable or turn power on to the servo axis after the fault condition is cleared.



MC_ClearFaults

NOTE

This function or function block returns cached data. See [Programming a Dual Core Controller](#) for more information.

3.2.1.1.1 Arguments

3.2.1.1.1.1 Input

En	Description
	Function enable – execute function. This Input must be on shot.
	Data type BOOL
	Range 0, 1

	Unit	N/A
	Default	—
Axis	Description	AXIS_REF.AXIS_NUM is the master axis number.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—

3.2.1.1.1.2 Output

OK	Description	Boolean output to indicate successful request. This output does not indicate that the fault are cleared, but simply indicates the request was made.
	Data type	BOOL

3.2.1.1.2 Usage

Upon the positive transition of the EN input, this function requests a Fault Reset of the Drive for the Axis defined in the axis input of this function.

3.2.1.1.3 Related Functions

[MC_ResetError](#)

3.2.1.1.4 Example


3.2.1.1.4.1 Structured Text

```
(* MC_ClearFaults ST example *)
MC_ClearFaults( Axis1); //clear drive faults for Axis 1
```

3.2.1.1.4.2 Function Block Diagram



3.2.1.1.4.3 Ladder Diagram



3.2.1.2 MC_CreatePLCAxis



Function - creates a PLCopen Axis.

A call to this function is automatically generated when the application is compiled, based on the data entered in the PLCopen Axis Data dialog.

⚠ IMPORTANT

MC_CreateAxis must be called between "MLMotionInit" (→ p. 414) and "MLMotionStart" (→ p. 417).

3.2.1.2.1 Arguments

3.2.1.2.1.1 Input

En	Description	Requests to create a PLCopen axis
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	No default
AxisName	Description	Axis name
	Data type	STRING
	Range	—
	Unit	N/A
	Default	—
BusInterface	Description	Bus interface identifier: "EtherCATDriver" = EtherCAT interface "MSBusDriver" = KAS Simulator interface
	Data type	STRING
	Range	—
	Unit	N/A
	Default	—
BusAddress	Description	Address of the drive on the bus
	Data type	DINT
	Range	bus dependent
	Unit	N/A
	Default	—
AxisNumber	Description	Axis number
	Data type	UINT
	Range	[1,256]
	Unit	N/A
	Default	—

AxisType	Description	0	MC_AXIS_TYPE_SERVO_STEPPER	A Servo or Stepper axis can be mapped to a physical or simulated drive. Either a servo or stepper drive is supported.
		1	MC_AXIS_TYPE_DIGITIZING	A digital position input from a drive or other device. It is useful as an input for gearing, camming, etc.
		2	MC_AXIS_TYPE_VIRTUAL	A virtual axis cannot be mapped to a physical or simulated drive. It is useful for generating motion trajectory as an input for gearing, camming, etc.
	Data Type	USINT		
	Range	[0,1]		
	Unit	N/A		
	Default	—		
DriveAxisNumber	Description	This one-based number specifies the axis on the drive. For a single-axis drive this number should be 1.		
	Data type	UINT		
	Range	[1,256]		
	Unit	N/A		
	Default	—		
UserUnits	Description	User unit portion of the user unit/feedback unit ratio		
	Data type	DINT		
	Range	[1, 2147483647]		
	Unit	User unit		
	Default	—		
FeedbackUnits	Description	Feedback unit portion of the user unit/feedback unit ratio		
	Data type	DINT		
	Range	[1, 2147483647]		
	Unit	Feedback units		
	Default	—		
Rollover	Description	Rollover position (0 = no rollover)		
	Data type	LREAL		
	Range	[0, 4294967296]		
	Unit	User unit		
	Default	—		

UpdateRate	Description	Servo update rate (0, 1, and 2 are reserved for future enhancements) 3 = 125 µsec 4 = 250 µsec 5 = 500 µsec 6 = 1 msec 7 = 2 msec 8 = 4 msec 9 = 8 msec
	Data type	UINT
	Range	[3,9]
	Unit	N/A
	Default	—

3.2.1.2.1.2 Output


OK	Description	Indicates the axis has been created.
	Data type	BOOL

3.2.1.2.2 Example


3.2.1.2.2.1 Structured Text

```
(* MC_CreatePLCAxis ST Example *)
AxisName1      := 'PLCOpenAxis1';
BusName1       := 'EtherCATDriver';
BusAddress1    := 1001;
AxisNumber1    := 1;
AxisType1      := MC_AXIS_TYPE_SERVO_STEPPER;
DriveAxisNumber1 := 1;
UserUnits1     := 360;
FeedbackUnits1 := 1048576;
Rollover1      := 0;
UpdateRate1    := 3;
MC_CreateAxis(AxisName1, BusName1, BusAddress1, AxisNumber1, AxisType1,
DriveAxisNumber1, UserUnits1, FeedbackUnits1, Rollover1, UpdateRate1);
```

3.2.1.2.2.2 Function Block Diagram



3.2.1.2.2.3 Ladder Diagram



3.2.1.3 MC_EStop



Function - causes an emergency stop (E-stop).

An E-stop stops motion interpolation, clear all moves from the queue (active and next), change the axis state to **ErrorStop**, and request the drive to open the position loop and disable the drive. The E-stop remains in effect until the application calls **MC_ResetError** to reset the E-stop.



MC_EStop

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.2.1.3.1 Arguments

3.2.1.3.1.1 Input

En	Description	A positive transition of this input causes an E-stop on the specified axis
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Axis identifier
	Data type	AXIS_REF
	Range	1-256 The AXIS_NUM element of the AXIS_REF structure must be in the range [1-256]
	Unit	N/A
	Default	—

3.2.1.3.1.2 Output

OK	Description	Indicates the E-stop was executed. If an invalid Axis input was specified, this output is not energized and no E-stop is performed.
	Data type	BOOL

3.2.1.3.2 Usage

Call MC_EStop to generate an emergency stop for an axis.

Call "MC_ResetError" (→ p. 273) to reset the emergency stop.

3.2.1.3.3 Related Functions


"MC_ResetError" (→ p. 273)

3.2.1.3.4 Example


3.2.1.3.4.1 Structured Text

```
(* MC_EStop ST example *)
ON EStopButton DO
MC_EStop( Axis1 );
MC_EStop( Axis2 );
END_DO;
```

3.2.1.3.4.2 Function Block Diagram



3.2.1.3.4.3 Ladder Diagram



3.2.1.4 MC_InitAxis



Function - initializes a PLCopen Axis' data.

A call to this function is automatically generated when the application is compiled, based on the data entered in the PLCopen Axis Data dialog.

En	MC_InitAxis	OK
AxisNumber		
VelocityLimit		
LowerLimit		
UpperLimit		
LimitControl		
PosErrorLimit		
InPositionBand		

MC_InitAxis

3.2.1.4.1 Arguments

3.2.1.4.1.1 Input

En	Description	Request to initialize a PLCopen axis
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxisNumber	Description	Axis number
	Data type	UINT
	Range	[1,256]
	Unit	none
	Default	—
VelocityLimit	Description	<i>Reserved for future use</i>
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—
LowerLimit	Description	<i>Reserved for future use</i>
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
UpperLimit	Description	<i>Reserved for future use</i>
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

LimitControl	Description	<i>Reserved for future use</i>
	Data type	UINT
	Range	[0,2]
	Unit	N/A
	Default	—
PosErrorLimit	Description	Position error limit – when the Position Error (command position – actual position) exceeds this value, an E-stop is generated
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
InPositionBand	Description	In-position bandwidth – when the axis actual position is within this distance from its programmed endpoint, the axis is considered “in position”
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.2.1.4.1.2 Output


OK	Description	Indicates the initialization is complete.
	Data type	BOOL

3.2.1.4.2 Example


3.2.1.4.2.1 Structured Text

```
(* MC_InitAxis ST example *)
AxisNumber1      := 1;
VelocityLimit1   := 10000; (*User unit/second*)
LowerPosLimit1   := 0;
UpperPosLimit1   := 0;
LimitControl1    := 0; (* Ignore lower and upper pos limit*)
PosErrorLimit1   := 10; (*User unit*)
InPosBand1       := 0;
MC_InitAxis(AxisNumber1, VelocityLimit1, LowerPosLimit1, UpperPosLimit1,
LimitControl1, PosErrorLimit1, InPosBand1);
```

3.2.1.4.2.2 Function Block Diagram



3.2.1.4.2.3 Ladder Diagram



3.2.1.5 MC_InitAxisFeedback



Function - initializes a PLCopen Digitizing Axis position data.

A call to this function is automatically generated when the application is compiled, based on the data entered in the PLCopen Axis Data dialog.




Figure 1-49: MC_InitAxisFeedback

3.2.1.5.1 Arguments

3.2.1.5.1.1 Input

En	Description	Request to Initialize a PLCopen Digitizing Axis. This input is only applicable to FFLD programs.
	Data type	BOOL
	Range	0,1
	Unit	N/A
	Default	-

AxisNumber	Description	Digitizing Axis Number
	Data type	UINT
	Range	[1,256]
	Unit	none
	Default	-
FeedbackPDOIndex	Description	The object Index through which the feedback data is sent.
	Data type	UINT
	Range	[0,65536]
	Unit	N/A
	Default	-
FeedbackPDOSubIndex	Description	The sub index of the object through which the feedback data is sent to controller.
	Data type	UINT
	Range	[0,255]
	Unit	
	Default	
FeedbackDataResolution	Description	The resolution of the Encoder
	Data type	UINT
	Range	[1,32]
	Unit	N/A
	Default	-

3.2.1.5.1.2 Output

OK	Description	Indicates the initialization is complete. This output is only applicable to FFLD programs.
	Data type	BOOL
ErrorID	Description	Indicates if the call failed or succeeded. If the call succeeds, will be set to 0.
	Data type	DINT

3.2.1.5.2 Example


3.2.1.5.2.1 Structured Text

```
(* MC_InitAxisFeedback ST example *)
// Initialize the digitizing Axis (Axis #3) with the Feedback object
0x60E4 subIndex 2.
```

```

coder resolution is 25bits.
rID := MC_InitAxisFeedback(3, 16#60E4, 16#02, 25);
    
```

3.2.1.5.2.2 FBD Example



3.2.1.6 MC_Power



- This function block requests to enable the drive and close the position loop, or disable the drive and open the position loop. The Status output indicates the state of the position loop. If the position loop is open, the axis command position is set to the actual position of the axis and tracks the actual position.




Figure 1-50: MC_Power

NOTE
 You must be careful if you have more than one instance of MC_Power FB for the same drive, scanned in the same cycle. The problem arises when one instance requests the drive to enable and the other requests the same drive to disable. To avoid this trap, it is recommended to have only one instance of MC_Power for all of your active programs.

NOTE
 This function or function block returns cached data. See [Programming a Dual Core Controller](#) for more information.

3.2.1.6.1 Arguments

3.2.1.6.1.1 Input

Enable	Description
	When this transitions go to high, the control closes the servo loop and sends a command to the drive to enable . When this transitions go to low, the control opens the servo loop and sends a command to the drive to disable .

	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
Enable Positive	Description	<i>for future enhancement</i>
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Enable Negative	Description	<i>for future enhancement</i>
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
BufferMode	Description	Unused
	Data type	SINT
	Range	[0]
	Unit	N/A
	Default	—

3.2.1.6.1.2 Output

Status	Description	Indicates the enabled/disabled state of the drive
	Data type	BOOL
Busy	Description	for future enhancement – always false
	Data type	BOOL
Error	Description	Indicates an invalid input was specified
	Data type	BOOL

ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT


3.2.1.6.2 Example

3.2.1.6.2.1 Structured Text

```
(* MC_Power ST example *)
Inst_MC_Power( CloseLoopReq, Axis1, TRUE, TRUE, 0 );
//Inst_MC_Power is an instance of MC_Power function block
DriveIsOn := Inst_MC_Power.Status; //store the Status output
into a user defined variable
```

3.2.1.6.2.2 Ladder Diagram

Close the servo loop and enable the drive when CloseLoop is high.
Open the servo loop and disable the drive when CloseLoop is low.



3.2.1.7 MC_ErrorDescription

PLCopen
 Pipe Network

Function - converts the PLCopen error IDs into message strings which can be used for display or logging.




Figure 1-51: MC_ErrorDescription Function Block

3.2.1.7.1 Arguments

3.2.1.7.1.1 Inputs

En	Description	If True, then this function will convert the Error Id into a string message
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
ErrorID	Description	Error ID generated from a PLCopen Function Block. See PLCopen Function Block ErrorID Output for output details.
	Data type	INT
	Range	0,69
	Unit	N/A
	Default	—

3.2.1.7.1.2 Outputs

OK	Description	If True, then the command completed successfully.
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Description	Description	String error description
	Data type	STRING
	Range	—
	Unit	N/A
	Default	—

3.2.1.7.2 Examples

3.2.1.7.2.1 Structured Text

```

Description:= MC_ErrorDescription(ErrorID);
    
```


3.2.1.7.2.2 IL

Not applicable

3.2.1.7.2.3 Function Block



3.2.1.7.2.4 Ladder Diagram



3.2.1.8 MC_ResetError



3.2.1.8.1 Description

Function - resets the errors of a specified axis.

This function performs these tasks in sequence:

1. Sends a request to the drive to clear any drive faults that exists
2. Resets the axis errors

NOTE
The condition causing the axis error has to be corrected before calling this function. The axis error still remains until the error condition exists when this function is called.

See also transition 15 in the status machine of the CANopen protocol.




Figure 1-52: MC_ResetError

NOTE
This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.2.1.8.2 Arguments

3.2.1.8.2.1 Input

En	Description	Requests to reset the axis errors
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—

3.2.1.8.2.2 Output

OK	Description	Indicates the function has completed successfully.
	Data type	BOOL


3.2.1.8.3 Example

3.2.1.8.3.1 Structured Text

```
//reset the axis and drive errors for Axis 1

MC_ResetError( Axis1 );
```

3.2.1.8.3.2 Ladder Diagram



3.2.1.9 MC_Stop PLCopen

3.2.1.9.1 Description

This function block aborts the active move, removes the next move from the queue, performs a controlled stop at the specified deceleration rate, and switches the axis to Stopping state.

MC_Stop cannot be aborted. This means that, while in Stopping state, no function block can command any motion on the axis. The axis remains in Stopping state until it reaches zero velocity and the Execute input is low. The application program can hold the axis in Stopping state even after it reaches zero velocity by leaving the Execute input high.

MC_Stop	
Execute	Done
Axis	Busy
Deceleration	Active
Jerk	Error
	ErrorID


Figure 1-53: MC_Stop

3.2.1.9.2 Time Diagram

The example below shows the behavior of the combination of a MC_Stop FB with a [MC_MoveVelocity](#) FB.

- A rotating axis is ramped down with FB2 MC_Stop
- The axis rejects motion commands as long as MC_Stop parameter "Execute" = TRUE

FB1 MC_MoveVelocity reports an error indicating the busy MC_Stop command.



NOTE
 This function block starts a motion-related action and therefore stores data for calculations and error checking.
 See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.1.9.3 Arguments

3.2.1.9.3.1 Input

Execute	Description	Requests to stop the axis. It can be held high to prevent any other moves from being queued
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Maximum deceleration
	Data type	LREAL
	Range	—

	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—

3.2.1.9.3.2 Output

Done	Description	Indicates the axis has reached zero velocity AND the Execute input is low
	Data type	BOOL
Busy	Description	High from the time the Execute input goes high until the axis reaches zero velocity AND the Execute input is low
	Data type	BOOL
Active	Description	High from the time the MC_Stop move becomes the active move, until the axis reaches zero velocity AND the Execute input is low
	Data type	BOOL
Error	Description	Indicates an invalid input was specified
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

3.2.1.9.4 Example

3.2.1.9.4.1 Structured Text

```
(* MC_Stop S
T example *)

Inst_MC_Stop( StopRequest , Axis1, 100.0, 100.0 ); //Inst_MC_Stop is an
instance of MC_Stop function block


StopComplete := Inst_MC_Stop.Done;           //store the Done output into a
user defined variable

StopActive := Inst_MC_Stop.Active;           //store the Active output into a
user defined variable

StopError := Inst_MC_Stop.Error;             //store the Error output into a
user defined variable
```

3.2.1.9.4.2 Ladder Diagram

Put Axis 1 into Stopping Mode



3.2.2 I/O Functions

This set of functions provides I/O control over TouchProbe functions.

3.2.2.1 MC_AbortTrigger



- When the Execute input transitions from low to high, this function block aborts an MC_TouchProbe function block.

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking. See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.2.1.1 Arguments

3.2.2.1.1.1 Input

Execute	Description	Enables execution
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Specifies the axis that was specified in the MC_TouchProbe function block which is to be aborted.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—

TriggerInput	<p>Description Specifies the Fast Input that was specified in the MC_TouchProbe function block which is to be aborted. The elements of TriggerInput are:</p> <p>InputID INT;</p> <ul style="list-style-type: none"> • InputIDINT <ul style="list-style-type: none"> • 0 = Touch Probe 1 / Capture Engine 0 • 1 = Touch Probe 2 / Capture Engine 1 • Range is [0,1] <p>Direction INT; 1 = rising edge, 2 = falling edge Range is [1,2]</p> <p>TrigID INT; is the axis number of the input. 0 indicates that the trigger axis is to be the same as Axis.AXIS_NUM. Range is [0,256]</p> <div style="background-color: #f0f0f0; padding: 5px;"> <p>NOTE</p> <p>TrigMode INT (TriggerInput.TrigMode) is not presently supported by this function. The TriggerInput.Mode may be supported in a future software version.</p> </div>
Data type	TRIGGER_REF
Range	See Description above
Unit	N/A
Default	—

3.2.2.1.1.2 Output

Done	<p>Description Function block has completed</p> <p>Data type BOOL</p>
Busy	<p>Description Indicates the function block is currently executing.</p> <p>Data type BOOL</p>
Error	<p>Description Indicates the function block did not complete due to an error. The ErrorID output indicates the type of error when this output is high.</p> <p>Data type BOOL</p>
ErrorID	<p>Description When the Error output is high, this output indicates the type of error. When the Error output is low, this output is undefined.</p> <p>Data type INT</p>

3.2.2.1.2 Usage

This function block is used to abort an MC_TouchProbe function block.

3.2.2.1.3 Related Functions


[MC_TouchProbe](#)

3.2.2.1.4 Example

3.2.2.1.4.1 Structured Text

```
(* MC_AbortTrigger ST example *)
Inst_MC_AbortTrigger( AbortReq, Axis1, TriggerInputRef );
//Inst_MC_AbortTrigger is an instance of MC_AbortTrigger
```

3.2.2.1.4.2 Ladder Diagram



3.2.2.2 MC_TouchProbe PLCopen

3.2.2.2.1 Description


This function block arms a Fast Input and returns the latched position when the Fast Input event occurs. This function block causes no motion.

When the Execute input transitions from low to high, the control requests the drive to arm its Fast Input to latch the axis position when a Fast Input occurs. The Axis input specifies which axis's position to latch and the TriggerInput input specifies which Fast Input to use and whether to trigger on the rising or falling edge of the Fast Input. When the Fast Input event occurs, the drive latches the axis's position. This function block then returns the latched position at the RecordedPosition output and set the Done output high. This process can be canceled with the AbortTrigger function block.

If the WindowOnly input is high, the FirstPosition input and the LastPosition input define a window in which a Fast Input is accepted. Any Fast Input events that occur outside the window is ignored.


If First Position ≤ LastPosition, the window in which a Fast Input is accepted is:

$$\text{FastInputPosition} \geq \text{FirstPosition} \text{ AND } \text{FastInputPosition} \leq \text{LastPosition}.$$



If First Position > LastPosition, the window in which a Fast Input is accepted is:

$$\text{FastInputPosition} \geq \text{FirstPosition} \text{ OR } \text{FastInputPosition} \leq \text{LastPosition}.$$



The following figure shows the ladder diagram view of the MC_TouchProbe function block:




Figure 1-54: MC_TouchProbe

TIP

The accuracy of captured position data depends on the travel velocity. Please see the article [MC_TouchProbe and Time-Based Capture on KDN](#) for more information and how to correct for timing.

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking. See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

IMPORTANT


There are some differences in how MC_TouchProbe interacts with AKD and AKD2G drives. Please refer to the following topics for some drive-specific information.

- ["AKD Support With MC_TouchProbe"](#) (→ p. 284)
- ["AKD2G Support With MC_TouchProbe"](#) (→ p. 284)

3.2.2.2 Arguments

3.2.2.2.1 Input

Execute	Description	Enables execution
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Selects the axis for which the position is latched
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
TriggerInput	Description	Sets up the mechanism on the controller for the capture input signal.

Data type	<p>TRIGGER_REF - an instance of the TRIGGER_REF reference function must first be setup in the Project Dictionary, as seen here.</p> 
Elements	<p><u>Capture Engine (drive capture engine to be used)</u> INT TriggerInput.InputID</p> <ul style="list-style-type: none"> • InputIDINT <ul style="list-style-type: none"> • 0 = Touch Probe 1 / Capture Engine 0 • 1 = Touch Probe 2 / Capture Engine 1 • Range is [0,1] <p><u>Trigger Direction (input signal's edge to capture)</u> INT TriggerInput.Direction 1 = rising edge 2 = falling edge Range is [1,2]</p> <p>TIP</p> <p>Trigger Direction is also sent to the servo drive and is shown in the WorkBench Position Capture screen Edge setup.</p> <p><u>Axis Number (where input comes from)</u> INT TriggerInput.TrigID 0 = trigger axis is to be the same as Axis.AXIS_NUM. Range is [0,256]</p> <p><u>Trigger Mode (capture method)</u> INT TriggerInput.TrigMode 0 = time based capture 1 = position based capture. For position based capture the TrigID must be the same as the Axis_Ref. Range is [0,1]</p> <p>NOTE</p> <p>The Mode (either Position or Time) must be configured the same in the servo drive. This can be done either:</p> <ul style="list-style-type: none"> • in COE Init commands and executed when the EtherCAT network is initialized (0x3460, subindex 3 and 4) • in the WorkBench Positon Capture screen (see image above).
Unit	N/A
Default	—
WindowOnly	<p>Description Enables a position latching window. When this input is set, a window is defined by the FirstPosition and LastPosition inputs. Any Fast Input event that occurs outside the window is ignored. The first Fast Input event that occurs within the window latches the axis position</p>
Data type	BOOL
Range	—
Unit	N/A

	Default	—
FirstPosition	Description	See the function block Description above for an explanation of how this input and the LastPosition input define the window. This input is only applicable when the WindowOnly input is high. If the WindowOnly input is low, this input is ignored
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
LastPosition	Description	See the function block Description above for an explanation of how this input and the FirstPosition input define the window. This input is only applicable when the WindowOnly input is high. If the WindowOnly input is low, this input is ignored
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

3.2.2.2.2 Output

Done	Description	Function block has completed and the RecordedPosition output is valid
	Data type	BOOL
Busy	Description	Indicates that the specified input is arming or is armed, and waiting for the trigger and recording of the position to occur
	Data type	BOOL
CommandAborted	Description	A TriggerAbort function block has executed and canceled this function
	Data type	BOOL
Error	Description	The function block has not completed successfully due to an error. The ErrorID output indicates the type of error
	Data type	BOOL
ErrorID	Description	When the Error output is high, this output indicates the type of error. When the Error output is low, this output is undefined
	Data type	INT
RecordedPosition	Description	When the Done output goes high, this output returns the latched position. When the Done output is low, this output is undefined

Data type	LREAL
Unit	User unit

3.2.2.2.3 Usage

This function block can be used to:

- Perform registration
- Determine the position of a product
- Measure product length

3.2.2.2.4 Limitations

- Both high speed inputs cannot be used at the same time.
- The TrigMode option is only used by MC_TouchProbe.

3.2.2.2.5 Related Functions

[MC_AbortTrigger](#)

3.2.2.2.6 See Also


- [Fast Inputs with Pipe Network Motion](#)
- [Fast Homing Example with the Pipe Network Motion Engine Axis Pipe Block](#)
- [Fast Homing Example with the PLCopen Motion Engine](#)
- [Pipe Network Registration and Fast Homing](#)
- [Registration Position Capture Example with Pipe Network Trigger Block](#)

3.2.2.2.7 Example

3.2.2.2.7.1 Structured Text

```
(* MC_TouchProbe ST example *)
TriggerInputRef.InputID := 1; //configure InputID
TriggerInputRef.Direction := 1; //configure Direction
TriggerInputRef.TrigID := 0; //configure TrigID
TriggerInputRef.TrigMode := 0; //Capture trigger based on
distributed clock time
Inst_MC_TouchProbe( ArmProbe, Axis1, TriggerInputRef, FALSE,0.0, 0.0 );
//Inst_MC_TouchProbe is an instance of MC_TouchProbe function block
ProbeIsDone := Inst_MC_TouchProbe.Done; //store Done output
into a user defined variable
ProbeValue := Inst_MC_TouchProbe.RecordedPosition; //store
RecordedPosition output into a user defined variable
```

3.2.2.2.7.2 Ladder Diagram



3.2.2.2.8 AKD Support With MC_TouchProbe


Following are several tips related to using MC_TouchProbe with AKD drives.

TIP

To use Capture Engine 1 modify the input PDOs that are used and add the Latch Position 1 parameter.

TIP

When using position-based capture, the proper Capture Mode and FB Source may need to be set up in the drive. One place to do that is in the Position Capture Screen in the KAS IDE embedded WorkBench:



TIP

When setting up Position Capture, check the CoE-Init Command settings shown below. This is to verify they do not overwrite the corresponding drive parameters with unwanted values when the EtherCAT network initializes.

Index	Subindex	Value	Comment	Direction	Source
0x6060	0	7	Opmode	Write	ESI File
0x60C2	1	1	Cycle time	Write	ESI File
0x60C2	2	-3	Cycle exp	Write	ESI File
0x3460	1	0	Latching engine 0 config to F10, CAP0.TRIGGER=0, 0x3460-1:=0 (1 byte)	Write	ESI File
0x3460	2	1	Latching engine 1 config to F11, CAP1.TRIGGER=1, 0x3460-2:=1 (1 byte)	Write	ESI File
0x60FE	2	196608	Digital Outputs Mask, 0x60fe:=0x30000 (4 bytes)	Write	ESI File
0x36E6	0	1	Set FBUS.PARAM02 to activate synchronization with the interrupt	Write	ESI File
0x36E8	0	1	Set FBUS.PARAM04 to disabled the drive on a motion error	Write	ESI File
0x3506	0	1	Set DRV.HWENMODE to disabled the rising edge of the hardware enable from clearing the drive faults	Write	ESI File
0x35CA	0	1048576	Set UNIT.PIN to set gear IN to the correct unit conversion.	Write	ESI File
0x365F	0	0	Set UNIT.VROTARY to set the velocity units to RPM.	Write	ESI File
0x3460	3	2	Capture mode to distributed clock time (DCT), CAP0.MODE=2, 0x3460-3:=0 (1 byte)	Write	ESI File
0x3460	4	2	Capture mode to distributed clock time (DCT), CAP1.MODE=2, 0x3460-4:=0 (1 byte)	Write	ESI File
0x50E2	0	1000	Set ILK.BUSFF (L0 = 1000) UINT32	Write	ESI File
0x3498	0	1	Set FBUS.PROTECTION (available only since FW 01-07-03-000)	Write	ESI File

3.2.2.2.9 AKD2G Support With MC_TouchProbe

Following are several tips related to using MC_TouchProbe with AKD2G drives.

NOTE

Currently, AKD2G only supports position capture.


- AKD2G does not use CAP1 or CAP2 to provide the EtherCAT touch probes. AKD2G supports ETG6010 and DS402 for Touch Probe objects

Two touch probes per axis are supported over EtherCAT with their own dedicated hardware in the drive. Each touch probe can capture two positions, the position on the rising and the position of the falling edge of the trigger input.

Following are the standards-compliant ETG6010 and DS402, EtherCAT / CANopen objects AKD2G supports.

Axis 1 Index	Axis 2 Index	Name	Note
60B8h	68B8h	Touch probe function / control	
60B9h	68B9h	Touch probe status	
60BAh	68BAh	Touch probe position 1 positive value	AXIS#.PL.FB, Scaling same as axis
60BBh	68BBh	Touch probe position 1 negative value	
60BCh	68BCh	Touch probe position 2 positive value	
60BDh	68BDh	Touch probe position 2 negative value	
60D0H	68D0h	Touch probe source	

- The KAS IDE prepopulates the following PDOs with the required Touch probe objects by default.
 - Rx PDO 0x1602 with the required Touch Probe control objects
 - Tx PDO 0x1A02 with the required Touch Probe status and position value objects.



- The Trigger input source can be set by sending a SDO command.
 - Axis1:
 - 0x60D0 sub Index 1 for Touch Probe 1 Source
 - 0x60D0 sub Index 2 for Touch Probe 2 Source
 - Axis2:
 - 0x68D0 sub Index 1 for Touch Probe 1 Source
 - 0x68D0 sub Index 2 for Touch Probe 2 Source
- 6#D0h, Touch Probe Source. The following table shows how AKD2G signals are mapped to the touch probe source entry in the object dictionary. Note that a few sources appear in both the standard and the manufacture ranges to provide some consistency.

DS402 & ETG6010 Values	Text from Standard	AKD2G Values for 6#D0h	Equivalent CAP#. TRIGGER	AKD2G Note
-32768 to -1	Manufacturer specific	-41 to -42	41 to 42	Z pulse for Axis 1 to 2
		-31 to -35	31 to 35	Z pulse for Feedback 1 to 5 As FB1, 2, 4, and 5 do not support Z pulses then these will not be shown. When we support SFA on FB 1 and 2 then Z pulse may be possible. X23 is optional so if not fitted then -33 will not be valid.
		-21 to -26	21 to 26	DIO1 to DIO6 When X22 is not fitted options -21 and -22 will not be valid. When X23 is not fitted options -23 to -26 will not be valid.
		-1 to -12	1 to 12	DIN1 to DIN12 When X22 is not fitted options -9 to -12 will not be valid.
0	Reserved			Not valid
1	Digital Input 1 (Touch Probe input)	1	1	DIN1. Fast Opto
2	Digital Input 2 (Touch Probe input)	2	2	DIN2. Fast Opto
3	Digital Input 3 (Touch Probe input)			Not valid
4	Digital Input 4 (Touch Probe input)			Not valid
5	Hardware zero pulse signal of position encoder	5	41 for Axis 1 42 for Axis 2	Valid if PL.FBSOURCE is using a feedback that supports a Z pulse.
6	Software zero pulse encoder			Not valid
7 to 32767	Reserved			Not valid

3.2.3 Information Functions

This set of functions provides feedback and allows you to write parameters.

3.2.3.1 MC_ReadActPos



- The MC_ReadActPos function block reads the actual position of the axis.




Figure 1-55: MC_ReadActPos

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.2.3.1.1 Arguments

3.2.3.1.1.1 Input

Enable	Description	Request to read the axis's actual position Keeps continuously to read the actual position every PLC cycle, as long as the Enable remains high
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.)
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—

3.2.3.1.1.2 Output

Valid	Description	Indicates the value at the Position output is available
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE.
	Data type	INT
Position	Description	Actual position of the axis.
	Unit	User unit
	Data type	LREAL

3.2.3.1.2 Example

3.2.3.1.2.1 Structured Text


```

(* MC_ReadActPos S
   T example *)
Inst_MC_ReadActPos( TRUE, Axis1 );
//Inst_MC_ReadActPos is an instance of MC_ReadActPos function block

ActualPos := Inst_MC_ReadActPos.Position;
//store Position output into a user defined variable
    
```

3.2.3.1.2.2 Ladder Diagram

Get the Axis 1 actual position for the Control Panel to display



3.2.3.2 MC_ReadActVel



- The MC_ReadActVel function block reads the actual velocity of the axis.




Figure 1-56: MC_ReadActVel

NOTE

This function or function block returns cached data. See [Programming a Dual Core Controller](#) for more information.

3.2.3.2.1 Arguments

3.2.3.2.1.1 Input

Enable	Description	Requests to read the axis's actual velocity
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—

Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—

3.2.3.2.1.2 Output

Valid	Description	Indicates the value at the ActualVelocity output is available
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE.
	Data type	INT
ActualVelocity	Description	Actual velocity of the axis. Please note that oscillations may be seen due to this being an instant velocity, not an average velocity.
	Unit	User unit/sec
	Data type	LREAL

3.2.3.2.2 Example

3.2.3.2.2.1 Structured Text


```

* MC_ReadActVel S
T example *);
Inst_MC_ReadActVel( TRUE, Axis1 ); //Inst_MC_ReadActVel is an instance of
MC_ReadActVel function block

ActualVel := Inst_MC_ReadActVel.ActualVelocity; // store ActualVelocity
output into a user defined variable

```

3.2.3.2.2.2 Ladder Diagram



3.2.3.3 MC_ReadAxisErr PLCopen ✔

3.2.3.3.1 Description

The Function Block MC_ReadAxisErr returns the error status of the specified axis.




Figure 1-57: MC_ReadAxisErr

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.2.3.3.2 Arguments

3.2.3.3.2.1 Input

Enable	Description	requests to read the error status of the axis
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—

3.2.3.3.2.2 Output

Valid	Description	Indicates the AxisErrorID output is valid
	Data type	BOOL
Busy	Description	Indicates this function block is executing

	Data type	BOOL
Error	Description	Indicates an invalid input
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT
AxisErrorID	Description	Indicates the error status of the axis. Each bit indicates a specific error. Both emergency-stop (E-stop) and controlled-stop (C-stop) errors are indicated. The table below defines the bits of this output.
	Data type	INT

Hexadecimal	Decimal	Description
0000H	0	No Error
0001H	1	User-set E-stop via MC_EStop, E-stop
0002H	2	Loss of Feedback, E-stop
0004H	4	Drive Fault, E-stop
0008H	8	Drive Communication Failure, E-stop
0400H	1024	Synchronization Error, C-stop
0700H	7192	Drive Overtravel Limit Exceeded, Cstop (see Overtravel Conditions)

NOTE


Multiple errors can be active at the same time. For example, if a User-set E-stop and an Excess Position Error E-stop are both active, the value would be 00000011H (17 decimal).

3.2.3.3.3 Example**3.2.3.3.3.1 Structured Text**

```
(* MC_ReadAxisErr ST example *)

Inst_MC_ReadAxisErr( TRUE, Axis1 );
//Inst_MC_ReadAxisErr is an instance of MC_ReadAxisErr function block
AxisErrorBits := Inst_MC_ReadAxisErr.AxisErrorID; //AxisErrorID contains
the error bits
```

3.2.3.3.3.2 Ladder Diagram



3.2.3.4 MC_ReadBoolPar PLCopen

3.2.3.4.1 Description

The MC_ReadBoolPar function block returns the value of the specified Boolean axis parameter.




Figure 1-58: MC_ReadBoolPar

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.2.3.4.2 Arguments

3.2.3.4.2.1 Input

Enable	Description	Requests to read the Boolean axis parameter
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.)
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
ParameterNumber	Description	Parameter number, see table in Axis Parameters
	Data type	INT
	Range	—
	Unit	N/A

Default	—
----------------	---

3.2.3.4.2.2 Output


Valid	Description	Indicates the Value output is valid
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT
Value	Description	State of the Boolean parameter
	Data type	BOOL

3.2.3.4.3 Example

3.2.3.4.3.1 Structured Text

```
(* MC_ReadBoolPar ST example *)
Inst_MC_ReadBoolPar( EnableRead, Axis1, MC_AXIS_PARAM_IN_POSITION );
Axis1InPosition := Inst_MC_ReadBoolPar.Value;
```

3.2.3.4.3.2 Ladder Diagram



3.2.3.5 MC_ReadParam PLCopen

3.2.3.5.1 Description

The MC_ReadParam function block returns the value of the specified axis parameter.




Figure 1-59: MC_ReadParam

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.2.3.5.2 Arguments**3.2.3.5.2.1 Input**

Enable	Description	Requests to read the axis parameter
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
ParameterNumber	Description	Parameter number, see the table in Axis Parameters .
	Data type	INT
	Range	—
	Unit	N/A
	Default	—


3.2.3.5.2.2 Output

Valid	Description	Indicates the Value output is valid
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT
Value	Description	Value of the parameter
	Data type	LREAL

3.2.3.5.3 Example**3.2.3.5.3.1 Structured Text**

```
(* MC_ReadParam ST example *)
Inst_MC_ReadParam( EnableRead, Axis1, MC_AXIS_PARAM_CMD_VEL );
Axis1_CmdVel := Inst_MC_ReadParam.Value;
```

3.2.3.5.3.2 Ladder Diagram



3.2.3.6 MC_ReadStatus PLCopen ✔

3.2.3.6.1 Description

The function block MC_ReadStatus returns the state of the specified axis.

Enable	Valid
Axis	Busy
	Error
	ErrorID
	ErrorStop
	Disabled
	Stopping
	StandStill
	DiscreteMotion
	ContinuousMotion
	SynchronizedMotion
	Homing
	ConstantVelocity
	Accelerating
	Decelerating

Figure 1-60: MC_ReadStatus

NOTE
 This function or function block returns cached data.
 See [Programming a Dual Core Controller](#) for more information.

3.2.3.6.2 Arguments

3.2.3.6.2.1 Input

Enable	Description	Requests to read and return the axis status
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function. click here...
	Data type	AXIS_REF

Range	[1,256]
Unit	N/A
Default	—

3.2.3.6.2.2 Output

Valid	Description	Indicates the outputs are valid
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT
ErrorStop	Description	Indicates Error Stop state – E-stop or C-stop
	Data type	BOOL
Disabled	Description	Indicates Disabled state – open loop and drive is disabled
	Data type	BOOL
Stopping	Description	Indicates Stopping state – MC_Stop command
	Data type	BOOL
StandStill	Description	Indicates Stand Still state – no move, closed loop, drive enabled
	Data type	BOOL
DiscreteMotion	Description	Indicates Discrete Motion state – programmed endpoint move is active
	Data type	BOOL
ContinuousMotion	Description	Indicates Continuous Motion state – unending, single-axis move is active
	Data type	BOOL
SynchronizedMotion	Description	Indicates Synchronized Motion state – slave move is active
	Data type	BOOL
Homing	Description	Indicates Homing state – a homing cycle is currently executing
	Data type	BOOL
ConstantVelocity	Description	Indicates the axis is moving at a constant velocity
	Data type	BOOL

Accelerating	Description	Indicates the axis is accelerating
	Data type	BOOL
Decelerating	Description	Indicates the axis is decelerating
	Data type	BOOL


3.2.3.6.3 Example

3.2.3.6.3.1 Structured Text

```
(* MC_ReadStatus ST example *)

Inst_MC_ReadStatus( EnableRead, Axis1 );
//Inst_MC_ReadStatus is an instance of MC_ReadStatus function block
AxisStopping := Inst_MC_ReadStatus.Stopping; // store Stopping output to
a user defined variable
AxisAccelerating := Inst_MC_ReadStatus.Accelerating; // store
Accelerating output to a user defined variable
```


3.2.3.6.3.2 Ladder Diagram



3.2.3.7 MC_WriteBoolPar PLCopen

3.2.3.7.1 Description

The MC_WriteBoolPar function block writes the specified axis Boolean parameter.



The MC_WriteBoolPar function block

3.2.3.7.2 Arguments

3.2.3.7.2.1 Input

Execute	Description	Requests to write a Boolean axis parameter
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
ParameterNumber	Description	Parameter number, see table in Axis Parameters
	Data type	INT
	Range	—
	Unit	N/A
	Default	—
Value	Description	State to write
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—

3.2.3.7.2.2 Output


Done	Description	Indicates the Boolean parameter has been written
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

3.2.3.7.3 Example

3.2.3.7.3.1 Structured Text

```
(* MC_WriteBoolPar ST example *)
WriteBool := FALSE;
Inst_MC_WriteBoolPar( WriteReq, Axis1, 1050, WriteBool );
```

3.2.3.7.3.2 Ladder Diagram



NOTE
 Currently, MC_WriteBoolPar does not support any parameters (1050 is an arbitrary number chosen for example)

3.2.3.8 MC_WriteParam PLCopen

3.2.3.8.1 Description

The MC_WriteParam function block writes the specified axis parameter.




Figure 1-61: The MC_WriteParam function block

NOTE
 This function or function block returns cached data.
 See [Programming a Dual Core Controller](#) for more information.

3.2.3.8.2 Arguments

3.2.3.8.2.1 Input

Execute	Description	Requests to write the axis parameter
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF

	Range	[1,256]
	Unit	N/A
	Default	—
ParameterNumber	Description	Parameter number, see table in Axis Parameters
	Data type	INT
	Range	—
	Unit	N/A
	Default	—
Value	Description	Value to write
	Data type	LREAL
	Range	—
	Unit	N/A
	Default	—

3.2.3.8.2.2 Output

Done	Description	Indicates the parameter has been written
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT


3.2.3.8.3 Example

3.2.3.8.3.1 Structured Text

```
(* MC_WriteParam ST example *)
```

```
MasterOffset := 12.34;
Inst_MC_WriteParam( EnableWrite, Axis1, MC_AXIS_PARAM_MASTER_OFFSET,
MasterOffset);
```

3.2.3.8.3.2 Ladder Diagram



3.2.4 PLCOpenMotion Functions


This set of functions provides control over an axis.

3.2.4.1 MC_Halt



3.2.4.1.1 Description

- This function block decelerates an axis to zero velocity. It is a queued single-axis move. The move is complete when the axis reaches zero velocity. It is typically used with Abort at the BufferMode input to terminate a move. To execute a stop that cannot be aborted, see [MC_Stop](#).




MC_Halt


3.2.4.1.2 Time Diagram

The example below shows the behavior in combination with a [MC_MoveVelocity](#).

- A rotating axis is ramped down with FB2 MC_Halt
- Another motion command overrides the MC_Halt command

MC_Halt allows this, in contrast to MC_Stop. The axis can accelerate again without reaching standstill.





NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking. See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.4.1.3 Arguments

3.2.4.1.3.1 Input

Execute	Description	Requests to queue the move
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Maximum deceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—

Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—
BufferMode	Description	0 = abort 1 = buffer 2 = blend to active 3 = blend to next 4 = blend to low velocity 5 = blend to high velocity
	Data type	SINT
	Range	[0,5]
	Unit	N/A
	Default	—

3.2.4.1.3.2 Output

Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint.
	Data type	BOOL
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL
Active	Description	Indicates this move is the active move
	Data type	BOOL
CommandAborted	Description	Indicates this move was aborted
	Data type	BOOL
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT


3.2.4.1.4 Example

3.2.4.1.4.1 Structured Text

```
(* MC_Halt ST example *)
Inst_MC_Halt( HaltReq, Axis1,100.0, 100.0, 0 );
//Inst_MC_Halt is an instance of MC_halt function block
HaltComplete := Inst_MC_Halt.Done; //store Done output into user
defined variable
```

3.2.4.1.4.2 Ladder Diagram


Stop both axes when the Run/Stop switch is set to Stop



3.2.4.2 MC_MoveAbsolute



- This function block performs a single-axis move to a specified endpoint position based on Axis, Position, Velocity, Acceleration, Deceleration, Jerk, and Direction parameters.





MC_MoveAbsolute

3.2.4.2.1 Time Diagram

The following figure shows two examples of the combination of two absolute move Function Blocks:

- The left part of timing diagram illustrates the case if the Second Function Block is called **after** the First one. If First reaches the commanded position of 6000 (and the velocity is 0) then the output Done causes the Second FB to move to the position 10000
- The right part of the timing diagram illustrates the case if the Second move Function Block starts the execution **while** the First FB is still executing. In this case the First motion is

interrupted and aborted by the Test signal during the constant velocity of the First FB. The Second FB moves directly to the position 10000 although the position of 6000 is not yet reached



NOTE
 This function block starts a motion-related action and therefore stores data for calculations and error checking.
 See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.4.2.2 Arguments

3.2.4.2.2.1 Input

Execute	Description	Requests to queue the move
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—

Axis	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
Position	Description	Endpoint position. If Rollover Position is nonzero, this value must be in the range $0 \leq \text{Position} < \text{Rollover Position}$ When not in Rollover mode, the input accepts a 64-bit floating point value. When converted to feedback units, the range is [-251,251-1] feedback units.
	Data type	LREAL
	Range	[see Description]
	Unit	User unit
	Default	—
Velocity	Description	Velocity setpoint
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration If Acceleration is not valid, ErrorID is set to 21 Selection of Acceleration and Jerk Parameters for Function Blocks
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—

Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk If Jerk is not valid, ErrorID is set to 21 Selection of Acceleration and Jerk Parameters for Function Blocks												
	Data type	LREAL												
	Range	—												
	Unit	User unit/sec ³												
	Default	—												
Direction	Description	<p>When Rollover Position is zero, a value of 0 must be specified. When Rollover Position is nonzero, a value of 1, 2, 3, or 4 must be specified.</p> <table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>no direction specification</td> </tr> <tr> <td>1</td> <td>positive direction. The axis travels in the positive direction to the endpoint</td> </tr> <tr> <td>2</td> <td>shortest distance. The axis travels in the direction that provides the shortest distance to the endpoint</td> </tr> <tr> <td>3</td> <td>negative direction. The axis travels in the negative direction to the endpoint</td> </tr> <tr> <td>4</td> <td>last direction. The axis travels to the endpoint in the same direction as its previous move</td> </tr> </tbody> </table> <p>If the Position input is the same as the axis's current position, then:</p> <ul style="list-style-type: none"> when Direction = 2 (shortest distance), the axis does not move and the Done output goes high indicating that the move has been completed. when Direction = 1, 3, or 4, the axis travels in the specified direction, through one rollover cycle, and arrives back at the same position. 	Value	Description	0	no direction specification	1	positive direction. The axis travels in the positive direction to the endpoint	2	shortest distance. The axis travels in the direction that provides the shortest distance to the endpoint	3	negative direction. The axis travels in the negative direction to the endpoint	4	last direction. The axis travels to the endpoint in the same direction as its previous move
Value	Description													
0	no direction specification													
1	positive direction. The axis travels in the positive direction to the endpoint													
2	shortest distance. The axis travels in the direction that provides the shortest distance to the endpoint													
3	negative direction. The axis travels in the negative direction to the endpoint													
4	last direction. The axis travels to the endpoint in the same direction as its previous move													
	Data type	SINT												
	Range	[0,4]												
	Unit	N/A												
	Default	—												
BufferMode	Description	0 = abort 1 = buffer 2 = blend to active 3 = blend to next 4 = blend to low velocity 5 = blend to high velocity												
	Data type	SINT												

Range	[0,5]
Unit	N/A
Default	—

3.2.4.2.2.2 Output

Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint.
	Data type	BOOL
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL
Active	Description	Indicates this move is the active move
	Data type	BOOL
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

3.2.4.2.3 Example


3.2.4.2.3.1 Structured Text

```

(* MC_MoveAbsolute S
T example *)
Inst_MC_MoveAbsolute( MovAbsReq, Axis1, 1234.567, 100.0, 100.0, 100.0, 0,
0, 0 ); //instance of MC_MoveAbsolute
MovAbsDone := Inst_MC_MoveAbsolute.Done; //store done output into user
defined variable
MovAbsBusy := Inst_MC_MoveAbsolute.Busy;
MovAbsActive := Inst_MC_MoveAbsolute.Active;
MovAbsAborted := Inst_MC_MoveAbsolute.CommandAborted;
MovAbsError := Inst_MC_MoveAbsolute.Error;
MovAbsErrID := Inst_MC_MoveAbsolute.ErrorID;

```

3.2.4.2.3.2 Ladder Diagram




3.2.4.3 MC_MoveAdditive



Function Block - Performs a single-axis move for a specified distance from the endpoint of the previous move.

It is typically used with Abort specified at the BufferMode input. If BufferMode is not Abort, this move is identical to an MC_MoveRelative.





MC_MoveAdditive

3.2.4.3.1 Time Diagram

This diagram shows two examples of the combination of two Function Blocks while the axis is in Discrete Motion state:

- The left part of the diagram illustrates when the Second Function Block is called **after** the First one.
 - If the First reaches the commanded distance 6000 (and the velocity is 0), the output **Done** causes the Second FB to move to the distance 10000.
- The right part of the diagram illustrates when the Second move Function Blocks starts the execution **while** the First FB is still executing.
 - The First motion is interrupted and aborted by the Test signal during the constant velocity of the First FB.
 - The Second FB adds on the previous commanded position of 6000 the distance 4000 and moves the axis to the resulting position of 10000.



NOTE
 This function block starts a motion-related action and therefore stores data for calculations and error checking.
 See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.4.3.2 Arguments

3.2.4.3.2.1 Input

Execute	Description	Requests to queue the move
	Data type	BOOL
	Range	0, 1
	Unit	N/A
Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF Structure
	Range	[1, 256]

	Unit	N/A
	Default	—
Distance	Description	Distance to add to the endpoint of the previous move
	Data type	REAL
	Range	—
	Unit	User unit
	Default	—
Velocity	Description	Velocity setpoint
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—


BufferMode	Description	0 = abort 1 = buffer 2 = blend to active 3 = blend to next 4 = blend to low velocity 5 = blend to high velocity
	Data type	SINT
	Range	[0,5]
	Unit	N/A
	Default	—

3.2.4.3.2.2 Output

Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint.
	Data type	BOOL
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL
Active	Description	Indicates this move is the active move
	Data type	BOOL
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE.
	Data type	INT

3.2.4.3.2.3 FFLD Language

Move Axis 1 an additive distance of 300



3.2.4.3.2.4 ST Language


```
(* MC_MoveAdditive ST example *)

Inst_MC_MoveAdditive( MovAddReq, Axis1, 123.456, 100.0, 100.0, 100.0, 0,
0 );
//Inst_MC_MoveAdditive is an instance of MC_MoveAdditive function
block
MovAddDone := Inst_MC_MoveAdditive.Done;
//store Done output into user defined variable
```

3.2.4.4 MC_MoveRelative



- This function block executes a single-axis move for a specified distance to perform incremental motion.




Figure 1-62: MC_MoveRelative

3.2.4.4.1 Time Diagram

This image is an example of the combination of two relative move Function Blocks.

- The left part of the timing diagram illustrates the case if the Second Function Block is called **after** the First one.
 - If First reaches the commanded distance 6000 (and the velocity is 0), then the output **Done** causes the Second FB to move to the distance 10000.
- The right part of the timing diagram illustrates the case if the Second move Function Blocks starts the execution **while** the First FB is still executing.
 - In this instance, the First motion is interrupted and aborted by the Test signal during the constant velocity of the First FB.
 - The Second FB **adds on the actual position** of 3250 the distance 4000 and moves the axis to the resulting position of 7250.




Figure 1-63: Time Diagrams: First and Second FBs




Figure 1-64: Time Diagram

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking.
 See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.4.4.2 Arguments

3.2.4.4.2.1 Input

Execute	Description	Requests to queue the move.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—

Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data Type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
Distance	Description	Distance
	Data Type	LREAL
	Range	—
	Unit	User unit
	Default	—
Velocity	Description	Velocity setpoint
	Data Type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data Type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data Type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data Type	LREAL
	Range	—
	Unit	User unit/sec ³

	Default	—
BufferMode	Description	0 = abort 1 = buffer 2 = blend to active 3 = blend to next 4 = blend to low velocity 5 = blend to high velocity
	Data Type	SINT
	Range	[0,5]
	Unit	N/A
	Default	—

3.2.4.4.2.2 Output

Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint.
	Data Type	BOOL
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended.
	Data Type	BOOL
Active	Description	Indicates this move is the active move.
	Data Type	BOOL
CommandAborted	Description	Indicates the move was aborted.
	Data Type	BOOL
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error.
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE.
	Data Type	INT


3.2.4.4.3 Example

3.2.4.4.3.1 Structured Text

```
(* MC_MoveRelative ST example *)
Inst_MC_MoveRelative( MovRelReq, Axis1, 10.0, 200.0,150.0, 150.0, 0,0 );
MovRelDone := Inst_MC_MoveRelative.Done; //store Done output into user
defined variable
```

See [Main](#) for more information about how this function is used in the Hole punch project.

3.2.4.4.3.2 Ladder Diagram



3.2.4.5 MC_MoveSuperimp



- This function block provides the ability to cause additional axis motion superimposed upon a currently executing move. A superimposed move is executed like an "MC_MoveRelative" (→ p. 313) move using the specified **Distance, Velocity** (i.e. VelocityDiff), **Acceleration, Deceleration**, and **Jerk** values. The interpolated command generated by a superimposed move is added to the command of the currently executing move. Subsequent calls to MC_MoveSuperimp can abort or blend to an executing MC_MoveSuperimp move.

This function block provides a way to smoothly apply a shift in axis position while it is executing a move.






Figure 1-65: MC_MoveSuperimp

3.2.4.5.1 Time Diagram





NOTE

1. The CommandAborted is not visible here, because the new command works on the same instance
2. The end position is between 7000 and 8000, depending on the timing of the aborting of the second command set for the MC_MoveSuperimposed

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking.
 See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.4.5.2 Arguments

3.2.4.5.2.1 Input

Execute	Description	Requests to queue the superimposed move
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.

	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
Distance	Description	Distance
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
VelocityDiff	Description	Velocity rate
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—

BufferMode	Description	0. abort 1. buffer 2. blend to active 3. blend to next 4. blend to low velocity 5. blend to high velocity
	Data type	SINT
	Range	[0,5]
	Unit	N/A
	Default	—

3.2.4.5.2.2 Output


Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint.
	Data type	BOOL
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL
Active	Description	Indicates this move is the active superimposed move
	Data type	BOOL
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

3.2.4.5.3 Example

3.2.4.5.3.1 Structured Text

```
(* MC_MoveSuperimp ST example *)
Inst_MC_MoveSuperimp( MovSupReq, Axis1, 123.555, 10.0, 100.0, 100.0, 0, 0
);
MovSupDone := Inst_MC_MoveSuperimp.Done; //store Done output into user
defined variable
```

3.2.4.5.3.2 Ladder Diagram



3.2.4.6 MC_MoveVelocity



- This function block performs a single-axis non-ending move at a specified velocity. This type of move can be terminated with the MC_Halt function block or by aborting it with another move.

TIP

Consider using the "MC_MoveContVel" (→ p. 324) function block. It is more flexible and allows for the continuous update of motion parameters.




Figure 1-66: MC_MoveVelocity


"MC_MoveContVel" (→ p. 324)


3.2.4.6.1 Time Diagram

The example below shows the behavior of the combination of a MC_Stop FB with a MC_MoveVelocity FB.

- A rotating axis is ramped down with FB2 MC_Stop
- The axis rejects motion commands as long as MC_Stop parameter "Execute" = TRUE

FB1 MC_MoveVelocity reports an error indicating the busy MC_Stop command.





NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking.
 See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.4.6.2 Arguments

3.2.4.6.2.1 Input

Execute	Description	Requests to queue the move
	Data type	BOOL
	Range	False, True
	Unit	N/A
	Default	—
Axis	Description	Identifier of a declared instance of the AXIS_REF library function. For more details,.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
Speed	Description	The target axis speed. Direction is specified by the Direction input parameter.
	Data type	LREAL
	Range	Positive values
	Unit	User unit/sec
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL

	Range	Positive values
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	Positive values
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—
Direction	Description	A 0 or False value specifies that the axis should move in the positive direction. A 1 or True value specifies that the axis should move in the negative direction.
	Data type	SINT
	Range	[0, 1]
	Unit	N/A
	Default	—
BufferMode	Description	The specified buffer mode. For more information see "Buffer Modes" .
	Data type	SINT
	Range	MC_BUFFER_MODE_ABORTING MC_BUFFER_MODE_BUFFERED MC_BUFFER_MODE_BLENDED_PREVIOUS MC_BUFFER_MODE_BLENDED_NEXT MC_BUFFER_MODE_BLENDED_LOW MC_BUFFER_MODE_BLENDED_HIGH
	Unit	N/A
	Default	—

3.2.4.6.2.2 Output

InVelocity	Description	Indicates the command velocity has reached the programmed velocity
-------------------	--------------------	--

	Data type	BOOL
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL
Active	Description	Indicates this move is the active move
	Data type	BOOL
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See table in PLCopen Function Block ErrorID Output
	Data type	INT


3.2.4.6.3 Example

3.2.4.6.3.1 Structured Text

```
(* MC_MoveVelocity ST example *)

Inst_MC_MoveVelocity( MovVelReq , Axis1, 200.0, 100.0, 100.0, 0, True,
MC_BUFFER_MODE_ABORTING );
```

3.2.4.6.3.2 Ladder Diagram



3.2.4.7 MC_MoveContVel



- This function block performs a single-axis non-ending move at a specified velocity with the option of continually updating the ongoing motion with the current input parameters. After **MC_MoveContVel** execution begins (**Execute** input - low to high), follow up changes to input parameters immediately affect the ongoing motion, without requiring an additional low to high transition on the **Execute** input.

This type of move can be terminated with the "**MC_Halt**" (→ p. 301) function block or by aborting it with another move.

MC_MoveContVel	
Execute	InVelocity
Axis	Busy
Velocity	Active
Acceleration	CommandAborted
Deceleration	Error
Jerk	ErrorID
ContinuousUpdate	
BufferMode	

MC_MoveContVel

NOTE
 This function or function block returns cached data.
 See [Programming a Dual Core Controller](#) for more information.


"MC_MoveVelocity" (→ p. 321)

3.2.4.7.1 Time Diagram

The example below shows the behavior of the combination of a "MC_Stop" (→ p. 274) function block with a MC_MoveContVel function block.

- A rotating axis is ramped down with FB2 "MC_Stop" (→ p. 274)
- The axis rejects motion commands as long as "MC_Stop" (→ p. 274) parameter "Execute" = TRUE

FB1 MC_MoveContVel reports an error indicating the busy "MC_Stop" (→ p. 274) command.



NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking.
See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.4.7.2 Arguments**3.2.4.7.2.1 Input**

Execute	Description	Requests to queue the move.
	Data type	BOOL
	Range	False, True
	Unit	N/A
	Default	—
Axis	Description	Identifier of a declared instance of the the AXIS_REF library function (for more details, .
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
Velocity	Description	The target axis velocity. Negative values of velocity will move the axis in the negative direction. Positive values will move the axis in the positive direction. A value of 0 is valid and indicates a deceleration to zero velocity.
	Data type	LREAL
	Range	All finite values
	Unit	User unit/sec
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL
	Range	Positive values
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	Positive values
	Unit	User unit/sec ²

	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—
ContinuousUpdate	Description	Determines if the inputs of the function block are re-evaluated every cycle or if they are only evaluated on the rising edge of Execute . If TRUE when the function block is triggered (on the rising edge of Execute), the function block uses the current updated values of the input variables and apply it to the ongoing movement of the axis. This will continue as long as ContinuousUpdate stays TRUE. The impact of ContinuousUpdate ends as soon as the function block is no longer busy (Busy output is FALSE) or ContinuousUpdate is set to FALSE.
	Data type	BOOL
	Range	False, True
	Unit	N/A
	Default	—
BufferMode	Description	The specified buffer mode. For more information see "Buffer Modes" .
	Data type	SINT
	Range	MC_BUFFER_MODE_ABORTING MC_BUFFER_MODE_BUFFERED MC_BUFFER_MODE_BLENDED_PREVIOUS MC_BUFFER_MODE_BLENDED_NEXT MC_BUFFER_MODE_BLENDED_LOW MC_BUFFER_MODE_BLENDED_HIGH
	Unit	N/A
	Default	—

3.2.4.7.2.2 Output

InVelocity	Description	Indicates the command velocity has reached the programmed velocity
	Data type	BOOL
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL


Active	Description	Indicates this move is the active move
	Data type	BOOL
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See table in PLCopen Function Block ErrorID Output
	Data type	INT

3.2.4.7.3 Example

3.2.4.7.3.1 Structured Text

```
(* MC_MoveContVel ST example *)
Inst_MC_MoveContVel( MovVelReq , Axis1, Vel, 100.0, 100.0, 0, True, MC_BUFFER_MODE_ABORTING );
```

3.2.4.7.3.2 Freeform Ladder Diagram



3.2.4.8 MC_SetOverride PLCopen ✔

3.2.4.8.1 Description

This function block writes the velocity override factor. A change in the velocity override factor takes effect immediately on the active move.

The velocity override factor is applied to the programmed velocity (of a "MC_MoveAbsolute" (→ p. 304), "MC_MoveAdditive" (→ p. 309), "MC_MoveRelative" (→ p. 313), "MC_MoveSuperimp" (→ p. 317), or "MC_MoveVelocity" (→ p. 321) function block) to determine the command velocity:

```
command velocity = programmed velocity * VelFactor
```





Figure 1-67: MC_SetOverride

3.2.4.8.2 Arguments

3.2.4.8.2.1 Input

Enable	Description	Request to write the override factors
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
VelFactor	Description	Velocity override factor
	Data type	REAL
	Range	[0.0, 2.0]
	Unit	N/A
	Default	—

3.2.4.8.2.2 Output

Enabled	Description	Indicates the override values have been written
	Data type	BOOL
Busy	Description	Indicates the function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input is specified
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT


3.2.4.8.3 Example

3.2.4.8.3.1 Structured Text

```
(* MC_SetOverride ST example *)

VelFactor := 1.25 ; //set the velocity factor to 1.25 (125%)
Inst_MC_SetOverride( TRUE , Axis1, VelFactor ); // Inst_MC_Setoverride is
an instance of MC_SetOverride
```

3.2.4.8.3.2 Ladder Diagram



3.2.5 Profile Functions

This set of functions provides commands for slave axes, such as cams and gearing.

3.2.5.1 MC_CamIn



- This function block performs a slave axis move which follows the master axis based on the Cam Table specified by CamTableID.

This function block is used to either initiate a new MC_CamIn move or to resume a previously programmed MC_CamIn move.

Refer to "MC_CamStartPos" (→ p. 343) and "MC_CamResumePos" (→ p. 341) for information on positioning the slave axis prior to calling MC_CamIn.



Figure 1-68: MC_CamIn

Aborting Camming

There are two common options to stop camming after MC_CamIn has been called.

- "MC_CamOut" (→ p. 338) will continue motion at the instantaneous final actual velocity of the slave axis when it is called, and axis motion will continue at that final actual velocity.

- "MC_Halt" (→ p. 301) (with buffer mode input = 0) will decelerate axis motion to 0 speed and stop motion.

The master / slave relationship between the two axes is ended when MC_CamOut or MC_Halt is called.

NOTE

Ending camming is also possible with other single axis function blocks such as "MC_MoveRelative" (→ p. 313) and "MC_MoveAbsolute" (→ p. 304).

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking.

See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.5.1.1 Arguments

3.2.5.1.1.1 Input

Execute	Description	Requests to queue the CamIn move
	Data type	BOOL
	Range	0, 1
	Unit	N/A
Master	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	1 - 256
	Unit	N/A
Slave	Description	AXIS_REF.AXIS_NUM is the slave axis number
	Data type	AXIS_REF
	Range	1-256
	Unit	N/A
MasterOffset	Description	Profile shift along the master axis. This input is not used if the StartMode input is set to 1 for Resume Mode.
	Data type	LREAL
	Range	—
	Unit	User unit
SlaveOffset	Description	Profile shift along the slave axis. This input is not used if the StartMode input is set to 1 for Resume Mode.
	Data type	LREAL
	Range	—

	Unit	User unit
MasterScaling	Description	Master axis profile range. This input is not used if the StartMode input is set to 1 for Resume Mode. Scaling must be a positive value that is greater than 0.
	Data type	LREAL
	Range	—
	Unit	User unit
SlaveScaling	Description	Slave axis profile range. This input is not used if the StartMode input is set to 1 for Resume Mode. Scaling must be a positive value that is greater than 0.
	Data type	LREAL
	Range	—
	Unit	User unit
Startmode	Description	Starting mode of the cam profile. 0 = Start Mode. Start a cam profile move. 1 = Resume Mode. Resume the most recent MC_CamIn move. This input indicates whether the axis should start a MC_CamIn move as an initial cam start (StartMode = 0) or if the axis should resume the most recently programmed MC_CamIn move (StartMode = 1). It should be noted that in the case of Resume Mode (StartMode = 1) that the inputs MasterOffset, SlaveOffset, MasterScaling, and SlaveScaling are not used. The function block will use the values that were in effect during the most recently programmed MC_CamIn move for the slave axis.
	Data type	INT
	Range	[0,1]
	Unit	N/A
CamTableID	Description	ID number of the profile to be used with MC_CamIn
	Data type	INT
	Range	—
	Unit	N/A

BufferMode	Description	The Buffer mode for CamIn block. Valid values include: <ul style="list-style-type: none"> • MC_BUFFER_MODE_ABORT • MC_BUFFER_MODE_BUFFERED For more information see Buffer Modes . MC_BUFFER_MODE_BUFFERED may only be used when an endpoint is specified with the previous move. This limits the use of MC_BUFFER_MODE_BUFFERED to when the previous move is a point-to-point move (" MC_MoveAbsolute " (→ p. 304) or " MC_MoveRelative " (→ p. 313)). MC_BUFFER_MODE_ABORT may be used to abort an existing camming, gearing, point-to-point, or velocities move.
	Data type	SINT
	Range	MC_BUFFER_MODE_ABORT MC_BUFFER_MODE_BUFFERED
	Unit	N/A

3.2.5.1.1.2 Output

InSync	Description	Indicates the slave axis is in sync with the profile.
	Data type	BOOL
	Range	0, 1
	Unit	N/A
Busy	Description	Indicates this function block is executing.
	Data type	BOOL
	Range	0, 1
	Unit	N/A
Active	Description	Indicates this move is the Active move.
	Data type	BOOL
	Range	0, 1
	Unit	N/A
CommandAborted	Description	Indicates the move was aborted.
	Data type	BOOL
	Range	0, 1
	Unit	N/A
Error	Description	Indicates an invalid input, or the move was terminated due to an error.
	Data type	BOOL
	Range	0, 1

	Unit	N/A
ErrorID	Description	Indicates the error if the Error output is high.
	Data type	INT
	Range	—
	Unit	N/A
EndOfProfile	Description	Indicates the end of profile has been reached. If the profile is periodic this output is set to ON for one ladder scan. If the profile is not periodic, the output remains ON while outside the range of the profile.
	Data type	BOOL
	Range	0, 1
	Unit	N/A

3.2.5.1.2 Usage

The slave axis immediately locks on to the Cam Table profile.

The **Master Offset** is used to shift the profile along the master axis.

The **Master Scaling** defines the range of the profile along the master axis.

The **Slave Offset** is used to shift the profile along the Slave axis.

The **Slave Scaling** defines the range of the profile along the slave axis.

If the profile is periodic, when the end of profile reached, the profile continues at the start of the profile. The EndOfProfile output is ON for 1 ladder scan.

If the profile is not periodic, when the end of profile is reached, the slave axis stops and remains at the end of the profile until the master axis returns to within the profile range as defined by MasterScaling. The EndOfProfile output remains ON anytime the master axis is outside of the profile range.

Adjustments computation is done:

When cam is first started, offsets are adjusted if necessary

- If slave is not absolute, then slave offset = slave offset + starting position
- If master is not absolute, then master offset = master offset + starting position.

At run-time

- Master position for profile = master position - master offset
- Use master position for profile table to obtain slave profile position
- Slave commanded position = slave profile position + slave offset

3.2.5.1.2.1 Dynamically Changing a Cam Profile

MC_CamIn can be used to dynamically change from one cam profile to another. Care must be taken when doing this to avoid unexpected motion.

TIP

Some tips for dynamically changing cam profiles:

- Verify that the first cam's last position and the replacement cam's first position are the same.
Note: Offsets as set by "MC_CamTblSelect" (→ p. 347) will affect actual cam position.

- Verify that the first cam's last velocity and the replacement cam's first velocity do not cause any unexpected motion.
- Jumps can be eliminated by defining the present cam as *Cyclic* and defining the replacement cam as an *Absolute Master* and *Slave*, as set by the "MC_CamTblSelect" (→ p. 347) inputs. This eliminates any possible small error accumulating when the cam is switched.

3.2.5.1.3 Related Functions

"MC_CamResumePos" (→ p. 341)

"MC_CamStartPos" (→ p. 343)

"MC_CamTblSelect" (→ p. 347)


"MC_CamOut" (→ p. 338)

3.2.5.1.4 Examples

3.2.5.1.4.1 Structured Text

```
(* MC_CamIn ST example *) //Inst_MC_CamIn is an instance of MC_CamIn
Inst_MC_CamIn( CamStartBool, Axis1, Axis2, 0.0, 0.0, 360.0, 360.0, 0,
CamTableID, 0 );
```

3.2.5.1.4.2 Ladder Diagram



These examples utilizes this screen shot showing the cam profile "MyProfile":

"Example 1" (→ p. 336)

"Example 2" (→ p. 336)

"Example 3" (→ p. 337)





Figure 1-69: MC_CamIn examples

3.2.5.1.4.3 Example 1




After MC_CamTblSelect and MC_CamIn are programmed with the above parameters, the slave axis is locked on to the profile. Since both have zero offsets, the profile is not shifted in either axis.

The initial condition of the master axis at position 0, yields a slave command position of 180.0. As the master axis moves positive, the slave position follows the profile. When the master position is at 90.0, the slave is commanded to 324.0 (see curve below where in = 90, out = 324). The slave follows the profile as the master axis moves until the master axis reaches a position of 360.0. At this time the slave is commanded to 180.0.

If the master were to continue to move past 360.0 the slave commanded position would remain at 180.0 since the Cyclic input is false. If the master moves negative and its position returns to less than 360.0, then the slave follows the profile again.

3.2.5.1.4.4 Example 2




After MC_CamTblSelect and MC_CamIn are programmed with the above parameters, the slave axis is locked on to the profile. Since the both axes have zero offsets, the profile is not shifted in either axis.

Neither the *MasterAbsolute* nor *SlaveAbsolute* input is on, so the profile is relative to the axes initial positions. Specifically, the initial condition of the master axis at position 180 would represent a master profile position of 0 (180-180). This yields a slave command position of 270 (180 + 90). As the master axis moves positive, the slave position follows the profile. When the master position is at 270, the slave is commanded to 414.0 (324 + 90). The slave follows the profile as the master axis moves until the master axis reaches a position of 540. At this time the slave is commanded to 270.0 (180 + 90).

If the master continues to move past 540.0, the slave commanded position follows the profile from the beginning since the Cyclic input is TRUE. When the master reaches a position of 630, the slave is commanded to a position of 414.0 (324 + 90).

3.2.5.1.4.5 Example 3



After MC_CamTblSelect and MC_CamIn are programmed with the above parameters, the slave axis is locked on to the profile. Since the both axes have offsets, the profile is shifted along both axes.

Specifically, the master axis is shifted 90, and the slave axis is shifted -180. Initially the master axis position of 180 yields a master position for the profile calculation of 90 (master position 180 -

Master offset 90), which yields a slave command position of 144 (slave profile command 324 + slave offset (-180)). As the master axis moves positive, the slave position follows the profile. When the master axis position is at 270, the master position for profile calculation is 180 (270 - 90). This yields a slave command position of 0 (180 + (-180)).

The slave follows the profile as the master axis moves until the master axis reaches a position of 450. The master axis position of 450 yields a master position for profile calculation of 360 (450 - 90). The slave command position is 0 (180 + (-180)).

When the master reaches a position of 450, the slave commanded position remains at 0 since the Cyclic input is false.

3.2.5.2 MC_CamOut



- This function block:

- aborts the active MC_CamIn move
- disengages the axis from its master
- and commands the axis to continue at its current velocity

TIP

The current velocity is calculated by taking the average of the actual velocity during the previous 16 cycles.

Like a MC_MoveVelocity move, the control continues to command the axis to move at this velocity until this MC_CamOut move is aborted. If this function block is called and the active move is not a MC_CamIn move, this function block returns an error and the active move is not aborted.

TIP

As an alternative method to cancel the cam motion, a single axis move ("[MC_MoveAbsolute](#)" (→ p. 304), "[MC_MoveRelative](#)" (→ p. 313), "[MC_MoveAdditive](#)" (→ p. 309), "[MC_MoveVelocity](#)" (→ p. 321), and "[MC_Halt](#)" (→ p. 301)) with the **buffermode** input set to **0** can be called. This will cancel the "[MC_CamIn](#)" (→ p. 330) function and start the new motion function on the slave axis. Many applications prefer calling MC_Halt instead of MC_CamOut because it will not send a velocity command to the slave axis.




Figure 1-70: MC_CamOut

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking.

See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.5.2.1 Arguments

3.2.5.2.1.1 Input

Execute	Description	Requests to queue the CamOut move
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Slave	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	1 – 256
	Unit	N/A
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—

3.2.5.2.1.2 Output

Done	Description	Indicates the axis is disengaged from its master
	Data type	BOOL
	Range	0, 1

	Unit	N/A
Busy	Description	Indicates this function block is executing
	Data type	BOOL
	Range	0, 1
	Unit	N/A
Active	Description	Indicates this move is the Active move
	Data type	BOOL
	Range	0, 1
	Unit	N/A
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
	Range	0, 1
	Unit	N/A
Error	Description	Indicates an invalid input was specified or no MC_CamIn move was active
	Data type	BOOL
	Range	0, 1
	Unit	N/A
ErrorID	Description	Indicates the error if the Error output is high
	Data type	INT
	Range	—
	Unit	N/A

3.2.5.2.2 Usage

This function block disengages the slave axis from a MC_CamIn move and then leaves the axis running at its current velocity. The axis continues to run at this velocity until this move is aborted.

3.2.5.2.3 Related Functions

[MC_CamIn](#)

[MC_CamTblSelect](#)

3.2.5.2.4 Example


3.2.5.2.4.1 Structured Text

```
(* MC_CamOut ST example *)

Inst_MC_CamOut
(ExecCamOut1,Axis1,CamOut1Acc,CamOut1Dec,CamOut1Jerk);

//Inst_MC_CamOut is an instance of MC_CamOut
```

3.2.5.2.4.2 Ladder Diagram




See [MC_CamIn](#) for examples.

3.2.5.3 MC_CamResumePos



- This function block returns the slave axis position for the most recently executed "MC_CamIn" (→ [p. 330](#)) profile, based on the current position of the master axis. This slave axis position can be used to command the slave axis to return to the proper location prior to resuming a MC_CamIn function. When calculating the slave axis position, MC_CamResumePos will utilize the master offset, slave offset, master scaling, and slave scaling of the most recently executed MC_CamIn function block for the slave axis.

The typical application of MC_CamResumePos is to aid in returning a slave axis back to its profile position after an event (e.g. E-stop) caused the slave axis to go off path. See [Resuming Camming After an E-Stop](#) for complete instructions.



MC_CamStartPos

NOTE
 This function block starts a motion-related action and therefore stores data for calculations and error checking.
 See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.5.3.1 Related Functions

- "MC_CamIn" (→ [p. 330](#))
- "MC_CamStartPos" (→ [p. 343](#))

3.2.5.3.2 Arguments

3.2.5.3.2.1 Inputs

Enable	Description	Enables execution of the function block
	Data Type	BOOL
	Range	N/A
	Units	N/A
	Default	—
Master	Description	Master axis. This must be the same as the Master Axis specified for the most recently executed MC_CamIn function block.
	Data Type	AXIS_REF
	Range	[1,256] for .AXIS_NUM
	Units	N/A
	Default	—
Slave	Description	Slave axis. This must be the same as the Slave Axis specified for the most recently executed MC_CamIn function block.
	Data Type	AXIS_REF
	Range	[1,256] for .AXIS_NUM
	Units	N/A
	Default	—
CamTableID	Description	Profile ID number. This value was generated by " MC_CamTblSelect " (→ p. 347). This must be the same as the CamTableID specified for the most recently executed MC_CamIn function block.
	Data Type	INT
	Range	[0,255]
	Units	N/A
	Default	—

3.2.5.3.2.2 Outputs

Done	Description	TRUE = the function block has successfully calculated the slave position. The slave position is available at the SlavePos output.
	Data Type	BOOL
	Units	N/A

Error	Description	TRUE = an invalid input was specified or an error occurred in the calculations. The value at the SlavePos output is undefined.
	Data Type	BOOL
	Units	N/A
ErrorID	Description	Indicates the error if Error output is set to TRUE. See table in PLCopen Function Block ErrorID Output
	Data Type	INT
	Units	N/A
SlavePos	Description	If the Done output is TRUE, this output returns the position for the slave axis given the profile, the current master axis position, and the previously programmed master and slave offsets and scaling.
	Data Type	LREAL
	Units	User Units

3.2.5.3.3 Examples


3.2.5.3.3.1 ST

```
Inst_MC_CamStartPos( TRUE, Axis1, Axis2, Profile1CamTableID);
```


3.2.5.3.3.2 IL

```
CAL Inst_MC_CamResumePos( TRUE, Axis1, Axis2, Profile1CamTable ID)
```

3.2.5.3.3.3 FBD



3.2.5.3.3.4 FFLD




3.2.5.4 MC_CamStartPos



- This function block returns the slave axis position for the specified profile, based on the current position of the master axis. This slave axis position can be used to command the slave axis to move to the proper location prior to commanding a "MC_CamIn" (→ p. 330) move with StartMode = 0 (Start mode).

The typical application of MC_CamStartPos is to aid in positioning a slave axis to its starting position for a MC_CamIn move with a slave absolute profile. See [Positioning an Axis Before Starting Camming](#) for complete instructions.



MC_CamStartPos

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking. See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.5.4.1 Arguments

3.2.5.4.1.1 Inputs

Enable	Description	Enables execution of the function block
	Data Type	BOOL
	Range	N/A
	Units	N/A
	Default	—
Master	Description	Master axis
	Data Type	AXIS_REF
	Range	[1,256] for .AXIS_NUM
	Units	N/A
	Default	—
Slave	Description	Slave axis
	Data Type	AXIS_REF
	Range	[1,256] for .AXIS_NUM
	Units	N/A

	Default	—
MasterOffset	Description	Master axis offset
	Data Type	LREAL
	Range	—
	Units	User Units
	Default	—
SlaveOffset	Description	Slave axis offset
	Data Type	LREAL
	Range	—
	Units	User Units
	Default	—
MasterScaling	Description	Master axis scale factor. Scaling must be a positive value that is greater than 0.
	Data Type	LREAL
	Range	—
	Units	User Units
	Default	—
SlaveScaling	Description	Slave axis scale factor. Scaling must be a positive value that is greater than 0.
	Data Type	LREAL
	Range	—
	Units	User Units
	Default	—
CamTableID	Description	Profile ID number. This number was generated by "MC_CamTblSelect" (→ p. 347).
	Data Type	INT
	Range	[0,255]
	Units	N/A
	Default	—

3.2.5.4.1.2 Outputs

Done	Description	TRUE = the function block has successfully calculated the slave position. The slave position is available at the SlavePos output.
	Data Type	BOOL

	Units	N/A
Error	Description	TRUE = an invalid input was specified or an error occurred in the calculations. The value at the SlavePos output is undefined.
	Data Type	BOOL
	Units	N/A
ErrorID	Description	Indicates the error if Error output is set to TRUE. See table in PLCopen Function Block ErrorID Output
	Data Type	INT
	Units	N/A
SlavePos	Description	If the Done output is TRUE, this output returns the position for the slave axis given the profile and the current master axis position.
	Data Type	LREAL
	Units	User Units

3.2.5.4.2 Examples


3.2.5.4.2.1 ST

```
Inst_MC_CamStartPos( TRUE, Axis1, Axis2, MasterOffset, SlaveOffset,
MasterScale, SlaveScale, Profile1CamTableID);
```


3.2.5.4.2.2 IL

```
CAL Inst_MC_CamStartPos( TRUE, Axis1, Axis2, MasterOffset,
SlaveOffset, MasterScale, SlaveScale, Profile1CamTable ID)
```

3.2.5.4.2.3 FBD



3.2.5.4.2.4 FFLD



3.2.5.5 MC_CamTblSelect



- This Function Block is defined to read and initialize the specified profile, returning an ID to be used with MC_CamIn function block.

3.2.5.5.1 Arguments

3.2.5.5.1.1 Input

Execute	Description	Requests to queue the slave gear ratio move
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
CamTable	Description	Profile name as defined in the CAM Profile Properties dialog
	Data type	STRING
	Range	—
	Unit	N/A
	Default	—
Periodic	Description	Selects if the profile is periodic (see also Usage section)
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
MasterAbsolute	Description	Selects if master profile is absolute or relative (see also Usage section)
	Data type	BOOL

	Range	0, 1
	Unit	N/A
	Default	—
SlaveAbsolute	Description	Selects if Slave profile is absolute or relative (see also Usage section)
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—

3.2.5.5.1.2 Output

Done	Description	Indicates the function block has completed successfully
	Data type	BOOL
	Range	0, 1
	Unit	N/A
Busy	Description	Indicates this function block is executing
	Data type	BOOL
	Range	0, 1
	Unit	N/A
Error	Description	Indicates an invalid input was specified
	Data type	BOOL
	Range	0, 1
	Unit	N/A
ErrorID	Description	Indicates the error if the Error output is high
	Data type	INT
	Range	—
	Unit	N/A
CamTableID	Description	Indicates the ID number of the profile to be used with MC_CamIn
	Data type	INT
	Range	0 - 255
	Unit	N/A

3.2.5.5.2 Usage

- Each positive transition of the **Enable** input will create a unique Cam ID and store the profile information in a table. The number of unique Cam IDs is limited to 256. If the application attempts to create more than 256 Cam IDs, the **Error** output will be true and the **ErrorID** output will be 22 (Too Many Profiles). It is only necessary to call MC_CamTblSelect once for each Profile/Periodic/MasterAbsolute/SlaveAbsolute configuration to be used.
- The **Periodic** input selects if the profile is to repeat each cycle. If the profile is not periodic and the master axis moves beyond the profile range, the slave stops at the end of the profile.

NOTE

If the master axis moves back into the profile range, the slave resumes following the profile.

- If the **MasterAbsolute** input is ON, the profile is in reference to the Master axis position. If the MasterAbsolute input is OFF, the profile is in reference to the Master axis position at the time the MC_CamIn function block is executed.
- Similarly, the **SlaveAbsolute** input selects if the slave positions are in reference to the Slave axis position or the Slave axis position at the time the MC_CamIn function block is executed.

TIP

If the SlaveAbsolute input is set to TRUE, the axis jumps back to the starting position. If you set this input to FALSE, the axis will no longer jump back; but rather, as the profile repeats, the slave moves relative to the start of each period.

3.2.5.5.3 Related Functions

- [MC_CamIn](#)
- [MC_CamOut](#)

3.2.5.5.4 Example


3.2.5.5.4.1 Structured Text

```
(* MC_CamTblSelect ST example *) //call this function block every scan until "Done"

Inst_MC_CamTblSelect(DoSelect, 'Profileb', TRUE, TRUE, TRUE ); //Inst_MC_CamTblSelect is instance of MC_CamTblSelect
CamSelDone := Inst_MC_CamTblSelect.Done; //store Done output to user defined variable
IF CamSelDone = TRUE THEN //when function block is "done" store CamTableID := Inst_MC_CamTblSelect.CamTableID; //CamTableID in user defined variable
END_IF;
```

See how this function is used in the Hole punch project [here](#)

3.2.5.5.4.2 Ladder Diagram



See [MC_CamIn](#) for examples.

3.2.5.6 MC_GearIn



3.2.5.6.1 Description

- This function block performs a slave axis move which follows the master axis based on the ratio specified by RatioNumerator and RatioDenominator.

$$\text{SlaveCommandPosition} = \frac{\text{MasterActualPosition} * \text{RatioNumerator}}{\text{RatioDenominator}}$$

When this command is executed, the slave axis accelerates or decelerates (using the Acceleration, Deceleration, and Jerk) to the target velocity determined by the master axis velocity and the ratio. When the slave axis reaches a velocity within the "In Gear" bandwidth around the target velocity, it locks on to the master, and the InGear output goes high. When the slave is locked to the master, the slave motion is no longer affected by the acceleration, deceleration, and jerk inputs.

For example if the "In Gear" bandwidth is set to 0.1 User Units per second, the InGear output will turn on if the slave velocity is within +/- 0.1 User Units per second of the target velocity.

The slave axis then continues to follow the master axis until this move is aborted.

Aborting Gearing

Gearing functions can generate large accelerations while following the master. If the aborting function block has small, non-zero Jerk, or small acceleration values, it can take a long time for an accelerating axis to reach the target velocity, or position of the aborting function block. If the Jerk and/or acceleration of the aborting function cannot be increased to suitable values, it may be desirable to:

- Abort the gearing function with an "MC_GearOut" (→ p. 360) with higher accelerations and/or Jerk values (or zero jerk value),
- Execute the next MC motion function block such as "MC_Halt" (→ p. 301).

Time to Reach the Target Velocity


While following the master, gearing functions can generate large accelerations. If the gearing function is aborted while the axis is currently accelerating, and the aborting function block has small non-zero Jerk or small acceleration values, it can take a long time to reach the target velocity, or position of the aborting function block. If the Jerk and/or acceleration of the aborting function cannot be increased to suitable values, it may be desirable to:

- Abort the gearing function with an MC_GearOut with higher accelerations and/or Jerk values (or zero jerk value),
- Execute the next MC motion function block such as "MC_Halt" (→ p. 301).

MC_GearIn	
Execute	InGear
Master	Busy
Slave	Active
RatioNumerator	CommandAborted
RatioDenominator	Error
Acceleration	ErrorID
Deceleration	
Jerk	
BufferMode	

MC_GearIn

3.2.5.6.2 Time Diagram



NOTE
 This function block starts a motion-related action and therefore stores data for calculations and error checking.
 See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.5.6.3 Arguments

3.2.5.6.3.1 Input

Execute	Description	Requests to queue the slave gear ratio move
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Master	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
Slave	Description	AXIS_REF.AXIS_NUM is the slave axis number
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A

	Default	—
RatioNumerator	Description	Numerator of master/slave ratio
	Data type	DINT
	Range	[-2147483648, 2147483647]
	Unit	N/A
	Default	—
RatioDenominator	Description	Denominator of master/slave ratio
	Data type	DINT
	Range	[-2147483648, 2147483647]
	Unit	N/A
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—
BufferMode	Description	0 = abort 1 = buffer
	Data type	SINT
	Range	[0,1]

Unit	N/A
Default	—

3.2.5.6.3.2 Output

InGear	Description	Indicates the slave axis is locked on to the master axis
	Data type	BOOL
Busy	Description	High from the moment the Execute input goes high until the time the move is ended
	Data type	BOOL
Active	Description	Indicates this move is the Active move
	Data type	BOOL
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT


3.2.5.6.4 Example

3.2.5.6.4.1 Structured Text

```
(* MC_GearIn ST example *)
Inst_MC_GearIn( GearInReq, Axis1, Axis2, 2, 1, 150.0, 150.0, 0, 0 );
//Inst_MC_GearIn is an instance of MC_GearIn
```

See also how this function is used in the Hole punch project [here](#)

3.2.5.6.4.2 Ladder Diagram



3.2.5.7 MC_GearInPos



- This function block performs a slave axis move which follows the master axis based on the ratio specified by RatioNumerator and RatioDenominator.

$$\text{SlaveCommandPosition} = \frac{\text{MasterActualPosition} * \text{RatioNumerator}}{\text{RatioDenominator}}$$

This function block also allows the application to specify sync positions for the master and slave axes. It is the point in which the master and slave axes become engaged in synchronous motion. When the master axis reaches the MasterStartDistance from the MasterSyncPosition, the slave axis begins to accelerate to the target velocity determined by the master axis velocity and the ratio. The slave axis arrives at the target velocity and the SlaveSyncPosition at the same time the master axis arrives at the MasterSyncPosition. At that time, the slave is locked on to the master and follows the master at the ratio specified. The slave axis continues to follow the master axis until this move is aborted.

Aborting Gearing

Gearing functions can generate large accelerations while following the master. If the aborting function block has small, non-zero Jerk, or small acceleration values, it can take a long time for an accelerating axis to reach the target velocity, or position of the aborting function block. If the Jerk and/or acceleration of the aborting function cannot be increased to suitable values, it may be desirable to:

- Abort the gearing function with an "MC_GearOut" (→ p. 360) with higher accelerations and/or Jerk values (or zero jerk value),
- Execute the next MC motion function block such as "MC_Halt" (→ p. 301).

Time to Reach the Target Velocity


While following the master, gearing functions can generate large accelerations. If the gearing function is aborted while the axis is currently accelerating, and the aborting function block has small non-zero Jerk or small acceleration values, it can take a long time to reach the target velocity, or position of the aborting function block. If the Jerk and/or acceleration of the aborting function cannot be increased to suitable values, it may be desirable to:

- Abort the gearing function with an MC_GearOut with higher accelerations and/or Jerk values (or zero jerk value),
- Execute the next MC motion function block such as "MC_Halt" (→ p. 301).

MC_GearInPos	
Execute	StartSync
Master	InSync
Slave	Busy
RatioNumerator	Active
RatioDenominator	CommandAborted
MasterSyncPosition	Error
SlaveSyncPosition	ErrorID
SyncMode	
MasterStartDistance	
BufferMode	

MC_GearInPos

3.2.5.7.1 Time Diagram



NOTE
 This function block starts a motion-related action and therefore stores data for calculations and error checking.
 See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.5.7.2 Arguments

3.2.5.7.2.1 Input

Execute	Description	Requests to queue the slave gear ratio move
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Master	Description	Name of a declared instance of the AXIS_REF library function (for more details,
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
Slave	Description	AXIS_REF.AXIS_NUM is the slave axis number

	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
RatioNumerator	Description	Numerator of master/slave ratio. The sign (+ or -) indicates the direction for the slave axis.
	Data type	DINT
	Range	[-2147483648, 2147483647]
	Unit	N/A
	Default	—
RatioDenominator	Description	Denominator of master/slave ratio. The sign (+ or -) indicates the direction for the master axis. The direction determines the sync trigger comparison direction for the slave. <ul style="list-style-type: none"> • For a master moving in the positive direction, use a positive RatioDenominator. • For a master moving in the negative direction, use a negative RatioDenominator.
	Data type	DINT
	Range	[-2147483648, 2147483647]
	Unit	N/A
	Default	—
MasterSyncPosition	Description	Master axis sync position
	Data type	LREAL
	Range	-1.7^{308} to 1.7^{308} (14 to 15 significant digits of accuracy)
	Unit	N/A
	Default	—
SlaveSyncPosition	Description	Slave axis sync position
	Data type	LREAL
	Range	-1.7^{308} to 1.7^{308} (14 to 15 significant digits of accuracy)
	Unit	N/A
	Default	—

SyncMode	<p>Description SyncMode determines the allowed conditions for synchronization:</p> <p>0 = Normal synchronization. Prior to executing the MC_GearInPos function block, the <i>Master</i> axis position must be before the <i>MasterSyncPosition</i> by a distance greater than the <i>MasterStartDistance</i>. The <i>Slave</i> axis position must be before the <i>SlaveSyncPosition</i>.</p> <p>In the case of axes that have a non-zero rollover, the MC_GearInPos function block will always assume the axes meet these conditions by assuming the sync point is in the next occurrence of the sync position.</p> <p><i>MasterStartDistance</i> must be positive and greater than the distance the master axis is currently moving per axis update. If the master start distance and the slave axis distance from the <i>SlaveSyncPosition</i> are sufficiently large enough, the slave axis will ramp to the sync position. If not sufficiently large enough, acceleration of the slave axis may be excessive.</p> <p>1 = Immediate synchronization allowed. This mode is only allowed if both the master and slave axes have rollover = 0. If the conditions of SyncMode = 0 are not met, Synchronization is allowed even though the axis positions may be beyond their respective Sync Positions. The <i>MasterStartDistance</i> may be 0. If the <i>MasterStartDistance</i> is zero, the Slave axis will synchronize with the master the instant the master axis crosses the <i>MasterSyncPosition</i>.</p> <p>If either the master or slave axis are beyond their respective sync start positions, the slave axis will immediately synchronize to the master axis. If the master start distance and the slave axis distance from the <i>SlaveSyncPosition</i> are sufficiently large enough, the slave axis will ramp to the sync position. If not sufficiently large enough or immediate synchronization occurs, slave axis acceleration may be excessive.</p> <p>Excessive slave acceleration may also occur if the master axis velocity is large or the master and slave axes have disproportionally different distances to their respective sync positions. If the slave axis is ahead of the master axis at the time of synchronization, the slave axis will move backwards.</p>
Data type	INT
Range	0-1
Unit	N/A
Default	—

MasterStartDistance	Description	When the master axis reaches this distance before MasterSyncPosition, the slave axis begins its lock-on process. ⚠ IMPORTANT The MasterStartDistance * (RatioNumerator/RatioDenominator) should be greater than (or equal to) the slave sync distance. The slave sync distance is defined as the distance between the slave position when MC_GearInPos executes and the SlaveSyncPosition . If the MasterStartDistance is too short, the MC_GearInPos may have excessive acceleration and a warning log message will be generated.
	Data type	LREAL
	Range	1.7 ⁻³⁰⁸ to 1.7 ³⁰⁸ (14 to 15 significant digits of accuracy)
	Unit	User unit
	Default	—
BufferMode	Description	1 = buffer
	Data type	SINT
	Range	[1]
	Unit	N/A
	Default	—

3.2.5.7.2.2 Output


StartSync	Description	Indicates that the master axis has reached the MasterStartDistance from the MasterSyncPosition and the lock-on process has begun
	Data type	BOOL
InSync	Description	Indicated the slave axis is locked on to the master axis
	Data type	BOOL
Busy	Description	High from the moment the Execute input goes high until the time the move is ended
	Data type	BOOL
Active	Description	Indicates this move is the Active move
	Data type	BOOL
CommandAborted	Description	Indicates the move was aborted. If the abort arises because the inputs cause inconsistent motion, then this FB: <ul style="list-style-type: none"> • performs no motion • sets an error flag • set the ErrorID to 13

	Data type	BOOL
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

3.2.5.7.3 Example

3.2.5.7.3.1 Example Description

- Master and Slave are rotary axes with rollovers at 360 degrees.
- The Master initial position is 0 degrees and the slave initial position is 45 degrees.
- The GearInPos FB commands the slave to accelerate up to the geared ratio (1:1) during the master start distance (90 degrees) and be synchronized with the master at the master and slave sync positions.




1. Master Axis
2. Slave Axis
3. Master Start Distance
4. Slave starts to accelerate
5. Master Sync Position
6. Slave Sync Position

3.2.5.7.3.2 Structured Text

```
(* MC_GearInPos ST example *)

Inst_MC_GearInPos( GearInPosReq, Axis1, Axis2, 2, 1, 0, 0, 0, 100.0, 1 );
//Inst_MC_GearInPos is instance of MC_GearInPos
GearInPosSync:= Inst_MC_GearInPos.InSync;
//store InSync output into user defined variable
```

3.2.5.7.3.3 Ladder Diagram



3.2.5.8 MC_GearOut



- This function block:

- aborts the active MC_GearIn or MC_GearInPos move,
- disengages the axis from its master,
- and commands the axis to continue at its current velocity.


TIP

The current velocity is calculated by taking the average of the actual velocity during the previous 16 cycles.

Like a [MC_MoveVelocity](#) move, the control continues to command the axis to move at this velocity until this MC_GearOut move is aborted. The Acceleration, Deceleration and Jerk input parameters are applied if this command velocity is modified by the [MC_SetOverride](#) function block. If this function block is called and the active move is not a [MC_GearIn](#) or [MC_GearInPos](#) move, this function block returns an error and the active move is not aborted.

NOTE

The MC_GearOut is done when the slave axis is disengaged from the master axis. Once done, the MC_GearOut will remain busy and active until it is aborted by a different motion function block. This is different behavior than most other motion function blocks. The MC_GearOut function block represents an exception to the exclusivity rule as the **Done** and **Active** outputs may be true at the same time.



MC_GearOut

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking.

See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.5.8.1 Arguments**3.2.5.8.1.1 Input**

Execute	Description	Requests to disengage the slave axis from a MC_GearIn or MC_GearInPos move
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Slave	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³

Default	—
----------------	---

3.2.5.8.1.2 Output

Done	Description	Indicates the axis is disengaged from its master
	Data type	BOOL
Busy	Description	Indicates the function is executing
	Data type	BOOL
Active	Description	Indicates this move is the Active move
	Data type	BOOL
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
Error	Description	Indicates an invalid input was specified or no MC_GearIn or MC_GearInPos move is active
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

3.2.5.8.2 Example


3.2.5.8.2.1 Structured Text

```

(* MC_GearOut ST example *)

Inst_MC_GearOut(ExecGearOut1,Axis1,GearOut1Acc,GearOut1Dec,GearOut1Jerk);
//Inst_MC_GearOut is instance of MC_GearOut
    
```

3.2.5.8.2.2 Ladder Diagram



3.2.5.9 MC_Phasing



Function Block - This function block:

- Performs a master position phase shift for the slave axis.
- Provides a way to smoothly apply a master offset instead of writing values directly to the Master Offset Parameter 1002.
- Is commonly used along with "MC_TouchProbe" (→ p. 279) for performing position corrections on the slave axis in a Mark to Mark registration application.

TIP

MC_Phasing performs a similar function to adjusting the MasterOffset input in the "MC_CamIn" (→ p. 330) function block. It has the additional feature of setting the velocity, acceleration, deceleration, and jerk motion parameters.

3.2.5.9.1 Description

- The distance entered at the **PhaseShift** input is iterated into the Slave axis's Master Offset.
 - This distance is iterated like a "MC_MoveRelative" (→ p. 313) move using the specified **Velocity, Acceleration, Deceleration, and Jerk** values.
- The difference is that the interpolated command delta is not commanded to the axis but is, instead, added to the Slave axis's Master Offset.
 - This shifts the Master axis's position as viewed by the Slave axis, causing a change in the Slave axis's physical position.
 - This only affects the Slave axis if it is executing a slave move.
- Subsequent calls to MC_Phasing can abort or blend to an executing MC_Phasing command.




Figure 1-71: MC_Phasing

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking. See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.5.9.2 Arguments

3.2.5.9.2.1 Input

Execute	Description	Requests to queue the phase shift
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Master	Description	Name of a declared instance of the AXIS_REF library function.)
	Data type	AXIS_REF

	Range	[1,256]
	Unit	N/A
	Default	—
Slave	Description	AXIS_REF AXIS_NUM is the slave axis number
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—
PhaseShift	Description	Amount of phase shift
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
Velocity	Description	Velocity setpoint
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³

	Default	—
BufferMode	Description	0. abort 1. buffer 2. blend to acrive 3. blend to next 4. blend to low velocity 5. blend to high velocity
	Data type	SINT
	Range	[0,5]
	Unit	N/A
	Default	—

3.2.5.9.2.2 Output


Done	Description	Indicates the phase shift has been completely applied
	Data type	BOOL
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL
Active	Description	Indicates this phase shift is the active phase shift
	Data type	BOOL
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

3.2.5.9.3 Example

3.2.5.9.3.1 Structured Text

```
(* MC_Phasing ST example *) //Inst_MC_Phasing is an instance of MC_
Phasing function block
Inst_MC_Phasing(PhasingAxis1, Axis2, Axis1, 1000.0,100.0, 200.0, 200.0,
0, 0 );
```

3.2.5.9.3.2 Ladder Diagram



3.2.5.10 MC_SyncSlaves PLCopen

3.2.5.10.1 Description

This function block allows the application to specify what slave axes are to be synchronized and which master they follow. After this function block is executed successfully, all the slave axes specified at the SlaveList input start their slave moves (i.e. MC_GearIn, MC_CamIn, etc.) on the same servo interrupt for a synchronized slave start. When a slave move is commanded for one of the slave axes listed, the slave move is queued but the motion is held off until all of the listed slaves have queued their slave moves.




Figure 1-72: MC_SyncSlaves

NOTE
 This function block starts a motion-related action and therefore stores data for calculations and error checking.
 See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.5.10.2 Arguments

3.2.5.10.2.1 Input

Execute	Description	A positive transition of this input causes the function block to execute
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Master	Description	Master axis identifier
	Data type	AXIS_REF
	Range	1 - 256

	Unit	N/A
	Default	—
SlaveCount	Description	The number of slave axes listed in the SlaveList array input that are to be synchronized. This number must not be greater than the declared size of the SlaveList array. If this number is 0, the list of synchronized slaves for the specified Master axis is cleared.
	Data type	AXIS_REF
	Range	1-256 The AXIS_NUM element of the AXIS_REF structure must be in the range [1-256]
	Unit	N/A
	Default	—
SlaveList	Description	The list of slave axes that are to be synchronized. Each element of this array contains a unique axis number. The axis number must not be the same as the Master axis number.
	Data type	UINT
	Range	1-32
	Unit	N/A
	Default	—

3.2.5.10.2.2 Output

Done	Description	Indicates the synchronized slave assignments were completed without error
	Data type	BOOL
Error	Description	Indicates an invalid input was specified
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

3.2.5.10.3 Usage

Call MC_SyncSlaves to specify the slave axes to synchronize.

Call each slave move (e.g. MC_GearIn) for each slave axis. The motion is held off until all the slave moves have been queued.

After all the slave moves have been queued, the interpolation for all the slave axes begin on the same servo interrupt, providing a synchronized start.

The master axis can be in motion prior to this sequence, or the master can be commanded after all the slave moves are queued.

3.2.5.10.4 Related Functions

[MC_GearIn](#)

[MC_GearInPos](#)


[MC_CamIn](#)

3.2.5.10.5 Example

3.2.5.10.5.1 Structured Text

```
(* MC_SyncSlaves ST example *)
// Inst_MC_SyncSlaves is an instance of MC_SyncSlaves function
block
Inst_MC_SyncSlaves( SyncSlaves, Axis1, SlaveCount, SlaveList );
```

3.2.5.10.5.2 Ladder Diagram



3.2.6 Reference Functions

This set of functions provides commands for reference points.

3.2.6.1 MC_Reference PLCopen

3.2.6.1.1 Description

This function block is used to execute a fast home to a switch. If the application selects to reference to the index mark of an encoder, or the null of a resolver (which is typical), the new position value is assigned to the position of the index of the encoder (or the null of the resolver) and not the position of the switch. The [ECATWriteSDO](#) function block is used to setup the trigger event and any desired preconditions. **This function block utilizes the Position Capture Mode of the AKD.**

NOTE

At this time, position capture is not available for PLCopen axes assigned to the secondary feedback input (digitizing axes). Therefore, MC_Reference cannot be used to home digitizing axes at this time.




Figure 1-73: MC_Reference

TIP

There are some differences between how an AKD and an AKD2G are used with this function block.

- ["AKD Support With MC_TouchProbe"](#) (→ p. 284)
- ["AKD2G Support With MC_TouchProbe"](#) (→ p. 284)

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking.

See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.6.1.2 Arguments

3.2.6.1.2.1 Input

Execute	Description	Requests to queue the MC_Reference move and arms reference trigger events
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.)
	Data type	AXIS_REF
	Range	[1,256]
	Unit	N/A
	Default	—

TriggerInput	Description	<p>TRIGGER_REF structure defines the trigger</p> <p>InputID INT :</p> <ul style="list-style-type: none"> • InputIDINT <ul style="list-style-type: none"> • 0 = Touch Probe 1 / Capture Engine 0 • 1 = Touch Probe 2 / Capture Engine 1 • Range is [0,1] <p>Direction INT; 1 = rising edge of trigger, 2 = falling edge of trigger</p> <p>Trigid INT; must be zero</p> <p>NOTE</p> <p>TrigMode INT (TriggerInput.TrigMode) is not presently supported by this function. The TriggerInput.Mode may be supported in a future software version.</p>
	Data type	TRIGGER_REF
	Range	See Description above
	Unit	N/A
	Default	—
Velocity	Description	Commanded velocity for the reference move
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—
Acceleration	Description	Commanded acceleration for the reference move
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Commanded deceleration for the reference move
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Commanded jerk for the reference move (if zero, then trapezoidal acc/dec is used)
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³

	Default	—
Direction	Description	Commanded Direction of the reference
	Data type	SINT
	Range	[0,1]
	Unit	N/A
	Default	—
Position	Description	The position the axis will be reset to when at the machine reference location
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
Option	Description	Option identifier for Resolvers/Modulo reference. 0 = Use latched position for reference 1 = use resolver position of nearest null for reference 2 pole resolver 2 = use resolver position of nearest null for reference 4 pole resolver 3 = use resolver position of nearest null for reference 6 pole resolver 4 = use resolver position of nearest null for reference 8 pole resolver 5 = use resolver position of nearest null for reference 10 pole resolver ... 15 = use resolver position of nearest null for reference 30 pole resolver
	Data type	SINT
	Range	[0,15]
	Unit	N/A
	Default	—

3.2.6.1.2.2 Output

Done	Description	Indicates the reference move and position adjustment is complete
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Active	Description	Indicates this move is the Active move
	Data type	BOOL
CommandAborted	Description	Indicates the move was aborted

	Data type	BOOL
Error	Description	Indicates an invalid input, or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if the Error output is high
	Data type	INT

3.2.6.1.3 Usage

The following lists the steps for homing a PLCopen axis, using the MC_Reference function block. Not all of the steps are necessary depending on the configuration and the homing cycle design.

The sequence of events of a PLCopen homing cycle consists of the following steps:

- Ensure Axis is not on Reference switch.
If a switch is used in the homing cycle for the event or precondition to the event, check to ensure the axis is not already tripping the switches that trigger the event and precondition. If it is, move the axis off the switches.
- Configure AKD capture engine
Configuration of the AKD capture engine is performed by writing drive CAN objects via SDO. It is accomplished with the [ECATWriteSdo](#) function. **The AKD Capture mode must be set to POSITION CAPTURE.**
The available configurations are discussed in [AKD Capture Engine Configuration](#) . Example AKD capture engine configurations and reference examples are discussed in [PLCopen Homing Methods](#).
- Call the MC_REFERENCE function to initiate optional homing motion and to arm the AKD capture engine
The MC_Reference function block selects the trigger edge (rising or falling edge) and arm the capture. Then, it optionally moves the axis to the reference location as directed by inputs to this function. When the AKD indicates that the capture event has occurred, the coordinate system is shifted so that the reference position input to this function block is set to the reference location. Then, the reference motion is stopped.
- Wait for the completion of the MC_Reference function block
The application is notified by the completion, abort or error of the homing by the MC_Reference function block.
- Upon completion of the MC_Reference function block, the axis can be moved to the home position with a [MC_MoveAbsolute](#) function block.

TIP

Once the MC_Reference block is queued, but before it is completed, the cycle can be aborted with a [MC_Halt](#) or [MC_Stop](#) function block or by queuing a new motion function block with the Abort selected for buffer mode.

3.2.6.1.4 Related Functions

[ECATWriteSdo](#)

[MC_MoveAbsolute](#)


3.2.6.1.5 Example

3.2.6.1.5.1 Structured Text

```
(* MC_Reference ST example *)
TriggerInput.InputID := 0; //configure the reference InputID
TriggerInput.DIRECTION := 1; //configure the reference direction
```

```
Inst_MC_Reference( RefReq, Axis1, TriggerInput, 20.0, 100.0, 100.0,
100.0, 0, 0.0, 0 );
```

3.2.6.1.5.2 Ladder Diagram



3.2.6.2 MC_SetPos PLCopen

3.2.6.2.1 Description

This function block changes the present actual position of the axis (as reported by "MC_ReadActPos" (→ p. 286)) to the position specified by the **Position** and **Mode** inputs. If a motor is associated with the axis, it will not move when MC_SetPos is executed. MC_SetPos does not cause any motion. It applies an offset to the command and actual positions.

MC_SetPos also sets the accumulated Superimposed distance value for the input axis to 0. See the table in [Axis Positions Data](#).

This function block replaces the MC_SetPosition function.




Figure 1-74: MC_SetPos

NOTE
 This function or function block returns cached data.
 See [Programming a Dual Core Controller](#) for more information.

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking.

See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.2.6.2.2 Arguments

For more detail on how inputs and outputs work, refer to PLCopen Function Blocks - General Rules.

3.2.6.2.2.1 Inputs

Execute	Description	Requests to change the axis position
	Data type	BOOL
	Range	0,1
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function. For more details Modify PLCopen Axis .
	Data type	AXIS_REF Structure
	Range	[1,256]
	Unit	N/A
	Default	—
Position	Description	Absolute Mode: New Axis Position to replace the present position. Relative Mode: Position offset to apply to present position (typically used with multiturn absolute position feedback devices).
	Data type	LREAL
	Range	—
	Unit	N/A
	Default	—
Mode	Description	LOW = Position input is an absolute position HIGH = Position input is a relative position
	Data type	BOOL
	Range	—
	Unit	N/A
	Default	—

3.2.6.2.2.2 Outputs

Done	Description	Indicates the reference move and position adjustment is complete
	Data type	BOOL

Busy	Description	Indicates this function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input, or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if the Error output is high See table in PLCopen Function Block ErrorID Output
	Data type	INT

3.2.6.2.3 Example

3.2.6.2.3.1 Structured Text


```
(* MC_SetPos ST example *)

Inst_MC_SetPos ( Axis1 , 0, 0 );
//Inst_MC_SetPos is an instance of MC_SetPos function

(* MC_SetPos absolute mode example: Set position value to zero. *)
Inst_MC_SetPos ( Axis1 , 0, 0 );
//Inst_MC_SetPos is an instance of MC_SetPos function

(* MC_SetPos relative mode example: Increase position value by 1000. *)
Inst_MC_SetPos ( Axis1 , 1000, 1 );
//Inst_MC_SetPos is an instance of MC_SetPos function
```

3.2.6.2.3.2 Ladder Diagram




TIP

This function block finishes immediately. Due to finishing immediately, the **Done** output does not get set to false in a second call to the same MC_SetPos instance unless there is an error.

If your application needs to look for a state change to determine if a particular call to MC_SetPos was successful, then one should AND the rising edge of the **Execute** input, the **Done** output, and the inverse of the **Error** output.

The FFLD example below shows how this can be done. In the example, the 'SetPosSuccessful'

variable will be set to TRUE for one cycle upon a successful call to the MC_SetPos instance.



3.2.6.3 MC_SetPosition

 **Function** - Deprecated by the "MC_SetPos" (→ p. 373) function block.

3.2.7 Registration Function Blocks

This set of function blocks allow for Mark-to-Mark or Mark-to-Machine registration.

See [Registration](#) for techniques on setting up and using the registration function blocks.

3.2.7.1 MC_MachRegist



3.2.7.2 Description

- This function block enables Mark-to-Machine registration.

- It is used on any servo or digitizing axis and with any move type.
- It is used most frequently in master/slave applications.



Used with ...	Effect
Non-slave moves	Resets the axis position when a good mark is captured by the fast input.

Used with ...	Effect
Slave moves	Applies a compensation offset to correct for the difference between the target position and the measured position. This provides the ability to compensate for product or process inconsistencies, provides a system that remains synchronized with no accumulated error, and maintains repeatable accuracy throughout the process.

- A positive transition of the **En** input starts registration.
 - The application may change the registration parameters while registration is active by changing the input values and causing another positive transition of the **En** input.
 - The function block then reads and applies the new values.
- The axis number at the **Axis** input indicates the axis whose position, at the fast input, is used to determine if the mark is a good mark.
- The **Distance**, **Tolerance**, and **Ignore** inputs are used to determine whether or not the registration mark is good.
 - For a mark to be recognized as good, it must be outside of the **Ignore** distance and the correct **Distance** from the previous mark +/- the **Tolerance** window.
 - A mark is bad if it occurs outside of the “good tolerance band” and is not ignored.
 - Both good marks and bad marks are recognized as marks, ignored marks are not recognized.
 - If all marks are to be recognized as good marks, enter 0 (zero) at both **Distance** and **Tolerance**.
- The **Distance** value defines the distance between good marks.
 - In Clear Lane and Product registration the **Distance** input value is typically the same as the **Target** input value.
 - In **Print** registration, the **Distance** is typically not the same as **Target**.
- The **Tolerance** value is the distance, plus and minus, about **Distance**.
 - Marks detected in this window are good marks and registration occurs.
 - Marks detected outside this window and outside the **Ignore** band, are bad marks and registration does not occur.
 - This window should be large enough to allow for the worst case error in the distance between the previous mark and the current mark.
- The **Ignore** value defines the distance from the previous mark where all marks detected by the fast input are ignored.
 - This is crucial when registering products that do not have Clear Lane registration marks.
- The **Target** input is the expected target position that is used to calculate how much registration compensation is to be applied when a registration mark is considered good.
 - When a good mark is detected, the position of the **PosAxis** is compared to the **Target** position to calculate a correction.
 - The registration correction is only applied with master/slave move types.
- The **Position** input is the position value the registration Axis position is reset to when a good registration mark is detected.
- When a good mark occurs, the position of the **PosAxis** is compared to the Target position and used to calculate the amount of registration compensation to apply to the **CompAxis**.
 - Registration compensation is applied to the axis specified at the **CompAxis** input under these conditions:
 - If **CompAxis** is a master axis, the compensation is applied to the master offsets of all its slaves.
 - This shifts the master’s position as seen by its slaves.

- If **CompAxis** is executing a slave move (e.g., "MC_GearIn" (→ p. 350) or "MC_CamIn" (→ p. 330)), the compensation is applied directly to the axis.
- The **PostTolerance** input is the distance, plus and minus, about the **Target** position used to determine if compensation is applied.
 - When a good mark occurs, the position of the **PosAxis** axis is checked to see if it lies in the window defined by **PostTolerance**.
 - If it is in the window, compensation is applied.
 - If it is outside the window, compensation is not applied even though a good mark was found.
- If **PosAxis** and **CompAxis** are different axes, the **RatioNumerator** and **RatioDenominator** inputs define the conversion factor for calculating the compensation value.
 - This is needed because the amount of error between actual and target positions is determined by the **PosAxis's** position and the compensation is applied to the **CompAxis**.
 - The **RatioNumerator** should typically be the number of User Units of **CompAxis** motion for one registration cycle.
 - The **RatioDenominator** should typically be the number of User Units of **PosAxis** motion for one registration cycle.
 - If **PosAxis** and **CompAxis** are the same, **RatioNumerator** and **RatioDenominator** should be the same value, thus resulting in a 1:1 ratio.
- The **Option** input defines various modes of operation for registration.
 - The first bit, 0001H, selects Absolute or Resetting.
 - This refers to the way the second mark and all subsequent marks are determined to be good marks.
 - With both registration schemes, the very first detected mark is the starting point.
 - With **Resetting** registration, when the next mark is detected, the position of that mark becomes the starting point for the next good mark detection calculation and so on.
 - The starting point is reset with each good or bad mark.
 - This allows the product to re-synchronize, if necessary, due to process issues (e.g., product shift) etc.
 - **Absolute** registration determines all good marks based on the very first mark.
 - The position of the second and each subsequent mark is compared to an integer multiple of **Distance** from the very first mark.
 - This method insures the product always registers to a known fixed distance.
 - The third bit, 0004H, must be 0 (zero).
 - Mark-to-machine registration requires time-based capture.

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking.
 See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

TIP

Is this the right function block to use?
 See [Deciding Which Function Blocks to Use for Registration](#) and [Registration Application Guide](#).

3.2.7.2.1 Arguments

3.2.7.2.1.1 Input

En	Description	Rising edge of EN enables execution
	Data Type	BOOL

	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Axis whose position is used to determine a good mark.
	Data Type	AXIS_REF
	Range	The range of .AXIS_NUM is [1,256]
	Unit	N/A
	Default	N/A
TriggerInput	Description	<p>Structure specifying the fast input. The structure elements are:</p> <ul style="list-style-type: none"> • InputIDINT <ul style="list-style-type: none"> • 0 = Touch Probe 1 / Capture Engine 0 • 1 = Touch Probe 2 / Capture Engine 1 • Range is [0,1] • DirectionINT <ul style="list-style-type: none"> • 1 = Rising edge • 2 = Falling edge • 3 = N/A • 4 = Toggle between both, falling edge first • 5 = Toggle between both, rising edge first, range = [1,5] • TrigIDINT <ul style="list-style-type: none"> • Axis number of the fast input. • Zero indicates this trigger axis is to be the same as the Axis input. • Range = [0,256]
		<p>NOTE</p> <p>TrigMode INT (TriggerInput.TrigMode) is not presently supported by this function. The TriggerInput.Mode may be supported in a future software version.</p>
	Data Type	TRIGGER_REF
	Range	
	Unit	
	Default	
Distance	Description	<ul style="list-style-type: none"> • This is the expected distance between good marks. • Along with Tolerance and Ignore, this value is used to determine if the mark detected by the fast input is a good mark.
	Data Type	LREAL

	Range	<ul style="list-style-type: none"> When converted to feedback units, the range is [-251,251-1]. This value must have the same sign as Ignore.
	Unit	User units
	Default	N/A
Tolerance	Description	This value specifies the distance, plus or minus, about Distance to determine if the mark detected by the fast input is a good mark.
	Data Type	LREAL
	Range	When converted to feedback units, the range is [0,251-1].
	Unit	User units
	Default	N/A
Ignore	Description	This value specifies the distance after the previous good mark in which any detected marks are ignored.
	Data Type	LREAL
	Range	<ul style="list-style-type: none"> When converted to feedback units, the range is [-251,251-1]. This value must have the same sign as Distance.
	Unit	User units
	Default	N/A
Target	Description	<ul style="list-style-type: none"> This is the target position. This position is compared to the actual position captured by the fast input to determine the amount of registration compensation to apply.
	Data Type	LREAL
	Range	When converted to feedback units, the range is: <ul style="list-style-type: none"> [-251,251-1] if PosAxis' rollover value is zero. [0, PosAxis' Rollover Value] if PosAxis' rollover value is non-zero (i.e., $\geq 0 < \text{PosAxis}' \text{Rollover Value}$).
	Unit	User units
	Default	N/A
Position	Description	<ul style="list-style-type: none"> The position the axis is set to when a good registration mark occurs. If the Inhibit Reference on Good Mark option is specified for the Option argument (see the "MC_MachRegist Options Table" (→ p. 382)), then this argument is not used. <ul style="list-style-type: none"> The position of the axis is not changed when a registration mark is encountered.
	Data Type	LREAL

	Range	When converted to feedback units, the range is: <ul style="list-style-type: none"> [-251,251-1] if PosAxis' rollover value is zero. [0, PosAxis' Rollover Value] if PosAxis' rollover value is non-zero (i.e., $\geq 0 < \text{PosAxis}' \text{Rollover Value}$).
	Unit	User units
	Default	N/A
PosAxis	Description	The position of this axis at the time the fast input occurs is compared to the Target position to determine the amount of registration compensation to apply.
	Data Type	AXIS_REF
	Range	The range of .AXIS_NUM is [1,256] The range of .AXIS_NUM is [1,256]
	Unit	N/A
	Default	N/A
CompAxis	Description	The calculated registration compensation is applied to this axis.
	Data Type	AXIS_REF
	Range	The range of .AXIS_NUM is [1,256] The range of .AXIS_NUM is [1,256]
	Unit	N/A
	Default	N/A
PosTolerance	Description	This value specifies the distance, plus or minus, about the Target position to determine if the position is accepted and the compensation value is calculated and applied.
	Data Type	LREAL
	Range	When converted to feedback units, the range is [-251,251-1].
	Unit	User units
	Default	N/A
RatioNumerator	Description	<ul style="list-style-type: none"> This value is typically the number of User Units of CompAxis motion for one product cycle. This value is used with RatioDenominator to create a conversion factor for calculating the compensation value when PosAxis and CompAxis are different axes.
	Data Type	DINT
	Range	When converted to feedback units, the range is [1,4294967295].
	Unit	User units

	Default	N/A
RatioDenominator	Description	<ul style="list-style-type: none"> This value is typically the number of User Units of PosAxis motion for one product cycle. This value is used with RatioNumerator to create a conversion factor for calculating the compensation value when PosAxis and CompAxis are different axes.
	Data Type	DINT
	Range	When converted to feedback units, the range is [1,4294967295].
	Unit	User units
	Default	N/A
Options	Description	<ul style="list-style-type: none"> Each bit enables / disables an option. The "MC_MachRegist Options Table" (→ p. 382) defines the bits. Any bits not defined are reserved. The third bit, 0004H, must be 0 (zero).
	Data Type	UINT
	Range	See the " MC_MachRegist Options Table " (→ p. 382).
	Unit	N/A
	Default	N/A

3.2.7.2.2 MC_MachRegist Options Table

MC_MachRegist Options Table

Hexadecimal	Decimal	Option	Description
0001 H	1	Absolute/Resetting	0 = Resetting, 1 = Absolute
0002 H	2	Reserved	0
0004 H	4	Time/position based capture	0 = time based capture, 1 = position based capture
0008 H	8	Inhibit Reference on Good Mark	0 = Perform reference, 1 = inhibit reference When this bit is set, the Position function block argument is unused and the axis position is not changed when a registration mark is encountered.
0010H	16	Inhibit Master Compensation	0 = Perform Master Compensation, 1 = Inhibit Master Compensation
0020H	32	Inhibit Slave Compensation	0 = Perform Slave Compensation, 1 = Inhibit Slave Compensation.

TIP

To use Capture Engine 1 modify the input PDOs that are used and add the Latch Position 1 parameter.

3.2.7.2.2.1 Outputs


RegistOn	Description	Indicates registration is activated.
	Data Type	BOOL
Aborted	Description	Indicates registration has been terminated by "MC_StopRegist" (→ p. 390).
	Data Type	BOOL
Error	Description	Indicates an invalid input was specified or registration was terminated due to an error.
	Data Type	BOOL
ErrorID	Description	<ul style="list-style-type: none"> Indicates the error if Error output is TRUE. See the table in PLCopen Function Block ErrorID Output.
	Data Type	INT

3.2.7.2.3 Related Functions

- "MC_ReadParam" (→ p. 293)
- "MC_StopRegist" (→ p. 390)
- "MC_WriteParam" (→ p. 299)

3.2.7.2.4 Examples


3.2.7.2.4.1 Function Block



3.2.7.2.4.2 Instruction List

```
CAL Inst_MC_MachRegist( ActivateReg, Axis2, Trig1, 360, 5, 90, 180, 0, Axis2, Axis2, 5, 1, 1, 0 )
```

3.2.7.2.4.3 Ladder Diagram



3.2.7.2.4.4 Structured Text

```
Inst_MC_MachRegist( ActivateReg, Axis2, Trig1, 360, 5, 90, 180, 0, Axis2, Axis2, 10, 1, 1, 0 );
```


3.2.7.3 MC_MarkRegist



3.2.7.3.1 Description

- This function block enables Mark-to-Mark registration.

- It is used on any servo or digitizing axis and with any move type.
- It is used most frequently in master/slave applications.



Used with ...	Effect
Non-slave moves	Resets the axis position when a good mark is captured by the fast input.

Used with ...	Effect
Slave moves	In addition to resetting the axis position, applies a compensation offset to correct for the difference between the target mark-to-mark distance and the measured mark-to-mark distance. This provides the ability to compensate for product or process inconsistencies, provides a system that remains synchronized with no accumulated error, and maintains repeatable accuracy throughout the process.

- A positive transition of the **En** input starts registration.
 - The application may change the registration parameters while registration is active by changing the input values and causing another positive transition of the **En** input.
 - The function block then reads and applies the new values.
- The axis number at the **Axis** input identifies the axis of registration.
 - If **Axis** is a master axis for another axis's slave move, Master Registration is activated.
 - Master Registration calculates a compensation that is added to the master offset of its slaves.
 - This offset shifts the position of the master axis as seen by its slaves.
 - The compensation is not applied to the master axis, but to its slaves.
 - If **Axis** is a slave axis, Slave Registration is activated.
 - Slave Registration calculates a compensation that is added to the slave offset of the axis.
 - This compensation value is applied directly to the slave axis.
- The **Distance**, **Tolerance**, and **Ignore** inputs are used to determine whether or not the registration mark is good.
 - For a mark to be recognized as good, it must be outside of the **Ignore** distance and the correct **Distance** from the previous mark +/- the **Tolerance** window.
 - A mark is bad if it occurs outside of the "good tolerance band" and is not ignored.
 - Both good marks and bad marks are recognized as marks, ignored marks are not recognized.
 - If all marks are to be recognized as good marks, enter 0 (zero) at both **Distance** and **Tolerance**.
- The **Distance** value defines the distance between good marks.
 - In Clear Lane and Product registration the **Distance** input value is typically the same as the **Target** input value.
 - In **Print** registration, the **Distance** is typically not the same as **Target**.
- The **Tolerance** value is the distance, plus and minus, about **Distance**.
 - Marks detected in this window are good marks and registration occurs.
 - Marks detected outside this window and outside the **Ignore** band, are bad marks and registration does not occur.
 - This window should be large enough to allow for the worst case error in the distance between the previous mark and the current mark.
- The **Ignore** value defines the distance from the previous mark where all marks detected by the fast input are ignored.
 - This is crucial when registering products that do not have Clear Lane registration marks.
- The **Target** input is the expected distance between good registration marks.
 - It is used to calculate how much registration compensation is applied when a registration mark is considered good.
 - In many applications, this is equivalent to the product length or the cycle length.

- When a good mark is detected, the actual distance between the good mark and the previous mark is determined and compared to the **Target** distance to calculate a correction.
- The registration correction is only applied with master/slave move types and always affects the slave axis.
- The **Position** input is the position value the registration Axis position is reset to when a good registration mark is detected.
- The **Option** input defines various modes of operation for registration.
 - The first bit, 0001H, selects Absolute or Resetting.
 - This refers to the way the second mark and all subsequent marks are determined to be good marks.
 - With both registration schemes, the very first detected mark is the starting point.
 - With **Resetting** registration, when the next mark is detected, the position of that mark becomes the starting point for the next good mark detection calculation and so on.
 - The starting point is reset with each good or bad mark.
 - This allows the product to re-synchronize, if necessary, due to process issues (e.g., product shift) etc.
- **Absolute** registration determines all good marks based on the very first mark.
 - The position of the second and each subsequent mark is compared to an integer multiple of **Distance** from the very first mark.
 - This method insures the product always registers to a known fixed distance.
-

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking.
 See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

TIP

Is this the right function block to use?
 See [Deciding Which Function Blocks to Use for Registration](#) and [Registration Application Guide](#).

3.2.7.3.2 Arguments

3.2.7.3.2.1 Input

En	Description	Rising edge of EN enables execution
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Axis to apply registration to
	Data type	AXIS_REF
	Range	The range of .AXIS_NUM is [1,256]
	Unit	N/A
	Default	N/A

TriggerInput	Description	<p>Structure specifying the fast input. The structure elements are:</p> <ul style="list-style-type: none"> • InputIDINT <ul style="list-style-type: none"> • 0 = Touch Probe 1 / Capture Engine 0 • 1 = Touch Probe 2 / Capture Engine 1 • Range is [0,1] • DirectionINT <ul style="list-style-type: none"> • 1 = Rising edge • 2 = Falling edge • 3 = N/A • 4 = Toggle between both, falling edge first • 5 = Toggle between both, rising edge first, range = [1,5] • TrigIDINT <ul style="list-style-type: none"> • Axis number of the fast input. • Zero indicates this trigger axis is to be the same as the Axis input. • Range = [0,256] <div data-bbox="726 817 1449 990" style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p style="text-align: center;">NOTE</p> <p>TrigMode INT (TriggerInput.TrigMode) is not presently supported by this function. The TriggerInput.Mode may be supported in a future software version.</p> </div>
	Data Type	TRIGGER_REF
	Range	
	Unit	
	Default	
Distance	Description	<ul style="list-style-type: none"> • This is the expected distance between good marks. • Along with Tolerance and Ignore, this value is used to determine if the mark detected by the fast input is a good mark.
	Data Type	LREAL
	Range	<ul style="list-style-type: none"> • When converted to feedback units, the range is [-251,251-1]. • This value must have the same sign as Ignore.
	Unit	User units
	Default	N/A
Tolerance	Description	<p>This value specifies the distance, plus or minus, about Distance to determine if the mark detected by the fast input is a good mark.</p>
	Data Type	LREAL
	Range	When converted to feedback units, the range is [0 ,251-1].
	Unit	User units

	Default	N/A
Ignore	Description	This value specifies the distance after the previous good mark in which any detected marks are ignored.
	Data Type	LREAL
	Range	<ul style="list-style-type: none"> When converted to feedback units, the range is [-251,251-1]. This value must have the same sign as Distance.
	Unit	User units
	Default	N/A
Target	Description	<ul style="list-style-type: none"> This is the target distance between good marks. This distance is compared to the actual distance measured by the fast input to determine the amount of registration compensation to apply.
	Data Type	LREAL
	Range	<ul style="list-style-type: none"> When converted to feedback units, the range is [-251,251-1]. This value must have the same sign as Distance.
	Unit	User units
	Default	N/A
Position	Description	<ul style="list-style-type: none"> The position the axis is set to when a good registration mark occurs. If the Inhibit Reference on Good Mark option is specified for the Option argument (see the "MC_MachRegist Options Table" (→ p. 389)), then this argument is not used. <ul style="list-style-type: none"> The position of the axis is not changed when a registration mark is encountered.
	Data Type	LREAL
	Range	When converted to feedback units, the range is: <ul style="list-style-type: none"> [-251,251-1] if PosAxis' rollover value is zero. [0, PosAxis' Rollover Value] if PosAxis' rollover value is non-zero (i.e., $\geq 0 < \text{PosAxis}' \text{Rollover Value}$).
	Unit	User units
	Default	N/A
Options	Description	<ul style="list-style-type: none"> Each bit enables / disables an option. The "MC_MachRegist Options Table" (→ p. 389) defines the bits. Any bits not defined are reserved.
	Data Type	UINT
	Range	See the " MC_MachRegist Options Table " (→ p. 389).
	Unit	N/A

Default	N/A
----------------	-----

3.2.7.3.3 MC_MachRegist Options Table

MC_MachRegist Options Table

Hexadecimal	Decimal	Option	Description
0001 H	1	Absolute/Resetting	0 = Resetting, 1 = Absolute
0002 H	2	Reserved	0
0004 H	4	Time/position based capture	0 = time based capture, 1 = position based capture
0008 H	8	Inhibit Reference on Good Mark	0 = Perform reference, 1 = inhibit reference When this bit is set, the Position function block argument is unused and the axis position is not changed when a registration mark is encountered.
0010H	16	Inhibit Master Compensation	0 = Perform Master Compensation, 1 = Inhibit Master Compensation
0020H	32	Inhibit Slave Compensation	0 = Perform Slave Compensation, 1 = Inhibit Slave Compensation.

TIP

To use Capture Engine 1 modify the input PDOs that are used and add the Latch Position 1 parameter.

3.2.7.3.3.1 Outputs


RegistOn	Description	Indicates registration is activated.
	Data Type	BOOL
Aborted	Description	Indicates registration has been terminated by " "MC_StopRegist" " (→ p. 390).
	Data Type	BOOL
Error	Description	Indicates an invalid input was specified or registration was terminated due to an error.
	Data Type	BOOL
ErrorID	Description	<ul style="list-style-type: none"> Indicates the error if Error output is TRUE. See the table in PLCopen Function Block ErrorID Output.
	Data Type	INT

3.2.7.3.4 Related Functions

- "["MC_ReadParam"](#)" (→ p. 293)
- "["MC_Stop"](#)" (→ p. 274)
- "["MC_WriteParam"](#)" (→ p. 299)

3.2.7.3.5 Examples


3.2.7.3.5.1 Function Block



3.2.7.3.5.2 Instruction List

```
CALL Inst_MC_MarkRegist( ActivateReg, Axis1, Trig1, 360, 5, 90, 360, 0, 0 )
```

3.2.7.3.5.3 Ladder Diagram



3.2.7.3.5.4 Structured Text

```
Inst_MC_MarkRegist( ActivateReg, Axis1, Trig1, 360, 5, 90, 360, 0, 0 );
```

3.2.7.4 MC_StopRegist PLCopen

3.2.7.4.1 Description

This function will turn off registration for the specified axis and disarm the specified fast input.



NOTE
 This function or function block returns cached data.
 See [Programming a Dual Core Controller](#) for more information.

3.2.7.4.2 Arguments

3.2.7.4.2.1 Input

En	Description	Enables execution
----	-------------	-------------------

	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Axis registration to turn off
	Data type	AXIS_REF
	Range	The range of .AXIS_NUM is [1,256]
	Unit	N/A
	Default	N/A
TriggerInput	Description	<p>Structure specifying the fast input to disarm. The structure elements are:</p> <p>InputID INT</p> <ul style="list-style-type: none"> • InputIDINT <ul style="list-style-type: none"> • 0 = Touch Probe 1 / Capture Engine 0 • 1 = Touch Probe 2 / Capture Engine 1 • Range is [0,1] <p>Direction INT 1 = rising edge, 2 = falling edge, 3 = NA, 4 = toggle between both, falling edge first, 5 = toggle between both, rising edge first, range = [1,5]</p> <p>TrigID INT Axis number of the fast input. 0 indicates this trigger axis is to be the same as the Axis input. range = [0,256]</p> <p>NOTE</p> <p>TrigMode INT (TriggerInput.TrigMode) is not presently supported by this function. The TriggerInput.Mode may be supported in a future software version.</p>
	Data type	TRIGGER_REF
	Range	
	Unit	
	Default	

3.2.7.4.2.2 Outputs

OK	Description	Indicates function executed successfully
	Data type	BOOL

TIP

To use Capture Engine 1 modify the input PDOs that are used and add the Latch Position 1 parameter.


3.2.7.4.3 Related Functions

[MC_MachRegist](#)


MC_MarkRegist

3.2.7.4.4 Examples

3.2.7.4.4.1 Function Block



3.2.7.4.4.2 Ladder Diagram



3.2.7.4.4.3 Structured Text

```
StopOK := MC_StopRegist( Axis1, Trig1);
```

3.2.8 Superimposed Axes

This feature allows the application program to superimpose the moves of multiple axes ("Superimposed Axes") on top of the move of another axis ("Receiving Axis"). This is performed internally by adding the command deltas of the Superimposed Axes to the command delta of the Receiving Axis. Up to four different Superimposed Axes can be superimposed upon a Receiving Axis.

See ["MC_AddSuperAxis"](#) (→ p. 392), ["MC_RemSuperAxis"](#) (→ p. 394) and [PLCopen Function Blocks - Overview](#) for more information.

3.2.8.1 MC_AddSuperAxis



Function Block - Adds a Superimposed Axis to the Axis's list of assigned superimposed axes.

While the Superimposed Axis is on this list, its command deltas will be added to the Axis's command deltas. Up to four different superimposed axes can be on an axis's list. The `Axis` and the `SuperimposedAxis` must have the same update rate. The `OK` output will go high to indicate that the function executed successfully. If the `OK` output does not go high, one of these errors was detected:

- Axis and SuperimposedAxis do not have the same update rate.
- Four different superimposed axes have already been assigned to Axis.
- Axis is not a valid axis - Axis is not a servo or virtual axis.
- SuperimposedAxis is not a valid axis number.
- SuperimposedAxis is not a servo or virtual axis.
- Axis could not acquire PLC motion engine lock.

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.2.8.1.1 Inputs

En	Description	Enables Execution
	Data Type	BOOL
	Range	N/A
	Unit	N/A
	Default	N/A
Axis	Description	Axis to receive the additional superimposed axis's command delta.
	Data Type	AXIS_REF
	Range	.AXIS_NUM [1,256]
	Unit	N/A
	Default	N/A
SuperimposedAxis	Description	Axis number of the superimposed axis whose command delta is added to delta of <i>Axis</i> .
	Data Type	UINT
	Range	[1,256]
	Unit	N/A
	Default	N/A


3.2.8.1.2 Outputs

OK	Description	Execution successful
	Data Type	BOOL
	Range	N/A

3.2.8.1.3 FBD Language



3.2.8.1.4 FFLD Language



3.2.8.1.5 IL Language

Not available.

3.2.8.1.6 ST Language

```
AddOKST := MC_AddSuperAxis( Axis1, 3 );
```

See Also

"MC_RemSuperAxis" (→ p. 394)

3.2.8.2 MC_RemSuperAxis

This function removes the Superimposed Axis from the Axis's list of assigned superimposed axes. If the value at `SuperimposedAxis` is 0 all the assigned superimposed axes will be removed from Axis's list. The `OK` output will go high to indicate that the function executed successfully. If the `OK` output does not go high, one of the following errors was detected:

- Axis is not a valid axis
- Axis is not a servo or virtual axis

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.2.8.2.1 Inputs

En	Description	Enables Execution
	Data Type	BOOL
	Range	-
	Unit	N/A
	Default	
Axis	Description	Axis whose list of assigned superimposed axes will be updated.
	Data Type	AXIS_REF
	Range	.AXIS_NUM [1,256]
	Unit	N/A
	Default	N/A
SuperimposedAxis	Description	Axis number of the superimposed axis that will be removed from Axis's list of assigned superimposed axes. A value of 0 will remove all superimposed axes from Axis's list.
	Data Type	UINT
	Range	N/A
	Unit	N/A
	Default	N/A

3.2.8.2.2 Outputs


OK	Description	Execution successful
	Data Type	BOOL
	Range	N/A

3.2.8.2.3 Examples


3.2.8.2.3.1 Structured Text

```
RemOK := MC_RemSuperAxis (Axis1, 3);
```

3.2.8.2.3.2 Function Block Diagram



3.2.8.2.3.3 Ladder Diagram



3.2.8.2.4 Related Functions

"MC_AddSuperAxis" (→ p. 392)

3.3 Motion Library- Common

Functions sorted in alphabetical order.

Name	Description	Return type
"MC_ErrorDescription" (→ p. 396)	Return a text description corresponding to a motion control error ID code	STRING
"MLMotionCycleTime" (→ p. 414)	Returns the Motion Base Cycle time in Seconds	
"MLMotionInit" (→ p. 414)	Initializes the motion library. Must be called before any other Motion Library function. Returns TRUE if the function succeeded. BasePeriod is the duration of one motion cycle in microseconds.	BOOL
"MLMotionRstErr" (→ p. 416)	Clears motion engine errors, motion bus driver errors, and EtherCAT network errors. MLMotionRstErr will return the motion engine status to the Stopped state, if an error condition was cleared successfully. Returns TRUE if the function succeeded.	BOOL

Name	Description	Return type
"MLMotionStart" (→ p. 417)	Starts the motion engine, motion bus driver, and initializes EtherCAT network to operational mode. Applicable to PLCopen and PipesNetwork motion engines. Returns TRUE if the function succeeded.	BOOL
"MLMotionStatus" (→ p. 418)	Returns the status of the motion engine 0: Not initialized 1: Running 2: Stopped 3: Error	None
"MLMotionStop" (→ p. 420)	Stops the motion bus driver, motion engine, and EtherCAT network operation, resulting in the EtherCAT network transitioning to the Init state. Returns TRUE if the function succeeded.	BOOL
MLMotionSysTime	Prints the system time to the log	BOOL
"MLProfileBuild" (→ p. 398)	Builds a cam profile from application data	See "Output" (→ p. 401)
"MLProfileCreate" (→ p. 406)	Creates a new cam profile object	None
"MLProfileInit" (→ p. 408)	Initializes a previously created cam profile object	BOOL
"MLProfileRelease" (→ p. 410)	Removes a Profile so the Profile ID may be used by a different or new Profile.	See "Output" (→ p. 411)

3.3.1 Motion Library - Common - Info

Name	Description	Return type
"MC_ErrorDescription" (→ p. 396)	Converts the PLCopen error IDs into message strings.	String

3.3.1.1 MC_ErrorDescription



Function - converts the PLCopen error IDs into message strings which can be used for display or logging.




Figure 1-75: MC_ErrorDescription Function Block

3.3.1.1.1 Arguments

3.3.1.1.1.1 Inputs

En	Description	If True, then this function will convert the Error Id into a string message
	Data type	BOOL

	Range	0, 1
	Unit	N/A
	Default	—
ErrorID	Description	Error ID generated from a PLCopen Function Block. See PLCopen Function Block ErrorID Output for output details.
	Data type	INT
	Range	0,69
	Unit	N/A
	Default	—

3.3.1.1.2 Outputs

OK	Description	If True, then the command completed successfully.
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Description	Description	String error description
	Data type	STRING
	Range	—
	Unit	N/A
	Default	—

3.3.1.1.2 Examples

3.3.1.1.2.1 Structured Text

```
Description := MC_ErrorDescription(ErrorID);
```


3.3.1.1.2.2 IL

Not applicable

3.3.1.1.2.3 Function Block



3.3.1.1.2.4 Ladder Diagram



3.3.2 Motion Library - Common - Profiles

Name	Description	Return type
"MLProfileBuild" (→ p. 398)	Builds a cam profile from application data	See "Output" (→ p. 401)
"MLProfileCreate" (→ p. 406)	Creates a new cam profile object	None
"MLProfileInit" (→ p. 408)	Initializes a previously created cam profile object	BOOL
"MLProfileRelease" (→ p. 410)	Removes a Profile so the Profile ID may be used by a different or new Profile.	See "Output" (→ p. 411)

3.3.2.1 MLProfileBuild



Function

is this a function or function block?

This Function Block allows the application to create a cam profile that may be executed by a cam block in PipeNetwork or PLCopen.

This Function Block will take input as cam data (see [Cam Profile Editor's Cam Table](#) for information) and profile properties from application data memory and compile the input data to a form the controller can use to calculate cam positions. The input cam data and profile properties are similar to the cam data entered in the IDE's Cam Editor and the runtime's Cam Profile Properties dialog. MLProfileBuild internally perform two functions:

1. Compile the cam data (like the cam editor performs in the IDE).
2. Puts the compiled profile into the profile object so it can be used by other Profile Function Blocks (provides similar functionality to ["MLProfileInit" \(→ p. 408\)](#)).

NOTE

Prior to using MLProfileBuild you must call ["MLProfileCreate" \(→ p. 406\)](#) to create the profile object. The ID output of MLProfileCreate is then used as the ProfileID input to MLProfileBuild. MLProfileCreate must be performed in the application *before* the ["MLMotionStart" \(→ p. 417\)](#) command is executed.

MLProfileBuild will compile the cam profile data specified at the CamData input and write the resulting profile to the CAM Profile object specified at input ProfileID. The created profile can then be used as an input to PLCopen Cam Function Blocks ([MC_CamTblSelect](#), [MC_CamIn](#), [MC_CamOut](#)), or any Pipe network Cam Profile Function/Function Blocks. When the operation is complete, the Done output will go high. If an error is encountered, the Error output will go high and the ErrorID output will return a error code. If the Error can be attributed to a specific profile element in the CamData array, ErrorElem will attempt to indicate the element in error.

3.3.2.1.0.1 CamProps_Ref Structure

The cam properties structure (CamProps_Ref) will contain the following data members:

Parameter	Type	Description
InputScale	LREAL	The input amplitude or master axis multiplier applied to the CAM profile
OutputScale	LREAL	The output amplitude or slave axis multiplier applied to the CAM profile

Parameter	Type	Description
InputOffset	LREAL	input offset or master axis shift applied to the CAM profile
OutputOffset	LREAL	The output offset or slave axis shift applied to the CAM profile


See [Master/Input offset](#) for more information about the parameters which transform the cam profile.

3.3.2.1.0.2 CamData_Ref Structure

The Cam_Data function block input will be an array of CamData_Ref structures. Each element of the structure will contain the following data members:

Parameter	Type	Description
MasterIn	LREAL	master position (in the unit range [0 - InputScale])
SlaveOut	LREAL	slave position (in the unit range [0 - OutputScale])
SegType	UINT	Defines the segment type for the segment following the master positions defined by MasterIn . 1. CAM_SEGMENT_TYPE_POINT = Point 5th order polynomial) 2. CAM_SEGMENT_TYPE_LINE = Line (constant velocity segment) 3. CAM_SEGMENT_TYPE_PARABOLIC = Parabolic (constant acceleration) See Cam Profile Segment Overview for information on the segment types.
Vel	LREAL	Cam velocity at the master position specified by MasterIn . Units: (slave position user units) / (master position user units)
Accel	LREAL	For CAM_SEGMENT_TYPE_POINT: Accel represents the cam acceleration at the master position specified by MasterIn . Units: (slave position user units) / (master position user units) For CAM_SEGMENT_TYPE_LINE and CAM_SEGMENT_TYPE_PARABOLIC: Accel is ignored.

The type of the Nth cam segment is defined by the Nth Cam_Data element. Since the cam will be constructed with one less segment than the Cam_Data elements, the last element's SegType will not be used.



See [Cam Profile Editor's Cam Table](#) for more information.

3.3.2.1.1 Arguments

3.3.2.1.1.1 Input

Enable	Description	Enable execution. Starts on rising edge.
	Data Type	BOOL
	Range	
	Unit	
	Default	
Cam_Props	Description	Structures containing the cam profile properties
	Data Type	CamProps_ref
	Range	
	Unit	
	Default	
Cam_Data	Description	Array of structures containing the cam profile data
	Data Type	CamData_ref
	Range	N=3 to 20,000 elements
	Unit	
	Default	3 elements minimum size
CamDataCount	Description	Number of elements in the Cam_Data array to be used.
	Data Type	UINT
	Range	3 - 20,000
	Unit	elements
	Default	3
ProfileID	Description	ID number of a created CAM Profile
	Data Type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	--
Cyclic	Description	False: one time through the profile; True: repeating profile
	Data Type	BOOL
	Range	0-1 (FALSE/TRUE)
	Unit	
	Default	

Options	Description	Describes the combinations of segments that may be used to build a cam profile.
	Data Type	UINT
	Range	CAM_PROFILE_OPTION_DEFAULT: Allows the use of point and line segments. CAM_PROFILE_OPTION_PARABOLIC: Allows the use of line and parabolic segments.
		NOTE The DEFAULT and PARABOLIC options cannot be combined. A cam profile can only use point and line segments, or parabolic and line segments. Point and parabolic segments cannot both be used in the same profile.
	Unit	
	Default	

3.3.2.1.1.2 Output

Done	Description	Indication of whether or not the profile was successfully compiled and built.
	Data Type	BOOL
	Range	0-1 (FALSE/TRUE)
	Unit	
Busy	Description	Indication that the function block is executing. TRUE if executing. False if not executing.
	Data Type	BOOL
	Range	0-1 (FALSE/TRUE)
	Unit	
Err	Description	Indication that the function did not execute correctly. ErrorID output will be valid and indicate the reason.
	Data Type	BOOL
	Range	0-1 (FALSE/TRUE)
	Unit	
ErrorID	Description	Indication of the reason for the failure to execute properly. See " Error Codes " (→ p. 402) table.
	Data Type	INT
	Range	
	Unit	


ErrorElem	Description	The array element number of the cam data where an error is detected
	Data Type	UINT
	Range	
	Unit	

3.3.2.1.2 Error Codes

NOTE

If **Cyclic** is TRUE and the Vel/Accel of the first and last elements do not match, MLProfileBuild will automatically copy the first element's vel/accel to the last element's. A LOG warning message will be posted indicating that this change has occurred.

ErrorID	Description
100	Cam_Data array does not have CamDataCount elements. The Cam_Data array is not large enough to hold the specified number of elements.
101	Invalid master or slave scale. The scale cannot be less than zero.
102	Element master or slave position is outside the range defined by Cam_Props.
103	A segment type was specified that is not supported by the value of the Options argument.
104	Master position of an element is too close to the master position of a previous element. $0.0000125 * InputScale$ (see "CamProps_Ref Structure" on page 398) is the minimum distance allowed.. Each element is compared to all previous elements. If the master distance between any two elements in the list are too close, this error will be generated.
106	Invalid profile ID. This can occur if the profile ID: <ul style="list-style-type: none"> 1. does not exist 2. has not been created yet 3. profile ID is not a profile
107	CamDataCount exceeds maximum array size of 20,000.
108	Profile is currently in use.
109	Attempting to build a profile already containing elements. Profile needs to be released first using MLProfileRelease.
110	The controller is running low on memory and could not allocate memory to hold the cam table data.
111	CamDataCount is not large enough. The minimum allowed value is 3.
112	For CAM_PROFILE_OPTION_PARABOLIC: Elements are not sorted in increasing order by master position. After the first element, each element must have its master position be greater than the master position of the previous element.

ErrorID	Description
113	<p>For CAM_SEGMENT_TYPE_PARABOLIC: The average velocity for the segment is outside of range defined by start and end element velocities.</p> <p>The following diagram illustrates the valid range for the average velocity.</p>  <p>The diagram, titled 'Cam Velocity Profile', shows a graph with 'Cam Velocity' on the vertical axis and 'Master Position' on the horizontal axis. A horizontal line represents the 'Start Velocity'. A red line starts at the 'Start Velocity' and curves upwards in a parabolic shape to a higher 'End Velocity'. A dashed horizontal line is drawn at the 'End Velocity' level. A vertical double-headed arrow between the 'Start Velocity' line and the dashed 'End Velocity' line is labeled 'Valid Average Velocity Range'. A red dashed line above the parabolic curve is labeled 'Parabolic Segment'.</p>
200	First element's <code>MasterIn</code> value not equal to zero.
201	Last element's <code>MasterIn</code> value does not equal value of X-amplitude.
202	Cannot modify the first element in the cam element table. <code>SlaveOut</code> value is outside the output range specified by <code>Cam_Props</code> .
203	Cannot modify the last element in the cam element table. <code>SlaveOut</code> value is outside the output range specified by <code>Cam_Props</code> .

3.3.2.1.3 Related Functions

- ["MLCamInit"](#) (→ p. 111)
- ["MLCamSwitch"](#) (→ p. 113)
- ["MLProfileCreate"](#) (→ p. 406)
- ["MLProfileInit"](#) (→ p. 408)
- ["MLProfileRelease"](#) (→ p. 410)
- ["MC_CamIn"](#) (→ p. 330)
- ["MC_CamOut"](#) (→ p. 338)
- [MC_CamTblSelect](#)

3.3.2.1.3.1 See Also

- [Cam Profile Segment Overview](#)

3.3.2.1.4 Example of How to Use MLProfileBuild

Prior to using `MLProfileBuild` you must first create a profile. This must be done prior to `MLMotionStart`.

```
// Allocate space for a profile that will be built later
profileID := MLProfileCreate('ProfileName');
```

Next you need to define your profile data. This is done by creating an array of `CamData_Ref` structures in the data dictionary and then entering each of your elements into that newly created structure. In this example `ProfileData` is the name of the `CamData_Ref` structure.

```

// Define the profile data
ProfileData[0].MasterIn := 0.0;
ProfileData[0].SlaveOut := 180.0;
ProfileData[0].SegType := CAM_SEGMENT_TYPE_POINT;
ProfileData[0].Velocity := 0.0;
ProfileData[0].Acceleration := 0.0;

ProfileData[1].MasterIn := 180.0;
ProfileData[1].SlaveOut := 324.0;
ProfileData[1].SegType := CAM_SEGMENT_TYPE_POINT;
ProfileData[1].Velocity := 0.5;
ProfileData[1].Acceleration := -0.025;

ProfileData[2].MasterIn := 360.0;
ProfileData[2].SlaveOut := 240.0;
ProfileData[2].SegType := CAM_SEGMENT_TYPE_POINT;
ProfileData[2].Velocity := 0.0;
ProfileData[2].Acceleration := 0.0;

```

Now you need to define your profile properties. This is done by creating a CamProps_Ref structure in the data dictionary and then entering each of the properties into the newly created structure. In this example ProfileProps is the name of the CamProps_Ref structure.

```

// Define the profile properties
ProfileProps.InputScale := 360.0; // Must be Positive!
ProfileProps.OutputScale := 360.0; // Must be Positive!
ProfileProps.InputOffset := 0.0;
ProfileProps.OutputOffset := 0.0;

```

Next call the MLProfileBuild Function Block in the IEC language of choice. As part of this call it is recommended that you validate the Done and Error output before proceeding.

```

// Build the profile
Inst_MLProfileBuild( TRUE, ProfileProps, ProfileData, 3, ProfileID, TRUE,
CAM_PROFILE_OPTION_DEFAULT);

```

Finally, after verifying that MLProfileBuild is Done and there are no errors, you can proceed and use the newly generated profile. The next step depends on the motion engine in use.

- PLCopen: call "MC_CamTblSelect" (→ p. 347)
- Pipe Network: call either "MLCamInit" (→ p. 111) or "MLCamSwitch" (→ p. 113)

NOTE

Pipe Network: In order to correctly set the cam scales and offsets (defined by the Cam_Props argument) "MLPrfWriteIScale" (→ p. 120), "MLPrfWriteOScale" (→ p. 123), "MLPrfWriteIOffset" (→ p. 119) and "MLPrfWriteOOffset" (→ p. 122) must be called before calling "MLCamSwitch" (→ p. 113),

```

// Switch Pipe Network Profile
MLPrfWriteIScale(profileID, ProfileProps.InputScale);
MLPrfWriteOScale(profileID, ProfileProps.OutputScale);
MLPrfWriteIOffset(profileID, ProfileProps.InputOffset);
MLPrfWriteOOffset(profileID, ProfileProps.OutputOffset);
MLCamSwitch(PipeNetwork.CAM, profileID);

```

3.3.2.1.5 Example of Building a Parabolic Cam Profile

In order to build a parabolic cam profile, your cam data elements must use `CAM_SEGMENT_TYPE_PARABOLIC` or `CAM_SEGMENT_TYPE_LINE` when defining the cam data array:

```

// Define the profile data
ProfileData[0].MasterIn      := 0.0;
ProfileData[0].SlaveOut     := 0.0;
ProfileData[0].SegType      := CAM_SEGMENT_TYPE_PARABOLIC;
ProfileData[0].Velocity     := 0.0;
ProfileData[0].Acceleration := 0.5;

ProfileData[1].MasterIn      := 50.0;
ProfileData[1].SlaveOut     := 150.0;
ProfileData[1].SegType      := CAM_SEGMENT_TYPE_LINE;
ProfileData[1].Velocity     := 5.0;
ProfileData[1].Acceleration := 0.0;           // Not used

ProfileData[2].MasterIn      := 55.0;
ProfileData[2].SlaveOut     := 175.0;
ProfileData[2].SegType      := CAM_SEGMENT_TYPE_PARABOLIC;
ProfileData[2].Velocity     := 5.0;
ProfileData[2].Acceleration := 0.0;           // No limit to the acceleration rate
of the segment.

ProfileData[3].MasterIn      := 105.0;
ProfileData[3].SlaveOut     := 250.0;
ProfileData[3].SegType      := CAM_SEGMENT_TYPE_PARABOLIC;
ProfileData[3].Velocity     := 0.0;
ProfileData[3].Acceleration := 0.5;

ProfileData[4].MasterIn      := 225.0;
ProfileData[4].SlaveOut     := 125.0;
ProfileData[4].SegType      := CAM_SEGMENT_TYPE_PARABOLIC;
ProfileData[4].Velocity     := -10.0;
ProfileData[4].Acceleration := 0.5;

ProfileData[5].MasterIn      := 360.0;
ProfileData[5].SlaveOut     := 0.0;
ProfileData[5].SegType      := CAM_SEGMENT_TYPE_PARABOLIC;           // Not used
ProfileData[5].Velocity     := 0.0;
ProfileData[5].Acceleration := 0.0;           // Not used

```

When calling the `MLProfileBuild` function block, make sure `CAM_PROFILE_OPTION_PARABOLIC` is specified for the `Option` argument: in the IEC language of choice. As part of this call it is recommended that you validate the **Done** and **Error** output before proceeding.

```

// Build the profile
Inst_MLProfileBuild( TRUE, ProfileProps, ProfileData, 3, ProfileID, TRUE,
CAM_PROFILE_OPTION_PARABOLIC);


```

3.3.2.1.6 Code Examples


Structured Text:

```
// Build the profile
Inst_MLProfileBuild( TRUE, ProfileProps, ProfileData, 3, ProfileID, TRUE,
CAM_PROFILE_OPTION_DEFAULT);
```

Function Block Diagram:



Ladder Diagram:



3.3.2.2 MLProfileCreate



Function - Creates a new Profile Object for use in a PLC Program or Pipe Network CAM block.
is this a function or function block?

This function block is automatically called if a Profile is created in the Project Explorer, with user-defined settings then entered in the CAM Profile Properties screen.

Profiles are created and initiated separately and the shape is modified with the CAM Editor. With the Editor profiles can be changed graphically or by manually changing values in a numeric table relating input and output values with specific slopes. The Cam Editor software tool provides the capability to visualize, analyze, edit, and smooth profiles.

Profile switching can be done on the fly, without losing synchronization and without dead time. In addition, the offsets and ratios of CAM Profiles can be changed on the fly.

NOTE

Profile objects are normally created in the Project Explorer. Then you do not have to add MLCamInit function blocks to their programs. By right clicking the Profiles folder under the PLC->Motion Tree, you can select Add new profile. Parameters are entered directly in a pop-up window, and the code is then automatically added to the current project.

TIP

This function should be called after "MLMotionInit" (→ p. 414) is called and before "MLMotionStart" (→ p. 417) is called.

3.3.2.2.1 Arguments**3.3.2.2.1.1 Input**

Name	Description	Name of initialized CAM Profile
	Data type	STRING
	Range	—
	Unit	N/A
	Default	—

3.3.2.2.1.2 Output

OK	Description	Indicates the profile has been created
	Data type	BOOL
ID	Description	Returns the ID number of the created CAM Profile. If MLProfileCreate(...) fails, then the ID is zero (NULL). A cam ProfileID = 0 (zero) is not valid for cam profile functions.
	Data type	DINT
	Unit	N/A


3.3.2.2.2 Related Functions

"MLProfileInit" (→ p. 408)

"MLCamInit" (→ p. 111)

3.3.2.2.3 Example**3.3.2.2.3.1 Structured Text**

```
//Create a new Profile
Profile_A := MLProfileCreate( 'Profile_A' );
```

3.3.2.2.3.2 Ladder Diagram**3.3.2.2.3.3 Function Block Diagram**

3.3.2.3 MLProfileInit

PLCopen ✓ Pipe Network ✓

Function - Initializes a previously created CAM Profile object for use in a PLC Program or Pipe Network CAM block.

is this a function or function block?

This function block is automatically called if a Profile is created in the Project Explorer, with user-defined settings then entered in the CAM Profile Properties screen.

Profiles are created and initiated separately and the shape is modified with the CAM Editor. With the Editor profiles can be changed graphically or by manually changing values in a numeric table relating input and output values with specific slopes. The Cam Editor software tool provides the capability to visualize, analyze, edit, and smooth profiles.

Profile switching can be done on the fly, without losing synchronization and without dead time. In addition, the offsets and ratios of CAM Profiles can be changed on the fly.

NOTE

Profile objects are normally initiated in the Project Explorer. Then you do not have to add MLCamInit function blocks to their programs. By right clicking the Profiles folder under the PLC->Motion Tree, you can select Add new profile. Parameters are entered directly in a pop-up window, and the code is then automatically added to the current project.

TIP

Loading a Profile Editor-generated profile into a ProfileID released by MLProfileRelease should be done with care. The MLProfileInit () function call can take in excess of 4 milliseconds to execute. Application execution is suspended during this time until the function call is completed.

3.3.2.3.1 Arguments

3.3.2.3.1.1 Input

ProfileID	Description	ID number of a created CAM Profile
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—
FileName	Description	Filename used to save Profile on the computer's hard disk
	Data type	STRING
	Range	—
	Unit	N/A
	Default	—

InputScale	Description	The input amplitude or x-axis multiplier applied to the CAM Profile
	Data type	LREAL
	Range	Positive
	Unit	N/A
	Default	—
OutputScale	Description	The output amplitude or y-axis multiplier applied to the CAM Profile
	Data type	LREAL
	Range	—
	Unit	N/A
	Default	—
InputOffset	Description	The input offset or x-axis shift applied to the CAM Profile.
	Data type	LREAL
	Range	—
	Unit	N/A
	Default	—
OutputOffset	Description	The output offset or y-axis shift applied to the CAM Profile
	Data type	LREAL
	Range	—
	Unit	N/A
	Default	—

3.3.2.3.1.2 Output

Default (.Q)	Description	Returns TRUE if a new CAM Profile is initialized
	Data type	BOOL
	Unit	N/A

3.3.2.3.1.3 Return Type

BOOL

3.3.2.3.2 Related Functions

"MLProfileCreate" (→ p. 406)


"MLCamInit" (→ p. 111)

3.3.2.3.3 Example


3.3.2.3.3.1 Structured Text

```
//Initialize a previously created CAM Profile
MLProfileCreate( Profile_A , 'Profile_A.5op' , 360, 360, 0, 0 );
```

3.3.2.3.3.2 Ladder Diagram



3.3.2.3.3.3 Function Block Diagram



3.3.2.4 MLProfileRelease



Function

is this a function or function block?

An application program is limited to 256 Profile ID's.

This FB releases an existing profile ID definition so that the profile ID can be used for a different/new Profile (minimizing the risk of reaching 256 Profile ID's). Once the existing Profile ID definition has been successfully released, the Profile ID can then be used by either "MLProfileInit" (→ p. 408) or "MLProfileBuild" (→ p. 398) to create a new Profile.

The Profile ID selected by the input parameter must not be in-use by a motion engine. In-use is defined as:

- For Pipe Network – it must not be currently selected for use by an active CAM block in an active pipe. Pipe has been activated by "MLCamSwitch" (→ p. 113).
- For PLCOpen – selected for use by "MC_CamIn" (→ p. 330) and has an active move.

There are a number of ways to change an in-use profile to one that is not in-use (deactivated):

- For Pipe Network – Perform a "MLCamSwitch" (→ p. 113) on an active Pipe to a different Profile or deactivate the pipe.
- For PLCOpen – whenever the active profile move is halted or aborted, the profile is no longer in use. "MC_CamOut" (→ p. 338) is one way of aborting the profile move. Actually, any PLCopen motion command that aborts a profile move will also deactivate a profile.

NOTE

Any profile ID created by [MC_CamTblSelect](#) from the specified ProfileID will be destroyed and need to be recreated upon completion of this FB. This means that all derived profile ID's created by MC_CamTblSelect FB must also not be in use by the PLCopen motion engine in order for this function to succeed.

TIP

Loading a Profile Editor-generated profile into a ProfileID released by MLProfileRelease should be done with care. The MLProfileInit () function call can take in excess of 4 milliseconds to execute. Application execution is suspended during this time until the function call is completed.

3.3.2.4.1 Arguments

For more information on how Arguments work, refer to [PLCopen function blocks - General rules](#) .

3.3.2.4.1.1 Input

Enable	Description	Enable execution of the function block. Successful completion will result in a profile ID that is no longer assigned to a specific profile and can be reused for a different/new Profile. Prior to reusing this Profile ID it will need to be re-initialized by either an MLProfileInit Function call or by calling MLProfileBuild.
	Data Type	BOOL
	Range	0, 1
	Unit	
	Default	0
ProfileID	Description	Specify a Profile ID that has been created by MLProfileCreate. This is the profile ID that will be released so it can be reused for different/new Profiles. This Profile ID must not be in use by a motion engine.
	Data Type	DINT
	Range	1 to 256
	Unit	
	Default	0

3.3.2.4.1.2 Output

Done	Description	If high, Successful completion. The Profile can now be reused.
	Data Type	BOOL
	Range	0, 1
Err	Description	If high, the Function Block did not complete successfully. Reason is given in Error ID.
	Data Type	BOOL
	Range	0, 1

ErrorID	Description	Indicates the reason for the failure. See "Error Codes" (→ p. 412) table for possible reasons.
	Data Type	INT
	Range	

3.3.2.4.2 Error Codes

ErrorID	Description
106	Invalid profile ID. Profile ID: 1. does not exist 2. has not been created yet 3. profile ID is not a profile
108	Profile cannot be released because it is in use by the motion engine or currently selected by an active CAM block.

3.3.2.4.3 Related Functions

"MLProfileCreate" (→ p. 406)

"MLProfileInit" (→ p. 408)

"MLProfileBuild" (→ p. 398)

"MLCamInit" (→ p. 111)

"MC_CamTblSelect" (→ p. 347)

"MC_CamIn" (→ p. 330)

"MC_CamOut" (→ p. 338)

3.3.2.4.4 Example


3.3.2.4.4.1 Structured Text

```

//Release a Cam Profile
Inst_MLProfileRelease( Profile_A , 'Profile_A.5op');

If Inst_MLProfileRelease.Done THEN
    // Do Something
ELSIF Inst_MLProfileRelease.Err THEN
    // Handle Error
END_IF;
    
```

3.3.2.4.4.2 Ladder Diagram



3.3.2.4.4.3 Function Block Diagram



3.3.3 Motion Library

Name	Description	Return Type
"MLMotionCycleTime" (→ p. 414)	Returns the Motion Base Cycle time in seconds.	
"MLMotionInit" (→ p. 414)	Initializes the motion library. <ul style="list-style-type: none"> • Must be called before any other Motion Library function. • BasePeriod is the duration of one motion cycle in microseconds. • Returns TRUE if the function succeeded. 	BOOL
"MLMotionRstErr" (→ p. 416)	Re-initializes the motion engine after a motion error. <ul style="list-style-type: none"> • Motion errors are for example communication errors of the motion bus. • Returns TRUE if the function succeeded. 	BOOL
"MLMotionStart" (→ p. 417)	Starts the motion engine, motion bus driver, and initializes EtherCAT network to operational mode. <ul style="list-style-type: none"> • Applicable to PLCopen and PipeNetwork motion engines. • Returns TRUE if the function succeeded. 	BOOL
"MLMotionStatus" (→ p. 418)	Returns the status of the motion engine 0: <ul style="list-style-type: none"> • Not initialized 1: • Running 2: • Stopped 3: Error 	None
"MLMotionStop" (→ p. 420)	Stops the motion bus driver, motion engine, and EtherCAT network operation. <ul style="list-style-type: none"> • Results in the EtherCAT network transitioning to the Init state. • Returns TRUE if the function succeeded. 	BOOL
MLMotionSysTime	Prints the system time to the log.	BOOL

3.3.3.1 State Machine




Figure 1-76: Motion State Machine

The Motion State Machine is driven by the IEC 61131-3 application with the help of the "Motion Library" (→ p. 413) function blocks.

Each arrow represents a transition from one State to another one.

3.3.3.2 MLMotionCycleTime



Function - Returns the Motion Base Cycle time in seconds.

3.3.3.2.1 Inputs

Enable	BOOL	Enable execution of the function
---------------	-------------	----------------------------------

3.3.3.2.2 Outputs


Ok	BOOL	If high, successful completion.
CycleTime	LREAL	PLC cycle period in seconds.

3.3.3.2.3 Example

3.3.3.2.3.1 Structured Text

```
//Read EtherCAT cycle rate in seconds
CycleTime := MLMotionCycleTime();
```

3.3.3.2.3.2 Ladder Diagram



3.3.3.2.3.3 Function Block Diagram



3.3.3.3 MLMotionInit



Function - Initializes the motion library.

Must be called before any other Motion Library function. Returns TRUE if the function succeeded.

NOTE

The BasePeriod argument establishes the base cycle time (in microseconds) for the Motion Engine when running simulations without the EtherCAT Motion Bus. When the EtherCAT Motion Bus is present, the EtherCAT cycle time overrides the BasePeriod argument (the cycle time is defined in the Master tab). The EtherCAT cycle time then becomes the base cycle time for the Motion Engine.

3.3.3.3.1 Parameter

BasePeriod : LREAL (input)**3.3.3.3.2 Return Type**

BOOL

3.3.3.3.3 Example**3.3.3.3.3.1 ST**

```

//Initialization code to start EtherCAT network.
//First initialize network with MLMotionInit command
//Then wait for command to finish by monitoring MLMotionStatus output
//Once initialized, create any cam profiles and PLCopen or Pipenetwork
devices
//Then call MLMotionStart and monitor MLMotionStatus again before
beginning rest of program
FirstCycle := TRUE;


On FirstCycle DO //Initialize the motion engine
    MLMotionInit( 1000);
END_DO;

MotionEngineStatus := MLMotionStatus();//Check the current status of the
motion engine
//Once motion engine is initialized, create CAM profiles and defined
Axis, then start the motion engine
ON MotionEngineStatus = MLSTATUS_INITIALISED DO
    Profiles( MLPR_CREATE_PROFILES );
    PLCopen( 0 );
    MLMotionStart();
END_DO;

IF MotionEngineStatus = MLSTATUS_RUNNING THEN
    bMotionEngineStarted := TRUE;
ELSE
    bMotionEngineStarted := FALSE;
END_IF;

```

3.3.3.3.3.2 FBD**3.3.3.3.3.3 FFLD**



3.3.3.4 MLMotionRstErr

PLCopen ✓ Pipe Network ✓

Function - Clears motion engine errors, motion bus driver errors, and EtherCAT network errors. MLMotionRstErr will return the motion engine status to the Stopped state.

Returns TRUE if the function succeeded.

3.3.3.4.1 Return Type

BOOL

3.3.3.4.1.1 ST Language

```


//Reset and restart motion engine
//Done to restart ethercat after controller error such as
//E30 or E33 that stops network communication
//First have to reset error, then start network again

ON ResetMotionEngineError DO
  MLMotionRstErr();
END_DO;


MotionEngineStatus:= MLMotionStatus();

ON StartMotionEngine DO
  MLMotionStart();
END_DO;
    
```

3.3.3.4.1.2 FBD Language



3.3.3.4.1.3 FFLD Language



See Also

- "MLMotionStart" (→ p. 417)
- "MLMotionStatus" (→ p. 418)
- "MLMotionStop" (→ p. 420)

3.3.3.5 MLMotionStart

PLCopen ✓

Pipe Network ✓

Function - Starts the motion engine, motion bus driver, clears the EtherCAT diagnostic registers of all nodes, and initializes EtherCAT network to operational mode.

Applicable to PLCopen and PipeNetwork motion engines. MLMotionStart does not clear any pre-existing error conditions. Returns TRUE if the function succeeded. If motion engine is in the Error state, MLMotionStart will return FALSE.

See also: "MLMotionStop" (→ p. 420), "MLMotionRstErr" (→ p. 416), "MLMotionStatus" (→ p. 418)

3.3.3.5.1 Return Type

BOOL

3.3.3.5.2 Example

3.3.3.5.2.1 ST

```
//Initialization code to start EtherCAT network.
//First initialize network with MLMotionInit command
//Then wait for command to finish by monitoring MLMotionStatus output
//Once initialized, create any cam profiles and PLCopen or Pipenetwork
devices
//Then call MLMotionStart and monitor MLMotionStatus again before
beginning rest of program
FirstCycle := TRUE;
```

```
On FirstCycle DO //Initialize the motion engine
```

```

    MLMotionInit( 1000);
END_DO;


MotionEngineStatus := MLMotionStatus();//Check the current status of the
motion engine
//Once motion engine is initialized, create CAM profiles and defined
Axis, then start the motion engine
ON MotionEngineStatus = MLSTATUS_INITIALISED DO
    Profiles( MLPR_CREATE_PROFILES );
    PLCopen( 0 );
    MLMotionStart();
END_DO;

IF MotionEngineStatus = MLSTATUS_RUNNING THEN
    bMotionEngineStarted := TRUE;
ELSE
    bMotionEngineStarted := FALSE;
END_IF;
    
```

3.3.3.5.2.2 FBD



3.3.3.5.2.3 FFLD



3.3.3.6 MLMotionStatus

PLCopen ✓ **Pipe Network** ✓

Function - Returns the status of the motion engine.

Based on the [Internal Defines](#), the status is one of these:

```
#define MLSTATUS_NOT_INITIALISED 0 (*Motion not initialised*)
#define MLSTATUS_RUNNING 1 (*Motion is running*)
#define MLSTATUS_STOPPED 2 (*Motion is stopped*)
#define MLSTATUS_ERROR 3 (*Motion is in error*)
```

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.3.3.6.1 Parameter

Status : DINT (output)

3.3.3.6.2 Return Type

None

3.3.3.6.3 Example

3.3.3.6.3.1 ST


```
//Initialization code to start EtherCAT network.
//First initialize network with MLMotionInit command
//Then wait for command to finish by monitoring MLMotionStatus output
//Once initialized, create any cam profiles and PLCopen or Pipenetwork
devices
//Then call MLMotionStart and monitor MLMotionStatus again before
beginning rest of program
FirstCycle := TRUE;

On FirstCycle DO //Initialize the motion engine
MLMotionInit( 1000);
END_DO;


MotionEngineStatus := MLMotionStatus();//Check the current status of the
motion engine
//Once motion engine is initialized, create CAM profiles and defined
Axis, then start the motion engine
ON MotionEngineStatus = MLSTATUS_INITIALISED DO
Profiles( MLPR_CREATE_PROFILES );
PLCopen( 0 );
MLMotionStart();
END_DO;

IF MotionEngineStatus = MLSTATUS_RUNNING THEN
bMotionEngineStarted := TRUE;
ELSE
bMotionEngineStarted := FALSE;
END_IF;
```

3.3.3.6.3.2 FBD



3.3.3.6.3.3 FFLD



3.3.3.7 MLMotionStop

PLCopen ✓
Pipe Network ✓

Function - Stops the motion bus driver, motion engine, and EtherCAT network operation, resulting in the EtherCAT network transitioning to the Init state.

Returns TRUE if the function succeeded.

See also: "MLMotionStart" (→ p. 417), "MLMotionRstErr" (→ p. 416), "MLMotionStatus" (→ p. 418)

3.3.3.7.1 Return Type

BOOL


3.3.3.7.2 Example

3.3.3.7.2.1 ST


```

//Stop the EtherCAT network
ON StopMotionEngine DO
    MLMotionStop();
END_DO;
```

3.3.3.7.2.2 FBD



3.3.3.7.2.3 FFLD



3.3.4 Coordinated Motion Function Blocks

These tables are a list of the Coordinated Motion function blocks:

- "Group Control" (→ p. 421)
- "Info" (→ p. 422)
- "Motion" (→ p. 422)
- "Reference" (→ p. 423)

3.3.4.1 Group Control

See "Coordinated Motion Location" (→ p. 423) to find this function block.

Name	Grouping	Description
MC_AddAxisToGrp	Group Control	Adds an axis to an axes group.
MC_CreateAxesGrp	Group Control	Create an axis group for coordinated motion.
MC_GrpDisable	Group Control	Changes the state of a group to GroupDisabled .
MC_GrpEnable	Group Control	Changes the state of a group from GroupDisabled to GroupStandby .
MC_GrpReadBoolPar	Group Control	Reads a value from the specified boolean group parameter
MC_GrpReadParam	Group Control	Reads a value from the specified group parameter.
MC_GrpReset	Group Control	Resets all the axes in an axes group.
MC_GrpReset	Group Control	Makes the transition from the state GroupErrorStop to GroupStandby by resetting all internal group-related errors. Resets axis errors and drive faults for each axis in the group.
MC_GrpStop	Group Control	Performs a non-aborted, controlled motion stop on all axes in an AxesGroup .
MC_GrpWriteBoolPar	Group Control	Writes a value to the specified Boolean group parameter.
MC_GrpWriteParam	Group Control	Writes a value to the specified group parameter.
MC_InitAxesGrp	Group Control	Initializes the kinematic limits for the axis group.

Name	Grouping	Description
MC_RemAxisFromGrp	Group Control	Removes an individual axis from an axis group.
MC_SetKinTra	Group Control	Sets the kinematic transform between the Machine Coordinate System and the Axes Coordinate System
MC_UngroupAllAxes	Group Control	Removes all axes from an axes group.

3.3.4.2 Info

See "[Coordinated Motion Location](#)" (→ p. 423) to find this function block.

Name	Grouping	Description
MC_GrpReadActAcc	Info	Reads the actual acceleration of the group and the axes in the group.
MC_GrpReadActPos	Info	Reads the actual position of the axes in the group.
MC_GrpReadActVel	Info	Reads the actual velocity of the group and the axes in the group.
MC_GrpReadCmdPos	Info	Reads the command position of the axes in the group.
MC_GrpReadCmdVel	Info	Reads the command velocity of the axes in the group and the path velocity.
MC_GrpReadError	Info	Reads the Group ErrorID in State ERRORSTOP.
MC_GrpReadStatus	Info	Returns the status of an axes group.

3.3.4.3 Motion

See "[Coordinated Motion Location](#)" (→ p. 423) to find this function block.

Name	Grouping	Description
MC_AxisSetDefaults	Motion	Sets the default kinematic parameters for an axis.
MC_ErrorDescription	Motion/Common > Info	Converts the PLCopen error IDs into message strings
MC_GrpHalt	Motion	Performs a controlled motion stop of all the axes in the group
MC_GrpSetOverride	Motion	Sets the velocity factor that is multiplied to the commanded velocity of all axes in the group.


Name	Grouping	Description
MC_MoveCircAbs	Motion	Commands interpolated circular movement on an axes group to the specified absolute positions.
MC_MoveCircRel	Motion	Commands interpolated circular movement on an axes group to the specified relative positions.
MC_MoveDirAbs	Motion	Commands movement of an axes group to an absolute position regardless of path.
MC_MoveDirRel	Motion	Commands movement of an axes group to a relative position regardless of path.
MC_MoveLinAbs	Motion	Commands interpolated linear movement on an axes group to the specified absolute positions.
MC_MoveLinRel	Motion	Commands interpolated linear movement on an axes group to the specified relative positions.

3.3.4.4 Reference

See "[Coordinated Motion Location](#)" (→ p. 423) to find this function block.

Name	Grouping	Description
MC_GrpSetPos	Reference	Sets the axis position for all of the axes in an axes group to the positions specified in the <code>Position</code> input.

3.3.4.4.1 Coordinated Motion Location



3.3.4.5 Coordinated Motion Group Control Library

Function	Description
"Related Functions" (→ p. 425)	Adds an axis to an axes group.
"Related Function Blocks" (→ p. 428)	Create an axis group for coordinated motion.
"Related Functions" (→ p. 431)	Changes the state of a group to GroupDisabled.
"MC_GrpEnable" (→ p. 432)	Changes the state of a group from GroupDisabled to GroupStandby.
"Related Function Blocks" (→ p. 434)	Reads a value from the specified Boolean group parameter
"Input" (→ p. 437)	Reads a value from the specified group parameter.
"Related Functions" (→ p. 438)	Makes the transition from the state GroupErrorStop to GroupStandby by resetting all internal group-related errors. Also resets axis errors and drive faults for each axis in the group.
"Related Functions" (→ p. 441)	Performs a non-aborted, controlled motion stop on all axes in an AxesGroup.
"Related Function Blocks" (→ p. 443)	Writes a value to the specified Boolean group parameter.
"Input" (→ p. 445)	Writes a value to the specified group parameter.
"Related Function Blocks" (→ p. 447)	Initializes the kinematic limits for the axis group.
"Related Functions" (→ p. 450)	Removes an individual axis from an axis group.

Function	Description
"Related Functions" (→ p. 455)	Removes all axes from an axes group.

3.3.4.5.1 MC_AddAxisToGrp



3.3.4.5.1.1 Description

This function block adds an axis to an axes group. Both the axis and the axes group must be created prior to calling this function block. See "Related Function Blocks" (→ p. 428) and [Create PLCopen Axis](#).

The IdentInGroup input specifies the index of the axis in the group. Axes do not need to be added in sequential order and gaps are acceptable. Gaps are ignored when the group is used.

The group must be in either the "GroupStandby" or "GroupDisabled" state when the axis is added. The state of the group can be read with "Related Functions" (→ p. 476). This implies that the group cannot be moving when the axis is added.

This function block does not cause motion.

TIP

- An axes group cannot contain more than one instance of an axis.
- Two active groups cannot contain the same axis. An "active" group is one in any state other than GroupDisabled.




Figure 1-77: MC_AddAxisToGrp

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking. See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.3.5 Related Functions

"Related Function Blocks" (→ p. 428), "Related Functions" (→ p. 476), "Related Functions" (→ p. 450), "Related Functions" (→ p. 455), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.5.0.1 Arguments

3.3.6 Input

Execute	Description	On the rising edge the axis is added to the group.
	Data type	BOOL
	Range	0, 1

	Unit	N/A
	Default	—
AxesGroup	Description	Reference to an axes group
	Data type	AXES_GROUP_REF
	Range	—
	Unit	N/A
	Default	—
Axis	Description	Reference to the axis to be added. An axes group cannot contain more than one instance of an axis.
	Data type	AXIS_REF
	Range	—
	Unit	N/A
	Default	—
IdentInGroup	Description	<p>The zero-based index of the axis in the group.</p> <ul style="list-style-type: none"> The axis slot in the group cannot be occupied by another axis. The index must be less than the maximum number of axes the group can contain. <p><code>MaxNumberOfAxes</code> is a property of the axes group and is set when the group is created.</p> <p>To remove an axis from a group see "Related Functions" (→ p. 450).</p>
	Data type	UINT
	Range	[0, MaxNumberOfAxes - 1]
	Unit	N/A
	Default	—

3.3.7 Output

Done	Description	If True, then the command completed successfully.
	Data type	BOOL
Error	Description	If True, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error identifier if Error output is set to True. See the table in PLCopen Function Block ErrorID Output .
	Data type	INT

3.3.7.0.1 Example


3.3.8 Structured Text

```
(*MC_AddAxisToGrp ST example *)
Inst_MC_AddAxisToGrp (AddAxisToGrp, Group1_ref, Axis_1, 0);
```


3.3.9 IL

```
BEGIN_IL
CAL Inst_MC_AddAxisToGrp( AddAxisToGrp, Group1_ref, Axis_1, 0 )
END_IL
```

3.3.10 FBD



3.3.11 Ladder Diagram



3.3.11.0.1 MC_CreateAxesGrp

PLCopen ✓

Pipe Network ✓

3.3.11.0.1.1 Description

MC_CreateAxesGrp creates an axes group for coordinated motion. More than one axes group may be created and be active at the same time but each axis can only be a part of one group at a time.

Example of a valid setup:

```
AxesGroup1: Axis0, Axis1, Axis2
AxesGroup2: Axis3, Axis4
```

Example of an invalid setup:

```
AxesGroup1: Axis0, Axis1, Axis2
AxesGroup2: Axis2, Axis3, Axis4
```

The invalid setup is not allowed because Axis2 would be a part of two axes groups at the same time.

If an axis needs to be in more than one group, it can be removed from one and then added to another group. This is done using "Related Functions" (→ p. 450) and "Related Functions" (→ p. 425).

⚠ IMPORTANT

MC_CreateAxesGrp must be called between "MLMotionInit" (→ p. 414) and "MLMotionStart" (→ p. 417).




Figure 1-78: MC_CreateAxesGrp

3.3.12 Related Function Blocks

"Related Function Blocks" (→ p. 447), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.12.0.0.1 Arguments

For more detail on how inputs and outputs work, refer to [PLCopen Function Blocks - General Rules](#).

3.3.12.0.0.2 Input

Execute	Description	On the rising edge, this function block will create a coordinated motion axes group
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
Name	Description	Axes Group Name
	Data Type	STRING
	Range	String length from 1 to 64 characters. The string length is limited to 64 characters for optimal controller performance.
	Unit	N/A
	Default	—

UpdateRate	Description	Update rate of the axes group. The group update rate will be the same as the Base Period specified in " MLMotionInit " (→ p. 414). The update rate will run at the Base Period if it is a smaller time than the Base Period. (0, 1, and 2 are reserved for future enhancements) 3 = 125 µsec 4 = 250 µsec 5 = 500 µsec 6 = 1 msec 7 = 2 msec 8 = 4 msec 9 = 8 msec
	Data Type	UINT
	Range	[3,9]
	Unit	N/A
	Default	—
MaxNumberOfAxes	Description	The maximum number of axes that can be controlled by the group.
	Data Type	UINT
	Range	[2,256]
	Unit	N/A
	Default	—
AxesGroupRef	Description	The axes group reference variable to be initialized with a reference to the new axes group.
	Data Type	AXES_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—

3.3.12.0.0.3 Output

Done	Description	If True, then the command completed successfully.
	Date Type	BOOL
Error	Description	If True, then an error has occurred.
	Date Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in PLCopen Function Block ErrorID Output .
	Date Type	INT

3.3.12.0.0.4 Example

Calls to this function block are automatically generated when the application is compiled. Users should not manually call this function block.


3.3.13 Structured Text

```
Inst_MC_CreateAxesGrp( DoExecute, 'Group1', UpdateRate_3, MaxAxes,
Group1_Ref);
```


3.3.14 Instruction List

```
BEGIN_IL
CAL Inst_MC_CreateAxesGrp1(DoExecute, 'Group1', UpdateRate_3,
MaxAxes, Group1_Ref)
END_IL
```

3.3.15 Function Block Diagram



3.3.16 Ladder Diagram



3.3.16.0.1 MC_GrpDisable

PLCopen ✓ Pipe Network ✓

3.3.16.0.1.1 Description

MC_GrpDisable changes the state for a group to GroupDisabled. If the group is already in GroupDisabled, then MC_GrpDisable will do nothing. This function block can be issued in the group states: (GroupDisabled, GroupStandby, or GroupErrorStop).

NOTE

MC_GrpDisable will fail if the group is in any state other than GroupStandby or GroupDisabled.

Refer to [Group State Diagrams](#) for details.




Figure 1-79: MC_GrpDisable

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking.

See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.3.17 Related Functions

"MC_GrpEnable" (→ p. 432), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.17.0.0.1 Arguments

3.3.18 Input

Execute	Description	On the rising edge, request to disable the axis group.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	The axis group to be disabled
	Data Type	AXIS_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—

3.3.19 Output

Done	Description	If True, then the command completed successfully.
	Data Type	BOOL
Error	Description	If True, then an error has occurred.
	Data Type	BOOL

ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in PLCopen Function Block ErrorID Output
	Data Type	INT

3.3.19.0.0.1 Example

3.3.20 ST

```
(* Inst_MC_GrpDisableST example *)
Inst_MC_GrpDisable( DisableGroup, Group1_Ref );
```


3.3.21 IL

```
BEGIN_IL
    CAL Inst_MC_GrpDisable( DisableGroup, Group1_Ref )
END_IL
```

3.3.22 FBD



3.3.23 FFLD



3.3.23.0.1 MC_GrpEnable

- PLCopen ✓
- Pipe Network ✓

Function Block - Changes the state of a group from GroupDisabled to GroupStandby. If the group is already in GroupStandby, then **MC_GrpEnable** does nothing.

3.3.23.0.1.1 Inputs

Input	Data Type	Range	Unit	Default	Description
Execute	BOOL	0, 1	N/A	No default	On the rising edge, request to enable the axis group.
AxisGroup	AXIS_GROUP_REF	N/A	N/A	No default	The axis group to be enabled.

3.3.23.0.1.2 Outputs

Output	Data Type	Range	Unit	Description
Done	BOOL	N/A	N/A	If TRUE, the command completed successfully.
Error	BOOL	N/A	N/A	If TRUE, an error has occurred.
ErrorID	INT	N/A	N/A	Indicates the error if Error output is TRUE. See the table in PLCopen Function Block ErrorID Output .

3.3.23.0.1.3 Remarks

NOTE
The group must be in GroupStandby to perform motion.

MC_GrpEnable fails under these conditions:

- It contains no axes.
- The group is not in GroupDisabled or GroupStandby.
- One or more axes in the group are in another group that is not in GroupDisabled.
- See [Group State Diagrams](#) for more information.





Figure 1-80: MC_GrpEnable


See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

NOTE
This function block starts a motion-related action and therefore stores data for calculations and error checking.
See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.3.23.0.1.4 FBD Language



3.3.23.0.1.5 FFLD Language



3.3.23.0.1.6 IL Language

```

BEGIN_IL
    CAL Inst_MC_GrpEnable( EnableGroup, Group1_Ref )
END_IL
    
```

3.3.23.0.1.7 ST Language

```
(* Inst_MC_GrpEnableST example *)
Inst_MC_GrpEnable( EnableGroup, Group1_Ref );
```

See Also

- "MC_ErrorDescription" (→ p. 396)
- "Related Functions" (→ p. 431)

3.3.23.0.2 MC_GrpReadBoolPar



3.3.23.0.2.1 Description

This function block reads a value from the specified Boolean group parameter. See [Recovery of the System State After an Axis Error](#) for more information.

MC_GrpReadBoolPar(Axesgroup_Ref GroupID, Uint BoolID) where BoolID can be one of the following 2 currently defined Booleans:

IGNORE_AXIS_ESTOP: ID = 1000 : The value read will be either TRUE or False as set by the MC_GrpWriteBoolPar function block.

AXIS_ESTOP_ACTIVE: ID = 1001 : This Read-only parameter will be asserted TRUE whenever an axis in the group is experiencing an Axis Estop Error. When there are no Axis Estop Errors present on the axes in a group, this parameter will be set to FALSE.




Figure 1-81: MC_GrpReadBoolPar

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.3.24 Related Function Blocks

"Related Function Blocks" (→ p. 443), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.24.0.0.1 Arguments

For more details on how inputs and outputs work, refer to [PLCopen Function Blocks - General Rules](#).

3.3.25 Input

Enable	Description
	If True, then request to read a value from the specified Boolean group parameter.

	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroupRef	Description	The axis group that the Boolean parameter value will be read from.
	Data Type	AXES_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
ParamNum	Description	ParamNum can be one of the following two currently defined Booleans: <ul style="list-style-type: none"> • IGNORE_AXIS_ESTOP: ID = 1000 : The value read will be either TRUE or False as set by the MC_GrpWriteBoolPar function block. • AXIS_ESTOP_ACTIVE: ID = 1001 : This Read-only parameter will be asserted TRUE whenever an axis in the group is experiencing an Axis Estop Error. When there are no Axis Estop Errors present on the axes in a group, this parameter will be set to FALSE.
	Data Type	UINT
	Range	1000, 1001
	Unit	UINT
	Default	—

3.3.26 Output

Done	Description	If True, then the command completed successfully.
	Data Type	BOOL
Error	Description	If True, an error has occurred.
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in PLCopen Function Block ErrorID Output .
	Data Type	INT
ParamValue	Description	True or False
	Data Type	BOOL

3.3.26.0.1 Example

3.3.27 ST

```
Inst_GrpReadBoolPar( DoEnable, Group1_Ref, AXIS_ESTOP_ACTIVE );
```


3.3.28 IL

```
BEGIN_IL
  Cal Inst_GrpReadBoolPar( DoEnable, Group1_Ref, AXIS_ESTOP_ACTIVE )
END_IL
```

3.3.29 FBD



3.3.30 FFLD



3.3.30.0.1 MC_GrpReadParam



This function block reads the value of the specified group parameter.




Figure 1-82: MC_GrpReadParam

NOTE
 This function or function block returns cached data.
 See [Programming a Dual Core Controller](#) for more information.

Related Function Blocks

"Input" (→ p. 445), "MC_ErrorDescription" (→ p. 396)
 See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.30.0.1.1 Arguments

For more details on how inputs and outputs work, refer to [PLCopen Function Blocks - General Rules](#).

3.3.31 Input

Enable	Description	If True, then request to read a value from the specified group parameter.
	Data Type	BOOL
	Range	0,1
	Unit	N/A
	Default	—
AxesGroupRef	Description	The axis group that the parameter value will be read from.
	Data Type	AXIS_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
ParamNum	Description	Currently, only one parameter is supported: MC_GRP_PARAM_CIRCLE_TOLERANCE: (ID = 2000): The value read will be the axes group circle construction tolerance. See Precision Requirements for Circular Move Input Parameters for more information.
	Data Type	LREAL
	Range	See Axes Group Parameters
	Unit	LREAL
	Default	—

3.3.32 Output

Done	Description	If True, then the command completed successfully.
	Data Type	BOOL
Error	Description	If True, an error has occurred.
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in PLCopen Function Block ErrorID Output.
	Data Type	INT
ParamValue	Description	The value of the group parameter.
	Data Type	LREAL


3.3.32.0.0.1 Examples

3.3.33 ST


```

Inst_MC_GrpReadParam( DoEnable, Group1_ref, MC_GRP_PARAM_CIRCLE_TOLERANCE
);
CircleTolerance := Inst_MC_GrpReadParam.ParamValue;
    
```

3.3.34 FBD



3.3.35 FFLD



3.3.35.0.1 MC_GrpReset



3.3.35.0.1.1 Description

This function block makes the transition from the state GroupErrorStop to GroupStandby by resetting all internal group-related errors – it does not affect the output of the FB instances. This function block also resets axis errors and drive faults for each axis in the group. This function block does not cause any motion.




Figure 1-83: MC_GrpReset

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking. See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.3.36 Related Functions

"Related Functions" (→ p. 474), "Related Functions" (→ p. 476), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.36.0.1 Arguments

For more details on how inputs and outputs work, refer to [PLCopen Function Blocks - General Rules](#).

3.3.37 Input

Execute	Description	On the rising edge, this FB resets group-related errors and all of the axes in the group.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	The axes group in which the axes will be reset.
	Data Type	AXES_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—

3.3.38 Output


Done	Description	If True, then the reset completed successfully.
	Data Type	BOOL
Busy	Description	If True, then the FB is executing.
	Data Type	BOOL
Error	Description	If True, an error has occurred.
	Data Type	BOOL
ErrorID	Description	Indicates the error identifier if Error output is set to TRUE. See table in PLCopen Function Block ErrorID Output .
	Data Type	INT

3.3.38.0.0.1 Example

3.3.39 ST

```
Inst_MC_GrpReset ( EnableReset, Group1_Ref );
```

3.3.40 FBD




3.3.41 IL

```

BEGIN_IL
    CAL Inst_MC_GrpReset ( EnableReset, Group1_Ref )
END_IL
    
```

3.3.42 FFLD



3.3.42.0.1 MC_GrpStop




3.3.42.0.1.1 Description

MC_GrpStop performs a controlled motion stop of all axes in the group. When the path velocity reaches zero any queued moves are flushed from the buffer and the Done output is set. When both the Done output is true and the application has cleared the Execute input the state transitions to GroupStandby. MC_GrpStop *can not be aborted*.

NOTE

MC_GrpStop does NOT prevent a single axis from executing nor does it prevent other Coordinated Motion moves from executing once MC_GrpStop has completed.



NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking. See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.3.43 Related Functions

"Related Functions" (→ p. 484), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.43.0.0.1 Arguments

For more details on how inputs and outputs work, refer to [PLCopen Function Blocks - General Rules](#).

3.3.44 Input

Execute	Description	On the rising edge the command to stop all of the axes in the group is initiated.
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	The axes group in which the axes will be stopped.
	Data type	AXES_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
Deceleration	Description	The path deceleration rate for all of the axes in the group
	Data type	LREAL
	Range	0 < Deceleration See Limitations on Acceleration and Jerk for more information.
	Unit	N/A
	Default	—
JerK	Description	Not supported
	Data type	LREAL
	Range	0 ≤ Jerk See Limitations on Acceleration and Jerk for more information.
	Unit	N/A
	Default	—

3.3.45 Output

Done	Description	If True, then the command completed successfully.
-------------	--------------------	---

	Data type	BOOL
Busy	Description	TRUE from the moment the EXECUTE input is TRUE until the stop is complete.
	Data type	BOOL
Active	Description	If True, then the stop is still executing.
	Data type	BOOL
Error	Description	If True, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error identifier if Error output is set to TRUE. See table in PLCopen Function Block ErrorID Output .
	Data type	INT

3.3.45.0.0.1 Example

3.3.46 Structured Text

```
Inst_MC_GrpStop ( EnableStop, Group1_Ref, Deceleration, Jerk );
```


3.3.47 IL

```


BEGIN_IL
    CAL Inst_MC_GrpStop ( EnableStop, Group1_Ref, Deceleration, Jerk )
END_IL

```

3.3.48 FBD



3.3.49 FFLD



3.3.49.0.1 MC_GrpWriteBoolPar PLCopen ✓ Pipe Network ✓

3.3.49.0.1.1 Description

This function block writes a value to the specified Boolean group parameter. See [Recovery of the System State After an Axis Error](#) for more information.

IGNORE_AXIS_ESTOP (BoolID = 1000), and the Value can be either TRUE or FALSE.

- Setting this Boolean Parameter to TRUE will result in the Coordinated Motion Engine NOT stopping all axes in a group when one of them is stopped due to an Axis Estop Error. Only the axis experiencing the error will stop when this Parameter is set to TRUE.
- When this parameter is FALSE (Default), all axes in a group will be stopped and the power off request is asserted for each axis.




Figure 1-84: MC_GrpWriteBoolPar

NOTE
 This function or function block returns cached data.
 See [Programming a Dual Core Controller](#) for more information.

3.3.50 Related Function Blocks

"[Related Function Blocks](#)" (→ p. 434), "[MC_ErrorDescription](#)" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.50.0.0.1 Arguments

For more details on how inputs and outputs work, refer to [PLCopen Function Blocks - General Rules](#).

3.3.51 Input

Execute	Description	On the rising edge, request to write a value to the specified Boolean group parameter.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroupRef	Description	The axis group that the Boolean parameter value will be written to.
	Data Type	AXES_GROUP_REF
	Range	N/A

	Unit	N/A
	Default	—
ParamNum	Description	The ID number of the Boolean parameter that is to be written IGNORE_AXIS_ESTOP (BoolID = 1000)
	Data Type	UINT
	Range	
	Unit	
	Default	
ParamValue	Description	True or false
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—

3.3.52 Output

Done	Description	If True, then the command completed successfully.
	Data Type	BOOL
Busy	Description	If True, then the function block is executing.
	Data Type	BOOL
Error	Description	If True, an error has occurred.
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in PLCopen Function Block ErrorID Output .
	Data Type	INT

3.3.52.0.0.1 Example

3.3.53 ST

```
Inst_MC_GrpWriteBoolPar( ExecuteWrite, Group1Ref, IGNORE_AXIS_ESTOP, true
);
```

3.3.54 IL


```

    BEGIN_IL
    Cal Inst_MC_GrpWriteBoolPar( ExecuteWrite, Group1Ref, IGNORE_AXIS_
ESTOP, true )
    END_IL
```

3.3.55 FBD



3.3.56 FFLD



3.3.56.0.1 MC_GrpWriteParam



This function block writes a value to the specified group parameter.




Figure 1-85: MC_GrpWriteParam

NOTE
 This function or function block returns cached data.
 See [Programming a Dual Core Controller](#) for more information.

Related Function Blocks

"Input" (→ p. 437), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.56.0.1.1 Arguments

For more details on how inputs and outputs work, refer to PLCopen Function Blocks - General Rules.

3.3.57 Input

Execute	Description	On the rising edge, request to write a value to the specified group parameter.
	Data Type	BOOL
	Range	0,1
	Unit	N/A
	Default	—

AxesGroupRef	Description	The axis group that the parameter value will be written to.
	Data Type	AXIS_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
ParamNum	Description	Currently, only one parameter is supported: MC_GRP_PARAM_CIRCLE_TOLERANCE: (ID = 2000): The value read will be the axes group circle construction tolerance. See Precision Requirements for Circular Move Input Parameters for more information.
	Data Type	LREAL
	Range	See Axes Group Parameters
	Unit	LREAL
	Default	—
ParamValue	Description	The new value for the group parameter
	Data Type	LREAL
	Range	parameter dependent
	Unit	parameter dependent
	Default	—

3.3.58 Output


Done	Description	If True, then the command completed successfully.
	Data Type	BOOL
Busy	Description	If True, then the function block is executing.
	Data Type	BOOL
Error	Description	If True, an error has occurred.
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in PLCopen Function Block ErrorID Output.
	Data Type	INT

3.3.58.0.0.1 Examples


3.3.59 ST.

```
Inst_MC_GrpWriteParam( DoExecute, Group1_ref, MC_GRP_PARAM_CIRCLE_TOLERANCE, CircleTolerance );
```

3.3.60 FBD



3.3.61 FFLD



3.3.61.0.1 MC_InitAxesGrp PLCopen ✓ Pipe Network ✓

3.3.61.0.1.1 Description

MC_InitAxesGrp initializes the kinematic limits for the axis group. During a move, the motion engine verifies that the limits are not exceeded.

NOTE
The function block returns an error if the group state is not GroupStandby or GroupDisabled.




Figure 1-86: MC_InitAxesGrp

3.3.62 Related Function Blocks

"Related Function Blocks" (→ p. 428), "MC_ErrorDescription" (→ p. 396)
See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.62.0.0.1 Arguments

3.3.63 Inputs

Execute	Description	On the rising edge, this function block will initialize the axis group.
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	The axis group to be initialized
	Data type	AXIS_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
VelocityLimit	Description	Velocity limit
	Data type	LREAL
	Range	$0 < \text{Velocity} < (20 * \text{Acceleration})$ and $0 < \text{Velocity} < (20 * \text{Deceleration})$ See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second
	Default	—
AccelerationLimit	Description	Acceleration limit
	Data type	LREAL
	Range	$0 < \text{Velocity} < (20 * \text{Acceleration})$ See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second ²
	Default	—
DecelerationLimit	Description	Deceleration limit
	Data type	LREAL
	Range	$0 < \text{Velocity} < (20 * \text{Deceleration})$ See Limitations on Acceleration and Jerk for more information.
	Unit	User units per second ²
	Default	—
Jerklimit	Description	Jerklimit
	Data type	LREAL

Range	(Velocity / 20) < Acceleration < (2 * Jerk) and (Velocity / 20) < Deceleration < (2 * Jerk) See Limitations on Acceleration and Jerk for more information.
Unit	User units per second ³
Default	

3.3.64 Outputs

Done	Description	If True, then the command completed successfully.
	Data type	BOOL
Error	Description	If True, then an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in PLCopen Function Block ErrorID Output
	Data type	INT

3.3.64.0.0.1 Example


3.3.65 Structured Text

```
(* Inst_MC_InitAxesGrpST example *)
Inst_MC_InitAxesGrp( initAxesGrp, grp, velLim, accelLim, decelLim,
jerkLim );
```


3.3.66 IL

```
BEGIN_IL
    CAL Inst_MC_InitAxesGrp( initAxesGrp, grp, velLim, accelLim,
decelLim, jerkLim )
END_IL
```

3.3.67 FBD



3.3.68 FFLD



3.3.68.0.1 MC_RemAxisFromGrp



3.3.68.0.1.1 Description

MC_RemAxisFromGrp removes a single axis from a group. This function block can be issued in the group states: (GroupDisabled, GroupStandby, or GroupErrorStop). The group’s state will change to GroupDisabled if the axis removed is the last valid axis in the group. This function block does not cause any motion.

NOTE

MC_RemAxisFromGrp will fail if the group is in any state other than GroupStandby or GroupDisabled. Refer to [Group State Diagrams](#) for details.




Figure 1-87: MC_RemAxisFromGrp

3.3.69 Related Functions

"Related Functions" (→ p. 425), "Related Functions" (→ p. 455), "MC_ErrorDescription" (→ p. 396)
 See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking. See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.3.69.0.0.1 Arguments

3.3.70 Input

Execute	Description	On the rising edge, request to remove an axis from the group
	Data type	BOOL
	Range	0, 1

	Unit	N/A
	Default	—
AxesGroupRef	Description	The axis group from which the axis will be removed
	Data type	AXIS_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
IdentInGroup	Description	The zero-based index of the axis in the group. <ul style="list-style-type: none"> The axis index in the group must contain a valid axis The index must be less than the maximum number of axes the group can contain. <p><code>MaxNumberOfAxes</code> is a property of the axes group and is set when the group is created.</p>
	Data type	UINT
	Range	[0, MaxNumberOfAxes - 1]
	Unit	N/A
	Default	—

3.3.71 Output

Done	Description	If True, then the command completed successfully.
	Data type	BOOL
Error	Description	If True, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error identifier if Error output is set to True. See the table in PLCopen Function Block ErrorID Output .
	Data type	INT

3.3.71.0.0.1 Example

3.3.72 ST

```
(* Inst_MC_InitAxisGrpST example *)
Inst_MC_RemAxisFromGrp( ExecuteRemAxisFromGrp, Group1_Ref, AxisId );
```


3.3.73 IL

```
BEGIN_IL


CAL Inst_MC_RemAxisFromGrp( ExecuteRemAxisFromGrp, Group1_Ref,
```

```
AxisId )
END_IL
```

3.3.74 FBD



3.3.75 FFLD



3.3.75.0.1 MC_SetKinTra PLCopen

3.3.75.0.1.1 Description

This function block sets the kinematic transform between the Machine Coordinate System and the Axes Coordinate System. It is useful for robotics, allowing the application to command motion in Cartesian coordinates for the robotic system.

After MC_SetKinTra(...) is called, the controller will automatically calculate the inverse kinematics for the robot axes, converting the robot path motion into the individual robot joint axis trajectories. Several transform types are available for common robotic systems and are configurable with the "MC_KIN_REF Structure" (→ p. 457). The parameters in the MC_KIN_REF structure define the specific robot geometry.

TIP

Description of the structure may be found in "MC_KIN_REF Structure" (→ p. 457).




Figure 1-88: MC_SetKinTra

3.3.75.0.1.2 Arguments

3.3.76 Input

Execute	Description	On the rising edge, request to load the kinematic transform.
	Data type	BOOL
	Range	0, 1

	Unit	N/A
	Default	N/A
AxesGroup	Description	The axis group that will receive the axis trajectory values from the kinematic transform.
	Data type	AXIS_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	N/A
KinTransform	Description	Kinematic robotic transform defined by the " MC_KIN_REF Structure " (→ p. 457)
	Data type	MC_KIN_REF
	Range	N/A
	Unit	N/A
	Default	N/A

3.3.77 Output

Done	Description	If True, then the command completed successfully.
	Data type	BOOL
Error	Description	If True, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See table in PLCopen Function Block ErrorID Output
	Data type	INT

3.3.77.0.0.1 Example

3.3.78 Structured Text

```
// MC_SetKinTra ST Example

// DeltaBotTransform is of type MC_KIN_REF

DeltaBotTransform.TransformType := MC_TRANSFORM_TYPE_DELTA;
DeltaBotTransform.KinParameters[MC_DELTA_KIN_PARAM_RADIUS_BASE_LENGTH] :=
10.0;
DeltaBotTransform.KinParameters[MC_DELTA_KIN_PARAM_RADIUS_END_LENGTH] :=
2.0;
DeltaBotTransform.KinParameters[MC_DELTA_KIN_PARAM_MOTOR_ARM_LENGTH] :=
5.0;
DeltaBotTransform.KinParameters[MC_DELTA_KIN_PARAM_END_ARM_LENGTH] :=
25.0;
```


```

Inst_MC_SetKinTra(True, DeltaBotAxesGrp, DeltaBotTransform);


// ...

Inst_MC_MoveLinAbs(True, DeltaBotAxesGrp, PositionList, DeltaBotVel,
DeltaBotAcc, DeltaBotDec, LREAL#0.0, MC_COORDINATE_SYSTEM_MCS, MC_BUFFER_
MODE_ABORTING, MC_TRANSITION_MODE_NONE, EmptyTransitionParams);
    
```

3.3.79 Function Block Diagram



3.3.80 Ladder Diagram



3.3.80.0.1 MC_UngroupAllAxes



3.3.80.0.1.1 Description

MC_UngroupAllAxes removes all axes from an axes group. This function block can be issued in the group states: (GroupDisabled, GroupStandby, or GroupErrorStop). The axes group state will be changed to GroupDisabled upon successful completion. This function block does not cause any motion.

NOTE

MC_UngroupAllAxes will fail if the group is in any state other than GroupStandby or GroupDisabled. Refer to [Group State Diagrams](#) for details.




Figure 1-89: MC_UngroupAllAxes

3.3.81 Related Functions

"Related Functions" (→ p. 425), "Related Functions" (→ p. 450), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking. See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.3.81.0.0.1 Arguments

3.3.82 Input

Execute	Description	On the rising edge, request to remove all axes in the axes group
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroupRef	Description	The axis group from which to remove all axes
	Data type	AXIS_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—

3.3.83 Output

Done	Description	If True, then the command completed successfully.
	Data type	BOOL
Error	Description	If True, an error has occurred
	Data type	BOOL
ErrorID	Description	Indicates the error identifier if 'Error' output is set to TRUE. See the table in PLCopen Function Block ErrorID Output .
	Data type	INT

3.3.83.0.0.1 Examples

3.3.84 ST

```
Inst_MC_UngroupAllAxes( ExecuteUngroup, Group1_Ref );
```


3.3.85 IL

```
BEGIN_IL
    CAL Inst_MC_UngroupAllAxes( ExecuteUngroup, Group1_Ref )
END_IL
```

3.3.86 FBD



3.3.87 FFLD





3.3.87.0.1 MC_KIN_REF Structure


The MC_KIN_REF structure defines the robotic system transform type and its parameters. The parameters are specific to each transform type. The general MC_KIN_REF structure is described below, with further parameter specific descriptions for each robotic transform type.

Member	Type	Description	Related Function Blocks
TransformType	UINT	A number that identifies the specific robotic system transform. The #defines for the transform types (MC_TRANSFORM_TYPE_GANTRY, MC_TRANSFORM_TYPE_DELTA, etc.) are listed below.	"Input" (→ p. 452)
KinParameters [0 - 31]	LREAL	An array of up to 32 parameters to define the robotic system and its kinematic transform. The parameter count (0 to 32) and the definition of each parameter is determined by the specific TransformType	"Input" (→ p. 452)

These parameters must be specified for all ACS axes in the AxisGroup, and there are two parameters for each ACS axis.

TransformType	Axis Mapping	Parameter Count	Parameter #	Description	Range																								
MC_TRANSFORM_TYPE_GANTRY	<p>The diagram shows a gantry robot with two vertical axes labeled 'A' and 'B'. A horizontal axis 'X' is shown between them. An inset table titled 'ACS Axes' lists the following:</p> <table border="1"> <thead> <tr> <th>Index</th> <th>Description</th> <th>Index</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Motor A</td> <td>0</td> </tr> <tr> <td>1</td> <td>Motor B</td> <td>1</td> </tr> <tr> <td>2</td> <td>Y-motor (optional)</td> <td>2</td> </tr> <tr> <td>3</td> <td>Z-motor (optional)</td> <td>3</td> </tr> <tr> <td>4</td> <td>u-motor (optional)</td> <td>4</td> </tr> <tr> <td>5</td> <td>Pass Through</td> <td>5</td> </tr> <tr> <td>6</td> <td>Pass Through</td> <td>6</td> </tr> </tbody> </table>	Index	Description	Index	0	Motor A	0	1	Motor B	1	2	Y-motor (optional)	2	3	Z-motor (optional)	3	4	u-motor (optional)	4	5	Pass Through	5	6	Pass Through	6	1	MC_GANTRY_KIN_PARAM_REVERSE_X	Reverse X-axis	0 = do not reverse 1 = reverse
Index	Description	Index																											
0	Motor A	0																											
1	Motor B	1																											
2	Y-motor (optional)	2																											
3	Z-motor (optional)	3																											
4	u-motor (optional)	4																											
5	Pass Through	5																											
6	Pass Through	6																											

Transform Type	Axis Mapping	Parameter Count	Parameter #	Description	Range
MC_TRANSFORM_TYPE_GANTRY_WITH_SKEW		3	MC_GANTRY_WITH_SKEW_KIN_PARAM_REVERSE_X	Reverse X-axis	0 = do not reverse 1 = reverse
			MC_GANTRY_WITH_SKEW_KIN_PARAM_SKEW_SCALE	Skew to linear unit ratio	Positive value
			MC_GANTRY_WITH_SKEW_KIN_PARAM_REVERSE_SKEW	Reverse Skew-axis	0 = do not reverse 1 = reverse
MC_TRANSFORM_TYPE_HBOT		3	MC_HBOT_KIN_PARAM_LIN_TO_ROT_RATIO	Linear to rotational unit ratio (ex: cm/degree)	Positive value
			MC_HBOT_KIN_PARAM_REVERSE_X	Reverse X-axis	0 = do not reverse 1 = reverse
			MC_HBOT_KIN_PARAM_REVERSE_Y	Reverse Y-axis	0 = do not reverse 1 = reverse

Transform Type	Axis Mapping	Parameter Count	Parameter #	Description	Range
MC_TRANSFORM_TYPE_TBOT		3	MC_TBOT_KIN_PARAM_LIN_TO_ROT_RATIO	Linear to Rotational unit ratio (ex: cm/degree)	Positive value
			MC_TBOT_KIN_PARAM_REVERSE_X	Reverse X-axis	0 = do not reverse 1 = reverse
			MC_TBOT_KIN_PARAM_REVERSE_Z	Reverse Y-axis	0 = do not reverse 1 = reverse
MC_TRANSFORM_TYPE_DELTA * Experimental *		4	MC_DELTA_KIN_PARAM_RADIUS_BASE_LENGTH	RadiusBaseLength	Positive, non-zero value
MC_DELTA_KIN_PARAM_RADIUS_END_LENGTH	RadiusEndLength				
MC_DELTA_KIN_PARAM_MOTOR_ARM_LENGTH	MotorArmLength				
MC_DELTA_KIN_PARAM_END_ARM_LENGTH	EndArmLength				

Transform Type	Axis Mapping	Parameter Count	Parameter #	Description	Range
MC_TRANSFORM_TYPE_SCARA_ELBOW_POS * Experimental *		2 or 3 The parameter count is depend on axis number of the AxisGroup. <ul style="list-style-type: none"> • 2 AxesGroup: 2 Parameters. (No Wrist) • 3 AxesGroup: 3 Parameters. (with Wrist) 	MC_SCARA_KIN_PARAM_UPPER_ARM_LENGTH	RobotUpperArmLength	Positive, non-zero value
			MC_SCARA_KIN_PARAM_LOWER_ARM_LENGTH	RobotLowerArmLength	
			MC_SCARA_KIN_PARAM_WRIST_LENGTH	RobotWristLength (Available for SCARA with wrist only)	
MC_TRANSFORM_TYPE_SCARA_ELBOW_NEG * Experimental *		2 or 3 The parameter count is depend on axis number of the AxisGroup. <ul style="list-style-type: none"> • 2 AxesGroup: 2 Parameters. (No Wrist) • 3 AxesGroup: 3 Parameters. (with Wrist) 	MC_SCARA_KIN_PARAM_UPPER_ARM_LENGTH	RobotUpperArmLength	Positive, non-zero value
			MC_SCARA_KIN_PARAM_LOWER_ARM_LENGTH	RobotLowerArmLength	
			MC_SCARA_KIN_PARAM_WRIST_LENGTH	RobotWristLength (Available for SCARA with wrist only)	

3.3.87.1 Coordinated Motion Info Library

Function	Description
"Related Functions" (→ p. 462)	Reads the actual acceleration of the group and the axes in the group.
"Related Functions" (→ p. 464)	Reads the actual position of the axes in the group.
"Related Functions" (→ p. 467)	Reads the actual velocity of the group and the axes in the group.

Function	Description
"Related Function Blocks" (→ p. 469)	Reads the command position of the axes in the group.
"Related Function Blocks" (→ p. 472)	Reads the command velocity of the axes in the group and the path velocity.
"Related Functions" (→ p. 474)	Reads the Group ErrorID in State ERRORSTOP.
"Related Functions" (→ p. 476)	Returns the status of an axes group.

3.3.87.1.1 MC_GrpReadActAcc



3.3.87.1.1.1 Description

The MC_GrpReadActAcc function block fills the array specified by the 'Acceleration' argument with the actual acceleration of the system in the coordinate system specified by the `CoordSystem` argument. The measured path acceleration is also calculated and reported via the 'PathAcceleration' output. This function block does not cause any motion.

NOTE

- The actual acceleration is smoothed over the last 10 samples. This reduces the error in acceleration estimation, but introduces a small amount of phase delay in the reported accelerations.
- Currently, only the ACS coordinate system is supported. See [Coordinate Systems](#) to learn more.




Figure 1-90: MC_GrpReadActAcc

There is a one-to-one correspondence between the axes in the Axes Group array and the acceleration values in the Acceleration array. Each element in the Acceleration array corresponds to the axis element in the Axes Group array. If an index in the Axes Group is unassigned then the acceleration value for that array element in the Acceleration array will be 0. If the element does contain an axis then the acceleration value will be filled with the current actual acceleration for that axis. Here is an example to illustrate how this works:



NOTE

This function or function block returns cached data. See [Programming a Dual Core Controller](#) for more information.

3.3.88 Related Functions

"Related Functions" (→ p. 464), "Related Functions" (→ p. 467), "Related Function Blocks" (→ p. 469), "Related Function Blocks" (→ p. 472)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.88.0.0.1 Arguments

For more detail on how inputs and outputs work, refer to [PLCopen Function Blocks - General Rules](#).

3.3.89 Input

Enable	Description	If True, then this function block will read the current actual acceleration of the group and the axes in the group
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	The axes group from which the actual acceleration will be read.
	Data type	AXES_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
CoordSystem	Description	The coordinate system used when reading the actual acceleration
	Data type	SINT
	Range	One of the following enumeration values: <ul style="list-style-type: none"> MC_COORDINATE_SYSTEM_ACS = 0 MC_COORDINATE_SYSTEM_MCS = 1 MC_COORDINATE_SYSTEM_PCS = 2
	Unit	N/A
	Default	—
Acceleration[]	Description	An array where the acceleration data will be written. The length of the array must equal the maximum number of axes allowed in the group. The maximum number of axes is an argument to "Related Function Blocks" (→ p. 428) that is used to create axes groups.
	Data type	LREAL
	Range	N/A
	Unit	User units per second ²
	Default	—

3.3.90 Output

Valid	Description	If true, the accelerations have been read without error.
	Data type	BOOL
Error	Description	If true, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output was set to TRUE. See the table PLCopen Function Block ErrorID Output
	Data type	INT
PathAcceleration	Description	The current measured path acceleration of the group, measured by taking the square root of the sum of the squared accelerations of each axis.
	Data type	LREAL
	Unit	User units per second ²

3.3.90.0.1 Example


3.3.91 Structured Text

```
Inst_MC_GrpReadActAcc( DoRead, Group, CoordSys, AccList );
```


3.3.92 IL

```
BEGIN_IL
CAL Inst_MC_GrpReadActAcc( DoRead, Group, CoordSys, AccList )
END_IL
```

3.3.93 FBD



3.3.94 Ladder Diagram



3.3.94.0.1 MC_GrpReadActPos

PLCopen ✓
Pipe Network ✓

3.3.94.0.1.1 Description

MC_GrpReadActPos fills the array specified by the 'Position' argument with the actual position of the system in the coordinate system specified by the CoordSystem argument. This function block does not cause any motion.

NOTE

Currently, only the ACS coordinate system is supported. See [Coordinate Systems](#) to learn more.




Figure 1-91: MC_GrpReadActPos

There is a one to one correspondence between the axes in the Axes Group and the position values in the Position Array. Each element in the Position Array corresponds to the axis element in the Axis Group array. If an index in the Axes Group is unassigned then the position value for that array element in the Position Array will be 0. If the element does contain an axis then the position value will be filled with the current actual position for that axis. Here is an example to illustrate how this works:



NOTE

This function or function block returns cached data. See [Programming a Dual Core Controller](#) for more information.

3.3.95 Related Functions

"Related Functions" (→ p. 467), "Related Functions" (→ p. 462), "Related Function Blocks" (→ p. 469), "Related Function Blocks" (→ p. 472)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.95.0.0.1 Arguments

For more detail on how inputs and outputs work, refer to [PLCopen Function Blocks - General Rules](#).

3.3.96 Input

Enable	Description	If True, then this function block will read the current actual position of the axes in the group
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—

AxesGroup	Description	The axes group from which the actual position will be read
	Data type	AXES_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
CoordSystem	Description	The coordinate system used when reading the actual position
	Data type	SINT
	Range	One of the following enumeration values: <ul style="list-style-type: none"> • MC_COORDINATE_SYSTEM_ACS = 0 • MC_COORDINATE_SYSTEM_MCS = 1 • MC_COORDINATE_SYSTEM_PCS = 2
	Unit	N/A
	Default	—
Position[]	Description	An array where the position data will be written. The length of the array must equal the maximum number of axes allowed in the group. The maximum number of axes is an argument to the CreateAxesGrp function block that is used to create axes groups.
	Data type	LREAL
	Range	N/A
	Unit	User units
	Default	—

3.3.97 Output

Valid	Description	If true, the positions have been read without error
	Data type	BOOL
Error	Description	If true, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table PLCopen Function Block ErrorID Output
	Data type	INT

3.3.97.0.0.1 Example

3.3.98 Structured Text


```
Inst_MC_GrpReadActPos( DoRead, Group, CoordSys, PosList );
```

3.3.99 IL


```

BEGIN_IL
CAL Inst_MC_GrpReadActPos( DoRead, Group, CoordSys, PosList )
END_IL
    
```

3.3.100 FBD



3.3.101 Ladder Diagram



3.3.101.0.1 MC_GrpReadActVel PLCopen ✓ Pipe Network ✓

3.3.101.0.1.1 Description

MC_GrpReadActVel fills the array specified by the 'Velocity' argument with the actual velocity of the system in the coordinate system specified by the CoordSystem argument. The measured path velocity is also calculated and reported via the 'PathVelocity' output. This function block does not cause any motion.

NOTE

- The actual velocity is smoothed over the last 10 samples. This reduces the error in velocity estimation, but introduces a small amount of phase delay in the reported velocities.
- Currently, only the ACS coordinate system is supported. See [Coordinate Systems](#) to learn more.





Figure 1-92: MC_GrpReadActVel

There is a one to one correspondence between the axes in the Axes Group and the velocity values in the Velocity Array. Each element in the Velocity array corresponds to the axis element in the Axes Group array. If a index in the Axes Group is unassigned then the velocity value for that array element in the Velocity array will be 0. If the element does contain an axis then the velocity value will be filled with the current actual velocity for that axis. Here is an example to illustrate how this works:

**NOTE**

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.3.102 Related Functions

"Related Functions" (→ p. 464), "Related Functions" (→ p. 462), "Related Function Blocks" (→ p. 469), "Related Function Blocks" (→ p. 472)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.102.0.0.1 Arguments

For more detail on how inputs and outputs work, refer to [PLCopen Function Blocks - General Rules](#).

3.3.103 Input

Enable	Description	If True, then this function block will read the current actual velocity of the group and the axes in the group
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	The axes group from which the actual velocity will be read
	Data type	AXES_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
CoordSystem	Description	The coordinate system used when reading the actual velocity
	Data type	SINT
	Range	One of the following enumeration values: <ul style="list-style-type: none"> MC_COORDINATE_SYSTEM_ACS = 0 MC_COORDINATE_SYSTEM_MCS = 1 MC_COORDINATE_SYSTEM_PCS = 2
	Unit	N/A
	Default	—

Velocity[]	Description	An array where the velocity data will be written. The length of the array must equal the maximum number of axes allowed in the group. The maximum number of axes is an argument to "Related Function Blocks" (→ p. 428) that is used to create axes groups.
	Data type	LREAL
	Range	N/A
	Unit	User units per second
	Default	—

3.3.104 Output

Valid	Description	If true, the velocities have been read without error.
	Data type	BOOL
Error	Description	If true, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table PLCopen Function Block ErrorID Output
	Data type	INT
PathVelocity	Description	The current measured path velocity of the group, measured by taking the square root of the sum of the squared velocities of each axis.
	Data type	LREAL
	Unit	User units per second

3.3.104.0.0.1 Example

3.3.105 Structured Text

```
Inst_MC_GrpReadActVel (DoRead, Group, CoordSys, VelList);
```


3.3.106 IL

```


BEGIN_IL
  CAL Inst_MC_GrpReadActVel (DoRead, Group, CoordSys, VelList)
END_IL

```

3.3.107 FBD



3.3.108 FFLD



3.3.108.0.1 MC_GrpReadCmdPos



3.3.108.0.1.1 Description

MC_GrpReadCmdPos fills the array (specified by the `Position` argument) with the commanded position of the coordinate system specified by the `CoordSystem` argument. This function block does not cause any motion.

NOTE
Currently, only the ACS coordinate system is supported. See [Coordinate Systems](#) to learn more.




Figure 1-93: MC_GrpReadCmdPos

There is a one to one correspondence between the axes in the Axes Group and the position values in the Position Array. Each element in the Position Array corresponds to the axis element in the Axis Group array. If an index in the Axes Group is unassigned then the position value for that array element in the Position Array will be 0. If the element does contain an axis then the position value will be filled with the current actual position for that axis. Here is an example to illustrate how this works:



NOTE
This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.3.109 Related Function Blocks

"Related Functions" (→ p. 464), "Related Functions" (→ p. 467), "Related Functions" (→ p. 462), "Related Function Blocks" (→ p. 472)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.109.0.0.1 Arguments

For more detail on how inputs and outputs work, refer to [PLCopen Function Blocks - General Rules](#).

3.3.110 Input

Enable	Description	If True, then this function block will read the current commanded position of the axes in the group
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	The axes group from which the commanded position will be read.
	Data type	AXES_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
CoordSystem	Description	The coordinate system used when reading the commanded position.
	Data type	SINT
	Range	One of the following enumeration values: <ul style="list-style-type: none"> • MC_COORDINATE_SYSTEM_ACS = 0 • MC_COORDINATE_SYSTEM_MCS = 1 • MC_COORDINATE_SYSTEM_PCS = 2
	Unit	N/A
	Default	—
Position[]	Description	An array where the position data will be written. The length of the array must equal the maximum number of axes allowed in the group. The maximum number of axes is an argument to " Related Function Blocks " (→ p. 428), which is used to create axes groups.
	Data type	LREAL
	Range	N/A
	Unit	User units
	Default	—

3.3.111 Output

Valid	Description	If true, that the positions have been read without error.
	Data type	BOOL

Error	Description	If true, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in PLCopen Function Block ErrorID Output
	Data type	INT

3.3.111.0.0.1 Example

3.3.112 Structured Text

```
(*MC_GrpReadCmdPos ST example *)
Inst_MC_GrpReadCmdPos(DoRead, Group, CoordSys, PosList );
```

3.3.113 IL


```
BEGIN_IL

    CAL Inst_MC_GrpReadCmdPos( DoRead, Group, CoordSys, PosList )
END_IL
```

3.3.114 FBD



3.3.115 FFLD



3.3.115.0.1 MC_GrpReadCmdVel



3.3.115.0.1.1 Description

MC_GrpReadCmdVel fills the array specified by the `Velocity` argument with the commanded velocity for the coordinate system, which is specified by the `CoordSystem` argument. The path velocity is also reported via the 'PathVelocity' output. This function block does not cause any motion.

NOTE

Currently, only the ACS coordinate system is supported. See [Coordinate Systems](#) to learn more.





Figure 1-94: MC_GrpReadCmdVel

There is a one to one correspondence between the axes in the Axes Group and the velocity values in the Velocity Array. Each element in the Velocity Array corresponds to the axis element in the Axis Group array. If an index in the Axes Group is unassigned then the velocity value for that array element in the Velocity Array will be 0. If the element does contain an axis then the velocity value will be filled with the current velocity for that axis. Here is an example to illustrate how this works:



NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.3.116 Related Function Blocks

"Related Functions" (→ p. 464), "Related Functions" (→ p. 467), "Related Functions" (→ p. 462), "Related Function Blocks" (→ p. 469)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.116.0.0.1 Arguments

For more detail on how inputs and outputs work, refer to [PLCopen Function Blocks - General Rules](#).

3.3.117 Input

Enable	Description	If True, then this function block will read the current commanded velocity of the group and the axes in the group
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	The axes group from which the commanded velocity will be read.
	Data type	AXES_GROUP_REF
	Range	N/A

	Unit	N/A
	Default	—
CoordSystem	Description	The coordinate system used when reading the commanded velocity.
	Data type	SINT
	Range	One of the following enumeration values: <ul style="list-style-type: none"> • MC_COORDINATE_SYSTEM_ACS = 0 • MC_COORDINATE_SYSTEM_MCS = 1 • MC_COORDINATE_SYSTEM_PCS = 2
	Unit	N/A
	Default	—
Velocity[]	Description	An array where the velocity data will be written. The length of the array must equal the maximum number of axes allowed in the group. The maximum number of axes is an argument to "Related Function Blocks" (→ p. 428), which is used to create axes groups.
	Data type	LREAL
	Range	N/A
	Unit	User units per second
	Default	—

3.3.118 Output

Valid	Description	If true, that the velocities have been read without error.
	Data type	BOOL
Error	Description	If true, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in PLCopen Function Block ErrorID Output
	Data type	INT
PathVelocity	Description	The current commanded path velocity of the group, measured by taking the square root of the sum of the squared velocities of each axis.
	Data type	LREAL
	Unit	User units per second

3.3.118.0.0.1 Example

3.3.119 Structured Text

```
(*MC_GrpReadCmdVel ST example *)
Inst_MC_GrpReadCmdVel(DoRead, Group, CoordSys, VelList );
```


3.3.120 IL

```
BEGIN_IL
    CAL Inst_MC_GrpReadCmdVel( DoRead, Group, CoordSys, VelList )
END_IL
```

3.3.121 FBD



3.3.122 FFLD



3.3.122.0.1 MC_GrpReadError

PLCopen Pipe Network

Function - describes general axes group errors.
This function does not cause any motion.




Figure 1-95: MC_GrpReadError

NOTE

This function or function block returns cached data.
See [Programming a Dual Core Controller](#) for more information.

3.3.123 Related Functions

"Related Functions" (→ p. 438), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.123.0.0.1 Arguments

3.3.124 Input

En	Description	Enables execution
	Data Type	BOOL
	Range	0,1
	Unit	N/A
	Default	—
AxesGroup	Description	The axes group from which the GroupErrorID will be read.
	Data Type	AXES_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—

3.3.125 Output

OK	Description	Indicates the function executed successfully
	Data Type	BOOL
GroupErrorID	Description	Displays the Error ID for the given Axis Group. See table in PLCopen Function Block ErrorID Output
	Data Type	INT

3.3.125.0.1 Examples


3.3.126 Structured Text

```
//Read a group error number
GroupErrorID:= MC_GrpReadError( Axis_Group );
```

3.3.127 FBD



3.3.128 FFLD



3.3.128.0.1 MC_GrpReadStatus

PLCopen ✓

Pipe Network ✓

3.3.128.0.1.1 Description

MC_GrpReadStatus returns the status of an axes group. This function block does not cause any motion. Refer to [Group State Diagrams](#) for details.

NOTE
 The following output is not currently supported. It will be supported in a future release.

- GroupHoming



Figure 1-96: MC_GrpReadStatus

NOTE
 This function or function block returns cached data.
 See [Programming a Dual Core Controller](#) for more information.

3.3.129 Related Functions

"MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.129.0.0.1 Arguments

3.3.129.0.0.2 Input

Enable	Description	If True, then the axes group status will be read.
	Data type	BOOL
	Range	0..1
	Unit	N/A
	Default	—
AxesGroup	Description	The axis group from which the status will be read
	Data type	AXIS_GROUP_REF

Range	N/A
Unit	N/A
Default	—

3.3.129.0.0.3 Output

Valid	Description	True if valid outputs are available
	Data type	BOOL
GroupMoving¹	Description	The axes group is in the Moving state, indicating that the group is enabled and currently executing a coordinated motion command.
	Data type	BOOL
GroupHoming¹	Description	Not supported
	Data type	BOOL
GroupErrorStop¹	Description	The axes group is in the ErrorStop state due to an axis error or group error. The group cannot accept coordinated motion commands. The execution of MC_GrpReset is required to change the group's state from ErrorStop to Standby.
	Data type	BOOL
GroupStandby¹	Description	The axes group is in the Standby state, meaning that the group is enabled and all its axes are enabled and the group is not currently executing a coordinated motion command. The axes group is ready to accept coordinated motion commands.
	Data type	BOOL
GroupStopping¹	Description	The axes group is in the Stopping state due the execution of MC_GrpStop. The axes group is enabled but cannot accept coordinated motion commands while in the Stopping state. The axes group remains in the Stopping state while MC_GrpStop is executing and will remain in the Stopping state while MC_GrpStop's Execute input is held high.
	Data type	BOOL
GroupDisabled¹	Description	The axis group is in the Disabled state and cannot accept coordinated motion commands.
	Data type	BOOL
ConstantVelocity	Description	True if the commanded path velocity is the same between the current scan of the application program and the previous scan. ConstantVelocity is always TRUE for Direct moves. The commanded path velocity of Direct moves is always zero.
	Data type	BOOL

Accelerating	Description	True if the commanded path velocity is accelerating between the current scan of the application program and the previous scan.
	Data type	BOOL
Decelerating	Description	True if the commanded path velocity is decelerating between the current scan of the application program and the previous scan.
	Data type	BOOL
InPosition	Description	True indicates that the axes group is “in position”. The following must be true for the axes group to be “in position”: <ul style="list-style-type: none"> • The axes group is enabled. • There are no moves in the group’s queue. • The servo loop is closed for each axis in the group. • There are no moves in the individual axis queue for each axis in the group. • The command delta is zero for each axis in the group. • The actual position is within the In-Position Bandwidth of the command position for each axis in the group.
	Data type	BOOL
Error	Description	If True, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error identifier if the Error output is set to TRUE. See the table in PLCopen Function Block ErrorID Output .
	Data type	BOOL

1 These outputs are mutually exclusive, meaning only one will be true at a time. All others will be false. Please refer to the [Group State Diagrams](#).

3.3.129.0.0.4 Example

3.3.130 Structured Text

```
//Check boolean status bits for an Axis Group
Inst_MC_GrpReadStatus( EnableGrpReadStatus, Group1_Ref );


IsGroupMoving:= Inst_MC_GrpReadStatus.GroupMoving;
IsGroupErrorStop:= Inst_MC_GrpReadStatus.GroupErrorStop;
IsGroupStandby:= Inst_MC_GrpReadStatus.GroupStandby;
IsGroupDisabled:= Inst_MC_GrpReadStatus.GroupDisabled;
Accelerating:= Inst_MC_GrpReadStatus.Accelerating;
IsConstantVelocity:= Inst_MC_GrpReadStatus.ConstantVelocity;
IsInPosition:= Inst_MC_GrpReadStatus.InPosition;
```

3.3.131 IL


```

BEGIN_IL
    CAL Inst_MC_GrpReadStatus( EnableGrpReadStatus, Group1_Ref )
END_IL
    
```

3.3.132 FBD



3.3.133 FFLD



3.3.133.1 Coordinated Motion Motion Library

Function	Description
"Related Functions" (→ p. 480)	Sets the default kinematic parameters for an axis.
"Related Functions" (→ p. 484)	Performs a controlled motion stop of all the axes in the group
"Related Functions" (→ p. 486)	Sets the velocity factor that is multiplied to the commanded velocity of all axes in the group.

Function	Description
"Related Functions" (→ p. 488)	Commands interpolated circular movement on an axes group to the specified absolute positions.
"Related Functions" (→ p. 495)	Commands interpolated circular movement on an axes group to the specified relative positions.
"Related Functions" (→ p. 501)	Commands movement of an axes group to an absolute position regardless of path.
"Related Functions" (→ p. 504)	Commands movement of an axes group to a relative position regardless of path.
"Related Functions" (→ p. 507)	Commands interpolated linear movement on an axes group to the specified absolute positions.
"Related Functions" (→ p. 512)	Commands interpolated linear movement on an axes group to the specified relative positions.

3.3.133.1.1 MC_AxisSetDefaults



3.3.133.1.1.1 Description

MC_AxisSetDefaults sets the default kinematic variables for "Related Functions" (→ p. 501) and "Related Functions" (→ p. 504). These variables are only used with the MC_MoveDir function blocks.

Each axis within the group must have the default kinematic parameters of Velocity, Acceleration, Deceleration, and Jerk set to values greater than zero. A non-zero Jerk value will perform an S-Curve rather than a trapezoidal move. Each axis within the group must have these values set before a direct move can be started.

NOTE

Jerk with a non-zero value is currently not supported for coordinated motion. Jerk parameters are currently ignored.

The function block returns an error if the group state is not GroupStandby or GroupDisabled.




Figure 1-97: MC_AxisSetDefaults

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking.

See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.3.134 Related Functions

"Related Functions" (→ p. 501), "Related Functions" (→ p. 504), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

See also:

- [Differences Between Functions and Function Blocks](#)
- Calling a function

3.3.134.0.0.1 Arguments

3.3.135 Input

Execute	Description	On the rising edge, request to set the default kinematic parameters.
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Axis	Description	Reference to the axis which will have its default kinematic parameters set.
	Data type	AXIS_REF
	Range	—
	Unit	N/A
	Default	—
Velocity	Description	The default velocity.
	Data type	LREAL
	Range	$0 < \text{Velocity} < (20 * \text{Acceleration})$ and $0 < \text{Velocity} < (20 * \text{Deceleration})$ See Limitations on Acceleration and Jerk for more information.
	Unit	User units per second
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration see "Selection of Acceleration and Jerk Parameters for Function Blocks"
	Data type	LREAL
	Range	$(\text{Velocity} / 20) < \text{Acceleration} < (2 * \text{Jerk})$ See Limitations on Acceleration and Jerk for more information.
	Unit	User units per second ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused

	Data type	LREAL
	Range	$(\text{Velocity} / 20) < \text{Deceleration} < (2 * \text{Jerk})$
	Unit	User unit per second ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk NOTE Currently the Jerk value is ignored for motion. Only trapezoidal motion is supported. see "Selection of Acceleration and Jerk Parameters for Function Blocks"
	Data type	LREAL
	Range	$(\text{Velocity} / 20) < \text{Acceleration} < (2 * \text{Jerk})$ and $(\text{Velocity} / 20) < \text{Deceleration} < (2 * \text{Jerk})$
	Unit	User units per second ³
	Default	—

3.3.136 Output

Done	Description	If True, then the command completed successfully.
	Data type	BOOL
Error	Description	If True, then an error has occurred
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in PLCopen Function Block ErrorID Output .
	Data type	DINT

3.3.136.0.0.1 Example

3.3.137 Structured Text

```
(* ST MC_AxisSetDefaults Example *)

default_velocity      := 50.0;
default_acceleration  := 250.0;
default_deceleration  := 300.0;
default_jerk          := 1000.0;


Inst_MC_AxisSetDefaults ( TRUE, CoordAxis1_ref, default_velocity,
default_acceleration, default_deceleration, default_jerk);
```

3.3.138 Instruction List


```

BEGIN_IL
  CAL Inst_MC_AxisSetDefaults( TRUE, CoordAxis1_Ref, default_velocity,
  default_acceleration, default_deceleration, default_jerk)
END_IL
    
```

3.3.139 Function Block Diagram



3.3.140 Ladder Diagram



3.3.140.0.1 MC_GrpHalt PLCopen ✓ Pipe Network ✓

3.3.140.0.1.1 Description

MC_GrpHalt performs a controlled motion stop of all the axes in the group. When the path velocity reaches zero any queued moves are flushed from the buffer, the Done output is set, and the state transitions to GroupStandby. Unlike MC_GrpStop, MC_GrpHalt can be aborted.

NOTE
 MC_GrpHalt does NOT prevent a single axis from executing nor does it prevent other Coordinated Motion moves from executing once MC_GrpHalt has completed.



NOTE
 This function block starts a motion-related action and therefore stores data for calculations and error checking.
 See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.3.141 Related Functions

"Related Functions" (→ p. 441), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.141.0.0.1 Arguments

For more details on how inputs and outputs work, refer to [PLCopen Function Blocks - General Rules](#).

3.3.142 Input

Execute	Description	On the rising edge the command to halt all of the axes in the group is initiated.
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	The axes group in which the axes will be stopped.
	Data type	AXES_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
Deceleration	Description	The path deceleration rate for all of the axes in the group
	Data type	LREAL
	Range	0 < Deceleration See Limitations on Acceleration and Jerk for more information.
	Unit	N/A
	Default	—
JerK	Description	Not supported
	Data type	LREAL
	Range	0 ≤ Jerk See Limitations on Acceleration and Jerk for more information.
	Unit	N/A
	Default	—

3.3.143 Output

Done	Description	If True, then the command completed successfully.
	Data type	BOOL

Busy	Description	TRUE from the moment the EXECUTE input is TRUE until the time the halt is completed.
	Data type	BOOL
Active	Description	Indicates that the halt is still executing.
	Data type	BOOL
CommandAborted	Description	If True, command was aborted by another FB.
	Data type	BOOL
Error	Description	If True, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error identifier if Error output is set to TRUE.. See table in PLCopen Function Block ErrorID Output .
	Data type	INT

3.3.143.0.1 Example


3.3.144 Structured Text

```
Inst_MC_GrpHalt ( EnableHalt, Group1_Ref, Deceleration, Jerk );
```


3.3.145 IL

```
BEGIN_IL
CAL Inst_MC_GrpHalt ( EnableHalt, Group1_Ref, Deceleration, Jerk )
END_IL
```

3.3.146 FBD



3.3.147 FFLD



3.3.147.0.1 MC_GrpSetOverride PLCopen ✓ Pipe Network ✓

3.3.147.0.1.1 Description

MC_GrpSetOverride sets the velocity factor that is multiplied to the commanded velocity of all axes in the group. This function block in itself does not cause any motion.




Figure 1-98: MC_GrpSetOverride

3.3.148 Related Functions

"MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.148.0.0.1 Arguments

For more detail on how inputs and outputs work, refer to [PLCopen Function Blocks - General Rules](#).

3.3.149 Input

Enable	Description	On the rising edge, changes the velocity multiplier for the axes group.
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	The axes group in which the velocity multiplier will be applied.
	Data type	AXES_GROUP_REF
	Range	N/A

	Unit	N/A
	Default	—
VelFactor	Description	The new multiplier factor for the commanded velocity of the axes group.
	Data type	REAL
	Range	[0.0 .. 2.0]
	Unit	N/A
	Default	—

3.3.150 Output

Enabled	Description	Indicates that the override was successful.
	Data type	BOOL
Busy	Description	If True, then the FB is executing.
	Data type	BOOL
Error	Description	If True, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error identifier if Error output is set to TRUE. See the table PLCopen Function Block ErrorID Output .
	Data type	INT

3.3.150.0.0.1 Example

3.3.151 ST

```
Inst_MC_GrpSetOverride( EnableOverride, Group1_Ref, VelocityFactor );
```


3.3.152 IL

```
BEGIN_IL
    CAL Inst_MC_GrpSetOverride( EnableOverride, Group1_Ref,
    VelocityFactor )
END_IL
```

3.3.153 FBD



3.3.154 FFLD



3.3.154.0.1 MC_MoveCircAbs



Function Block - commands interpolated circular movement on an axes group to the specified absolute positions in the coordinate system as specified by the 'CoordSystem' argument.

See [Circular Moves Diagrams](#) for detailed information on the movement options.

NOTE

- An error is returned if the group is in the GroupDisabled state.
- An error is returned if the input parameters do not meet the required precision. See [Precision Requirements for Circular Move Input Parameters](#) for more information.

NOTE

- Circular motion is only supported for axes groups with only two attached axes
- S-Curve motion is not currently supported. The *Jerk* input is currently ignored. S-Curve motion and the *Jerk* argument will be supported in a future release. .

When all motion has completed successfully, the state of the axes group goes to GroupStandby.




Figure 1-99: MC_MoveCircAbs

3.3.155 Related Functions

"Related Functions" (→ p. 495), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.155.0.0.1 Arguments

3.3.156 Input

Execute	Description	On the rising edge request to perform a circular absolute move
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	The axis group that will perform the circular absolute move
	Data type	AXIS_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
CircMode	Description	Specifies the meaning of the AuxPoint[] input.
	Data type	SINT One of the following enumeration values: <ul style="list-style-type: none"> • MC_CIRC_MODE_BORDER = 0 • MC_CIRC_MODE_CENTER = 1
	Range	N/A
	Unit	N/A
	Default	—
AuxPoint[]	Description	Array of absolute positions for each axis in the group. The meaning depends on the value of the CircMode input: <ul style="list-style-type: none"> • MC_CIRC_MODE_BORDER: AuxPoint defines a point on the circle which is crossed on the path from the starting to the end point. • MC_CIRC_MODE_CENTER: AuxPoint defines the center point of the circle.
	Data type	LREAL
	Range	[0, Number of axes in group - 1]
	Unit	N/A
	Required Precision	1 part in 100,000. See Precision Requirements for Circular Move Input Parameters .

	Default	—
EndPoint[]	Description	Array of absolute end positions for each axis in the group
	Data type	LREAL
	Range	[0, Number of axes in group - 1]
	Unit	N/A
	Default	—
	Required Precision	1 part in 100,000. See Precision Requirements for Circular Move Input Parameters .
PathChoice	Description	Specifies the direction of the path. This argument is only relevant when CircMode is MC_CIRC_MODE_CENTER.
	Data type	SINT One of the following enumeration values: <ul style="list-style-type: none"> • MC_CIRC_PATHCHOICE_CLOCKWISE = 0 = Clockwise • MC_CIRC_PATHCHOICE_COUNTERCLOCKWISE = 1 = Counterclockwise
	Range	N/A
	Unit	N/A
	Default	—
Velocity	Description	Maximum velocity of the defined path
	Data type	LREAL
	Range	$0 < \text{Velocity} < (20 * \text{Acceleration})$ and $0 < \text{Velocity} < (20 * \text{Deceleration})$ See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second
	Default	—
Acceleration	Description	Maximum acceleration
	Data type	LREAL
	Range	$0 < \text{Velocity} < (20 * \text{Acceleration})$ See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second ²
	Default	—
Deceleration	Description	Maximum Deceleration
	Data type	LREAL

	Range	0 < Velocity < (20 * Deceleration) See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second ²
	Default	—
JerK	Description	Maximum jerk
	Data type	LREAL
	Range	For trapezoidal velocity profiles: 0 For S-Curve velocity profiles: (Velocity / 20) < Acceleration < (2 * Jerk) and (Velocity / 20) < Deceleration < (2 * Jerk) See Limitations on Acceleration and Jerk for more information.
		NOTE S-Curve motion is currently not supported and the <i>JerK</i> input is currently ignored. S-Curve motion and the <i>JerK</i> argument will be supported in a future release.
	Unit	user units per second ³
	Default	—
CoordSystem	Description	The coordinate system used when commanding the circular absolute move. Currently, only the ACS coordinate system is supported. See Coordinate Systems to learn more.
	Data type	SINT
	Range	One of the following enumeration values: <ul style="list-style-type: none"> MC_COORDINATE_SYSTEM_ACS = 0 MC_COORDINATE_SYSTEM_MCS = 1 MC_COORDINATE_SYSTEM_PCS = 2
	Unit	N/A
	Default	—
BufferMode	Description	Defines the chronological sequence of the function block relative to the previous block. The blending modes (2, 3, 4, & 5) match the path velocity at the active move's endpoint. Some individual axis velocities may make an abrupt change if the path of the next move travels in a different direction. A transition move may be programmed at the <code>TransitionMode</code> input to avoid this. See the table in Buffer Modes .

	Data type	SINT One of the following enumeration values: <ul style="list-style-type: none"> • MC_BUFFER_MODE_BUFFERED = 1 = Buffered • MC_BUFFER_MODE_BLENDED_PREVIOUS = 2 = Blending Previous • MC_BUFFER_MODE_BLENDED_NEXT = 3 = Blending Next • MC_BUFFER_MODE_BLENDED_LOW = 4 = Blending Low • MC_BUFFER_MODE_BLENDED_HIGH = 5 = Blending High <i>BufferMode = Abort = 0 is not allowed with this function block.</i>
	Range	—
	Unit	N/A
	Default	—
TransitionMode	Description	Coupled with the TransitionParameter[], this input defines the shape and dynamics of the inserted contour to connect the current motion with the next motion in the queue. See Transition Between Moves for additional information.
	Data type	SINT
	Range	The value is limited to the following: <ul style="list-style-type: none"> • MC_TRANSITION_MODE_NONE = 0 • MC_TRANSITION_MODE_CORNER_DISTANCE = 3
	Unit	N/A
	Default	—
	TransitionParameter[] Description	This array is dependent on the TransitionMode specified. The transition parameter values are applied to the axis group. See table: "Transition Mode Parameters" for details.
	Data type	LREAL
	Range	[1, N] N values are supplier specified dependent on the TransitionMode selected.
	Unit	N/A
	Default	—

3.3.157 Output

Done	Description	If True, then the command completed successfully.
	Data type	BOOL

Busy	Description	If True, then the function block is executing.
	Data type	BOOL
Active	Description	If True, then the function block is controlling motion.
	Data type	BOOL
CommandAborted	Description	If True, command was aborted by another function block.
	Data type	BOOL
Error	Description	If True, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See table in PLCopen Function Block ErrorID Output
	Data type	INT

3.3.157.0.1 Example

3.3.158 ST

```

Inst_MC_MoveCircAbs( ExecuteMove, Group1_Ref, MC_CIRC_MODE_BORDER,
AuxPoints, EndPoints, MC_CIRC_PATHCHOICE_CLOCKWISE, Velocity,
Acceleration, Deceleration, Jerk, MC_COORDINATE_SYSTEM_ACS, MC_BUFFER_
MODE_ABORTING, MC_TRANSITION_MODE_NONE, TransitionParams );
    
```

3.3.159 IL


```

BEGIN_IL


    CAL Inst_MC_MoveCircAbs( ExecuteMove, Group1_Ref, MC_CIRC_MODE_
BORDER, AuxPoints, EndPoints, MC_CIRC_PATHCHOICE_CLOCKWISE, Velocity,
Acceleration, Deceleration, Jerk, MC_COORDINATE_SYSTEM_ACS, MC_BUFFER_
MODE_ABORTING, MC_TRANSITION_MODE_NONE, TransitionParams )

END_IL
    
```

3.3.160 FBD



3.3.161 FFLD



3.3.161.0.1 MC_MoveCircRel



3.3.161.0.1.1 Description

MC_MoveCircRel commands interpolated circular movement on an axes group to the specified relative positions in the coordinate system as specified by the 'CoordSystem' argument. See [Circular Moves Diagrams](#) for detailed information on the movement options.

NOTE

An error is returned if the group is in the GroupDisabled state.

NOTE

- Circular motion is only supported for axes groups with only two attached axes
- S-Curve motion is not currently supported. The *Jerk* input is currently ignored. S-Curve motion and the *Jerk* argument will be supported in a future release. .

When all motion has completed successfully, the state of the axes group goes to GroupStandby.




Figure 1-100: MC_MoveCircRel

3.3.162 Related Functions

"Related Functions" (→ p. 488), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.162.0.0.1 Arguments

3.3.163 Input

Execute	Description	On the rising edge request to perform a circular relative move.
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	The axis group that will perform the circular relative move
	Data type	AXIS_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
CircMode	Description	Specifies the meaning of the AuxPoint[] input (see AuxPoint[] below).

	Data type	SINT One of the following enumeration values: <ul style="list-style-type: none"> MC_CIRC_MODE_BORDER = 0 MC_CIRC_MODE_CENTER = 1
	Range	N/A
	Unit	N/A
	Default	—
AuxPoint[]	Description	Array of relative positions for each axis in the group. The meaning depends on the value of the CircMode input: <ul style="list-style-type: none"> MC_CIRC_MODE_BORDER: AuxPoint defines a point on the circle which is crossed on the path from the starting to the end point. MC_CIRC_MODE_CENTER: AuxPoint defines the center point of the circle. In all cases the points are relative to the starting point.
	Data type	LREAL
	Range	[0, Number of axes in group - 1]
	Unit	N/A
	Default	—
	Required Precision	1 part in 100,000. See Precision Requirements for Circular Move Input Parameters .
EndPoint[]	Description	Array of relative end positions for each axis in the group.
	Data type	LREAL
	Range	[0, Number of axes in group - 1]
	Unit	N/A
	Default	—
	Required Precision	1 part in 100,000. See Precision Requirements for Circular Move Input Parameters .
PathChoice	Description	Specifies the direction of the path. This argument is only relevant when CircMode is MC_CIRC_MODE_CENTER.
	Data type	SINT One of the following enumeration values: <ul style="list-style-type: none"> MC_CIRC_PATHCHOICE_CLOCKWISE = 0 = Clockwise MC_CIRC_PATHCHOICE_COUNTERCLOCKWISE = 1 = Counterclockwise
	Range	N/A
	Unit	N/A

	Default	—
Velocity	Description	Maximum velocity of the defined path
	Data type	LREAL
	Range	$0 < \text{Velocity} < (20 * \text{Acceleration})$ and $0 < \text{Velocity} < (20 * \text{Deceleration})$ See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second
	Default	—
Acceleration	Description	Maximum acceleration
	Data type	LREAL
	Range	$0 < \text{Velocity} < (20 * \text{Acceleration})$ See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second ²
	Default	—
Deceleration	Description	Maximum Deceleration
	Data type	LREAL
	Range	$0 < \text{Velocity} < (20 * \text{Deceleration})$ See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second ²
	Default	—
Jerk	Description	Maximum jerk
	Data type	LREAL
	Range	For trapezoidal velocity profiles: 0 For S-Curve velocity profiles: $(\text{Velocity} / 20) < \text{Acceleration} < (2 * \text{Jerk})$ and $(\text{Velocity} / 20) < \text{Deceleration} < (2 * \text{Jerk})$ See Limitations on Acceleration and Jerk for more information.
		NOTE S-Curve motion is currently not supported and the <i>Jerk</i> input is currently ignored. S-Curve motion and the <i>Jerk</i> argument will be supported in a future release.
	Unit	user units per second ³
	Default	—

CoordSystem	Description	The coordinate system used when commanding the circular relative move Currently, only the ACS coordinate system is supported. See Coordinate Systems to learn more.
	Data type	SINT
	Range	One of the following enumeration values: <ul style="list-style-type: none"> MC_COORDINATE_SYSTEM_ACS = 0 MC_COORDINATE_SYSTEM_MCS = 1 MC_COORDINATE_SYSTEM_PCS = 2
	Unit	N/A
	Default	—
BufferMode	Description	Defines the chronological sequence of the function block relative to the previous block. The blending modes (2, 3, 4, & 5) match the path velocity at the active move's endpoint. Some individual axis velocities may make an abrupt change if the path of the next move travels in a different direction. A transition move may be programmed at the <code>TransitionMode</code> input to avoid this. See the table in Buffer Modes .
	Data type	SINT One of the following enumeration values: <ul style="list-style-type: none"> MC_BUFFER_MODE_ABORTING = 0 = Abort MC_BUFFER_MODE_BUFFERED = 1 = Buffered MC_BUFFER_MODE_BLENDED_PREVIOUS = 2 = Blending Previous MC_BUFFER_MODE_BLENDED_NEXT = 3 = Blending Next MC_BUFFER_MODE_BLENDED_LOW = 4 = Blending Low MC_BUFFER_MODE_BLENDED_HIGH = 5 = Blending High
	Range	—
	Unit	N/A
	Default	—
TransitionMode	Description	Coupled with the <code>TransitionParameter[]</code> , this input defines the shape and dynamics of the inserted contour to connect the current motion with the next motion in the queue. See Transition Between Moves for additional information.
	Data type	SINT
	Range	The value is limited to the following: <ul style="list-style-type: none"> MC_TRANSITION_MODE_NONE = 0 MC_TRANSITION_MODE_CORNER_DISTANCE = 3
	Unit	N/A

Default	—
TransitionParameter[] Description	This array is dependent on the TransitionMode specified. The transition parameter values are applied to the axis group. See table: "Transition Mode Parameters" for details.
Data type	LREAL
Range	[1, N] N values are supplier specified dependent on the TransitionMode selected.
Unit	N/A
Default	—

3.3.164 Output

Done	Description	If True, then the command completed successfully.
	Data type	BOOL
Busy	Description	If True, then the function block is executing.
	Data type	BOOL
Active	Description	If True, then the function block is controlling motion.
	Data type	BOOL
CommandAborted	Description	If True, command was aborted by another function block.
	Data type	BOOL
Error	Description	If True, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See table in PLCopen Function Block ErrorID Output
	Data type	INT

3.3.164.0.0.1 Example

3.3.165 ST


```
Inst_MC_MoveCircRel( ExecuteMove, Group1_Ref, MC_CIRC_MODE_BORDER,
AuxPoints, EndPoints, MC_CIRC_PATHCHOICE_CLOCKWISE, Velocity,
Acceleration, Deceleration, Jerk, MC_COORDINATE_SYSTEM_ACS, MC_BUFFER_
MODE_ABORTING, MC_TRANSITION_MODE_NONE, TransitionParams );
```

3.3.166 IL


```
BEGIN_IL
CAL Inst_MC_MoveCircRel( ExecuteMove, Group1_Ref, MC_CIRC_MODE_
```

```
BORDER, AuxPoints, EndPoints, MC_CIRC_PATHCHOICE_CLOCKWISE, Velocity,
Acceleration, Deceleration, Jerk, MC_COORDINATE_SYSTEM_ACS, MC_BUFFER_
MODE_ABORTING, MC_TRANSITION_MODE_NONE, TransitionParams )
END_IL
```

3.3.167 FBD



3.3.168 FFLD



3.3.168.0.1 MC_MoveDirAbs PLCopen ✓ Pipe Network ✓

3.3.168.0.1.1 Description

MC_MoveDirAbs commands the movement of an axes group to a specified absolute position in the specified coordinate system without taking care of how (on which path) the target position is reached.

NOTE

- An error is returned if the group is in the GroupDisabled state.
- This function block does not have its own Acceleration, Deceleration, Velocity, and Jerk arguments. These are set using "Related Functions" (→ p. 480).
- The maximum number of axes is set by the **MaxNumberOfAxes** input set in the "Related Function Blocks" (→ p. 428) function block.
- S-Curve motion is not currently supported. The *Jerk* input is currently ignored. S-Curve motion and the *Jerk* argument will be supported in a future release. .

When all motion is completed successfully, the state becomes GroupStandby.




Figure 1-101: MC_MoveDirAbs

3.3.169 Related Functions

"Related Functions" (→ p. 504), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.169.0.0.1 Arguments

3.3.170 Input

Execute	Description	On the rising edge, request to perform a direct absolute move.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	Reference to an axes group
	Data Type	AXES_GROUP_REF
	Range	—
	Unit	N/A
	Default	—
Position[]	Description	Array of absolute end positions for each axis in the group.
	Data Type	LREAL

	Range	[0, Number of axes in group - 1]
	Unit	N/A
	Default	—
CoordSystem	Description	The coordinate system used when commanding the direct absolute move Currently, only the ACS coordinate system is supported. See Coordinate Systems to learn more.
	Data Type	SINT
	Range	<ul style="list-style-type: none"> • MC_COORDINATE_SYSTEM_ACS = 0 • MC_COORDINATE_SYSTEM_MCS = 1 • MC_COORDINATE_SYSTEM_PCS = 2
	Unit	N/A
	Default	—
BufferMode	Description	Defines the chronological sequence of the function block relative to the previous block. See the table in Buffer Modes .
	Data Type	SINT MC_BUFFER_MODE_ABORTING = 0 = Abort MC_BUFFER_MODE_BUFFERED = 1 = Buffered
	Range	—
	Unit	N/A
	Default	—

3.3.171 Output

Done	Description	If True, then the command completed successfully.
	Data type	BOOL
Busy	Description	If True, then the function block is executing.
	Data type	BOOL
Active	Description	If True, then the function block is controlling motion.
	Data type	BOOL
CommandAborted	Description	If True, command was aborted by another function block.
	Data type	BOOL
Error	Description	If True, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See table in PLCopen Function Block ErrorID Output .

Data type INT

3.3.171.0.0.1 Example


3.3.172 Structure Text

```
Inst_MC_MoveDirAbs( DirectMove, Group1_Ref, PositionList, MC_COORDSYSTEM_
ACS, MC_BUFFER_MODE_ABORTING);
```


3.3.173 IL

```
BEGIN_IL
CAL Inst_MC_MoveDirAbs( DirectMove, Group1_Ref, PositionList, MC_
COORD_SYSTEM_ACS, MC_BUFFER_MODE_ABORTING)
END_IL
```

3.3.174 Function Block Diagram



3.3.175 Ladder Diagram



3.3.175.0.1 MC_MoveDirRel

PLCopen ✓

Pipe Network ✓

3.3.175.0.1.1 Description

MC_MoveDirRel commands a movement of an axes group to a relative position in the specified coordinate system without taking care of how (on which path) the target position is reached.

NOTE

- An error is returned if the group is in the GroupDisabled state.
- This function block does not have its own Acceleration, Deceleration, Velocity, and Jerk arguments. These are set using "Related Functions" (→ p. 480).
- The maximum number of axes is set by the **MaxNumberOfAxes** input set in the "Related Function Blocks" (→ p. 428) function block.
- S-Curve motion is not currently supported. The *JerK* input is currently ignored. S-Curve motion and the *JerK* argument will be supported in a future release. .

When all motion has completed successfully, the state of the axes group goes to GroupStandby.




Figure 1-102: MC_MoveDirRel

3.3.176 Related Functions

"Related Functions" (→ p. 501), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.176.0.0.1 Arguments

3.3.177 Input

Execute	Description	On the rising edge request to perform a direct relative move.
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	Reference to an axes group
	Data type	AXES_GROUP_REF
	Range	—
	Unit	N/A
	Default	—
Distance[]	Description	An array containing the distance for each axis in the group.
	Data type	LREAL
	Range	[0, Number of axes in group - 1]
	Unit	N/A
	Default	—

CoordSystem	Description	The coordinate system used when commanding the direct relative move. Currently, only the ACS coordinate system is supported. See Coordinate Systems to learn more.
	Data type	SINT
	Range	<ul style="list-style-type: none"> MC_COORDINATE_SYSTEM_ACS = 0 MC_COORDINATE_SYSTEM_MCS = 1 MC_COORDINATE_SYSTEM_PCS = 2
	Unit	N/A
	Default	—
BufferMode	Description	Defines the chronological sequence of the function block relative to the previous block. See the table in Buffer Modes
	Data type	SINT MC_BUFFER_MODE_ABORTING = 0 = Abort MC_BUFFER_MODE_BUFFERED = 1 = Buffered
	Range	—
	Unit	N/A
	Default	—

3.3.178 Output

Done	Description	If True, then the command completed successfully.
	Data type	BOOL
Busy	Description	If True, then the function block is executing. .
	Data type	BOOL
Active	Description	If True, then the function block is controlling motion.
	Data type	BOOL
CommandAborted	Description	If True, command was aborted by another function block.
	Data type	BOOL
Error	Description	If True, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See table in PLCopen Function Block ErrorID Output .
	Data type	INT

3.3.178.0.0.1 Example


3.3.179 Structure Text

```
Inst_MC_MoveDirRel( ExecuteMove, Group1_Ref, DistanceList, MC_COORDINATE_
SYSTEM_ACS, MC_BUFFER_MODE_ABORTING );
```


3.3.180 IL

```
BEGIN_IL
CAL Inst_MC_MoveDirRel( ExecuteMove, Group1_Ref, DistanceList, MC_
COORDINATE_SYSTEM_ACS, MC_BUFFER_MODE_ABORTING )
END_IL
```

3.3.181 Function Block Diagram



3.3.182 Ladder Diagram



3.3.182.0.1 MC_MoveLinAbs



3.3.182.0.1.1 Description

MC_MoveLinAbs commands interpolated linear movement on an axes group to the specified absolute positions in the coordinate system as specified by the 'CoordSystem' argument. The dimensionality of the move is determined by the number of axes mapped to the group.

NOTE

- An error is returned if the group is in the GroupDisabled state.
- The maximum number of axes is set by the **MaxNumberOfAxes** input set in the ["Related Function Blocks"](#) (→ p. 428) function block.
- S-Curve motion is not currently supported. The *Jerk* input is currently ignored. S-Curve motion and the *Jerk* argument will be supported in a future release. .

When all motion has completed successfully, the state of the axes group goes to GroupStandby.




Figure 1-103: MC_MoveLinAbs

3.3.183 Related Functions

"Related Functions" (→ p. 512), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.183.0.0.1 Arguments

3.3.184 Input

Execute	Description	On the rising edge request to perform a linear absolute move.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	The axis group that will perform the linear absolute move
	Data Type	AXIS_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
Position[]	Description	Array of absolute end positions for each axis in the group.
	Data Type	LREAL
	Range	N/A
	Unit	user units

	Default	—
Velocity	Description	Maximum velocity of the defined path
	Data Type	LREAL
	Range	$0 < \text{Velocity} < (20 * \text{Acceleration})$ and $0 < \text{Velocity} < (20 * \text{Deceleration})$ See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second
	Default	—
Acceleration	Description	Maximum acceleration
	Data Type	LREAL
	Range	$0 < \text{Velocity} < (20 * \text{Acceleration})$ See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second ²
	Default	—
Deceleration	Description	Maximum deceleration
	Data Type	LREAL
	Range	$0 < \text{Velocity} < (20 * \text{Deceleration})$ See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second ²
	Default	—
Jerk	Description	Maximum jerk
	Data Type	LREAL
	Range	For trapezoidal velocity profiles: 0 For S-Curve velocity profiles: $(\text{Velocity} / 20) < \text{Acceleration} < (2 * \text{Jerk})$ and $(\text{Velocity} / 20) < \text{Deceleration} < (2 * \text{Jerk})$ See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second ³
	Default	—

NOTE
 S-Curve motion is currently not supported and the *Jerk* input is currently ignored. S-Curve motion and the *Jerk* argument will be supported in a future release.

CoordSystem	Description	The coordinate system used when commanding the linear absolute move. Currently, only the ACS coordinate system is supported. See Coordinate Systems to learn more.
	Data Type	SINT
	Range	One of the following enumeration values: <ul style="list-style-type: none"> • MC_COORDINATE_SYSTEM_ACS = 0 • MC_COORDINATE_SYSTEM_MCS = 1 • MC_COORDINATE_SYSTEM_PCS = 2
	Unit	N/A
	Default	—
BufferMode	Description	Defines the chronological sequence of the function block relative to the previous block. MC_BUFFER_MODE_ABORTING = 0 = Abort MC_BUFFER_MODE_BUFFERED = 1 = Buffered MC_BUFFER_MODE_BLENDED_PREVIOUS = 2 = Blending Previous MC_BUFFER_MODE_BLENDED_NEXT = 3 = Blending Next MC_BUFFER_MODE_BLENDED_LOW = 4 = Blending Low MC_BUFFER_MODE_BLENDED_HIGH = 5 = Blending High The buffer mode is limited to MC_BUFFER_MODE_BUFFERED for groups with more than two axes. The blending modes (2, 3, 4, & 5) match the path velocity at the active move's endpoint. Some individual axis velocities may make an abrupt change if the path of the next move travels in a different direction. A transition move may be programmed at the <code>TransitionMode</code> input to avoid this. See the table in Buffer Modes
	Data Type	SINT
	Range	—
	Unit	N/A
	Default	—
TransitionMode	Description	Coupled with the <code>TransitionParameter[]</code> , this input defines the shape and dynamics of the inserted contour to connect the current motion with the next motion in the queue. See Transition Between Moves for additional information.
	Data type	SINT
	Range	The value is limited to the following: <ul style="list-style-type: none"> • MC_TRANSITION_MODE_NONE = 0 • MC_TRANSITION_MODE_CORNER_DISTANCE = 3 The transition mode is limited to MC_TRANSITION_MODE_NONE for groups with more than three axes.

Unit	N/A
Default	—
TransitionParameter[] Description	This array is dependent on the TransitionMode specified. The transition parameter values are applied to the axis group. See table: "Transition Mode Parameters" for details.
Data Type	LREAL
Range	[1, N] N values are supplier specified dependent on the TransitionMode selected.
Unit	N/A
Default	—

3.3.185 Output

Done	Description	If True, then the command completed successfully.
	Data type	BOOL
Busy	Description	If True, then the function block is executing.
	Data type	BOOL
Active	Description	If True, then the function block is controlling motion.
	Data type	BOOL
CommandAborted	Description	If True, then the command was aborted by another function block.
	Data type	BOOL
Error	Description	If True, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See table in PLCopen Function Block ErrorID Output
	Data type	INT

3.3.185.0.0.1 Example

3.3.186 Structured Text


```
(* Inst_MC_MoveLinAbsST example *)
Inst_MC_MoveLinAbs( ExecuteLinearMove, Group1_Ref, PositionList,
Velocity, Acceleration, Deceleration, Jerk, CoordSystem, BufferMode,
TransitionMode, TransitionParams );
```

3.3.187 IL


```

BEGIN_IL
  CAL Inst_MC_MoveLinAbs( ExecuteLinearMove, Group1_Ref, PositionList,
    Velocity, Acceleration, Deceleration, Jerk, CoordSystem, BufferMode,
    TransitionMode, TransitionParams )
END_IL
    
```

3.3.188 FBD



3.3.189 FFLD



3.3.189.0.1 MC_MoveLinRel PLCopen ✓ Pipe Network ✓

3.3.189.0.1.1 Description

MC_MoveLinRel commands interpolated linear movement of an axes group to the specified relative positions. The dimensionality of the move is determined by the number of axes mapped to the group.

NOTE

- An error is returned if the group is in the GroupDisabled state.
- The maximum number of axes is set by the **MaxNumberOfAxes** input set in the "Related Function Blocks" (→ p. 428) function block.
- S-Curve motion is not currently supported. The *Jerk* input is currently ignored. S-Curve motion and the *Jerk* argument will be supported in a future release. .

When all motion has completed successfully, the state of the axes group goes to GroupStandby. See [Transition Between Moves](#) for additional information.




Figure 1-104: MC_MoveLinRel

3.3.190 Related Functions

"Related Functions" (→ p. 507), "MC_ErrorDescription" (→ p. 396)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.190.0.0.1 Arguments

3.3.191 Input

Execute	Description	On the rising edge request to perform a linear relative move
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	The axis group that will perform the linear relative move
	Data Type	AXIS_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
Distance[]	Description	Array of distances for each axis in the group.
	Data Type	LREAL
	Range	N/A
	Unit	user units

	Default	—
Velocity	Description	Maximum velocity of the defined path
	Data Type	LREAL
	Range	$0 < \text{Velocity} < (20 * \text{Acceleration})$ and $0 < \text{Velocity} < (20 * \text{Deceleration})$ See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second
	Default	—
Acceleration	Description	Maximum acceleration
	Data Type	LREAL
	Range	$0 < \text{Velocity} < (20 * \text{Acceleration})$ See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second ²
	Default	—
Deceleration	Description	Maximum deceleration
	Data Type	LREAL
	Range	$0 < \text{Velocity} < (20 * \text{Deceleration})$ See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second ²
	Default	—
Jerk	Description	Maximum jerk
	Data Type	LREAL
	Range	For trapezoidal velocity profiles: 0 For S-Curve velocity profiles: $(\text{Velocity} / 20) < \text{Acceleration} < (2 * \text{Jerk})$ and $(\text{Velocity} / 20) < \text{Deceleration} < (2 * \text{Jerk})$ See Limitations on Acceleration and Jerk for more information.
	Unit	user units per second ³
	Default	—

NOTE

S-Curve motion is currently not supported and the *Jerk* input is currently ignored. S-Curve motion and the *Jerk* argument will be supported in a future release.

CoordSystem	Description	The coordinate system used when commanding the linear relative move Currently, only the ACS coordinate system is supported. See Coordinate Systems to learn more.
	Data Type	SINT
	Range	One of the following enumeration values: <ul style="list-style-type: none"> • MC_COORDINATE_SYSTEM_ACS = 0 • MC_COORDINATE_SYSTEM_MCS = 1 • MC_COORDINATE_SYSTEM_PCS = 2
	Unit	N/A
	Default	—
BufferMode	Description	Defines the chronological sequence of the function block relative to the previous block. MC_BUFFER_MODE_ABORTING = 0 = Abort MC_BUFFER_MODE_BUFFERED = 1 = Buffered MC_BUFFER_MODE_BLENDING_PREVIOUS = 2 = Blending Previous MC_BUFFER_MODE_BLENDING_NEXT = 3 = Blending Next MC_BUFFER_MODE_BLENDING_LOW = 4 = Blending Low MC_BUFFER_MODE_BLENDING_HIGH = 5 = Blending High The buffer mode is limited to MC_BUFFER_MODE_BUFFERED for groups with more than two axes. The blending modes (2, 3, 4, & 5) match the path velocity at the active move's endpoint. Some individual axis velocities may make an abrupt change if the path of the next move travels in a different direction. A transition move may be programmed at the <code>TransitionMode</code> input to avoid this. See the table in Buffer Modes
	Data Type	SINT
	Range	—
	Unit	N/A
	Default	—
TransitionMode	Description	Coupled with the <code>TransitionParameter[]</code> , this input defines the shape and dynamics of the inserted contour to connect the current motion with the next motion in the queue. See Transition Between Moves for additional information.
	Data Type	SINT
	Range	The value is limited to the following: <ul style="list-style-type: none"> • MC_TRANSITION_MODE_NONE = 0 • MC_TRANSITION_MODE_CORNER_DISTANCE = 3 The transition mode is limited to MC_TRANSITION_MODE_NONE for groups with more than three axes.

Unit	N/A
Default	—
TransitionParameter[] Description	This array is dependent on the TransitionMode specified. The transition parameter values are applied to the axis group. See table: "Transition Mode Parameters" for details.
Data Type	LREAL
Range	[0, N] The value of N is dependent on the TransitionMode specified.
Unit	N/A
Default	—

3.3.192 Output

Done	Description	If True, then the command completed successfully.
	Data type	BOOL
Busy	Description	If True, then the function block is executing.
	Data type	BOOL
Active	Description	If True, then the function block is still controlling motion.
	Data type	BOOL
CommandAborted	Description	If True, then the command was aborted by another function block.
	Data type	BOOL
Error	Description	If True, then an error has occurred
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See table in PLCOpen Function Block ErrorID Output
	Data type	INT

3.3.192.0.0.1 Example

3.3.193 Structured Text

```
(* Inst_MC_MoveLinRelST example *)


Inst_MC_MoveLinRel( ExecuteLinearMove, Group1_Ref, DistanceList,
Velocity, Acceleration, Deceleration, Jerk, CoordSystem, BufferMode,
TranstionMode, TransitionParams );
```

3.3.194 IL


```

BEGIN_IL
    CAL Inst_MC_MoveLinRel( ExecuteLinearMove, Group1_Ref, DistanceList,
        Velocity, Acceleration, Deceleration, Jerk, CoordSystem, BufferMode,
        TransitionMode, TransitionParams )
END_IL
    
```

3.3.195 FBD



3.3.196 FFLD



3.3.196.1 Coordinated Motion Reference Library

Function	Description
"Related Functions" (→ p. 517)	Sets the position of the group.

3.3.196.1.1 MC_GrpSetPos PLCopen ✓ Pipe Network ✓

3.3.196.1.1.1 Description

MC_GrpSetPos sets the axis command position for all of the axes in an axes group to the positions specified in the `Position` input. This function block does not cause any motion. The axes group must be enabled and in Standby mode for MC_GrpSetPos to execute. If it is not, this FB will return an error and the axis positions will remain unchanged. The command position is that returned by the Function Block MC_GrpReadCmdPos.




Figure 1-105: MC_GrpSetPos

NOTE

This function block starts a motion-related action and therefore stores data for calculations and error checking.

See [Calling Function Blocks Multiple Times in the Same Cycle](#) if using a dual-core controller.

3.3.197 Related Functions

"MC_ErrorDescription" (→ p. 396), "Related Function Blocks" (→ p. 469)

See [Coordinated Motion](#), the top-level topic for Coordinated Motion.

3.3.197.0.0.1 Arguments

3.3.198 Input

Execute	Description	On the rising edge, request to set the position of the group
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
AxesGroup	Description	The axis group for which to set the positions
	Data Type	AXIS_GROUP_REF
	Range	N/A
	Unit	N/A
	Default	—
Position[]	Description	An array containing the position for each axis in the group. If "Relative" is set, position represents a distance rather than an absolute position. The length of the array must equal the maximum number of axes allowed in the group. The maximum number of axes is an argument to MC_CreateAxesGrp, which is used to create axes groups.
	Data Type	LREAL
	Range	[0, Number of axes in group-1]

	Unit	N/A
	Default	—
Relative	Description	Request to set relative (1) or absolute (0) position
	Data Type	BOOL
	Range	1, 0
	Unit	N/A
	Default	—
CoordSystem	Description	The coordinate system used when setting the positions.
	Data Type	SINT
	Range	One of the following enumeration values: <ul style="list-style-type: none"> • MC_COORDINATE_SYSTEM_ACS = 0 • MC_COORDINATE_SYSTEM_MCS = 1 • MC_COORDINATE_SYSTEM_PCS = 2 Currently, only the ACS coordinate system is supported. See Coordinate Systems for more information.
	Unit	N/A
	Default	—
BufferMode	Description	Currently unused
	Data Type	SINT
	Range	[0, 0]
	Unit	N/A
	Default	—

3.3.199 Output


Done	Description	If True, then the command completed successfully.
	Data Type	BOOL
Busy	Description	Currently unused, returns FALSE
	Data Type	BOOL
CommandAborted	Description	Currently unused, returns FALSE
	Data Type	BOOL
Error	Description	If True, an error has occurred.
	Data Type	BOOL
ErrorID	Description	Indicates the error identifier if Error output is set to TRUE. See the table in PLCopen Function Block ErrorID Output .
	Data Type	INT

3.3.199.0.0.1 Example

3.3.200 ST

```
Inst_MC_GrpSetPos( DoSetPos, Group1, PositionArray, Relative, MC_
COORDINATE_SYSTEM_ACS, 0 );
```


3.3.201 FBD



3.3.202 IL

```
BEGIN_IL
CAL Inst_MC_GrpSetPos( DoSetPos, Group1, PositionArray, Relative,
MC_COORDINATE_SYSTEM_ACS, BufferMode);
END_IL
```

3.3.203 FFLD



4 Fieldbus Library

4.1 EtherCAT Library

This is a list of EtherCAT function blocks:

Name	Description
"DriveParamRead" (→ p. 522)	Reads a drive parameter (ASCII format).
"DriveParamStrRead" (→ p. 527)	Reads a single drive parameter (ASCII format).
"DriveParamWrite" (→ p. 530)	Writes a drive parameter (ASCII format).
"ECATCommErrors" (→ p. 534)	Returns a list of bad EtherCAT connections.
"ECATDeviceAction" (→ p. 537)	Performs an action on an EtherCAT device.
"ECATDeviceStatus" (→ p. 539)	Provides EtherCAT state and port link status information for an EtherCAT device.
"ECATDevReadParam" (→ p. 542)	This function block returns the EtherCAT device-specific information.
"ECATGetObjVal" (→ p. 546)	Reads cyclic drive parameter (String format) by returning the value of an EtherCAT PDO element.
"ECATMasterStatus" (→ p. 547)	Reads the EtherCAT master state and the lost frame counter.
"ECATReadData" (→ p. 549)	Reads cyclic parameter (byte offset format).
"ECATReadSDO" (→ p. 551)	Reads parameter (32-bit format) using SDO command.
"ECATWCStatus" (→ p. 555)	Returns the current number of working counter errors for the Sync unit.
"ECATWriteData" (→ p. 556)	Writes cyclic parameter (byte offset format).
"ECATWriteSDO" (→ p. 558)	Writes parameter (32-bit format) using SDO command.
"FSoEParamsInit" (→ p. 562)	Transfers safety parameters from the safety master to safety slave devices to initialize the safety network.

The EtherCAT SDO function blocks are activated by the CANopen over EtherCAT (CoE) protocol in a client/server mode.

- The client (aka EtherCAT master) is the KAS Runtime application.
- The servers (aka EtherCAT slaves) are the drives and I/O nodes where data can be retrieved.
- The SDO function blocks only support the reading and writing of 32-bit values.
 - It is the fundamental size of CANopen SDO calls.

4.1.1 Why use ECATReadSdo and ECATWriteSdo FBs?

The "ECATReadSDO" ([→ p. 551](#)) and "ECATWriteSDO" ([→ p. 558](#)) response time is faster and is typically preferred over "DriveParamRead" ([→ p. 522](#)) and "DriveParamWrite" ([→ p. 530](#)).

4.1.2 Why use the DriveParam FBs?

The reasons to prefer the DriveParam FBs are:

- They allow direct use of the parameter name.
 - e.g., IL.LIMITP instead of the SDO index: 356Eh
- They can be used to setup a drive terminal in the HMI application.
 - This is similar to the [Terminal](#) view available in the AKD widget embedded in the KAS IDE.

4.1.3 EtherCAT Function Blocks That Work With Drive Parameters

These function blocks are used to work with drive parameters that are not supported by ML and MC function blocks. They support reading and writing drive parameters using the non-cyclic SDO channel in the EtherCAT network. The ASCII name for the parameter is used as an input.

4.1.3.1 Execution Time

These function blocks typically take a longer time to execute (up to ten cycles to finish executing). It takes the same amount of time to Read or Write a parameter.

NOTE

It takes more than one cycle to execute these function blocks (but less than 100 ms).

4.1.3.1.1 Reason

It is not only linked to the SDO ASCII communication. Because these FBs are waiting for the AKD drive to respond, the execution time can also increase due to the load of the AKD firmware at the time you call them.

4.1.3.1.2 Result

The PLC code is overrunning the cycle duration. as explained in Tasking Model / Scheduling. As a consequence, you can see the following message in the Controller Log window:

"The Virtual Machine missed 1 cycle(s) of PLC execution"

4.1.3.1.3 Solution

When this happens we recommend to:

- Use these function blocks sparingly in programs
- Rely on the EtherCAT read/write SDO function blocks whenever possible
- Smooth the load of the PLC code by executing these function blocks at the required update rate.

See some stats about the FB execution time

- There is a small difference in timing when running EtherCAT at 2ms compared to other frequencies.

	0.25, 0.5, 1ms	2ms
Mean	9ms	14ms
Min	3ms	8ms
Max	16ms	24ms

- **Max** time to consider when executing a single SDO command, (i.e. before the Done output becomes true): **24ms**.
- **Max** time to consider when executing a single Drive Parameter command (i.e. before the Done output becomes True): **60 ms**

	4 kHz	1 kHz
Mean	20 ms	11 ms
Min	15 ms	9 ms
Max	45 ms	58 ms

- When sending multiple commands to a single drive, only one command can be sent at a time. Therefore the time to execute multiple commands is:
Number of commands x Execution time of a single command
- When commands are sent to different AKD drives at the same time, the requests do not interfere with each other. So you can be confident the function finishes execution in the same max time as to one drive.

4.1.4 EtherCAT Function Blocks That Work With SDOs

"ECATReadSDO" (→ p. 551) and "ECATWriteSDO" (→ p. 558) are used to work with drive or remote I/O parameters that are not supported by ML and MC function blocks. Drive or remote I/O parameters that have an associated SDO number can be read and written using these function blocks.

NOTE

It takes more than one cycle to execute these function blocks (but less than 100 ms).

See some stats about the FB execution time

- There is a small difference in timing when running EtherCAT at 2ms compared to other frequencies.

	0.25, 0.5, 1ms	2ms
Mean	9ms	14ms
Min	3ms	8ms
Max	16ms	24ms

- **Max** time to consider when executing a single SDO command, (i.e. before the Done output becomes true): **24ms**.
- **Max** time to consider when executing a single Drive Parameter command (i.e. before the Done output becomes True): **60 ms**

	4 kHz	1 kHz
Mean	20 ms	11 ms
Min	15 ms	9 ms
Max	45 ms	58 ms


- When sending multiple commands to a single drive, only one command can be sent at a time. Therefore the time to execute multiple commands is:
Number of commands x Execution time of a single command
- When commands are sent to different AKD drives at the same time, the requests do not interfere with each other. So you can be confident the function finishes execution in the same max time as to one drive.

4.1.5 DriveParamRead

PLCopen
Pipe Network

Function Block - Reads a drive parameter by sending an ASCII command to a drive.

4.1.5.1 Inputs

Input	Data Type	Range	Unit	Default	Description
Execute	BOOL	0, 1	N/A	No default	<p>On the rising edge of Execute, a drive parameter is read.</p> <ul style="list-style-type: none"> The function block processes only one request at a time. If Execute is toggled quickly so that another rising edge occurs before the function block has completed, the function block does not issue a second read command.
Drive	INT	No range	N/A	No default	<p>The address of the drive where data is read.</p> <ul style="list-style-type: none"> The first node usually has the value 1001. The second node usually has the value 1002. <p>Alternately, use the members of the EtherCAT structure to specify a drive's address to Create Variables.</p> 
Param	STRING	No range	N/A	No default	The parameter to read.

4.1.5.2 Outputs

Output	Data Type	Range	Unit	Description
Done	BOOL	No range	N/A	Indicates whether this function block has completed without error.
Error	BOOL	No range	N/A	Indicates whether this function block call has completed with error.
ErrorID	DINT	No range	N/A	<p>The DriveParamRead error result if Error is TRUE. Upon success, Error is set to 0 (zero). See the "EtherCAT Error Codes" (→ p. 524) for more information.</p>
Value	LREAL	No range	N/A	<p>The value of the drive parameter. Value is only set when the function block has successfully completed.</p>
Units	STRING	No range	N/A	<p>The value of the drive parameter. Value is only set when the function block has successfully completed.</p>

4.1.5.3 Remarks

Use this function block to read drive parameters that are not supported by other function blocks. Examples include:

- Motor temperature
 - Drive bus voltage
 - Present drive limit settings
 - Present regeneration loading
 - Drive display
 - Fault history
- It takes multiple cycles to complete this function block.
 - Typically only **one DriveParamRead** or **DriveParamWrite** function should be active for **each axis** at one time.
 - If executing this function block continuously or if multiple times is required, add code that waits for this function block to complete (Done bit = 1) before executing it again.
 - See **stats** about the "Execution Time" (→ p. 521).
 - See "EtherCAT Function Blocks That Work With Drive Parameters" (→ p. 521) for information about function blocks that are not supported by ML and MC function blocks.




Figure 1-106: DriveParamRead

NOTE

This function block **uses and reserves** the EtherCAT SDO Channel. The SDO Channel remains reserved until the done output is TRUE. This FB should be called at each cycle until the done output is TRUE. If it is not called at each cycle, the rest of SDO communication (e.g., the AKD GUI Views) is blocked. Using this FB in SFC P0 or P1 steps is not recommended because these steps are executed only once. If this FB is used in P0 or P1, then it must be used in an SFC N step to ensure the FB completes.

4.1.5.3.1 EtherCAT Error Codes


List of EtherCAT Error Codes

Error Code	Value dec (hex)	Description
ECERR_OK	0	The SDO call succeeded
ECERR_DEVICE_ERROR	1792 (0x700)	EtherCAT device is not accessible
ECERR_DEVICE_INVALIDCMD	1794 (0x702)	Invalid mailbox command
ECERR_DEVICE_INVALIDINDEX	1795 (0x703)	An invalid value for the Index input was specified
ECERR_DEVICE_INVALIDACCESS	1796 (0x704)	Reading of the variable is not permitted


Error Code	Value dec (hex)	Description
ECERR_DEVICE_INVALIDSIZE	1797 (0x705)	An invalid size for the parameter was specified
ECERR_DEVICE_INVALIDDATA	1798 (0x706)	Invalid parameter value(s) in SDO index and/or sub-index
ECERR_DEVICE_NOTREADY	1799 (0x707)	Device is not in a ready state, network is not in operational
ECERR_DEVICE_BUSY	1800 (0x708)	Device is not available to respond
ECERR_DEVICE_INVALIDCONTEXT	1801 (0x709)	Device responded with an illegal error code, indicating the command is not allowed under the present conditions
ECERR_DEVICE_NOMEMORY	1802 (0x70A)	EtherCAT mailbox is out of memory or device is out of disk space
ECERR_DEVICE_INVALIDPARM	1803 (0x70B)	EtherCAT mailbox request was not valid
ECERR_DEVICE_NOTFOUND	1804 (0x70C)	EtherCAT device not found
ECERR_DEVICE_SYNTAX	1805 (0x70D)	An unexpected error occurred
ECERR_DEVICE_INVALIDSTATE	1810 (0x712)	The EtherCAT device is in an invalid state
ECERR_DEVICE_TIMEOUT	1817 (0x719)	The EtherCAT device failed to respond, timing out
ECERR_DEVICE_INSERTMAILBOX	1826 (0x722)	Error while inserting the mailbox command into internal FIFO
ECERR_DEVICE_INVALIDOFFSET	1827 (0x723)	An invalid value for the SubIndex input was specified
ECERR_DEVICE_UNKNOWNMAILBOXCMD	1828 (0x724)	The master sent an unknown mailbox command to the slave
ECERR_DEVICE_ACCESSDENIED	1829 (0x725)	Device responded with an invalid access error code, indicating the command is not allowed
ECERR_DEVICE_INVALIDADDR	1832 (0x728)	Can't send a mailbox command to the specified slave
ECERR_DEVICE_NOT_A_FSOE_MASTER	1836 (0x72c)	Device is not a FSoE master.
ECERR_DEVICE_PARAM_ACCESS_ERROR	1920 (0x780)	Unknown error occurred while accessing parameter
ECERR_DEVICE_PARAM_NOT_FOUND	1921 (0x781)	Parameter was not found
ECERR_DEVICE_PARAM_NOT_INTEGER	1922 (0x782)	Parameter is a floating-point value. Integer value required.
ECERR_DEVICE_VALUE_IS_NEGATIVE	1923 (0x783)	No negative values allowed. Value specified was negative.

Error Code	Value dec (hex)	Description
ECERR_DEVICE_VALUE_OUT_OF_RANGE	1924 (0x784)	Value is out of data-range
ECERR_DEVICE_VALUE_GREATER_THAN_MAX	1925 (0x785)	Value bigger than maximum
ECERR_DEVICE_VALUE_LOWER_THAN_MIN	1926 (0x786)	Value lower than minimum
ECERR_CLIENT_ERROR	2048 (0x800)	Error in Mailbox response to a previously sent mailbox command
ECERR_CLIENT_TIMEOUT	2049 (0x801)	The SDO command timed out
ECERR_CLIENT_INVALIDPARM	2050 (0x802)	An invalid value was specified
ECERR_CLIENT_INVALIDSIZE	2051 (0x803)	An invalid value for the size input was specified

4.1.5.4 FBD Language



4.1.5.5 FLD Language



4.1.5.6 IL Language

Not available.

4.1.5.7 ST Language

```
(* Read PL.KP on first AKD Drive on EtherCAT network *)

(* The code continually calls the FB (without re-executing it) until the
first execution is done, then reads the returned value from the drive and
reset the FB *)

IF ReadPropGain then
  Inst_DriveParamRead1( 1, 1001, 'PL.KP' );
End_If;
```

```

On Inst_DriveParamRead1.Done do
  Inst_DriveParamRead1( 0, 1001, 'PL.KP' );
  PositionProportionalGain := Inst_DriveParamRead1.Value; (* Reads the
returned value from the drive *)
  ReadPropGain := 0; (* Reset the FB *)
End_DO;

```

See Also

"DriveParamWrite" (→ p. 530)

4.1.6 DriveParamStrRead

PLCopen 

Pipe Network 

 **Function Block** - reads a single drive parameter by sending an ASCII command to a drive.

4.1.6.1 Inputs

Input	Data Type	Range	Unit	Default	Description
Execute	BOOL	0, 1	N/A	No default	Executes the function block.
Drive	INT	No range	N/A	No default	The address of the drive from which data is read.
Param	STRING	No range	N/A	No default	The parameter to read.

4.1.6.2 Outputs

Output	Data Type	Range	Unit	Description
Done	BOOL	No range	N/A	Indicates whether this function block has completed without error.
Error	BOOL	No range	N/A	Indicates whether this function block call has completed with error.
ErrorID	DINT	No range	N/A	The DriveParamStrRead error result if Error is TRUE. Upon success, Error is set to 0 (zero). See the "EtherCAT Error Codes" (→ p. 528) for more information.
Value	STRING	No range	N/A	The value of the drive parameter. Value is only set when the function block has successfully completed.

4.1.6.3 Remarks

The value returned is the string response from the drive.

NOTE

This differs from "DriveParamRead" (→ p. 522) because the drive response is not parsed. **DriveParamRead** parses the drive response and returns the numeric value of the parameter and the units found that represent that parameter.

Since **DriveParamStrRead** returns the drive response directly, it can be used to read parameters that have string representations (e.g., the AKD2G's AXIS#.FAULTMSG# parameters).

See "EtherCAT Function Blocks That Work With Drive Parameters" (→ p. 521) for information about function blocks that are not supported by ML and MC function blocks.




Figure 1-107: DriveParamStrRead

NOTE

This function block **uses and reserves** the EtherCAT SDO Channel. The SDO Channel remains reserved until the done output is TRUE. This FB should be called at each cycle until the done output is TRUE. If it is not called at each cycle, the rest of SDO communication (e.g., the AKD GUI Views) is blocked. Using this FB in SFC P0 or P1 steps is not recommended because these steps are executed only once. If this FB is used in P0 or P1, then it must be used in an SFC N step to ensure the FB completes.

4.1.6.3.1 EtherCAT Error Codes

List of EtherCAT Error Codes

Error Code	Value dec (hex)	Description
ECERR_OK	0	The SDO call succeeded
ECERR_DEVICE_ERROR	1792 (0x700)	EtherCAT device is not accessible
ECERR_DEVICE_INVALIDCMD	1794 (0x702)	Invalid mailbox command
ECERR_DEVICE_INVALIDINDEX	1795 (0x703)	An invalid value for the Index input was specified
ECERR_DEVICE_INVALIDACCESS	1796 (0x704)	Reading of the variable is not permitted
ECERR_DEVICE_INVALIDSIZE	1797 (0x705)	An invalid size for the parameter was specified
ECERR_DEVICE_INVALIDDATA	1798 (0x706)	Invalid parameter value(s) in SDO index and/or sub-index
ECERR_DEVICE_NOTREADY	1799 (0x707)	Device is not in a ready state, network is not in operational
ECERR_DEVICE_BUSY	1800 (0x708)	Device is not available to respond
ECERR_DEVICE_INVALIDCONTEXT	1801 (0x709)	Device responded with an illegal error code, indicating the command is not allowed under the present conditions
ECERR_DEVICE_NOMEMORY	1802 (0x70A)	EtherCAT mailbox is out of memory or device is out of disk space

Error Code	Value dec (hex)	Description
ECERR_DEVICE_INVALIDPARM	1803 (0x70B)	EtherCAT mailbox request was not valid
ECERR_DEVICE_NOTFOUND	1804 (0x70C)	EtherCAT device not found
ECERR_DEVICE_SYNTAX	1805 (0x70D)	An unexpected error occurred
ECERR_DEVICE_INVALIDSTATE	1810 (0x712)	The EtherCAT device is in an invalid state
ECERR_DEVICE_TIMEOUT	1817 (0x719)	The EtherCAT device failed to respond, timing out
ECERR_DEVICE_INSERTMAILBOX	1826 (0x722)	Error while inserting the mailbox command into internal FIFO
ECERR_DEVICE_INVALIDOFFSET	1827 (0x723)	An invalid value for the SubIndex input was specified
ECERR_DEVICE_UNKNOWNMAILBOXCMD	1828 (0x724)	The master sent an unknown mailbox command to the slave
ECERR_DEVICE_ACCESSDENIED	1829 (0x725)	Device responded with an invalid access error code, indicating the command is not allowed
ECERR_DEVICE_INVALIDADDR	1832 (0x728)	Can't send a mailbox command to the specified slave
ECERR_DEVICE_NOT_A_FSOE_MASTER	1836 (0x72c)	Device is not a FSoE master.
ECERR_DEVICE_PARAM_ACCESS_ERROR	1920 (0x780)	Unknown error occurred while accessing parameter
ECERR_DEVICE_PARAM_NOT_FOUND	1921 (0x781)	Parameter was not found
ECERR_DEVICE_PARAM_NOT_INTEGER	1922 (0x782)	Parameter is a floating-point value. Integer value required.
ECERR_DEVICE_VALUE_IS_NEGATIVE	1923 (0x783)	No negative values allowed. Value specified was negative.
ECERR_DEVICE_VALUE_OUT_OF_RANGE	1924 (0x784)	Value is out of data-range
ECERR_DEVICE_VALUE_GREATER_THAN_MAX	1925 (0x785)	Value bigger than maximum
ECERR_DEVICE_VALUE_LOWER_THAN_MIN	1926 (0x786)	Value lower than minimum
ECERR_CLIENT_ERROR	2048 (0x800)	Error in Mailbox response to a previously sent mailbox command
ECERR_CLIENT_TIMEOUT	2049 (0x801)	The SDO command timed out
ECERR_CLIENT_INVALIDPARM	2050 (0x802)	An invalid value was specified
ECERR_CLIENT_INVALIDSIZE	2051 (0x803)	An invalid value for the size input was specified

4.1.6.3.2 Usage

Use this FB to read drive parameters that are not supported by other function blocks.

Examples are motor temperature, drive bus voltage, present drive limit settings, present regen loading, drive display, and fault history.

4.1.6.4 FBD Language

Not available.

4.1.6.5 FFLD Language

Not available.

4.1.6.6 IL Language

Not available.

4.1.6.7 ST Language

```

(* Read AXIS1.FAULTMSG1 on first AKD2G Drive on EtherCAT
network *)

(* The code continually calls the FB (without re-executing it) until the
first execution is done, then reads the returned value from the drive and
reset the FB *)

IF ReadFaultMsg Then
  Inst_DriveParamStrRead1(True, 1001, 'AXIS1.FAULTMSG1' );
End_If;

On Inst_DriveParamStrRead1 Do
  FaultMsg := Inst_DriveParamStrRead1.Value; (* Reads the returned value
from the drive *)
  Inst_DriveParamStrRead1(False, 1001, 'AXIS1.FAULTMSG1');
  ReadFaultMsg := False; (* Reset the FB *)
End_DO;

```

See Also


- "DriveParamRead" (→ p. 522)
- "DriveParamWrite" (→ p. 530)

4.1.7 DriveParamWrite



Function Block - Writes a drive parameter by sending an ASCII command to a drive.

4.1.7.1 Inputs

Input	Data Type	Range	Unit	Default	Description
Execute	BOOL	0, 1	N/A	No default	On the rising edge of Execute, a drive parameter is set. <ul style="list-style-type: none"> The function block processes only one request at a time. If Execute is toggled quickly so that another rising edge occurs before the function block has completed, the function block does not issue a second write command.
Drive	INT	No range	N/A	No default	The address of the drive where data is written. <ul style="list-style-type: none"> The first node usually has the value 1001. The second node usually has the value 1002. Alternately, use the members of the EtherCAT structure to specify a drive's address to Create Variables . 
Param	STRING	No range	N/A	No default	The parameter to write.
Value	LREAL	No range	N/A	No default	The value to set the drive parameter to.

4.1.7.2 Outputs

Output	Data Type	Range	Unit	Description
Done	BOOL	No range	N/A	Indicates whether this function block has completed without error.
Error	BOOL	No range	N/A	Indicates whether this function block call has completed with error.
ErrorID	DINT	No range	N/A	The DriveParamWrite error result if Error is TRUE. Upon success, Error is set to 0 (zero). See the " EtherCAT Error Codes " (→ p. 532) for more information.

4.1.7.3 Remarks

Use this function block to change drive parameters. Examples include tuning parameters and changing drive limits (i.e., peak current).

- It takes multiple cycles to complete this function block.
- Typically only **one DriveParamRead** or **DriveParamWrite** function should be active for **each axis** at one time.
- If executing this function block continuously or if multiple times is required, add code that waits for this function block to complete (Done bit = 1) before executing it again.

- See **stats** about the "Execution Time" (→ p. 521).
- See "EtherCAT Function Blocks That Work With Drive Parameters" (→ p. 521) for information about function blocks that are not supported by ML and MC function blocks.




Figure 1-108: DriveParamWrite

NOTE

This function block **uses and reserves** the EtherCAT SDO Channel. The SDO Channel remains reserved until the done output is TRUE. This FB should be called at each cycle until the done output is TRUE. If it is not called at each cycle, the rest of SDO communication (e.g., the AKD GUI Views) is blocked. Using this FB in SFC P0 or P1 steps is not recommended because these steps are executed only once. If this FB is used in P0 or P1, then it must be used in an SFC N step to ensure the FB completes.

4.1.7.3.1 EtherCAT Error Codes


List of EtherCAT Error Codes

Error Code	Value dec (hex)	Description
ECERR_OK	0	The SDO call succeeded
ECERR_DEVICE_ERROR	1792 (0x700)	EtherCAT device is not accessible
ECERR_DEVICE_INVALIDCMD	1794 (0x702)	Invalid mailbox command
ECERR_DEVICE_INVALIDINDEX	1795 (0x703)	An invalid value for the Index input was specified
ECERR_DEVICE_INVALIDACCESS	1796 (0x704)	Reading of the variable is not permitted
ECERR_DEVICE_INVALIDSIZE	1797 (0x705)	An invalid size for the parameter was specified
ECERR_DEVICE_INVALIDDATA	1798 (0x706)	Invalid parameter value(s) in SDO index and/or sub-index
ECERR_DEVICE_NOTREADY	1799 (0x707)	Device is not in a ready state, network is not in operational
ECERR_DEVICE_BUSY	1800 (0x708)	Device is not available to respond
ECERR_DEVICE_INVALIDCONTEXT	1801 (0x709)	Device responded with an illegal error code, indicating the command is not allowed under the present conditions


Error Code	Value dec (hex)	Description
ECERR_DEVICE_NOMEMORY	1802 (0x70A)	EtherCAT mailbox is out of memory or device is out of disk space
ECERR_DEVICE_INVALIDPARM	1803 (0x70B)	EtherCAT mailbox request was not valid
ECERR_DEVICE_NOTFOUND	1804 (0x70C)	EtherCAT device not found
ECERR_DEVICE_SYNTAX	1805 (0x70D)	An unexpected error occurred
ECERR_DEVICE_INVALIDSTATE	1810 (0x712)	The EtherCAT device is in an invalid state
ECERR_DEVICE_TIMEOUT	1817 (0x719)	The EtherCAT device failed to respond, timing out
ECERR_DEVICE_INSERTMAILBOX	1826 (0x722)	Error while inserting the mailbox command into internal FIFO
ECERR_DEVICE_INVALIDOFFSET	1827 (0x723)	An invalid value for the SubIndex input was specified
ECERR_DEVICE_UNKNOWNMAILBOXCMD	1828 (0x724)	The master sent an unknown mailbox command to the slave
ECERR_DEVICE_ACCESSDENIED	1829 (0x725)	Device responded with an invalid access error code, indicating the command is not allowed
ECERR_DEVICE_INVALIDADDR	1832 (0x728)	Can't send a mailbox command to the specified slave
ECERR_DEVICE_NOT_A_FSOE_MASTER	1836 (0x72c)	Device is not a FSoE master.
ECERR_DEVICE_PARAM_ACCESS_ERROR	1920 (0x780)	Unknown error occurred while accessing parameter
ECERR_DEVICE_PARAM_NOT_FOUND	1921 (0x781)	Parameter was not found
ECERR_DEVICE_PARAM_NOT_INTEGER	1922 (0x782)	Parameter is a floating-point value. Integer value required.
ECERR_DEVICE_VALUE_IS_NEGATIVE	1923 (0x783)	No negative values allowed. Value specified was negative.
ECERR_DEVICE_VALUE_OUT_OF_RANGE	1924 (0x784)	Value is out of data-range
ECERR_DEVICE_VALUE_GREATER_THAN_MAX	1925 (0x785)	Value bigger than maximum
ECERR_DEVICE_VALUE_LOWER_THAN_MIN	1926 (0x786)	Value lower than minimum
ECERR_CLIENT_ERROR	2048 (0x800)	Error in Mailbox response to a previously sent mailbox command
ECERR_CLIENT_TIMEOUT	2049 (0x801)	The SDO command timed out
ECERR_CLIENT_INVALIDPARM	2050 (0x802)	An invalid value was specified

Error Code	Value dec (hex)	Description
ECERR_CLIENT_INVALIDSIZE	2051 (0x803)	An invalid value for the size input was specified

4.1.7.4 FBD Language



4.1.7.5 FLD Language



4.1.7.6 IL Language

Not available. - IS THIS TRUE?

4.1.7.7 ST Language

```
(* Write 58.000 to PL.KP of first AKD Drive on EtherCAT network *)
Inst_DriveParamWrite( TRUE, 1001, 'PL.KP', 58 );
```

See Also

"DriveParamRead" (→ p. 522)

4.1.8 ECATCommErrors



Function Block - Returns a list of bad EtherCAT connections.

4.1.8.1 Inputs

Input	Data Type	Range	Unit	Default	Description
Execute	BOOL	0, 1	N/A	No default	Read the communication errors on the rising edge.

Input	Data Type	Range	Unit	Default	Description
Connection	ECATCommErr_ref See the "ECATCommErr_ref Structure" (→ p. 535) table.	N= 0 to 2 times the number of EtherCAT devices.	N/A	No default	Array of bad connections. The safe size for the list is $[2 * (\text{number of devices}) - 1]$.

4.1.8.2 Outputs

Output	Data Type	Range	Unit	Description
Done	BOOL	N/A		Indicates when the function is complete.
Error	BOOL	N/A		Indicates the function failed due to an error.
ErrorID	DINT	N/A		The function call error result, if Error is TRUE. <ul style="list-style-type: none"> See the "Possible Error Codes and Descriptions" (→ p. 536) table. Upon success, Error is set to 0 (zero).
ConnectionCount	UINT	N/A		The number of bad connections. Valid indices in the Connection array range from zero to ConnectionCount - 1 (assuming that ConnectionCount != 0).

4.1.8.3 Remarks

If EtherCAT network communication is shutdown, the failed connections are based on information that was taken at the time the network was shutdown.




Figure 1-109: ECATCommErrors Function Block

TIP

See [Check the Connections for Errors](#) for an example of implementing this function.

4.1.8.3.1 ECATCommErr_ref Structure

ECATCommErr_ref Structure

Parameter	Type	Description
CommErrorCounter	UINT	The Communication Error Counter for this port.
ConnectedSlaveAddress	INT	The EtherCAT address of the connected device.
ConnectedSlavePortID	UINT	The port number of the connected device.
LostLinkCounter	UINT	The Lost Link Counter for this port.
SlaveAddress	INT	The EtherCAT address of the device that owns the port.
SlavePortID	UINT	The port number.

4.1.8.3.2 EtherCAT Port Numbers Defines

EtherCAT Port Numbers Defines

Define	Port
#define EC_PORT_A	0 (* Port A *)
#define EC_PORT_B	1 (* Port B *)
#define EC_PORT_C	2 (* Port C *)
#define EC_PORT_D	3 (* Port D*)

4.1.8.3.3 Possible Error Codes and Descriptions


Possible Error Codes and Descriptions

Error Code	Description
ECERR_DEVICE_ERROR	The EtherCAT driver is in a bad state
ECERR_INVALID_ARRAY_SIZE	The size of the Connections is too small


NOTE

When the array size is smaller than the number of bad connections, the array is filled with the data to the extent of the size of the array and the error 'ECERR_INVALID_ARRAY_SIZE' is also set. In this scenario, the output **ConnectionCount** is set to the size of the array and it is smaller than the number of actual bad connections.

4.1.8.4 FBD Language



4.1.8.5 FFLD Language



4.1.8.6 IL Language

Not available.

4.1.8.7 ST Language

```

(*****)
Read EtherCAT communication errors.
(*****)
commErrors( TRUE, Connection);
    
```

See Also

- "ECATDeviceStatus" (→ p. 539)
- "ECATMasterStatus" (→ p. 547)


4.1.9 ECATDeviceAction



Function Block - performs an action on an EtherCAT device.

4.1.9.1 Inputs

Input	Data Type	Range	Unit	Default	Description
Execute	BOOL	0, 1	N/A	No default	When Execute is set to TRUE, an action is performed.
DeviceAddress	INT	No range	N/A	No default	The address of the device to perform an action on. <ul style="list-style-type: none"> • The first node usually has the value 1001. • The second node usually has the value 1002. • Use the members of the EtherCAT structure to specify a device's address when you Create Variables.
Action	INT	No range	N/A	No default	The action to be performed. Action can be one of these values: <ul style="list-style-type: none"> • DEVICE_ACTION_CONNECT <ul style="list-style-type: none"> • Connects a slave into the EtherCAT network. • This action can only be executed when the motion engine is stopped. • DEVICE_ACTION_DISCONNECT <ul style="list-style-type: none"> • Disconnects a slave from the EtherCAT network. • This action can only be executed when the motion engine is stopped.




4.1.9.2 Outputs

Output	Data Type	Range	Unit	Description
Done	BOOL	No range	N/A	Indicates whether the ECATDeviceAction function block completed without error.

Output	Data Type	Range	Unit	Description
Error	BOOL	No range	N/A	Indicates whether the ECATDeviceAction function block completed with error.
ErrorID	DINT	No range	N/A	The ECATDeviceAction error result if Error is TRUE. <ul style="list-style-type: none"> • See "Error Codes" (→ p. 538). • Upon success, Error is set to 0 (zero).

4.1.9.3 Remarks



ECATDeviceAction function block

- This function returns immediately.
- It can be called multiple times in one cycle.

These actions are currently supported

- **DEVICE_ACTION_DISCONNECT**
 - The EtherCAT master is notified to expect the node to be removed from the EtherCAT when ECATDeviceAction is called with DEVICE_ACTION_DISCONNECT.
 - Any Axis/Axes mapped to a drive node is automatically simulated.
 - The last position from the physical drive is carried over to the simulation when the EtherCAT restarts.
- **DEVICE_ACTION_CONNECT**
 - This action connects the already disconnected node to the EtherCAT Network.
 - The axis (or axes) that was acting as simulated axis becomes a normal axis when the drive node is connected.
 - The axis/axes position comes directly from the configured drive feedback.
 - The position is **not** automatically transferred from the simulated axis.

4.1.9.4 Usage

The EtherCAT network needs to be stopped to use this function block.

- This is achieved by either:
 - Calling **ECATDeviceAction** prior to calling "MLMotionStart" (→ p. 417).
 - First calling "MLMotionStop" (→ p. 420) to stop the network.
- See [Modular EtherCAT Concept](#) for more information on modular machine design.

4.1.9.5 Error Codes


Error Code	Value Dec (hex)	Description
ECERR_OK	0	The action succeeded.
ECERR_DEVICE_ACTION_IS_INVALID	1000 (0x3E8)	The specified device action is invalid.

Error Code	Value Dec (hex)	Description
ECERR_DEVICE_IS_DC_CLOCK_MASTER	1001 (0x3E9)	The Device is a DC Clock Master.
ECERR_DEVICE_IS_IN_DC_MASTER_UPSTREAM	1002 (0x3EA)	The device is before the DC Clock Master.
ECERR_DEVICE_ACTION_MINIMUM_ONE_NODE_REQD	1003 (0x3EB)	Minimum one node is required in the EtherCAT Network.
ECERR_DEVICE_ERROR	1792 (0x700)	EtherCAT device is not accessible.
ECERR_DEVICE_NOTREADY	1799 (0x707)	Device is not in a ready state. The EtherCAT network is not in the desired state for the specified action.
ECERR_DEVICE_INVALIDADDR	1832 (0x728)	The specified EtherCAT node address is invalid.

4.1.9.5.1 FBD Language



4.1.9.5.2 FFLD Language



4.1.9.5.3 IL Language

Not available.

4.1.9.5.4 ST Language

```

MLMotionStop();
MotionEngineStatus := MLMotionStatus();
On MotionEngineStatus = MLSTATUS_STOPPED Do
  Inst_ECATCHDeviceAction(True, EtherCAT.AKD_3, DEVICE_ACTION_DISCONNECT);
  If Inst_ECATCHDeviceAction.Error Then
    // Handle Error
    // Error ID value is in Inst_ECATCHDeviceAction.Error
  End_If;
End_Do;
    
```

See Also


- "MLMotionStart" (→ p. 417)
- "MLMotionStop" (→ p. 420)

4.1.10 ECATCHDeviceStatus

PLCopen ✓

Pipe Network ✓

- This function block provides the EtherCAT state and the port link status information for the EtherCAT device. If the EtherCAT network communication is not running due to a shutdown, the device status contains information that was taken at the time the network was shutdown. This function block is useful in locating the device(s) with communication errors when the "ECATWCStatus" (→ p. 555) function indicates there are EtherCAT communication errors.



ECATDeviceStatus function block

4.1.10.1 Arguments

4.1.10.1.1 Input

Execute	Description	Read the device status on the rising edge
	Data type	BOOL
	Range	0,1
	Unit	N/A
	Default	
DeviceAddress	Description	The address of the device from which data is read. The first node usually has the value '1001'. The second node usually has the value '1002'. Alternately, you can use the members of the EtherCAT structure to specify a device's address when you create the variable.
	Data type	INT
	Range	-
	Unit	N/A
	Default	-

4.1.10.1.2 Output

Done	Description	Indicates when the function is complete
	Data type	BOOL
	Unit	N/A

State	Description	Indicates the EtherCAT state of the device. See "State Defines" (→ p. 541) below for details. <ul style="list-style-type: none"> • A value of zero indicates that there is no communication with the device and the state is unknown. • Bits 3:0 indicate the actual state of the Device. • An EC_STATE_ERROR (bit 4 set to 1) indicates the device is not in the EtherCAT Master requested State due to error conditions such as loss of communication..
	Data type	UINT
	Unit	N/A
LinkStatus	Description	Provides the physical link status of the device's ports. See "LinkStatus Defines" (→ p. 541) below. <ul style="list-style-type: none"> • If no communication is possible with the device, then bit 0 is set to '1'. • If a link is detected on a port (A-D), then the corresponding bit (4-7) will be set to '1'. If no link is detected then the corresponding bit will be set to '0'.
	Data type	UINT
	Unit	N/A
Error	Description	Indicates the function failed due to an error.
	Data type	BOOL
	Unit	N/A
ErrorID	Description	The function call error result, if Error is TRUE (see list of Error Codes in table below). Upon success, Error is set to zero..
	Data type	DINT
	Unit	

State Defines

```
#define EC_STATE_NO_COMMUNICATION 0 (* 0x00 = No Communication to
device *)
#define EC_STATE_INIT 1 (* 0x01 = Device in Init state
*)
#define EC_STATE_PREOP operational state *)
#define EC_STATE_BOOTSTRAP 3 (* 0x03 = Device in Bootstrap
state *)
#define EC_STATE_SAFEOP 4 (* 0x04 = Device in Safe-
Operational state *)
#define EC_STATE_OP 8 (* 0x08 = Device in Operational
state *)
#define EC_STATE_ERROR 16 (* 0x10 bit 4 set to 1; Device
not in requested state error *)
```

LinkStatus Defines

```
#define EC_LINK_NO_COMMUNICATION 1 (* 0x1 = No communication to
device; bit 0 set to 1 *)
#define EC_LINK_PORT_A 16 (* 0x10 = Link detected on Port
A; bit 4 set to 1 *)
#define EC_LINK_PORT_B 32 (* 0x20 = Link detected on Port
B; bit 5 set to 1 *)
#define EC_LINK_PORT_C 64 (* 0x40 = Link detected on Port
C; bit 6 set to 1 *)
#define EC_LINK_PORT_D 128 (* 0x80 = Link detected on Port
D; bit 7 set to 1 *)
```

4.1.10.2 Related Functions

"ECATWCStatus" (→ p. 555), "ECATMasterStatus" (→ p. 547)

4.1.10.3 Example




See [Checking the Device States](#): in the [EtherCAT Communication Diagnosis Steps](#) section of the Troubleshooting chapter for an example of implementing this function.

4.1.10.3.1 Structured Text


```
(*****
(* Read AKD_1 device state and link status*)
*****)

Inst_EcDeviceStatus(TRUE, EtherCAT.AKD_1);
```

4.1.10.3.2 FBD



4.1.10.3.3 FFLD




4.1.11 ECATDevReadParam



This function block returns the EtherCAT device-specific information.
is this a function or function block?

See "EtherCAT Function Blocks That Work With Drive Parameters" (→ p. 521) for information about function blocks that are not supported by ML and MC function blocks.



ECATDevReadParam

4.1.11.1 Arguments

4.1.11.1.1 Input

Enable	Description	Requests to read the EtherCAT device-specific parameter
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
DeviceAddress	Description	The address of the device from which data is read. <ul style="list-style-type: none"> • The first node usually has the value '1001'. • The second node usually has the value '1002'. • Alternately, use the members of the EtherCAT structure to specify a device's address when the variable is created.
	Data type	INT
	Range	-
	Unit	N/A
	Default	—
ParameterNumber	Description	Parameter number See the table in "EtherCAT Device Parameters" (→ p. 544).
	Data type	INT
	Range	—
	Unit	N/A
	Default	—

4.1.11.1.2 Output

Done	Description	Indicates when the function is complete.
	Data type	BOOL
Error	Description	Indicates an invalid input.

	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE See " List of EtherCAT Error Messages " (→ p. 544).
	Data type	INT
Value	Description	Value of the parameter
	Data type	LREAL

List of EtherCAT Error Messages

Error Code	Value dec (hex)	Description
ECERR_OK	0	No Error
ECERR_DEVICE_ERROR	1792 (0x700)	EtherCAT device is not accessible.
ECERR_DEVICE_INVALIDADDR	1832 (0x728)	EtherCAT device address is invalid.
ECERR_DEVICE_PARAM_NOT_FOUND	1921 (0x781)	Parameter was not found.

4.1.11.1.3 EtherCAT Device Parameters

This is a list of currently supported parameters read by ECATDevParamRead.

Parameter	ID	Name	R/W	Description									
DEVICE_PARAM_DEVICE_TYPE	1	Device Type	Read Only	EtherCAT Device Type <table border="1" data-bbox="810 1003 1369 1317"> <thead> <tr> <th>Output Value</th> <th>Numerical Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>DEVICE_TYPE_OTHER</td> <td>0</td> <td>The EtherCAT device is not a drive.</td> </tr> <tr> <td>DEVICE_TYPE_DRIVE</td> <td>1</td> <td>The EtherCAT device is a drive.</td> </tr> </tbody> </table>	Output Value	Numerical Value	Description	DEVICE_TYPE_OTHER	0	The EtherCAT device is not a drive.	DEVICE_TYPE_DRIVE	1	The EtherCAT device is a drive.
Output Value	Numerical Value	Description											
DEVICE_TYPE_OTHER	0	The EtherCAT device is not a drive.											
DEVICE_TYPE_DRIVE	1	The EtherCAT device is a drive.											

Parameter	ID	Name	R/W	Description		
DEVICE_PARAM_DRIVE_FAMILY	2	Drive Family	Read Only	EtherCAT device drive family details.		
				Output Value	Numerical Value	Description
				DEVICE_NOT_A_DRIVE	-1	The EtherCAT device is not a drive.
				DRIVE_FAMILY_OTHER	0	The drive family cannot be determined.
				DRIVE_FAMILY_S300_S700	1	The device is an S300/S700 family drive.
				DRIVE_FAMILY_AKD	2	The device is in the AKD2G, AKD-N, or AKD servo drive family.
DRIVE_FAMILY_AKT2G_STEPPER	3	The device is an AKT2G Stepper family drive.				
DEVICE_PARAM_DRIVE_GEN	3	Drive Generation	Read Only	EtherCAT drive generation details.		
				Output Value	Numerical Value	Description
				DEVICE_NOT_A_DRIVE	-1	The EtherCAT device is not a drive.
				DRIVE_GEN_UNKNOWN	0	The drive generation cannot be determined.
				DRIVE_GEN_1	1	The device is a 1 st generation drive (e.g., AKD, AKD-N, S300, S700, AKT2G-SM-L15, AKT2G-SM-L50).
DRIVE_GEN_2	2	The device is a 2 nd generation drive (e.g., AKD2G).				

4.1.11.2 Example


4.1.11.2.1 Structured Text

```
(* ECATDevReadParam ST example *)
Inst_ECATDevReadParam( TRUE, EtherCAT.AKD_2, DEVICE_PARAM_DEVICE_TYPE );
DeviceType := Inst_ECATDevReadParam.Value;


Inst_ECATDevReadParam( TRUE, EtherCAT.AKD_2, DEVICE_PARAM_DRIVE_FAMILY );
DeviceFamily := Inst_ECATDevReadParam.Value;

Inst_ECATDevReadParam( TRUE, EtherCAT.AKD_2, DEVICE_PARAM_DRIVE_GEN );
DriveGen := Inst_ECATDevReadParam.Value;
```

4.1.11.2.2 Ladder Diagram




4.1.11.2.3 FBD



4.1.12 ECATGetObjVal

PLCopen ✔
Pipe Network ✔

NOTE

 **Function** - Deprecated as of KAS v2.7.
The recommended best practice is to map a PLC variable to a PDO object.


4.1.13 ECATMasterStatus

PLCopen ✓ **Pipe Network** ✓

- This function block reads the EtherCAT master state and the lost frame counter, to determine if EtherCAT is running normally.

TIP

See the [EtherCAT Communication Diagnosis Steps](#) section of the Troubleshooting chapter for more information.



ECATMasterStatus function block

4.1.13.1 Arguments**4.1.13.1.1 Input**

Enable	Description	Request to read the ECAT master state and the lost frame count. Keeps continuously reads the master state and the lost frame count as long as the Enable remains high.
	Data type	BOOL
	Range	0,1
	Unit	N/A
	Default	—

4.1.13.1.2 Output

Valid	Description	Indicates the values at the 'State' and LostFrameCount outputs are valid.
	Data type	BOOL
	Unit	N/A
Error	Description	Indicates error
	Data type	BOOL
	Unit	N/A

ErrorID	Description	Error code when when the function block failed due to error.
	Data type	DINT
	Unit	N/A
State	Description	Indicates the ECAT state of the Master. See State Defines for details
	Data type	UINT
	Unit	N/A
LostFrameCount	Description	Total cumulative number of cyclic frames sent with no-response since the ECAT started by calling the MLMoitonStart. Missing return frames will generate an A38 alarm. The Counter is reset to 0 when the MLMotionStart is called.
	Data type	UDINT
	Unit	N/A

State Defines

```
#define EC_STATE_NO_COMMUNICATION 0 (* 0x00 = No Communication to device *)
#define EC_STATE_INIT 1 (* 0x01 = Device in Init state *)
#define EC_STATE_PREOP 2 (* 0x02 = Device in Pre-operational state *)
#define EC_STATE_BOOTSTRAP 3 (* 0x03 = Device in Bootstrap state *)
#define EC_STATE_SAFEOP 4 (* 0x04 = Device in Safe-Operational state *)
#define EC_STATE_OP 8 (* 0x08 = Device in Operational state *)
```

4.1.13.2 Related Functions


"ECATWCStatus" (→ p. 555), "ECATDeviceStatus" (→ p. 539).

4.1.13.3 Examples


4.1.13.3.1 Structured Text

```
// ECATMasterStatus
Inst_ECATMasterStatus( True );
MasterState := Inst_ECATMasterStatus.State;
MasterLastFrameCount := Inst_ECATMasterStatus.LostFrameCount;
```

4.1.13.3.2 FBD



4.1.13.3 FFLD



4.1.14 ECATReadData



Function - allows a direct access to the memory [image](#) of the EtherCAT frame which is sent or received when you need to debug your application.

! IMPORTANT

This is a low level function and it should only be used carefully by **advanced users**.

You access the EtherCAT image element by giving the offset in the image and the size of the element.

If you have a device other than the drive, ECATReadData is used for more than just debug. It is used to get the status of the module (e.g. Stepper I/O slice).

4.1.14.1 Arguments

4.1.14.1.1 Input

Offset	Description	Offset in bytes from the beginning of the frame ! IMPORTANT The Offset value required to access may change when the firmware for any device on the EtherCAT network is updated or whenever the EtherCAT network topology changes. When performing an update of a network device or changing the network topology, one should export the ENI file and check the Offset value needed to access the desired information.
	Data type	UINT
	Range	0- <i>size of frame</i> (maximum size of an Ethernet frame is 1500)
	Unit	bytes
	Default	—
Nbytes	Description	Number of bytes to read

	Data type	SINT
	Range	1, 2 or 4
	Unit	bytes
	Default	—
Direction	Description	Direction of the frame (true = output image, false = input image).
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—

NOTE

The valid ranges for the **Value** parameter are:
 For 1 byte: 0 to 255
 For 2 bytes: 0 to 65535
 For 4 bytes: - 2147483648 to 2147483648 (The sign bit represents the most significant bit in the data word)

4.1.14.1.2 Output

Value	Description	Value of the EtherCAT frame
	Data type	DINT
	Unit	N/A

4.1.14.2 Related Functions

[ECATGetObjVal](#)


4.1.14.3 Example

4.1.14.3.1 Structured Text


```
// Read 4 bytes starting at offset 26 of the output image
```

```
Position := ECATReadData(26, 4, true);
```

4.1.14.3.2 FBD



4.1.14.3.3 FFLD




4.1.15 ECATReadSDO



- This function block reads a 32-bit word from I/O nodes using a CANopen SDO read command. Is typically used to query the status of inputs.

See "[EtherCAT Function Blocks That Work With SDOs](#)" (→ p. 522) for information about function blocks which are used to work with drive or remote I/O parameters that are not supported by ML and MC function blocks.




ECATReadSdo

4.1.15.0.1 State Diagram

	Range	0, 1
	Unit	N/A
	Default	—
Index	Description	<p>The object directory index of the data to be read. For more details, refer to:</p> <ul style="list-style-type: none"> • Communication SDOs • Manufacturer specific SDOs • Profile specific SDOs <p>To read/write an SDO object with an index greater than 16#7FFF (32767), the value must be entered in the form <code>any_to_int(index # in hex format)</code>. For example <code>any_to_int(16#8321)</code>.</p>
	Data type	INT
	Range	—
	Unit	N/A
	Default	—
Subindex	Description	<p>The sub-index of the object directory variable to be read. For more details, refer to:</p> <ul style="list-style-type: none"> • Communication SDOs • Manufacturer specific SDOs • Profile specific SDOs <p>To read/write an SDO object with an index greater than 16#7FFF (32767), the value must be entered in the form <code>any_to_int(index # in hex format)</code>. For example <code>any_to_int(16#8321)</code>.</p>
	Data type	SINT
	Range	—
	Unit	N/A
	Default	—
Size	Description	The size (number of bytes) to write.
	Data type	SINT
	Range	1 - 4
	Unit	N/A
	Default	—

DeviceAddress	Description	The EtherCAT address of the device from which data is written to. The first node usually has the value '1001'. The second node usually has the value '1002'. Alternately, use the members of the EtherCAT structure to specify a drive's address to Create Variables .
	Data type	INT
	Range	—
	Unit	N/A
	Default	—



4.1.15.1.2 Output

Done	Description	Indicates whether the SDO call has completed without error.
	Data type	BOOL
	Unit	N/A
Error	Description	Indicates whether the SDO call has completed with error:
	Data type	BOOL
	Unit	N/A
ErrorID	Description	The SDO call error result, if Error is TRUE (see list of Error Codes in table below). Upon success, Error is set to zero.
	Data type	DINT
	Unit	N/A
Value	Description	The value of the object directory variable being read. Value is only set when an SDO read command has successfully completed.
	Data type	DINT
	Unit	N/A

4.1.15.2 Related Functions

[ECATWriteSDO](#)


4.1.15.3 Example

4.1.15.3.1 Structured Text


```
(* Read PL.KP on first AKD Drive on EtherCAT network *)
Inst_ECATReadSdo( TRUE, 16#3542, 0, 4, 1001 );
PositionProportionalGain := Inst_ECATReadSdo.Value;
```

```
(* Read the 4 byte data in SDO index 8321h (33569 decimal), sub-index 1
on the first AKD Drive
Inst_ECATReadSdo( TRUE, any_to_int(16#8321), 1, 4, 1001 );
ParamValue := Inst_ECATReadSdo.Value;
```

4.1.15.3.2 FBD



4.1.15.3.3 FLD




4.1.16 ECATWCStatus

PLCopen Pipe Network

Function - returns the current number of working counter errors for the Sync unit. The working counter errors are cleared to zero when the EtherCAT network is taken from **Init** to **OP** state.

- Value **0** means no working counter errors.
- When the value is non zero, the master will automatically reduce the count by **1** for every thousand good frames received.
- When the working counter error exceeds the **Working Counter Error Limit**, the EtherCAT network will be stopped.



ECATWCStatus function

4.1.16.1 Arguments

4.1.16.1.1 Input

SyncUnit	Description	Sync Unit Index (for future compatibility with multiple frames)
	Data type	INT
	Range	0
	Unit	N/A
	Default	-

4.1.16.1.2 Output

Count	Description	Working Counter error
	Data type	UDINT
	Unit	N/A

4.1.16.2 Related Functions

"ECATDeviceStatus" (→ p. 539), "ECATMasterStatus" (→ p. 547)

4.1.16.3 Example

TIP

See [Checking for Working Counter Errors](#): in the [EtherCAT Communication Diagnosis Steps](#) section of the Troubleshooting chapter for an example of implementing this function.

4.1.16.3.1 Structured Text


```

(*****)
(* read Ethercat Working counter value *)
(*****)
wcErrorCounter := ECATWCStatus( 0 );
    
```

4.1.16.3.2 FBD



4.1.16.3.3 FFLD



4.1.17 ECATWriteData

PLCopen  **Pipe Network** 

IMPORTANT

This is a low level function and it should only be used carefully by **advanced users**.

 **Function** - Modify the EtherCAT process image by directly writing values in it.

If you have a device other than the drive, ECATWriteData is used for more than just debug. It is used to set the status of the module (e.g. Stepper I/O slice) in the case your project is based on an external XML file because it contains unsupported EtherCAT Device.

4.1.17.1 Arguments

4.1.17.1.1 Input

Offset	Description	Offset in bytes from the beginning of the frame ⓘ IMPORTANT The Offset value required to access may change when the firmware for any device on the EtherCAT network is updated or whenever the EtherCAT network topology changes. When performing an update of a network device or changing the network topology, one should export the ENI file and check the Offset value needed to access the desired information.
	Data type	UINT
	Range	0 - 1500
	Unit	bytes
	Default	—
Nbytes	Description	Number of bytes to write
	Data type	SINT
	Range	1, 2 or 4
	Unit	bytes
	Default	—
Value	Description	Value to be written in the image. Only the number of bytes specified by Nbytes is copied.
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

NOTE

The valid ranges for the **Value** parameter are:
 For 1 byte: 0 to 255
 For 2 bytes: 0 to 65535
 For 4 bytes: - 2147483648 to 2147483648 (The sign bit represents the most significant bit in the data word)

4.1.17.1.2 Output

Default (.Q)	Description	True if data was written.
	Data type	BOOL
	Unit	N/A

4.1.17.2 Related Functions

[ECATReadData](#)

4.1.17.3 Example


4.1.17.3.1 Structured Text

```


//For use with Kollmorgen Thermocouple slice I/O to read in deg C
//Lookup offset by exporting ENI file after EtherCAT network is scanned
//Use offst 124 (byte) to write 0 in control word to allow temperature to
be shown on status byte

ON WriteControlOnly DO
  ECATWriteData( 124, 1, 0 );
END_DO
    
```

4.1.17.3.2 FBD



4.1.17.3.3 FFLD




4.1.18 ECATWriteSDO

PLCopen ✓ **Pipe Network** ✓

- This function block writes a 32-bit word to I/O nodes using a CANopen SDO write command.

See "[EtherCAT Function Blocks That Work With SDOs](#)" (→ p. 522) for information about function blocks which are used to work with drive or remote I/O parameters that are not supported by ML and MC function blocks.



ECATWriteSdo

4.1.18.0.1 State Diagram




Figure 1-111: ECATWriteSdo State Diagram

NOTE

This function block **uses and reserves** the EtherCAT SDO Channel. The SDO Channel remains reserved until the done output is TRUE. This FB should be called at each cycle until the done output is TRUE. If it is not called at each cycle, the rest of SDO communication (e.g., the AKD GUI Views) is blocked. Using this FB in SFC P0 or P1 steps is not recommended because these steps are executed only once. If this FB is used in P0 or P1, then it must be used in an SFC N step to ensure the FB completes.

4.1.18.1 Arguments

4.1.18.1.1 Input


Execute

Description

On the rising edge of Execute, an SDO write command will be issued. The function block will only handle one SDO command at a time. If Execute is toggled quickly so that another rising edge occurs before the SDO command has completed, the function block will not issue a second SDO command.

	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Index	Description	<p>The object directory index of the data to be written to. For more details, refer to:</p> <ul style="list-style-type: none"> • Communication SDOs • Manufacturer specific SDOs • Profile specific SDOs <p>To read/write an SDO object with an index greater than 16#7FFF (32767), the value must be entered in the form <code>any_to_int(index # in hex format)</code>. For example <code>any_to_int(16#8321)</code>.</p>
	Data type	INT
	Range	—
	Unit	N/A
	Default	—
Subindex	Description	<p>The sub-index of the object directory variable to be written to. For more details, refer to:</p> <ul style="list-style-type: none"> • Communication SDOs • Manufacturer specific SDOs • Profile specific SDOs <p>To read/write an SDO object with an index greater than 16#7FFF (32767), the value must be entered in the form <code>any_to_int(index # in hex format)</code>. For example <code>any_to_int(16#8321)</code>.</p>
	Data type	SINT
	Range	—
	Unit	N/A
	Default	—
Size	Description	The size (number of bytes) to write.
	Data type	SINT
	Range	1 - 4
	Unit	N/A
	Default	—

DeviceAddress	Description	The EtherCAT address of the device from which data will be written to. The first node usually has the value '1001'. The second node usually has the value '1002'. Alternately, use the members of the EtherCAT structure to specify a drive's address to Create Variables .
	Data type	INT
	Range	—
	Unit	N/A
	Default	—
Value	Description	The value to write to the object directory variable.
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—



4.1.18.1.2 Output

Done	Description	Indicates whether the SDO call has completed without error.
	Data type	BOOL
	Unit	N/A
Error	Description	Indicates whether the SDO call has completed with error:
	Data type	BOOL
	Unit	N/A
ErrorID	Description	The SDO call error result, if Error is TRUE (see). Upon success, Error is set to zero.
	Data type	DINT
	Unit	N/A

4.1.18.2 Related Functions

[ECATReadSDO](#)


4.1.18.3 Example

4.1.18.3.1 Structured Text


```
(* Write 58.000 to PL.KP of first AKD Drive on EtherCAT network *)
Inst_ECATWriteSdo( TRUE, 16#3542, 0, 4, 1001, 58000 );
```

```
(* Write a value of 246 to the 4 byte data in SDO index 8321h (33569 decimal), sub-index 1 on the first AKD Drive *)
Inst_ECATWriteSdo( TRUE, any_to_int(16#8321), 1, 4, 1001, 246 );
```

4.1.18.3.2 FBD



4.1.18.3.3 FFLD



4.1.19 FSoEParamsInit

PLCopen Pipe Network

4.1.19.1 Description

This function block reads the Safety parameters from the FSoE Master from the input **FSoEMasterAddress** and transfers them to the intended safety slave device using EtherCAT SDO communication.

- The function block checks the FSoE master's register for the safety parameter transfer on the rising edge of the **Execute** input.
- The function block gets the EtherCAT address of the safety slave that will receive the safety parameter if the FSoE master has any safety parameters to transfer.
- Once the address is read and validated from the FSoE master the function block reads the actual parameter from the FSoE master and writes the parameter to the safe Slave.
- The **Done** output is set to "1" when all parameters to all of the intended Safety slaves are written.
- The **Error** output will be set to "1" and the appropriate ErrorID will be set in the **ErrorID** output if any error occurred during this process.




Figure 1-112: FSoEParamsInit Function Block

FSoE masters supported by this function block:


- BBH SCU-1-EC

See Also

- [Set Up FSoE Master and an AKD2G with SafeMotion Monitor](#)
- [AKD2G Safety Parametrization Using FSoE with SCU-1-EC and PxMM/PCMM2G](#)
- [Troubleshooting FSoE Safety Parameters](#)

4.1.19.2 Arguments

4.1.19.2.1 Inputs

Execute	Description	On the rising edge the function block initiates safety parameter transfer from the FSoE master at address <i>FSoEMasterAddress</i> to its safety slaves.
	Data type	BOOL
	Range	False, True
	Unit	N/A
	Default	—
FSoE Master's EtherCAT device address	Description	The EtherCAT slave address of the FSoE master that will be asked to initialize safety parameters. The first EtherCAT slave usually has the value '1001'. The second slave usually has the value '1002'. Alternately, you can use the members of the EtherCAT structure to specify the EtherCAT address of the safety master.
		
	Data type	INT
	Range	—
	Unit	N/A
	Default	—

4.1.19.2.2 Outputs

Done	Description	Indicates whether the parameter initialization has completed without error.
-------------	--------------------	---

	Data type	BOOL
	Unit	N/A
Error	Description	Indicates whether the parameter initialization has completed with an error:
	Data type	BOOL
	Unit	N/A
ErrorID	Description	The parameter initialization error result (see list of Error Codes in table below). Upon success, Error is set to zero.
	Data type	DINT
	Unit	N/A

4.1.19.3 EtherCAT Error Codes

List of EtherCAT Error Codes

Error Code	Value dec (hex)	Description
ECERR_OK	0	The SDO call succeeded
ECERR_DEVICE_ERROR	1792 (0x700)	EtherCAT device is not accessible
ECERR_DEVICE_INVALIDCMD	1794 (0x702)	Invalid mailbox command
ECERR_DEVICE_INVALIDINDEX	1795 (0x703)	An invalid value for the Index input was specified
ECERR_DEVICE_INVALIDACCESS	1796 (0x704)	Reading of the variable is not permitted
ECERR_DEVICE_INVALIDSIZE	1797 (0x705)	An invalid size for the parameter was specified
ECERR_DEVICE_INVALIDDATA	1798 (0x706)	Invalid parameter value(s) in SDO index and/or sub-index
ECERR_DEVICE_NOTREADY	1799 (0x707)	Device is not in a ready state, network is not in operational
ECERR_DEVICE_BUSY	1800 (0x708)	Device is not available to respond
ECERR_DEVICE_INVALIDCONTEXT	1801 (0x709)	Device responded with an illegal error code, indicating the command is not allowed under the present conditions
ECERR_DEVICE_NOMEMORY	1802 (0x70A)	EtherCAT mailbox is out of memory or device is out of disk space
ECERR_DEVICE_INVALIDPARM	1803 (0x70B)	EtherCAT mailbox request was not valid
ECERR_DEVICE_NOTFOUND	1804 (0x70C)	EtherCAT device not found
ECERR_DEVICE_SYNTAX	1805 (0x70D)	An unexpected error occurred
ECERR_DEVICE_INVALIDSTATE	1810 (0x712)	The EtherCAT device is in an invalid state


Error Code	Value dec (hex)	Description
ECERR_DEVICE_TIMEOUT	1817 (0x719)	The EtherCAT device failed to respond, timing out
ECERR_DEVICE_INSERTMAILBOX	1826 (0x722)	Error while inserting the mailbox command into internal FIFO
ECERR_DEVICE_INVALIDOFFSET	1827 (0x723)	An invalid value for the SubIndex input was specified
ECERR_DEVICE_UNKNOWNMAILBOXCMD	1828 (0x724)	The master sent an unknown mailbox command to the slave
ECERR_DEVICE_ACCESSDENIED	1829 (0x725)	Device responded with an invalid access error code, indicating the command is not allowed
ECERR_DEVICE_INVALIDADDR	1832 (0x728)	Can't send a mailbox command to the specified slave
ECERR_DEVICE_NOT_A_FSOE_MASTER	1836 (0x72c)	Device is not a FSoE master.
ECERR_DEVICE_PARAM_ACCESS_ERROR	1920 (0x780)	Unknown error occurred while accessing parameter
ECERR_DEVICE_PARAM_NOT_FOUND	1921 (0x781)	Parameter was not found
ECERR_DEVICE_PARAM_NOT_INTEGER	1922 (0x782)	Parameter is a floating-point value. Integer value required.
ECERR_DEVICE_VALUE_IS_NEGATIVE	1923 (0x783)	No negative values allowed. Value specified was negative.
ECERR_DEVICE_VALUE_OUT_OF_RANGE	1924 (0x784)	Value is out of data-range
ECERR_DEVICE_VALUE_GREATER_THAN_MAX	1925 (0x785)	Value bigger than maximum
ECERR_DEVICE_VALUE_LOWER_THAN_MIN	1926 (0x786)	Value lower than minimum
ECERR_CLIENT_ERROR	2048 (0x800)	Error in Mailbox response to a previously sent mailbox command
ECERR_CLIENT_TIMEOUT	2049 (0x801)	The SDO command timed out
ECERR_CLIENT_INVALIDPARM	2050 (0x802)	An invalid value was specified
ECERR_CLIENT_INVALIDSIZE	2051 (0x803)	An invalid value for the size input was specified

4.1.19.4 Examples


4.1.19.4.1 Structured Text

```
Inst_FSoEParamsInit(True, EtherCAT.FSoE_Mst_1);
```

4.1.19.4.2 FBD



4.1.19.4.3 FFLD



4.2 EtherNet/IP (ODVA)

Explicit messaging may be performed using the following functions.

4.2.1 eipAdapter



Function Block - provides information about the current state of the Scanner connection.

4.2.1.1 Inputs

Input	Data Type	Range	Unit	Default	Description
N/A	N/A	N/A	N/A	N/A	This function block has no inputs. It automatically refers to the adapter in the project.

4.2.1.2 Outputs

Output	Data Type	Range	Unit	Description
Run	BOOL			TRUE, if the EIP stack is running.
IOcnx	BOOL			TRUE, if an I/O connection is established with the Scanner.

4.2.1.3 Remarks

- This function block is used in a program on the Adapter side.
- The servers (adapters) accessed by this block must be configured in the EtherNet/IP Scanner fieldbus configuration.
- Only one explicit message (read or write) can be sent at one time to the same server.
 - If another message is pending you receive the error report 3 (busy) after calling the block to start a new exchange.
- Consider [SerializeIn](#) and [SerializeOut](#) functions for extracting data from the read buffer.

4.2.1.4 Example

```

Inst_eipAdapter(); // read the EtherNet/IP adapter status


EIP_running := Inst_eipAdapter.Run; // is it running?
EIP_connected := Inst_eipAdapter.IOcnx; // and connected?
    
```

See Also

- "eipReadAttr" (→ p. 567)
- "eipWriteAttr" (→ p. 569)

4.2.2 eipReadAttr



 **Function Block** - sends an explicit message (UCMM) to an EtherNet/IP adapter, for reading a single CIP attribute.

4.2.2.1 Inputs

Input	Data Type	Range	Unit	Default	Description
Attr	UINT				Identifier of the CIP attribute.
Class	UINT				Class identifier of the CIP object.
Data	array of UINT				Buffer where to store the received data. If the actual attribute length is greater than the size of this array, value will be truncated when read.
Inst	UINT				Instance identifier of the CIP object.
SrvIP	STRING				IP address of the server (adapter) (e.g., configured in the EtherNet/IP Scanner configuration).
Snd	BOOL				A rising edge on this input starts the exchange. The DONE output signals the end of exchange.

4.2.2.2 Outputs

Output	Data Type	Range	Unit	Description
Done	BOOL			This output is TRUE during one cycle when the exchange is finished, whether the exchange succeeded or failed. Warning: This output can be TRUE just after the call to block when starting a new exchange in case of invalid parameters.
EmErr	UINT			In case of a UCMM error, this is the CIP general status error code.
EmErrExt	UINT			In case of a UCMM error, this is the CIP extended status error code.
Err	UINT			Main error report. Can be one of these values: 0 = no error. 1 = invalid input arguments. 2 = system is busy (see remarks). 3 = timeout waiting for the answer (the timeout value is 3 seconds). 4 = UCMM error was returned by the server others = internal errors (reserved for technical support).
RcvSize	UINT			Actual size of the CIP attribute answered by the server. If this size is greater than the size of the DATA input array, it indicates the value was truncated.

4.2.2.3 Remarks

- The CIP instance number can be 16-bits [1...65535].
- The servers (adapters) accessed by this block must be configured in the EtherNet/IP Scanner fieldbus configuration.
- Only one explicit message (read or write) can be sent at one time to the same server.
 - If another message is pending you receive the error report 3 (busy) after calling the block to start a new exchange.
- Consider [SerializeIn](#) and [SerializeOut](#) functions for extracting data from the read buffer.

4.2.2.4 FBD Language

Not available.

4.2.2.5 FFLD Language

Not available.

4.2.2.6 IL Language

Not available.

4.2.2.7 ST Language


```
// used variables
// Inst_eipReadAttr : eipReadAttr ;
// bRead : BOOL ; (* request for READ *)
// DataRead : ARRAY [0 .. 15] OF USINT ; (* read data *)
// Server identification and CIP things
#define SRVIP '192.168.33.21'
#define CLASSID UINT#100
#define INSTID_READ UINT#1
#define ATTRID UINT#3
////////////////////////////////////
////////////////////////////////////
// requested READ command
if bRead then
  Inst_eipReadAttr (bRead, SRVIP, CLASSID, INSTID_READ, ATTRID,
DataRead);
end_if;
// READ answer here ?
if Inst_eipReadAttr.Done then
  // check answer - if OK answered data is in DataRead array
  if Inst_eipReadAttr.Err = 0 then
    printf ('READ ok - size = %lu bytes',
      any_to_dint (Inst_eipReadAttr.RcvSize));
  else
    printf ('READ Error %lu (UCMM Error %lu, %lu)',
      any_to_dint (Inst_eipReadAttr.Err),
      any_to_dint (Inst_eipReadAttr.EmErr),
      any_to_dint (Inst_eipReadAttr.EmErrExt));
  end_if;
  // reset READ command and block input
  Inst_eipReadAttr (false, SRVIP, CLASSID, INSTID_READ, ATTRID,
DataRead);
  bRead := false;
end_if;
```

See Also

- "eipAdapter" (→ p. 566)
- "eipWriteAttr" (→ p. 569)

4.2.3 eipWriteAttr



 **Function Block** - sends an explicit message (UCMM) to an EtherNet/IP adapter, for writing a single CIP attribute.

4.2.3.1 Inputs

Input	Data Type	Range	Unit	Default	Description
Attr	UINT				Identifier of the CIP attribute.
Class	UINT				Class identifier of the CIP object.
Data	array of UINT				Buffer containing the data to write.
Inst	UINT				Instance identifier of the CIP object.
SrvIP	STRING				IP address of the server (adapter) (e.g., configured in the EtherNet/IP Scanner configuration).
Size	UINT				Number of bytes to write. Cannot exceed 450 bytes.
Snd	BOOL				A rising edge on this input starts the exchange. The DONE output signals the end of exchange.

4.2.3.2 Outputs

Output	Data Type	Range	Unit	Description
Done	BOOL			This output is TRUE during one cycle when the exchange is finished, whether the exchange succeeded or failed. Warning: This output can be TRUE just after the call to block when starting a new exchange in case of invalid parameters.
EmErr	UINT			In case of a UCMM error, this is the CIP general status error code.
EmErrExt	UINT			In case of a UCMM error, this is the CIP extended status error code.
Err	UINT			Main error report. Can be one of these values: 0 = no error. 1 = invalid input arguments. 2 = system is busy (see remarks). 3 = timeout waiting for the answer (the timeout value is 3 seconds). 4 = UCMM error was returned by the server others = internal errors (reserved for technical support).
RcvSize	UINT			Actual size of the CIP attribute answered by the server. If this size is greater than the size of the DATA input array, it indicates the value was truncated.

4.2.3.3 Remarks

- The CIP instance number can be 16-bits [1...65535].
- The servers (adapters) accessed by this block must be configured in the EtherNet/IP Scanner fieldbus configuration.
- Only one explicit message (read or write) can be sent at one time to the same server.
 - If another message is pending you receive the error report 3 (busy) after calling the block to start a new exchange.
- Consider [SerializeIn](#) and [SerializeOut](#) functions for extracting data from the read buffer.

4.2.3.4 FBD Language

Not available.

4.2.3.5 FFLD Language

Not available.

4.2.3.6 IL Language

Not available.

4.2.3.7 ST Language

```
// used variables
// Inst_eipWriteAttr : eipWriteAttr ;
// bWrite : BOOL ; (* request for WRITE *)
// DataWrite : ARRAY [0 .. 15] OF USINT; (* written data *)
// uiSizeWrite : UINT := UINT#16 ; (* number of bytes to read *)
// Server identification and CIP things
#define SRVIP '192.168.33.21'
#define CLASSID UINT#100
#define INSTID_WRITE UINT#2
#define ATTRID UINT#3
////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////
////////////////////////////////////////////////////////////////
// requested WRITE command
if bWrite then
    Inst_eipWriteAttr (bWrite, SRVIP, CLASSID, INSTID_WRITE, ATTRID,
                      uiSizeWrite, DataWrite);
end_if;
// WRITE answer here ?
if Inst_eipWriteAttr.Done then
    // check answer
    if Inst_eipWriteAttr.Err = 0 then
        printf ('WRITE ok');
    else
        printf ('WRITE Error %lu - (UCMM Error %lu, %lu)',
              any_to_dint (Inst_eipWriteAttr.Err),
              any_to_dint (Inst_eipWriteAttr.EmErr),
              any_to_dint (Inst_eipWriteAttr.EmErrExt));
    end_if;
    // reset WRITE command and block input
    Inst_eipWriteAttr (false, SRVIP, CLASSID, INSTID_WRITE, ATTRID,
                      uiSizeWrite, DataWrite);
    bWrite := false;
end_if;
```

See Also

- ["eipAdapter" \(→ p. 566\)](#)
- ["eipReadAttr" \(→ p. 567\)](#)

5 System Library

This section details the Library functions and function blocks that relate to the system. This includes:

- "Controller Functions" (→ p. 572)
- "File Tools Function Blocks" (→ p. 582)
- "TCP/IP Function Blocks" (→ p. 606)
- "UDP Functions for PxMM and Simulator" (→ p. 622)

5.1 Controller Functions


This is the list of Library functions related to the controller.

List of Controller Functions

Name	Description
"GetCtrlErrors" (→ p. 573)	Get a list of the active errors and alarms on the controller.
"ClearCtrlErrors" (→ p. 572)	Clears the list of active errors and alarms on the controller.
"GetCtrlPerf" (→ p. 577)	Generate a text file with performance statistics of the controller.
"GetCtrlInfo" (→ p. 574)	Get the serial, model, and/or part number of the controller.

5.1.1 ClearCtrlErrors



 **Function** - Clears the active errors and alarms on the controller.

5.1.1.1 Inputs

Input	Data Type	Range	Unit	Default	Description
EN					Enable the function.

5.1.1.2 Outputs

Output	Data Type	Range	Unit	Description
Q	BOOL			


5.1.1.3 Remarks

- Only clearable errors will be cleared.
- See [Errors](#) for a list of errors and alarms that may be generated.


NOTE

If clearable and non-clearable errors are present and this function is called, the Output Q is turned to TRUE but the non-clearable errors remain.

5.1.1.3.1 FBD Language



5.1.1.3.2 FFLD Language



5.1.1.3.3 IL Language

Not available.

5.1.1.3.4 ST Language

```
//Attempt to clear active controller level errors and alarms (such as E33)
IF ClearControllerErrors THEN
ClearCtrlErrors();
END_IF;
```

5.1.2 GetCtrlErrors



Function - Returns active errors and alarms on the controller in two arrays of hundred Booleans.

Every index in the array corresponds to the error and alarm numbers in the tables. See [Errors](#) for a list of errors and alarms that may be generated.

5.1.2.1 Arguments

5.1.2.1.1 Input

EN	BOOL	Enable
ActiveError	BOOL[100]	Array of bool with the size equal to 100
ActiveAlarm	BOOL[100]	Array of bool with size equal to 100

5.1.2.1.2 Output

OK	BOOL	
Q	DINT	Status of the execution

Status meaning:

Bit	Value 0	No error, no alarm, no shut down
0		
Bit	Value 1	There is an active error or an active alarm (i.e. there is something in the array ActiveError/ActiveAlarm)
0		


Bit 1	Value 0	No shut down
Bit 1	Value 1	The PLC processes will be shut down. This will start 10 seconds after the error is triggered
Bit 2-15	Value 2 4 9 to 2147483648	reserved

5.1.2.2 Examples


TIP

See [Checking for existing EtherCAT Alarms and Errors](#): in the [EtherCAT Communication Diagnosis Steps](#) section of the Troubleshooting chapter for an example of implementing this function.

5.1.2.2.1 FBD



5.1.2.2.2 FFLD




5.1.2.2.3 ST

```
//Retrieve active controller level alarm and errors.
//Check status output to see if any error or alarm is active and if PLC
is shutting down
ControllerErrorStatus:= GetCtrlErrors( ActiveControllerErrors,
ActiveControllerAlarms);
ActiveError:= ControllerErrorStatus.0;
PLCShutDown:= ControllerErrorStatus.1;
E30Active:= ActiveControllerErrors[30];
```

5.1.3 GetCtrlInfo

PLCopen ✓ Pipe Network ✓

- This function block returns a String containing the value of the control parameter requested.



5.1.3.1 Arguments

5.1.3.1.1 Input

Execute	Description	Rising edge of enable initiates read of parameter
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Parameter Number	Description	Parameter number to read
	Data Type	INT
	Range	[1,6]
	Unit	N/A

Value Description	These parameters are also Internal Defines , as shown in the table below.		
	Value	Integer Representation	Description
	CTRLINFO_SERIAL_NUMBER	1	Controller serial number
	CTRLINFO_MODEL_NUMBER	2	Controller model number
	CTRLINFO_PART_NUMBER	3	Controller part number
	CTRLINFO_CPU_CORE_COUNT	4	Number of CPU cores in the controller
	CTRLINFO_PROJECT_BUILD_NO	5	The project build number of the running application
	CTRLINFO_PROJECT_COMPILE_TIME	6	The project compile time of the running application

5.1.3.1.2 Output

Done	Description	Indication that read completed without error
	Data Type	BOOL
Error	Description	Indication that read completed with error
	Data Type	BOOL
ErrorID	Description	Error value to indicate error condition

Data Type	INT These parameters are also Internal Defines , as shown in the table below.															
	<table border="1"> <thead> <tr> <th>Value</th> <th>Integer Representation</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>CTRLINFO_ERROR_NO_ERROR</td> <td>0</td> <td>No error</td> </tr> <tr> <td>CTRLINFO_ERROR_INV_PARAMETER</td> <td>1</td> <td>Invalid parameter</td> </tr> <tr> <td>CTRLINFO_ERROR_CANT_READ_DATA</td> <td>2</td> <td>Error reading data</td> </tr> <tr> <td>CTRLINFO_ERROR_NOT_PDMM</td> <td>3</td> <td>Not valid on a non-PCMM2G, PCMM, or AKD PDMM controller.</td> </tr> </tbody> </table>	Value	Integer Representation	Description	CTRLINFO_ERROR_NO_ERROR	0	No error	CTRLINFO_ERROR_INV_PARAMETER	1	Invalid parameter	CTRLINFO_ERROR_CANT_READ_DATA	2	Error reading data	CTRLINFO_ERROR_NOT_PDMM	3	Not valid on a non-PCMM2G, PCMM, or AKD PDMM controller.
Value	Integer Representation	Description														
CTRLINFO_ERROR_NO_ERROR	0	No error														
CTRLINFO_ERROR_INV_PARAMETER	1	Invalid parameter														
CTRLINFO_ERROR_CANT_READ_DATA	2	Error reading data														
CTRLINFO_ERROR_NOT_PDMM	3	Not valid on a non-PCMM2G, PCMM, or AKD PDMM controller.														
Value	Description String containing data that was read.															
	Data Type STRING															

5.1.3.2 Examples


5.1.3.2.1 Structured Text

```

Inst_GetCtrlInfo( ExecuteRead, CTRLINFO_SERIAL_NUMBER);

if Inst_GetCtrlInfo.Done then
    serialNumber := Inst_GetCtrlInfo.Value;
end_if;
    
```


5.1.3.2.2 Ladder Diagram



5.1.4 GetCtrlPerf

- PLCopen ✔
- Pipe Network ✔

- This function block returns controller CPU performance statistics.



GetCtrlPerf

See also:

- [Differences Between Functions and Function Blocks](#)
- [Calling a function block](#)

5.1.4.1 Arguments

5.1.4.1.1 Input

Execute	Description	On the rising edge, request to collect the controller's performance data.
	Data type	BOOL
	Range	0,1
	Unit	N/A
	Default	—
DataPointCount	Description	The number of motion manager cycles over which performance statistics will be gathered.
	Data type	UDINT
	Range	2 - 240,000
	Unit	N/A
	Default	—


5.1.4.1.2 Output

Done	Description	If True, then the command completed successfully.
	Data type	BOOL
Error	Description	If True, an error has occurred.
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. ErrorID = 0 indicates no error, ErrorID = 1 indicates an error
	Data type	INT
MissedCycles	Description	Indicates the number of missing VM cycles.
	Data type	UDINT
MeanVmTime	Description	The mean VM execution time measured in microseconds.
	Data type	LREAL
StdDevVmTime	Description	The standard deviation of the VM execution time measured in microseconds.
	Data type	LREAL
MinVmTime	Description	The minimum VM execution time measured in microseconds.
	Data type	LREAL
MaxVmTime	Description	The maximum VM execution time measured in microseconds.
	Data type	LREAL
MeanMotMgrTime	Description	The mean motion manager execution time measured in microseconds.
	Data type	LREAL
StdDevMotMgrTime	Description	The standard deviation of the motion manager execution time measured in microseconds.
	Data type	LREAL
MinMotMgrTime	Description	The minimum motion manager execution time measured in microseconds.
	Data type	LREAL
MaxMotMgrTime	Description	The maximum motion manager execution time measured in microseconds.
	Data type	LREAL


MeanCpuIdlePct	Description	The mean percentage of time the controller CPU is idle. CPU idle period is measured across all CPU cores. ⚡ TIP See Figure 1-7: Motion, PLC and Real Time Margin Time Calculations and Figure 1-8: Multiple Core Controller, PLC and Real Time Margin Time Calculations . to see the idle period in relationship to a PLC application execution cycle.
	Data type	LREAL
StdDevCpuIdlePct	Description	The standard deviation of the measurements of the time that the controller CPU is idle. CPU idle period is measured across all cpu cores. ⚡ TIP See Figure 1-7: Motion, PLC and Real Time Margin Time Calculations and Figure 1-8: Multiple Core Controller, PLC and Real Time Margin Time Calculations . to see the idle period in relationship to a PLC application execution cycle.
	Data type	LREAL
MinCpuIdlePct	Description	The minimum measurement of the time that the controller CPU is idle. CPU idle period is measured across all cpu cores. ⚡ TIP See Figure 1-7: Motion, PLC and Real Time Margin Time Calculations and Figure 1-8: Multiple Core Controller, PLC and Real Time Margin Time Calculations . to see the idle period in relationship to a PLC application execution cycle.
	Data type	LREAL
MaxCpuIdlePct	Description	The maximum measurement of the time that the controller CPU is idle. CPU idle period is measured across all cpu cores. ⚡ TIP See Figure 1-7: Motion, PLC and Real Time Margin Time Calculations and Figure 1-8: Multiple Core Controller, PLC and Real Time Margin Time Calculations . to see the idle period in relationship to a PLC application execution cycle.
	Data type	LREAL

5.1.4.2 Example

5.1.4.2.1 FBD



5.1.4.2.2 FFLD



5.1.4.2.3 Structured Text

```

//Read controller performance data from last 1000 cycles (1 second at
T#1ms update rate)
Inst_GetCtrlPerf( ReadPerformanceData, 1000 );

IF Inst_GetCtrlInfo.Done THEN
MissedCycles:= Inst_GetCtrlPerf.MissedCycles;
MaxVmTimeMs:= Inst_GetCtrlPerf.MaxVmTime;
MaxMotionManagerTime:= Inst_GetCtrlPerf.MaxMotMgrTime;
MeanCPUIdlePercentage:= Inst_GetCtrlPerf.MeanCpuIdlePct;
MaxCPUIdlePercentage:= Inst_GetCtrlPerf.MaxCpuIdlePct;
END_IF;
    
```

5.2 File Tools Function Blocks

This section documents function blocks that can be applied to files.

Function Block	Use
"FileClose" (→ p. 582)	Close an open file.
"FileCopy" (→ p. 583)	Copy a file.
"FileDelete" (→ p. 585)	Remove a file.
"FileEOF" (→ p. 586)	Test if the end of the file is reached in a file that is open for reading.
"FileExists" (→ p. 588)	Test if a file exists.
"FileOpenA" (→ p. 589)	Create or open a file in append mode.
"FileOpenR" (→ p. 591)	Open a file for reading.
"FileOpenW" (→ p. 592)	Create or reset a file and open it for writing.
"FileReadBinData" (→ p. 594)	Read binary data from a file.
"FileReadLine" (→ p. 596)	Read a string value from a text file.
"FileRename" (→ p. 597)	Rename a file.
"FileSeek" (→ p. 599)	Set the current position of a file.
"FileSize" (→ p. 601)	Get the size of a file.
"FileWriteBinData" (→ p. 602)	Write binary data to a file.
"FileWriteLine" (→ p. 604)	Write a string value to a text file.

5.2.1 FileClose PLCopen

5.2.1.1 Description

This function block closes an open file.




Figure 1-113: The FileCopy Function Block

5.2.1.1.1 Related Functions

"FileEOF" (→ p. 586), "FileOpenA" (→ p. 589), "FileOpenR" (→ p. 591), "FileOpenW" (→ p. 592), "FileReadLine" (→ p. 596), "FileReadBinData" (→ p. 594), "FileSeek" (→ p. 599), "FileWriteBinData" (→ p. 602), "FileWriteLine" (→ p. 604)

See also: [File Management](#)

5.2.1.2 Arguments

5.2.1.2.1 Input

Execute	Description	On the rising edge request to perform closing a file.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
ID	Description	ID of the open file.
	Data Type	UDINT
	Range	N/A
	Unit	N/A
	Default	—

5.2.1.2.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT

5.2.1.3 Example

5.2.1.3.1 Structured Text

```
(* FileClose example *)
CASE StepCounter OF
0:
  Inst_FileClose(TRUE, MyOutputFileID);
  StepCounter := StepCounter + 1;
1:
  Inst_FileClose(TRUE, MyOutputFileID);
  IF Inst_FileClose.Done THEN
    Inst_FileClose(FALSE, 0);
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
```

5.2.2 FileCopy

5.2.2.1 Description

This function block copies a file's contents to a new file. Please note that large files will take a noticeable amount of time to complete. For example, a 1000KB file takes approximately 0.6 seconds.




Figure 1-114: The FileCopy Function Block

5.2.2.1.1 Related Functions

"FileDelete" (→ p. 585), "FileRename" (→ p. 597), "FileExists" (→ p. 588), "FileSize" (→ p. 601)

See also: [File Management](#)

5.2.2.2 Arguments

5.2.2.2.1 Input

Execute	Description	On the rising edge request to perform copying a file
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Src	Description	The path to the source file
	Data Type	STRING
	Range	N/A
	Unit	N/A
	Default	—
Dst	Description	The destination path to the new file
	Data Type	STRING
	Range	N/A
	Unit	user units
	Default	—

5.2.2.2.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL

Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT

5.2.2.3 Example

5.2.2.3.1 Structured Text

```
(* FileCopy example *)
CASE StepCounter OF
0:
  Inst_FileCopy(TRUE, 'Source.txt', 'Dest.txt');
  StepCounter := StepCounter + 1;
1:
  Inst_FileCopy(TRUE, 'Source.txt', 'Dest.txt');
  IF Inst_FileCopy.Done THEN
    Inst_FileCopy(FALSE, '', '');
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
```

5.2.3 FileDelete PLCopen

5.2.3.1 Description

This function block removes a file from the file system.




Figure 1-115: The FileDelete Function Block

5.2.3.1.1 Related Functions

["FileCopy"](#) (→ p. 583), ["FileRename"](#) (→ p. 597), ["FileExists"](#) (→ p. 588), ["FileSize"](#) (→ p. 601)

See also: [File Management](#)

5.2.3.2 Arguments

5.2.3.2.1 Input

Execute	Description	On the rising edge request to perform deletion of a file
----------------	--------------------	--

	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Path	Description	The path to the file to be deleted
	Data Type	STRING
	Range	N/A
	Unit	N/A
	Default	—

5.2.3.2.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT

5.2.3.3 Example

5.2.3.3.1 Structured Text

```
(* FileDelete example *)
CASE StepCounter OF
0:
  Inst_FileDelete(TRUE, 'Test.txt');
  StepCounter := StepCounter + 1;
1:
  Inst_FileDelete(TRUE, 'Test.txt');
  IF Inst_FileDelete.Done THEN
    Inst_FileDelete(FALSE, '');
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
```

5.2.4 FileEOF

5.2.4.1 Description

This function block tests if the end of a file has been encountered.




Figure 1-116: The FileCopy Function Block

5.2.4.1.1 Related Functions

"FileClose" (→ p. 582), "FileOpenA" (→ p. 589), "FileOpenR" (→ p. 591), "FileOpenW" (→ p. 592), "FileReadLine" (→ p. 596), "FileReadBinData" (→ p. 594), "FileSeek" (→ p. 599), "FileWriteBinData" (→ p. 602), "FileWriteLine" (→ p. 604)

See also: [File Management](#)

5.2.4.2 Arguments

5.2.4.2.1 Input

Execute	Description	On the rising edge test if the end of the file is reached in a file that is open for reading.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
ID	Description	ID of the open file.
	Data Type	UDINT
	Range	N/A
	Unit	N/A
	Default	—

5.2.4.2.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in " File and TCP/IP Function Block ErrorID Output " (→ p. 640)
	Data Type	DINT
EOF	Description	TRUE if the end of the file has been encountered.
	Data Type	BOOL

5.2.4.3 Example

5.2.4.3.1 Structured Text

```

(* FileEOF example *)
CASE StepCounter OF
0:
  Inst_FileEOF(TRUE, MyInputFileID);
  StepCounter := StepCounter + 1;
1:
  Inst_FileEOF(TRUE, MyInputFileID);
  IF Inst_FileEOF.Done THEN
    EofReached := Inst_FileEOF.EOF;
    Inst_FileEOF(FALSE, 0);
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
    
```

5.2.5 FileExists PLCopen

5.2.5.1 Description

This function block tests if a file exists.




Figure 1-117: The FileExists Function Block

5.2.5.1.1 Related Functions

"FileCopy" (→ p. 583), "FileDelete" (→ p. 585), "FileRename" (→ p. 597), "FileSize" (→ p. 601)

See also: [File Management](#)

5.2.5.2 Arguments

5.2.5.2.1 Input

Execute	Description	On the rising edge test to see if a file exists
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—

Path	Description	The path to the file
	Data Type	STRING
	Range	N/A
	Unit	N/A
	Default	—

5.2.5.2.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT
Exists	Description	The existence of the file. True: this value indicates the file exists False: this value indicates the file does not exist.
	Data Type	BOOL

5.2.5.3 Example

5.2.5.3.1 Structured Text

```
(* FileExists example *)
CASE StepCounter OF
0:
  Inst_FileExists(TRUE, 'Test.txt');
  StepCounter := StepCounter + 1;
1:
  Inst_FileExists(TRUE, 'Test.txt');
  IF Inst_FileExists.Done THEN
    TestFileExists := Inst_FileExists.Exists;
    Inst_FileExists(FALSE, '');
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
```

5.2.6 FileOpenA

5.2.6.1 Description

This function block opens a file in "append" mode.

Files must be closed using the ["FileClose"](#) (→ p. 582) function block.

NOTE

The controller allows only 32 open files at any given time.




Figure 1-118: The FileOpenA function block

5.2.6.1.1 Related Functions

"FileClose" (→ p. 582), "FileEOF" (→ p. 586), "FileOpenR" (→ p. 591), "FileOpenW" (→ p. 592), "FileReadLine" (→ p. 596), "FileReadBinData" (→ p. 594), "FileSeek" (→ p. 599), "FileWriteBinData" (→ p. 602), "FileWriteLine" (→ p. 604)

5.2.6.2 Arguments

5.2.6.2.1 Input

Execute	Description	On the rising edge request to open a file
	Data Type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Path	Description	The path of the file to open or create.
	Data Type	STRING
	Range	n/a
	Unit	n/a
	Default	—

5.2.6.2.2 Output

Done	Description	If TRUE, then the command completed successfully.
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred.
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT
ID	Description	ID of the open file.
	Data Type	UDINT

5.2.6.3 Example

5.2.6.3.1 Structured Text

```
(* FileOpenW example *)
(* Replace FileOpenW with FileOpenA or FileOpenR as needed*)
CASE StepCounter OF
0:
  Inst_FileOpenW(TRUE, 'Results.txt');
  StepCounter := StepCounter + 1;
1:
  Inst_FileOpenW(TRUE, 'Results.txt');
  IF Inst_FileOpenW.Done THEN
    ResultsFileID := Inst_FileOpenW.ID;
    Inst_FileOpenW(FALSE, '');
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
```

5.2.7 FileOpenR PLCopen

5.2.7.1 Description

This function block opens a file for reading.

Files must be closed using the "FileClose" (→ p. 582) function block.

NOTE

The controller allows only 32 open files at any given time.




Figure 1-119: The FileOpenR function block

5.2.7.1.1 Related Functions

"FileClose" (→ p. 582), "FileEOF" (→ p. 586), "FileOpenA" (→ p. 589), "FileOpenW" (→ p. 592), "FileReadLine" (→ p. 596), "FileReadBinData" (→ p. 594), "FileSeek" (→ p. 599), "FileWriteBinData" (→ p. 602), "FileWriteLine" (→ p. 604)

5.2.7.2 Arguments

5.2.7.2.1 Input

Execute	Description	On the rising edge request to open a file
	Data Type	BOOL
	Range	0, 1
	Unit	n/a

	Default	—
Path	Description	The path of the file to open or create.
	Data Type	STRING
	Range	n/a
	Unit	n/a
	Default	—

5.2.7.2.2 Output

Done	Description	If TRUE, then the command completed successfully.
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred.
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT
ID	Description	ID of the open file.
	Data Type	UDINT

5.2.7.3 Example

5.2.7.3.1 Structured Text

```
(* FileOpenW example *)
(* Replace FileOpenW with FileOpenA or FileOpenR as needed*)
CASE StepCounter OF
0:
  Inst_FileOpenW(TRUE, 'Results.txt');
  StepCounter := StepCounter + 1;
1:
  Inst_FileOpenW(TRUE, 'Results.txt');
  IF Inst_FileOpenW.Done THEN
    ResultsFileID := Inst_FileOpenW.ID;
    Inst_FileOpenW(FALSE, '');
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
```

5.2.8 FileOpenW PLCopen

5.2.8.1 Description

This function block opens a file for writing. If a file already exists, it will be overwritten.

Files must be closed using the "FileClose" (→ p. 582) function block.

NOTE

The controller allows only 32 open files at any given time.




Figure 1-120: The FileOpenW function block

5.2.8.1.1 Related Functions

"FileClose" (→ p. 582), "FileEOF" (→ p. 586), "FileOpenA" (→ p. 589), "FileOpenR" (→ p. 591), "FileReadLine" (→ p. 596), "FileReadBinData" (→ p. 594), "FileSeek" (→ p. 599), "FileWriteBinData" (→ p. 602), "FileWriteLine" (→ p. 604)

5.2.8.2 Arguments

5.2.8.2.1 Input

Execute	Description	On the rising edge request to open a file
	Data Type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Path	Description	The path of the file to open or create.
	Data Type	STRING
	Range	n/a
	Unit	n/a
	Default	—

5.2.8.2.2 Output

Done	Description	If TRUE, then the command completed successfully.
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred.
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT
ID	Description	ID of the open file.
	Data Type	UDINT

5.2.8.3 Example

5.2.8.3.1 Structured Text

```

(* FileOpenW example *)
(* Replace FileOpenW with FileOpenA or FileOpenR as needed*)
CASE StepCounter OF
0:
  Inst_FileOpenW(TRUE, 'Results.txt');
  StepCounter := StepCounter + 1;
1:
  Inst_FileOpenW(TRUE, 'Results.txt');
  IF Inst_FileOpenW.Done THEN
    ResultsFileID := Inst_FileOpenW.ID;
    Inst_FileOpenW(FALSE, '');
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
    
```

5.2.9 FileReadBinData PLCopen

5.2.9.1 Description

This function block reads binary data from a file. FileReadBinData stops reading from the file if it fills the passed **Frame** array, reads **FrameSize** bytes, or encounters the end of file, whichever comes first.

After a successful call to FileReadBinData, one may use [SerializeIn](#) to extract variable data from the binary data read from a file.




Figure 1-121: The FileReadBinData Function Block

5.2.9.1.1 Related Functions

"FileClose" (→ p. 582), "FileEOF" (→ p. 586), "FileOpenA" (→ p. 589), "FileOpenR" (→ p. 591), "FileOpenW" (→ p. 592), "FileReadLine" (→ p. 596), "FileSeek" (→ p. 599), "FileWriteBinData" (→ p. 602), "FileWriteLine" (→ p. 604), [SerializeIn](#)

See also: [File Management](#)

5.2.9.2 Arguments

5.2.9.2.1 Input

Execute	Description	On the rising edge read the size of a file.
	Data Type	BOOL
	Range	0, 1

	Unit	N/A
	Default	—
ID	Description	ID of the open file.
	Data Type	UDINT
	Range	N/A
	Unit	N/A
	Default	—
Frame	Description	Where the binary data will be stored
	Data Type	USINT[]
	Range	N/A
	Unit	N/A
	Default	—
FrameSize	Description	Number of bytes to store in the <i>Frame</i> array.
	Data Type	DINT
	Range	N/A
	Unit	N/A
	Default	—

5.2.9.2.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT
NbRead	Description	The number of bytes read from the file.
	Data Type	STRING

5.2.9.3 Example

5.2.9.3.1 Structured Text

```
(* FileReadBinData example *)
CASE StepCounter OF
0:
  Inst_FileReadBinData(TRUE, MyInputFileID, InputFrame, 128);
```

```

StepCounter := StepCounter + 1;
1:
Inst_FileReadBinData(TRUE, MyInputFileID, InputFrame, 128);
IF Inst_FileReadBinData.Done THEN
  BytesRead := Inst_FileReadBinData.NbRead;
  Inst_FileReadBinData(FALSE, 0, InputFrame, 0);
  StepCounter := StepCounter + 1;
END_IF;
END_CASE;

```

5.2.10 FileReadLine PLCopen

5.2.10.1 Description

This function block reads a string value from a file. FileReadLine stops reading from the file if 255 characters are read (the maximum length of the STRING type) or if a new line is encountered.




Figure 1-122: The FileReadLine Function Block

5.2.10.1.1 Related Functions

"FileClose" (→ p. 582), "FileEOF" (→ p. 586), "FileOpenA" (→ p. 589), "FileOpenR" (→ p. 591), "FileOpenW" (→ p. 592), "FileReadBinData" (→ p. 594), "FileSeek" (→ p. 599), "FileWriteBinData" (→ p. 602), "FileWriteLine" (→ p. 604)

See also: [File Management](#)

5.2.10.2 Arguments

5.2.10.2.1 Input

Execute	Description	On the rising edge read the size of a file.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
ID	Description	ID of the open file.
	Data Type	UDINT
	Range	N/A
	Unit	N/A
	Default	—

5.2.10.2.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT
Value	Description	The string value read from the file.
	Data Type	STRING

5.2.10.3 Example

5.2.10.3.1 Structured Text

```
(* FileReadLine example *)
CASE StepCounter OF
0:
  Inst_FileReadLine(TRUE, MyInputFileID);
  StepCounter := StepCounter + 1;
1:
  Inst_FileReadLine(TRUE, MyInputFileID);
  IF Inst_FileReadLine.Done THEN
    lineText := Inst_FileReadLine.Value;
    Inst_FileReadLine(FALSE, 0);
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
```

5.2.11 FileRename PLCopen

5.2.11.1 Description

This function block renames a file.




Figure 1-123: The FileRename Function Block

5.2.11.1.1 Related Functions

["FileCopy"](#) (→ p. 583), ["FileDelete"](#) (→ p. 585), ["FileExists"](#) (→ p. 588), ["FileSize"](#) (→ p. 601)

See also: [File Management](#)

5.2.11.2 Arguments

5.2.11.2.1 Input

Execute	Description	On the rising edge request to rename a file
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Path	Description	The path to the file to be renamed
	Data Type	STRING
	Range	N/A
	Unit	N/A
	Default	—
NewName	Description	The new name of the file
	Data Type	STRING
	Range	N/A
	Unit	user units
	Default	—

5.2.11.2.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT

5.2.11.3 Example

5.2.11.3.1 Structured Text

```
(* FileRename example *)
CASE StepCounter OF
0:
  Inst_FileRename(TRUE, 'Original.txt', 'Renamed.txt');
```

```

StepCounter := StepCounter + 1;
1:
Inst_FileRename(TRUE, 'Original.txt', 'Renamed.txt');
IF Inst_FileRename.Done THEN
  Inst_FileRename(FALSE, '', '');
  StepCounter := StepCounter + 1;
END_IF;
END_CASE;

```

5.2.12 FileSeek PLCopen

5.2.12.1 Description

This function block sets the current position in an open file.




Figure 1-124: The FileCopy Function Block

5.2.12.1.1 Related Functions

"FileClose" (→ p. 582), "FileEOF" (→ p. 586), "FileOpenA" (→ p. 589), "FileOpenR" (→ p. 591), "FileOpenW" (→ p. 592), "FileReadLine" (→ p. 596), "FileReadBinData" (→ p. 594), "FileWriteBinData" (→ p. 602), "FileWriteLine" (→ p. 604)

See also: [File Management](#)

5.2.12.2 Arguments

5.2.12.2.1 Input

Execute	Description	On the rising edge test if the end of the file is reached in a file that is open for reading.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
ID	Description	ID of the open file.
	Data Type	UDINT
	Range	N/A
	Unit	N/A
	Default	—

POS	Description	Number of bytes to offset from ORG. <ul style="list-style-type: none"> • If ORG = SEEK_SET, then POS should be ≥ 0 • If ORG = SEEK_END, then POS should be ≤ 0 • If ORG = SEEK_CUR, then POS can be positive or negative
	Data Type	DINT
	Range	N/A
	Unit	N/A
	Default	—
ORG	Description	Origin of the move. <ul style="list-style-type: none"> • SEEK_SET = beginning of the file • SEEK_CUR = current position • SEEK_END = end of the file
	Data Type	DINT
	Range	SEEK_SET, SEEK_CUR, SEEK_END
	Unit	N/A
	Default	—

5.2.12.2.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in " File and TCP/IP Function Block ErrorID Output " (→ p. 640)
	Data Type	DINT

5.2.12.3 Example

5.2.12.3.1 Structured Text

```
(* FileSeek example *)
CASE StepCounter OF
0:
  (* Move to beginning of the file *)
  Inst_FileSeek(TRUE, MyInputFileID, 0, SEEK_SET);
  StepCounter := StepCounter + 1;
1:
  Inst_FileSeek(TRUE, MyInputFileID, 0, SEEK_SET);
  IF Inst_FileSeek.Done THEN
    Inst_FileSeek(FALSE, 0, 0, SEEK_SET);
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
```


5.2.13 FileSize PLCopen

5.2.13.1 Description

This function block renames a file.




Figure 1-125: The FileSize Function Block

5.2.13.1.1 Related Functions

"FileCopy" (→ p. 583), "FileDelete" (→ p. 585), "FileRename" (→ p. 597), "FileExists" (→ p. 588)

See also: [File Management](#)

5.2.13.2 Arguments

5.2.13.2.1 Input

Execute	Description	On the rising edge read the size of a file
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Path	Description	The path to the file
	Data Type	STRING
	Range	N/A
	Unit	N/A
	Default	—

5.2.13.2.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL

ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT
Size	Description	The size of the file in bytes
	Data Type	DINT

5.2.13.3 Example

5.2.13.3.1 Structured Text

```
(* FileSize example *)
CASE StepCounter OF
0:
  Inst_FileSize(TRUE, 'Test.txt');
  StepCounter := StepCounter + 1;
1:
  Inst_FileSize(TRUE, 'Test.txt');
  IF Inst_FileSize.Done THEN
    TestFileSize := Inst_FileSize.Size;
    Inst_FileSize(FALSE, '');
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
```

5.2.14 FileWriteBinData PLCopen

5.2.14.1 Description

This function block writes binary data to a file. Before using FileWriteBinData, you may use [SerializeOut](#) to copy variable data to a binary frame.




Figure 1-126: The FileWriteLine Function Block

5.2.14.1.1 Related Functions

"FileClose" (→ p. 582), "FileEOF" (→ p. 586), "FileOpenA" (→ p. 589), "FileOpenR" (→ p. 591), "FileOpenW" (→ p. 592), "FileReadBinData" (→ p. 594), "FileReadLine" (→ p. 596), "FileSeek" (→ p. 599), "FileWriteLine" (→ p. 604)

See also: [File Management](#)

5.2.14.2 Arguments

5.2.14.2.1 Input

Execute	Description	On the rising edge write binary data to a file.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
ID	Description	ID of the open file.
	Data Type	UDINT
	Range	N/A
	Unit	N/A
	Default	—
Frame	Description	The array of binary data to write
	Data Type	USINT[]
	Range	N/A
	Unit	N/A
	Default	—
FrameSize	Description	Number of bytes to write from the <i>Frame</i> array.
	Data Type	DINT
	Range	N/A
	Unit	N/A
	Default	—

5.2.14.2.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in " File and TCP/IP Function Block ErrorID Output " (→ p. 640)
	Data Type	DINT

5.2.14.3 Example

5.2.14.3.1 Structured Text

```
(* FileWriteBinData example *)
CASE StepCounter OF
```

```

0:
  Inst_FileWriteBinData(TRUE, MyOutputFileID, OutputFrame, 128);
  StepCounter := StepCounter + 1;
1:
  Inst_FileWriteBinData(TRUE, MyOutputFileID, OutputFrame, 128);
  IF Inst_FileWriteBinData.Done THEN
    Inst_FileWriteBinData(FALSE, 0, OutputFrame, 0);
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;

```

5.2.15 FileWriteLine PLCopen

5.2.15.1 Description

This function block writes a string value to a file. An end-of-line character is systematically written after the string value.




Figure 1-127: The FileWriteLine Function Block

5.2.15.1.1 String Escape Sequences

For greater formatting control over your STRING output, you may escape the STRING by prepending a \$ and use a pre-defined sequence. This is called a string escape sequence.

Escape Sequence	Result
\$\$	\$
\$'	'
\$L	linefeed
\$N	newline
\$P	page (form feed)
\$R	return
\$T	tab
\$xx	hex value

The following is an example of how STRING escape sequences can be used.

```

ID:=FileOpenW('c:\ myfile.txt');
WOK:=FileWriteLine(ID, '123456$N');
//WOK:=FileWriteLine(ID, '$N');
WOK:=FileWriteLine(ID, 'abcd$N');
WOK:=FileWriteLine(ID, 'the end');
WOK:=FileClose(ID);

```

The example outputs a file which reads:

```

123456
abcd
the end

```

5.2.15.1.2 Related Functions

"FileClose" (→ p. 582), "FileEOF" (→ p. 586), "FileOpenA" (→ p. 589), "FileOpenR" (→ p. 591), "FileOpenW" (→ p. 592), "FileReadBinData" (→ p. 594), "FileReadLine" (→ p. 596), "FileSeek" (→ p. 599), "FileWriteBinData" (→ p. 602)

See also: [File Management](#)

5.2.15.2 Arguments

5.2.15.2.1 Input

Execute	Description	On the rising edge write a string value to a file.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
ID	Description	ID of the open file.
	Data Type	UDINT
	Range	N/A
	Unit	N/A
	Default	—
IN	Description	The string value to be written.
	Data Type	STRING
	Range	N/A
	Unit	N/A
	Default	—

5.2.15.2.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in " File and TCP/IP Function Block ErrorID Output " (→ p. 640)
	Data Type	DINT

5.2.15.3 Example

5.2.15.3.1 Structured Text

```
(* FileWriteLine example *)
CASE StepCounter OF
0:
  Inst_FileWriteLine(TRUE, MyOutputFileID, 'Hello, world.');
```

```
  StepCounter := StepCounter + 1;
```

```
1:
  Inst_FileWriteLine(TRUE, MyOutputFileID, 'Hello, world.');
```

```
  IF Inst_FileWriteLine.Done THEN
```

```
    Inst_FileWriteLine(FALSE, 0, '');
```

```
    StepCounter := StepCounter + 1;
```

```
  END_IF;
```

```
END_CASE;
```

5.3 TCP/IP Function Blocks

This section documents function blocks that are used to communicate via TCP/IP.

Function Block	Description
"TcpAccept" (→ p. 606)	Performs the <i>accept</i> operation.
"TcpBinReceive" (→ p. 608)	Receives characters over a socket connection.
"TcpBinSend" (→ p. 610)	Sends characters over a socket.
"TcpClose" (→ p. 612)	Closes and releases a socket.
"TcpConnect" (→ p. 613)	Creates a new socket and performs the <i>connect</i> operation.
"TcplsConnected" (→ p. 615)	Tests if a client socket is connected.
"TcplsValid" (→ p. 617)	Tests if a socket is valid.
"TcpListen" (→ p. 618)	Creates a new socket by performing the <i>bind</i> and <i>listen</i> operations.
TcpReceive	Receives characters over a socket connection.
"TcpSend" (→ p. 620)	Sends characters over a socket.

5.3.1 TcpAccept



- This function block performs the **accept** operation using default TCP settings. You will have to use the "TcpClose" (→ p. 612) function block to release the socket returned by TcpAccept.

TIP

It is possible that the socket becomes invalid if an error occurs in the TCP connection after this function block is called. You must use the "TcpIsValid" (→ p. 617) function block after "TcpSend" (→ p. 620). If the socket is no longer valid then you must close it by using the "TcpClose" (→ p. 612) function block.




Figure 1-128: The TcpAccept function block

5.3.1.0.1 Related Functions

"TcpBinReceive" (→ p. 608), "TcpBinSend" (→ p. 610), "TcpClose" (→ p. 612), "TcpConnect" (→ p. 613), "TcpIsConnected" (→ p. 615), "TcpIsValid" (→ p. 617), "TcpListen" (→ p. 618), TcpReceive, "TcpSend" (→ p. 620)

5.3.1.1 Arguments

5.3.1.1.1 Input

Execute	Description	On the rising edge accept a new socket connection
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
ListenID	Description	The ID of a server socket returned by the TcpListen function block
	Data Type	UDINT
	Range	N/A
	Unit	N/A
	Default	—

5.3.1.1.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT

ID	Description	ID of a new client socket accepted, or invalid ID if no new connection.
	Data Type	UDINT

5.3.1.2 Example

5.3.1.2.1 Structured Text

```

(* TcpAccept example *)
CASE StepCounter OF
0:
  Inst_TcpAccept(TRUE, MyListenID);
  StepCounter := StepCounter + 1;
1:
  Inst_TcpAccept(TRUE, MyListenID);
  IF Inst_TcpAccept.Done THEN
    MySocketID := Inst_TcpAccept.ID;
    Inst_TcpAccept(FALSE, 0);
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;

```

5.3.2 TcpBinReceive



- This function block receives characters over a socket connection. It is possible that the number of characters actually received is less than the number expected. In that case, you will have to call this function again on the next cycle to receive the pending characters.

TIP

It is possible that the socket becomes invalid if an error occurs in the TCP connection after this function block is called. You must use the "TcpIsValid" (→ p. 617) function block after "TcpSend" (→ p. 620). If the socket is no longer valid then you must close it by using the "TcpClose" (→ p. 612) function block.




Figure 1-129: The TcpBinReceive function block

5.3.2.0.1 Related Functions

"TcpAccept" (→ p. 606), "TcpBinSend" (→ p. 610), "TcpClose" (→ p. 612), "TcpConnect" (→ p. 613), "TcpIsConnected" (→ p. 615), "TcpIsValid" (→ p. 617), "TcpListen" (→ p. 618), TcpReceive, "TcpSend" (→ p. 620)

5.3.2.1 Arguments

5.3.2.1.1 Input

Execute	Description	On the rising edge request to perform copying a file
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
ID	Description	The ID of the client socket
	Data Type	UDINT
	Range	N/A
	Unit	N/A
	Default	—
Data	Description	The array where the received data will be stored.
	Data Type	USINT[]
	Range	N/A
	Unit	N/A
	Default	—
MaxChar	Description	The maximum number of bytes to receive
	Data Type	DINT
	Range	N/A
	Unit	N/A
	Default	—

5.3.2.1.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT
NbRcv	Description	The number of characters actually received
	Data Type	DINT

5.3.2.2 Example

5.3.2.2.1 Structured Text

```
(* TcpBinReceive example *)
CASE StepCounter OF
0:
  Inst_TcpBinReceive(TRUE, MySocketID, MydataArray, 256);
  StepCounter := StepCounter + 1;
1:
  Inst_TcpBinReceive(TRUE, MySocketID, MydataArray, 256);
  IF Inst_TcpBinReceive.Done THEN
    BytesReceived := Inst_TcpBinReceive.NbRcv;
    Inst_TcpBinReceive(FALSE, 0, MydataArray, 0);
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
```

5.3.3 TcpBinSend

PLCopen 

- This function block sends characters over a socket. It is possible that the number of characters actually sent is less than the number expected. In that case, you will need to use TcpBinSend again to send the pending characters.

TIP

It is possible that the socket becomes invalid if an error occurs in the TCP connection after this function block is called. You must use the "TcpIsValid" (→ p. 617) function block after "TcpSend" (→ p. 620). If the socket is no longer valid then you must close it by using the "TcpClose" (→ p. 612) function block.




Figure 1-130: The TcpBinSendf function block

5.3.3.0.1 Related Functions

"TcpAccept" (→ p. 606), "TcpBinReceive" (→ p. 608), "TcpClose" (→ p. 612), "TcpConnect" (→ p. 613), "TcpIsConnected" (→ p. 615), "TcpIsValid" (→ p. 617), "TcpListen" (→ p. 618), "TcpReceive", "TcpSend" (→ p. 620)

5.3.3.1 Arguments

5.3.3.1.1 Input

Execute	Description	On the rising edge send a string over a socket connection.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
ID	Description	The ID of the client socket
	Data Type	UDINT
	Range	N/A
	Unit	N/A
	Default	—
Data	Description	The data array to send
	Data Type	USINT[]
	Range	N/A
	Unit	N/A
	Default	—
DataSize	Description	Number of bytes in the Data array to send.
	Data Type	DINT
	Range	N/A
	Unit	N/A
	Default	—

5.3.3.1.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT
NbSent	Description	The number of characters actually sent.
	Data Type	DINT

5.3.3.2 Example

5.3.3.2.1 Structured Text

```

(* TcpBinSend example *)
CASE StepCounter OF
0:
  Inst_TcpBinSend(TRUE, MySocketID, MydataArray, 256);
  StepCounter := StepCounter + 1;
1:
  Inst_TcpBinSend(TRUE, MySocketID, MydataArray, 256);
  IF Inst_TcpBinSend.Done THEN
    BytesSent := Inst_TcpBinSend.NbSent;
    Inst_TcpBinSend(FALSE, 0, MydataArray, 0);
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;

```

5.3.4 TcpClose



- This function block closes and releases a socket. You are responsible for closing any socket created by the "TcpListen" (→ p. 618), "TcpAccept" (→ p. 606), or "TcpConnect" (→ p. 613) function blocks, even if they have become invalid.




Figure 1-131: The TcpClose function block

5.3.4.0.1 Related Functions

"TcpAccept" (→ p. 606), "TcpBinReceive" (→ p. 608), "TcpBinSend" (→ p. 610), "TcpConnect" (→ p. 613), "TcpIsConnected" (→ p. 615), "TcpIsValid" (→ p. 617), "TcpListen" (→ p. 618), TcpReceive, "TcpSend" (→ p. 620)

5.3.4.1 Arguments

5.3.4.1.1 Input

Execute	Description	On the rising edge close a socket.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
ID	Description	The ID of the client socket

Data Type	UDINT
Range	N/A
Unit	N/A
Default	—

5.3.4.1.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in " File and TCP/IP Function Block ErrorID Output " (→ p. 640)
	Data Type	DINT

5.3.4.2 Example

5.3.4.2.1 Structured Text

```
(* TcpClose example *)
CASE StepCounter OF
0:
  Inst_TcpClose(TRUE, MySocketID);
  StepCounter := StepCounter + 1;
1:
  Inst_TcpClose(TRUE, MySocketID);
  IF Inst_TcpClose.Done THEN
    Inst_TcpClose(FALSE, 0);
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
```

5.3.5 TcpConnect



- This function block creates a new socket and performs the **connect** operation using default TCP settings, and a specified server address and port. You will have use the "[TcpClose](#)" ([→ p. 612](#)) function block to release the socket returned by TcpConnect.

TIP

It is possible that the function returns a valid socket ID even if the connection to the server is not yet actually performed. After calling this function, you must use the "[TcpIsConnected](#)" ([→ p. 615](#)) function block to know if the connection is ready.




Figure 1-132: The TcpConnect function block

5.3.5.0.1 Related Functions

"TcpAccept" (→ p. 606), "TcpBinReceive" (→ p. 608), "TcpBinSend" (→ p. 610), "TcpClose" (→ p. 612), "TcpIsConnected" (→ p. 615), "TcpIsValid" (→ p. 617), "TcpListen" (→ p. 618), TcpReceive, "TcpSend" (→ p. 620)

5.3.5.1 Arguments

5.3.5.1.1 Input

Execute	Description	On the rising edge request to connect a socket to a server.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Address	Description	The IP Address of the remote server.
	Data Type	STRING
	Range	N/A
	Unit	N/A
	Default	—
Port	Description	The network port to use.
	Data Type	DINT
	Range	N/A
	Unit	user units
	Default	—

5.3.5.1.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL

Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT
ID	Description	ID of the new client socket
	Data Type	UDINT

5.3.5.2 Example

5.3.5.2.1 Structured Text

```
(* TcpConnect example *)
CASE StepCounter OF
0:
  Inst_TcpConnect(TRUE, '192.168.1.1', 1234);
  StepCounter := StepCounter + 1;
1:
  Inst_TcpConnect(TRUE, '192.168.1.1', 1234);
  IF Inst_TcpConnect.Done THEN
    MySocketID := Inst_TcpConnect.ID;
    Inst_TcpConnect(FALSE, '', 0);
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
```

5.3.6 TcplsConnected



- This function block tests if a client socket is connected.

TIP

It is possible that the socket becomes invalid if an error occurs in the TCP connection after this function block is called. You must use the ["TcpIsValid"](#) (→ p. 617) function block after ["TcpSend"](#) (→ p. 620). If the socket is no longer valid then you must close it by using the ["TcpClose"](#) (→ p. 612) function block.




Figure 1-133: The TcpIsConnected function block

5.3.6.0.1 Related Functions

"TcpAccept" (→ p. 606), "TcpBinReceive" (→ p. 608), "TcpBinSend" (→ p. 610), "TcpClose" (→ p. 612), "TcpConnect" (→ p. 613), "TcpIsConnected" (→ p. 615), "TcpIsValid" (→ p. 617), "TcpListen" (→ p. 618), TcpReceive, "TcpSend" (→ p. 620)

5.3.6.1 Arguments

5.3.6.1.1 Input

Execute	Description	On the rising edge test whether a socket is connected.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
ID	Description	ID of the client socket
	Data Type	UDINT
	Range	N/A
	Unit	N/A
	Default	—

5.3.6.1.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT
Connected	Description	TRUE if connection is correctly established.
	Data Type	BOOL

5.3.6.2 Example

5.3.6.2.1 Structured Text

```
(* TcpIsConnected example *)
CASE StepCounter OF
0:
  Inst_TcpIsConnected(TRUE, MySocketID);
  StepCounter := StepCounter + 1;
1:
```



```

Inst_TcpIsConnected(TRUE, MySocketID);
IF Inst_TcpIsConnected.Done THEN
  MyTcpIsConnected := Inst_TcpIsConnected.Connected;
  Inst_TcpIsConnected(FALSE, 0);
  StepCounter := StepCounter + 1;
END_IF;
END_CASE;

```

5.3.7 TcplsValid

PLCopen 

- This function block tests if a socket is valid.




Figure 1-134: The TcpIsValid function block

5.3.7.0.1 Related Functions

"TcpAccept" (→ p. 606), "TcpBinReceive" (→ p. 608), "TcpBinSend" (→ p. 610), "TcpClose" (→ p. 612), "TcpConnect" (→ p. 613), "TcpIsConnected" (→ p. 615), "TcpListen" (→ p. 618), TcpReceive, "TcpSend" (→ p. 620)

5.3.7.1 Arguments

5.3.7.1.1 Input

Execute	Description	On the rising edge request to perform copying a file
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
ID	Description	The ID of the client socket.
	Data Type	UDINT
	Range	N/A
	Unit	N/A
	Default	—

5.3.7.1.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT
Valid	Description	TRUE if the specified socket is still valid.
	Data Type	BOOL

5.3.7.2 Example

5.3.7.2.1 Structured Text

```
(* TcpIsValid example *)
CASE StepCounter OF
0:
  Inst_TcpIsValid(TRUE, MySocketID);
  StepCounter := StepCounter + 1;
1:
  Inst_TcpIsValid(TRUE, MySocketID);
  IF Inst_TcpIsValid.Done THEN
    MyTcpIsValid := Inst_TcpIsValid.Valid;
    Inst_TcpIsValid(FALSE, 0);
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
```

5.3.8 TcpListen



- This function block creates a new socket by performing the **bind** and **listen** operations using default TCP settings. You will have to use the "TcpClose" (→ p. 612) function block to release the socket returned by TcpListen.




Figure 1-135: The TcpListen function block

5.3.8.0.1 Related Functions

"TcpAccept" (→ p. 606), "TcpBinReceive" (→ p. 608), "TcpBinSend" (→ p. 610), "TcpClose" (→ p. 612), "TcpConnect" (→ p. 613), "TcpIsConnected" (→ p. 615), "TcpIsValid" (→ p. 617), TcpReceive, "TcpSend" (→ p. 620)

5.3.8.1 Arguments

5.3.8.1.1 Input

Execute	Description	On the rising edge listen for socket connections
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
Port	Description	The network port to use
	Data Type	DINT
	Range	N/A
	Unit	N/A
	Default	—
Backlog	Description	The size of the queue for pending connections. If more than Backlog number of connection attempts are made prior to a "TcpAccept" (→ p. 606) call, then the controller may refuse the connections.
	Data Type	DINT
	Range	N/A
	Unit	N/A
	Default	—

5.3.8.1.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT
ListenID	Description	The ID of the new listen socket
	Data Type	UDINT

5.3.8.2 Example

5.3.8.2.1 Structured Text

```
(* TcpListen example *)
CASE StepCounter OF
0:
  Inst_TcpListen(TRUE, 1234, 2);
  StepCounter := StepCounter + 1;
1:
  Inst_TcpListen(TRUE, 1234, 2);
  IF Inst_TcpListen.Done THEN
    MyListenID := Inst_TcpListen.ListenID;
    Inst_TcpListen(FALSE, 0, 0);
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
```

5.3.9 TcpSend

PLCopen ✓

- This function block sends characters over a socket. It is possible that the number of characters actually sent is less than the number expected. In that case, you will need to use `TcpSend` again to send the pending characters.

✎ TIP

It is possible that the socket becomes invalid if an error occurs in the TCP connection after this function block is called. You must use the `"TcpIsValid"` (→ p. 617) function block after `"TcpSend"` (→ p. 620). If the socket is no longer valid then you must close it by using the `"TcpClose"` (→ p. 612) function block.




Figure 1-136: The `TcpSend` function block

5.3.9.0.1 Related Functions

`"TcpAccept"` (→ p. 606), `"TcpBinReceive"` (→ p. 608), `"TcpBinSend"` (→ p. 610), `"TcpClose"` (→ p. 612), `"TcpConnect"` (→ p. 613), `"TcpIsConnected"` (→ p. 615), `"TcpIsValid"` (→ p. 617), `"TcpListen"` (→ p. 618), `TcpReceive`

5.3.9.1 Arguments

5.3.9.1.1 Input

Execute	Description	On the rising edge send a string over a socket connection.
	Data Type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
ID	Description	The ID of the client socket.
	Data Type	UDINT
	Range	N/A
	Unit	N/A
	Default	—
NbChar	Description	The number of characters to send.
	Data Type	DINT
	Range	N/A
	Unit	N/A
	Default	—
Data	Description	The IP Address of the remote server.
	Data Type	STRING
	Range	N/A
	Unit	N/A
	Default	—

5.3.9.1.2 Output

Done	Description	If TRUE, then the command completed successfully
	Data Type	BOOL
Error	Description	If TRUE, an error has occurred
	Data Type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE. See the table in "File and TCP/IP Function Block ErrorID Output" (→ p. 640)
	Data Type	DINT
NbSent	Description	The number of characters actually sent.
	Data Type	DINT

5.3.9.2 Example

5.3.9.2.1 Structured Text

```
(* TcpSend example *)
CASE StepCounter OF
0:
  Inst_TcpSend(TRUE, MySocketID, 5, 'Hello');
  StepCounter := StepCounter + 1;
1:
  Inst_TcpSend(TRUE, MySocketID, 5, 'Hello');
  IF Inst_TcpSend.Done THEN
    BytesSent := Inst_TcpSend.NbSent;
    Inst_TcpSend(FALSE, 0, 0, '');
    StepCounter := StepCounter + 1;
  END_IF;
END_CASE;
```

5.4 UDP Functions for PxMM and Simulator

UDP ([User Datagram Protocol](#)) is a communications protocol which allows computers to exchange messages across an IP network.

When a UDP packet is sent to a broadcast address (e.g., 255.255.255.255), the AKD PDMM or PCMM automatically converts the given broadcast address to the broadcast address of its Ethernet interface.

Example: If the controller's IP address is 192.168.1.10 and the subnet mask is 255.255.255.0, the controller's Ethernet interface broadcast address is 192.168.1.255.

This list of UDP functions provide a KAS controller to communicate with a remote PC or another KAS controller over an Ethernet network.

Function	Description
"udpAddrMake" (→ p. 622)	Build an address buffer for UDP functions
"udpClose" (→ p. 624)	Close a socket
"udpCreate" (→ p. 625)	Create a UDP socket
"udpIsValid" (→ p. 626)	Test if a socket is valid
"udpRcvFrom" (→ p. 627)	Receive a telegram
"udpRcvFromArray" (→ p. 629)	Receive a byte array through UDP
"udpRcvFromVar" (→ p. 631)	Receives the contents of a variable through UDP
"udpSendTo" (→ p. 633)	Send a telegram
"udpSendToArray" (→ p. 634)	Send a byte array through UDP
"udpSendToVar" (→ p. 636)	Sends the contents of a local variable through UDP

TIP

See this [Wikipedia page](#) about [User Datagram Protocol](#) for more information.

5.4.1 udpAddrMake

PLCopen 

5.4.1.1 Description

This function builds an address buffer for UDP functions. This function is required for building an internal "UDP" address to be passed to the ["udpSendTo"](#) (→ p. 633) function in case of UDP client processing.

5.4.1.2 Arguments

5.4.1.2.1 Input

En	Description	Execute the function
	Data type	BOOL
	Range	[0,1]
	Unit	N/A
	Default	—
IPaddr	Description	IP address in the form <code>xxx.xxx.xxx.xxx</code>
	Data type	STRING
	Range	[0.0.0.0,255.255.255.255]
	Unit	N/A
	Default	—
port	Description	IP port number
	Data type	DINT
	Range	[0,+65535]
	Unit	N/A
	Default	—
addr[]	Description	Buffer where to store the UDP address (filled on output)
	Data type	USINT
	Range	[0,32]
	Unit	N/A
	Default	—

5.4.1.2.2 Output


OK	Description	Returns true when the function successfully executes. See Function - General rules .
	Data type	BOOL
	Unit	N/A

5.4.1.3 Examples


5.4.1.3.1 Structured Text

```
bAddrMake := udpAddrMake('10.156.238.176',Server_Port,add); //server details
```

5.4.1.3.2 Ladder Diagram



5.4.1.3.3 Function Block Diagram



5.4.2 udpClose



5.4.2.1 Description

This function closes a socket.

5.4.2.2 Arguments

5.4.2.2.1 Input

En	Description	Execute the function
	Data type	BOOL
	Range	[0,1]
	Unit	N/A
	Default	—
sock	Description	ID of the socket
	Data type	DINT
	Range	[0,+65535]
	Unit	N/A
	Default	—

5.4.2.2.2 Output


OK	Description	Returns true when the function successfully executes. See Function - General rules .
	Data type	BOOL
	Unit	N/A

5.4.2.3 Examples

5.4.2.3.1 Structured Text

```
udpClose(Socket_Number); //Close socket
```

5.4.2.3.2 Ladder Diagram



5.4.2.3.3 Function Block Diagram



5.4.3 udpCreate

PLCopen

5.4.3.1 Description

This function creates a UDP socket.

5.4.3.2 Arguments

5.4.3.2.1 Input

En	Description	Execute the function
	Data type	BOOL
	Range	[0,1]
	Unit	N/A
	Default	—
port	Description	UDP port number to be attached to the server socket or 0 for a client socket.
	Data type	DINT
	Range	[0,+65535]
	Unit	N/A
	Default	—

5.4.3.2.2 Output

OK	Description	Returns true when the function successfully executes. See Function - General rules .
	Data type	BOOL
	Unit	N/A


sock	Description	ID of the new socket
	Data type	DINT
	Unit	N/A

5.4.3.3 Examples

5.4.3.3.1 Structured Text

```
Socket_Number := udpCreate(Client_Port); //create a socket
```

5.4.3.3.2 Ladder Diagram



5.4.3.3.3 Function Block Diagram



5.4.4 udplsValid



5.4.4.1 Description

This function states whether a socket is valid or not.

5.4.4.2 Arguments

5.4.4.2.1 Input

En	Description	Execute the function
	Data type	BOOL
	Range	[0,1]
	Unit	N/A
	Default	—
sock	Description	ID of the socket
	Data type	DINT
	Range	[0,+65535]
	Unit	N/A
	Default	—

5.4.4.2.2 Output


OK	Description	Returns true when the function successfully executes. See Function - General rules .
	Data type	BOOL
	Unit	N/A

5.4.4.3 Examples

5.4.4.3.1 Structured Text

```
bIsValid := udpIsValid(Socket_Number); //Valid socket?
```

5.4.4.3.2 Ladder Diagram



5.4.4.3.3 Function Block Diagram



5.4.5 udpRcvFrom

PLCopen

5.4.5.1 Description

This function receives a UDP telegram. If the characters are received, the function fills the ADD argument with the internal "UDP" of the sender. This buffer can then be passed to the ["udpSendTo"](#) (→ p. 633) function to send the answer.

5.4.5.2 Arguments

5.4.5.2.1 Input

En	Description	Execute the function
	Data type	BOOL
	Range	[0,1]
	Unit	N/A
	Default	—
sock	Description	ID of the socket
	Data type	DINT
	Range	[0,+65535]
	Unit	N/A

	Default	—
nb	Description	Maximum number of characters received
	Data type	DINT
	Range	[0,+65535]
	Unit	N/A
	Default	—
add[]	Description	Buffer containing the UDP address of the transmitter (filled on output)
	Data type	USINT
	Range	[0,32]
	Unit	N/A
	Default	—
data	Description	Buffer where to store received characters
	Data type	STRING
	Range	[0,255]
	Unit	N/A
	Default	—

5.4.5.2.2 Output


OK	Description	Returns true when the function successfully executes. See Function - General rules .
	Data type	BOOL
	Unit	N/A
Q	Description	Actual number of received characters
	Data type	DINT
	Unit	N/A

5.4.5.3 Examples


5.4.5.3.1 Structured Text

```
ReceivedBytes := udpRcvFrom(Socket_Number, 5, add, data); //Read the
position
```

5.4.5.3.2 Ladder Diagram



5.4.5.3 Function Block Diagram



5.4.6 udpRcvFromArray



5.4.6.1 Description

This function receives an array of bytes.

5.4.6.2 Arguments

5.4.6.2.1 Input

En	Description	Execute the function
	Data type	BOOL
	Range	[0,1]
	Unit	N/A
	Default	—
sock	Description	Socket number, return value from "udpCreate" (→ p. 625)
	Data type	DINT
	Range	[0,+65535]
	Unit	N/A
	Default	—
nb	Description	Number of bytes to be transferred
	Data type	DINT
	Range	[0,+65535]
	Unit	N/A
	Default	—

add[]	Description	Array which contains information about the server
	Data type	USINT
	Range	[0,32]
	Unit	N/A
	Default	—
data[]	Description	Array of bytes to be transferred
	Data type	USINT
	Range	[0,+65535]
	Unit	N/A
	Default	—

5.4.6.2.2 Output


OK	Description	Returns true when the function successfully executes. See Function - General rules .
	Data type	BOOL
	Unit	N/A
Q	Description	Number of bytes received
	Data type	DINT
	Unit	N/A

5.4.6.3 Examples


5.4.6.3.1 Structured Text

```
BytesReceived := udpRcvFromArray(Socket_Number, nb, add, Frame);
```

5.4.6.3.2 Ladder Diagram




5.4.6.3.3 Function Block Diagram




5.4.7 udpRcvFromVar

PLCopen 

 **Function** - receives the contents a variable sent from another controller and saves it to a local variable.

This allows for the exchange of data across controllers.












TIP

Limitations:

- Function block instance variable types are not supported.
- The following types of variables cannot be sent or received:
 - Variables defined with a UDFB.
 - The Input and Output variables defined for a sub-program.
- "udpSendToVar" (→ p. 636) and "udpRcvFromVar" (→ p. 631) will not automatically swap bytes for big vs. little endian systems.
- Send / receive functionality is supported as follows:

Controller Compatibility Matrix for UDP Communication

	PCMM / AKD PDMM	PCMM2G	Simulator
PCMM / AKD PDMM			
PCMM2G			
Simulator			

The compatibility is based on the endianness of the controller's information. The PCMM and AKD PDMM are big-endian while the PCMM2G and Simulator are little-endian.

- 3rd party stand-alone programs on x86 platforms are responsible for endian conversions for UDP telegrams from a PDMM/PCMM.

5.4.7.1 Arguments

5.4.7.1.1 Input

En	Description	Execute the function
	Data type	BOOL
	Range	[0,1]
	Unit	N/A

	Default	—
sock	Description	Socket number, return value from "udpCreate" (→ p. 625)
	Data type	DINT
	Range	[0,+65535]
	Unit	N/A
	Default	—
add[]	Description	Array which contains information about the sender (server) of information. This includes the sender's IP address.
	Data type	USINT
	Range	[0,32]
	Unit	N/A
	Default	—
varName	Description	The name of a PxMM variable (or array or structure) that will store data from the sender. The variable should be the same type as what is being sent. See "udpSendToVar" (→ p. 636).
	Data type	STRING
	Range	
	Unit	N/A
	Default	—

5.4.7.1.2 Output


OK	Description	Returns true when the function successfully executes. See Function - General rules .
	Data type	BOOL
	Unit	N/A
Q	Description	Number of bytes received
	Data type	DINT
	Unit	N/A

5.4.7.2 Examples


5.4.7.2.1 Structured Text

```
udpRcvFromVar ( Socket_Number, Add, MyUDPVar )
```

5.4.7.2.2 Ladder Diagram



5.4.7.2.3 Function Block Diagram



5.4.8 udpSendTo



5.4.8.1 Description

This function sends UDP data to a server.

5.4.8.2 Arguments

5.4.8.2.1 Input

En	Description	Execute the function
	Data type	BOOL
	Range	[0,1]
	Unit	N/A
	Default	—
sock	Description	ID of the client socket
	Data type	DINT
	Range	[0,+65535]
	Unit	N/A
	Default	—
nb	Description	Number of bytes of data to send
	Data type	DINT
	Range	[0,65535]
	Unit	N/A
	Default	—
add[]	Description	Buffer containing the UDP address
	Data type	USINT
	Range	[0,32]

	Unit	N/A
	Default	—
data	Description	The characters to send
	Data type	STRING
	Range	[0,255]
	Unit	N/A
	Default	—

5.4.8.2.2 Output


OK	Description	Returns true when the function successfully executes. See Function - General rules .
	Data type	BOOL
	Unit	N/A

5.4.8.3 Examples


5.4.8.3.1 Structured Text

```
bUdpSendTo := udpSendTo(Socket_Number, 5, add, '1000');
```

5.4.8.3.2 Ladder Diagram



5.4.8.3.3 Function Block Diagram



5.4.9 udpSendToArray



5.4.9.1 Description

This function sends an array of bytes.

5.4.9.2 Arguments

5.4.9.2.1 Input

En	Description	Execute the function
	Data type	BOOL
	Range	[0,1]
	Unit	N/A
	Default	—
sock	Description	Socket number, return value from "udpCreate" (→ p. 625)
	Data type	DINT
	Range	[0,+65535]
	Unit	N/A
	Default	—
nb	Description	Number of bytes to be transferred
	Data type	DINT
	Range	[0,+65535]
	Unit	N/A
	Default	—
add[]	Description	Array which contains information about the server
	Data type	USINT
	Range	[0,32]
	Unit	N/A
	Default	—
data[]	Description	Array of bytes to be transferred
	Data type	USINT
	Range	[0,+65535]
	Unit	N/A
	Default	—

5.4.9.2.2 Output


OK	Description	Returns true when the function successfully executes. See Function - General rules .
	Data type	BOOL
	Unit	N/A

5.4.9.3 Examples


5.4.9.3.1 Structured Text

```
Success := udpSendToArray(Socket_Number, nb, add, Frame);
```

5.4.9.3.2 Ladder Diagram



5.4.9.3.3 Function Block Diagram



5.4.10 udpSendToVar

PLCopen

Function - sends the contents of a local variable to another controller. This allows for the exchange of data across controllers.












TIP

Limitations:

- Function block instance variable types are not supported.
- The following types of variables cannot be sent or received:
 - Variables defined with a UDFB.
 - The Input and Output variables defined for a sub-program.
- "udpSendToVar" (→ p. 636) and "udpRcvFromVar" (→ p. 631) will not automatically swap bytes for big vs. little endian systems.
- Send / receive functionality is supported as follows:

Controller Compatibility Matrix for UDP Communication

	PCMM / AKD PDMM	PCMM2G	Simulator
--	-----------------	--------	-----------

PCMM / AKD PDMM			
PCMM2G			
Simulator			

The compatibility is based on the endianness of the controller's information. The PCMM and AKD PDMM are big-endian while the PCMM2G and Simulator are little-endian.

- 3rd party stand-alone programs on x86 platforms are responsible for endian conversions for UDP telegrams from a PDMM/PCMM.

5.4.10.1 Arguments

5.4.10.1.1 Input

En	Description	Execute the function
	Data type	BOOL
	Range	[0,1]
	Unit	N/A
	Default	—
sock	Description	Socket number, return value from "udpCreate" (→ p. 625)
	Data type	DINT
	Range	[0,+65535]
	Unit	N/A
	Default	—
add[]	Description	Array which contains information about the sender (server) of information. This includes the sender's IP address.
	Data type	USINT
	Range	[0,32]
	Unit	N/A
	Default	—
varName	Description	The name of a variable (or array or structure) to send to the receiver. The variable should be the same type as what is expected by the receiver. See "udpRcvFromVar" (→ p. 631).
	Data type	
	Range	

Unit	N/A
Default	—

5.4.10.1.2 Output


OK	Description	Returns true when the function successfully executes. See Function - General rules .
	Data type	BOOL
	Unit	N/A

5.4.10.2 Examples


5.4.10.2.1 Structured Text

```
udpSendToVar ( Socket_Number, Add, MyUDPVar )
```

5.4.10.2.2 Ladder Diagram




5.4.10.2.3 Function Block Diagram



5.5 PrintMessage

- PLCopen
- Pipe Network

 **Function** - used to generate a log message with any wanted strings in the [Log Messages](#) window.

5.5.1 Input

Level	Description	Level of the logged message. In other words, its importance. Keep in mind that not all messages are displayed in the log windows by default. Only Error and Critical messages are displayed by default. Change the log settings to display a lower level. PrintMessage logs SYSTEM messages.
	Data type	DINT
	Range	[0 , 4] Defines are: LEVEL_DEBUG, LEVEL_INFO, LEVEL_WARNING, LEVEL_ERROR, LEVEL_CRITICAL

	Unit	N/A
	Default	—
Message	Description	Content of the message. A string of 255 characters maximum.
	Data type	String
	Range	1 to 255 characters
	Unit	N/A
	Default	—

5.5.2 Output

Default (.Q)	Description	Returns true when function successfully executes.
	Data type	BOOL
	Unit	N/A

5.5.3 Remarks

5.5.3.1 Source

PrintMessage uses the SYSTEM message type.

To view all messages generated by PrintMessage, go to the log configuration and select the specified level for the SYSTEM source.

5.5.3.2 Level

The message could be sent with a logging level from 0 to 4 that qualifies its importance.

- The highest level, 4, logs critical messages.
 - Available levels are: Debug, Informational, Warning, Error, and Critical.
- Only Error and Critical messages are generated by default.
 - To force the system to generate every message level, use the [Configuration Settings](#) to change the settings to the desired level.

! IMPORTANT

Enabling all messages can slow down the application's execution. To avoid locking up communications between the IDE and Runtime, you must never include a print statement in your program that prints to the log every update cycle.

5.5.4 Usage

```
PrintMessage( LEVEL_DEBUG, 'Message string to be logged' );
```

5.5.5 Structured Text

```


        // It's possible to create a temporary variable with the
        message.

MESSAGE := CONCAT( 'MachineState=', ANY_TO_STRING(MachineState), '.
MachineSpeed=', ANY_TO_STRING(MachineSpeed) );


// Then print the message to the log window
PrintMessage( LEVEL_INFO, MESSAGE );
PrintMessage( LEVEL_WARNING, MESSAGE );
PrintMessage( LEVEL_ERROR, MESSAGE );

// Or to create the string directly in the function call:
PrintMessage( LEVEL_CRITICAL, CONCAT( 'MachineState=', ANY_TO_STRING
(MachineState), '. MachineSpeed=', ANY_TO_STRING(MachineSpeed) ) );
    
```

5.5.6 FBD Language



5.5.7 FFLD Language



5.6 File and TCP/IP Function Block ErrorID Output

Following is the list of possible errors that could be returned at the **ErrorID** output of the "File Tools Function Blocks" (→ p. 582) and "TCP/IP Function Blocks" (→ p. 606).

File Function Block Errors

ErrorID	Description
16000	Error opening file.
16001	All PLC file handles used.
16002	File ID is invalid.
16003	File ID has been closed.
16004	Error in file stream.
16005	End of file encountered.
16006	Internal file FB error.
16007	Unknown file error.
16008	No such file or directory.
16009	Bad file descriptor.
16010	File already exists.
16011	Too many open files in the system.
16012	Text file is busy.
16013	File is too large.
16014	File system is read only.
16015	File locking deadlock.
16016	Filename is too long.
16017	File positioning error.
16018	Bad or corrupted file system detected .

TCP/IP Function Block Errors

ErrorID	Description
16100	Connection error.
16101	TCP ID has been closed.
16102	All PLC TCP handles used.
16103	TCP ID is invalid.
16104	Failed to allocate TCP/IP socket.
16105	TCP operation internal error.

6 Kollmorgen UDFBs

A Kollmorgen UDFB¹ is a pre-defined function block created by Kollmorgen to simplify certain tasks or demonstrate a particular function.

- A Kollmorgen UDFB must be instantiated before it may be used.
- The code inside a Kollmorgen UDFB can be modified by creating an unlocked copy in the subprogram section in the project tree.

6.1 Create an Instance

1. Open the PLC code.
2. Select the UDFB in the [Library](#) tree.
3. Drag-and-drop the UDFB in the PLC editor to create the instance of the UDFB.
An instance of the UDFB has now been created in **Subprograms**.

NOTE

An instance of the UDFB cannot be created directly from the dictionary or from the PLC Editor.

¹"User Defined Function Block" UDFB can be used as a sub-function block in another program of the application. It is described using FBD, LD, ST or IL language. Input / output parameters of a UDFB (as well as private variables) are declared in the variable editor as local variables of the UDFB


6.2 Working with Kollmorgen UDFBs

By default all Kollmorgen UDFBs are protected, meaning they may not be modified or renamed. When a Kollmorgen UDFB is dropped into an instance it is not editable.

There are two solutions to make it editable:


- Right click a Kollmorgen UDFB that has been dropped into an instance (in **Subprograms**) and select **Unlock**.

This creates an unlocked version of the UDFB with the name "U<sequence number><UDFB name>".



- Instead of dropping a Kollmorgen UDFB into an instance, right click on the UDFB and select **Create unlocked copy in Subprograms**.

This creates an unlocked instance of the UDFB with the name "U<sequence number><Kollmorgen UDFB name>".



Once a Kollmorgen UDFB is unlocked, it may be renamed and exported by right-clicking on the UDFB.

- Renamed UDFBs must have unique names.
- Importing a saved UDFB increments the UDFB's name.

TIP

For a UDFB to modify a structure or array based on the output, it must first be defined it as an input.

The input is automatically set as an INOUT parameter.

This is because OUTs are strictly simple types.

6.2.0.1 FB_FirstOrderDigitalFilter

This FB is defined to filter an Analog signal.

In any control system with an analog feedback signal present there is the risk of unwanted noise and jitter that can compromise the signal integrity yielding a less the desirable system.

This Kollmorgen UDFB will provide a digital first order filter of an analog feedback signal from an LVDT, tension transducer, potentiometer, encoder, resolver, or some other like device. The amount of filtering is based on a gain value and can provide no filter to full filter conditioning.

The following figure shows the function block I/O




Figure 1-137: CBS First Order Digital Filter

6.2.0.1.1 Arguments

6.2.0.1.1.1 Inputs

EN	Description	Enables execution (FFLD only)
	Data type	BOOL
	Range	—
	Unit	N/A
	Default	
AnalogInput	Description	Analog Input from transducer
	Data type	INT
	Range	—
	Unit	N/A
	Default	
FilterGain	Description	Filter Gain
	Data type	REAL
	Range	[1 - 0.05]
	Unit	N/A
	Default	—

6.2.0.1.1.2 Outputs

OK	Description	Execution Complete
	Data type	BOOL
	Range	[0,1]
	Unit	
FilterOutput	Description	Filtered analog input value

Data type	REAL
Range	[0,1]
Unit	

6.2.0.1.2 Usage

When using this UDFB, the Enable (EN) input should always be energized to provide the desired filtering.

- The AnalogInput input is the unfiltered "raw" analog feedback signal from an LVDT, tension transducer, potentiometer, or some other like device.
- The FilterGain defines the amount of filtering to be used.
 - The range of the gain is from 1.0 or no filtering to 0.05 or the maximum filtering.
- The FilterOutput is the filtered analog input.
 - It is typically used as an input to some other function block or UDFB that has an analog input (e.g., the MCFB_GearedWebTension UDFB).
- The implementation of the digital first order filter is for PLCopen.
- The equation is defined as: $Input * Gain + Output * (1 - Gain) = Output$.
- The steady state filter delay with a gain of 0.8 can be seen in the "Filter Input Delay" (→ p. 645) table.

6.2.0.1.2.1 Filter Input Delay

Example: Filter Input Delay

FilterGain	FilterInput	FilterOutput
0.8	0	0
	100	80
	100	96
	100	99.2
	100	99.84
	100	99.968
	100	99.9936
	100	99.99872
	100	99.999744
	100	99.9999488
	100	99.99998976
	100	99.99999795
	100	99.99999959
	100	99.99999992


FilterGain	FilterInput	FilterOutput
100	100	99.99999998
100	100	100
100	100	100
100	100	100
100	100	100
100	100	100
100	100	100
100	100	100
100	100	100

6.2.0.1.2.2 Filter Delay Tn

From this table:

- The numbers of filter delays for a steady state analog input at a given gain are listed.
- The range of the filter gain is between 1.00 and 0.05.
- For a filter gain of 0.8 there is a delay of 15 time constants with a time constant defined as the rate the UDFB is scanned or executed in the application.
 - Example: If the UDFB was executed every millisecond a gain of 0.8 would provide a filter delay of 15ms.
 - Conversely a gain of 1.00 provides zero filtering and the output signal follows the input signal, and a gain of 0.05 provides the most filtering for 463 ms.

Filter Delay Tn



6.2.0.1.2.3 Example: Filter Input Lag - Random Input

Of course a real world analog input is most always a varying feedback signal.

In this table, an initial input of 100, a gain of 0.8, and a random variability of 10%. Filter Input

Example: Filter Input Lag - Random Input

Filter Input	Filter Current Output	Amount of Input Filtering	Random Filter % Variation
0	0	0	10%
100	80	-20	
97.38903813	93.9112305	-	
		3.477807626	
92.67638093	92.92335084	0.246969915	

Filter Input	Filter Current Output	Amount of Input Filtering	Random Filter % Variation
94.12988912	93.88858146	-	0.241307655
103.0835564	101.2445614	-	1.838994993
91.16845433	93.18367575	2.015221422	
93.23936976	93.22823096	-	0.011138803
94.90272089	94.56782291	-	0.334897986
103.3070737	101.5592235	-	1.747850153
96.83149418	97.77704005	0.945545867	
96.35024002	96.63560002	0.285360007	
99.82417525	99.1864602	-	0.637715045
105.0792636	103.9007029	-	1.178560685
97.36988208	98.67604626	1.306164172	
107.82502	105.9952253	-	1.829794752
97.7886524	99.42996698	1.641314572	
108.2038024	106.4490353	-	1.754767081
91.58527607	94.55802792	2.972751845	
93.6783421	93.85427926	0.175937164	
102.8695349	101.0664838	-	1.803051129
93.95916817	95.3806313	1.421463121	
108.6579707	106.0025028	-	2.655467871
109.3425748	108.6745604	-	0.668014397
103.9066	104.8601921	0.953592077	
92.30112142	94.81293555	2.511814127	
109.4460726	106.5194452	-	2.926627416
94.88799896	97.21428821	2.326289251	
105.4738635	103.8219484	-	1.651915057


Filter Input	Filter Current Output	Amount of Input Filtering	Random Filter % Variation
102.988167	103.1549233	0.166756284	
92.92925408	94.97438792	2.045133846	
95.58185568	95.46036213	- 0.121493552	
109.414248	106.6234708	- 2.790777178	
106.5661311	106.577599	0.011467953	
99.85857253	101.2023778	1.343805301	
107.865421	106.5328124	- 1.332608643	
92.19683177	95.0640279	2.867196126	
104.8558146	102.8974573	- 1.958357346	
104.5140236	104.1907104	- 0.323313268	
104.3675014	104.3321432	- 0.035358206	
109.2704266	108.2827699	- 0.987656683	
101.4962729	102.8535723	1.35729941	
92.19199163	94.32430776	2.132316128	
99.13065312	98.16938405	- 0.961269073	
103.5068114	102.4393259	- 1.067485466	
109.502983	108.0902516	- 1.412731426	
99.05504822	100.8620889	1.80704068	
94.97711299	96.15410817	1.176995182	
107.1063597	104.9159094	- 2.190450308	
91.12245188	93.88114339	2.758691504	
108.130314	105.2804799	- 2.849834129	
104.2923832	104.4900025	0.197619344	
101.3775072	102.0000062	0.62249907	
100.5303014	100.0399168	- 0.490384645	Averages

6.2.0.1.3 Example


6.2.0.1.3.1 Structured Text

```
//Filter analog input signal with a gain of 0.8 to remove noise
FilteredOutput:= Inst_FB_FirstOrderDigitalFilter( AnalogInput1Value, 0.8
);
```

6.2.0.1.3.2 Ladder Diagram



6.2.0.1.3.3 Function Block Diagram



6.2.0.2 FB_PWDutyOutput

- The Pulse Width Duty Cycle function block accepts an input value between the minimum and maximum input range and converts this to a duty cycle percentage. The output is then cycled on and off over the period of the duty cycle at the duty cycle percentage.

- If it is desired to have the output ON time range from 0 to the duty cycle period, the minimum should be set to zero and the maximum to the duty cycle period.
- If the calculated duty cycle based on the input and range values is less than the minimum ON time (MinTime), the output will not come on.
- If the calculated duty cycle is between or equal to the range values the output is cycled by the duty cycle.
- If the calculated duty cycle is greater than the maximum ON time (MaxTime) the output will remain on.

The following figure shows the function block I/O




Figure 1-138: Pulse Width Duty Cycle

6.2.0.2.1 Arguments

6.2.0.2.1.1 Input

Argument	Description
uEN01	Enable for the block

	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A
	Default	—
uInputCommand	Description	Signal Input (sometimes the output of a PID block).
	Data type	REAL
	Range	[0 to --]
	Unit	N/A
	Default	—
uPeriod	Description	Period of the duty cycle
	Data type	TIME
	Range	[0 , --]
	Unit	N/A
	Default	—
uMaxInput	Description	uInputCommand at or above this number that sets DutyOutput =1
	Data type	REAL
	Range	uMinInput to --
	Unit	N/A
	Default	—
uMinInput	Description	uInputCommand at or below this number set DutyOutput = 0
	Data type	REAL
	Range	0 to uMaxInput
	Unit	N/A
	Default	—
uMaxTime	Description	Maximum on time for the Output
	Data type	TIME
	Range	uMinTime to uPeriod
	Unit	N/A
	Default	—
uMinTime	Description	Minimum on-time for the PW Duty Output
	Data type	TIME

Range	0 to uMaxTime
Unit	N/A
Default	—

6.2.0.2.1.2 Output

OK	Description	Function block is OK.
	Data type	BOOL
	Range	[0, 1]
TM1	Description	On-time of the Output
	Data type	TIME
	Range	0 to uPeriod
DutyOutput	Description	PW signal (switching between 0 and 1). DutyOutput is set to 0 when the function block is not active (not enabled by the first input).
	Data type	BOOL
	Range	[0, 1]

6.2.0.2.2 Usage

Flash a warning light for operators.

6.2.0.2.3 Related Functions

[Timers](#)

6.2.0.2.4 Example

6.2.0.2.4.1 Function Block Calculations

```

IF (uInputCommand - uMinInput) < 0 then           //If Command less than
MinInput turn out put off
  DutyOutput := 0;
ELSIF (uInputCommand - uMaxInput) > 0 then       //If Command greater than
MaxInput turn out put on
  DutyOutput := 1;
ELSE
  DutyCycle := (uInputCommand - uMinInput)/(uMaxInput -
uMinInput);           //Calculate Duty Cycle
  ONTimeFromInput := DutyCycle * any_to_REAL(uPeriod) ;      //Calculate
Ontime

  IF any_to_TIME(ONTimeFromInput) < uMinTime then
    DutyOutput := 0;
  ELSIF any_to_TIME(ONTimeFromInput) > uMaxTime then
    DutyOutput := 1;
  ELSE
    TM1 := any_to_TIME(ONTimeFromInput) ;
    TM0 := uPERIOD - TM1;           //Calculate offtime
    DutyOutput := Inst_blinkA( 1 , TM0 , TM1 );           //Use BlinkA


```

```
function to set PW output
    END_IF ;
END_IF ;
```


6.2.0.2.4.2 Structured Text

```
Inst_FB_PWDutyOutput( PWDuty_3_Switch, PWDuty_In3, PWDuty_3_Period, PWDuty_3_MaxInput,
PWDuty_3_MinInput, PWDuty_3_MaxTime, PWDuty_3_MinTime);
PWDuty_3_OK:=Inst_FB_PWDutyOutput.OK;
PWDuty_3_Time:=Inst_FB_PWDutyOutput.TM1;
PWDuty_3_Output:=Inst_FB_PWDutyOutput.DutyOutput;
```

6.2.0.2.4.3 Ladder Diagram



6.2.0.2.4.4 Function Block Diagram



6.2.0.3 FB_ScaleInput

- Scale DINT to LREAL.

Converts un-scaled DINT values from Analog Inputs into user units of type LREAL. The input signal is converted based on a linear mapping automatically calculated by two points entered. InputMin is

mapped to OutputMin, InputMax is mapped to OutputMax, and all values in between are scaled automatically. If an input value is not between the selected Min/Max, the Boolean output OutsideRange turns TRUE, and the OutputSignal is set to the corresponding OutputMin or OutputMax value.

The following figure shows the function block I/O:




Figure 1-139: Scale Input

6.2.0.3.1 Arguments

6.2.0.3.1.1 Input

InputSignal	Description	Un-scaled input signal
	Data type	DINT
	Range	[0 , 4]
	Unit	N/A
	Default	—
InputMin	Description	Minimum value of accepted input signal range
	Data type	DINT
	Range	[0 , 4]
	Unit	N/A
	Default	—
InputMax	Description	Maximum value of accepted input signal range
	Data type	DINT
	Range	[0 , 4]
	Unit	N/A
	Default	—
OutputMin	Description	Output value mapped to the InputMin
	Data type	LREAL
	Range	[0 , 4]
	Unit	N/A

	Default	—
OutputMax	Description	Output value mapped to the InputMax
	Data type	LREAL
	Range	[0 , 4]
	Unit	N/A
	Default	—

6.2.0.3.1.2 Output

OutputSignal	Description	Scaled value of the Input Signal with type converted to LREAL. Stays within specified Min/Max output values
	Data type	LREAL
	Unit	N/A
OutsideRange	Description	True if InputSignal is outside range setup by min/max values, otherwise FALSE
	Data type	BOOL
	Unit	N/A

6.2.0.3.2 Usage

Scale an analog signal from a drive.

6.2.0.3.3 Related Functions

[UDFB ScaleOutput](#)


6.2.0.3.4 Example

6.2.0.3.4.1 Structured Text


```

//Scale an integer based analog input signal into floating point LREAL
variable
ScaleInput_1( Analog_In, Analog_In_Min, Analog_In_Max, LREAL_Out_Min,
LREAL_Out_Max );
LREAL_OutputSignal:= ScaleInput_1.OutputSignal;
Analog_Range_Err:= ScaleInput_1.OutsideRange;
    
```

6.2.0.3.4.2 Ladder Diagram



6.2.0.3.4.3 Function Block Diagram



6.2.0.4 FB_ScaleOutput

- Scale LREAL to DINT .

This Kollmorgen UDFB converts un-scaled LREAL values from a PLC Program into units of type DINT that can be mapped to an analog output. The input signal is converted based on a linear mapping automatically calculated by two points entered. InputMin is mapped to OutputMin, InputMax is mapped to OutputMax, and all values in between are scaled automatically. If an input value is not between the selected Min/Max, the Boolean output OutsideRange turns TRUE, and the OutputSignal is set to the corresponding OutputMin or OutputMax value.

The following figure shows the function block I/O:




Figure 1-140: Scale Output

6.2.0.4.1 Arguments

6.2.0.4.1.1 Input

InputSignal	Description	Un-scaled input signal
	Data type	LREAL
	Range	[0 , 4]
	Unit	N/A
	Default	—
InputMin	Description	Minimum value of accepted input signal range
	Data type	LREAL
	Range	[0 , 4]
	Unit	N/A
	Default	—
InputMax	Description	Maximum value of accepted input signal range
	Data type	LREAL
	Range	[0 , 4]
	Unit	N/A
	Default	—

OutputMin	Default	—
	Description	Output value mapped to the InputMin
	Data type	DINT
	Range	[0 , 4]
	Unit	N/A
OutputMax	Default	—
	Description	Output value mapped to the InputMax
	Data type	DINT
	Range	[0 , 4]
	Unit	N/A
	Default	—

6.2.0.4.1.2 Output

OutputSignal	Description	Scaled value of the Input Signal with type converted to DINT. Stays within specified Min/Max output values
	Data type	DINT
	Unit	N/A
OutsideRange	Description	True if InputSignal is outside range setup by min/max values, otherwise FALSE
	Data type	BOOL
	Unit	N/A

6.2.0.4.2 Usage

Scale an analog signal to a drive.

6.2.0.4.3 Related Functions

[UDFB ScaleInput](#)

6.2.0.4.4 Example

6.2.0.4.4.1 Structured Text


```

Inst_ScaleOutput1( ScaleOutput_In2, ScaleOutput_In2_
Min,ScaleOutput_In2_Max, ScaledOutput_2_Min, ScaledOutput_2_Max
);


ScaledOutput_2:=Inst_ScaleOutput1.OutputSignal;

ScaledOutput_2_Err:=Inst_ScaleOutput1.OutsideRange;
    
```

6.2.0.4.4.2 Ladder Diagram



6.2.0.4.4.3 Function Block Diagram



6.2.0.5 FB_ElapseTime

- This Kollmorgen UDFB keeps track of the time (oTotalOnTime) that a Boolean input variable is on. Once the iEN00 enable input is high the Kollmorgen UDFB will keep track of the total time iVariable is on. If iVariable changes to an off state while iEN00 is on, the oTotalOnTime will stop.

oTotalOnTime will start to add again once iVariable changes state to high. As long as the iEN00 input is on, iVariable can change states many times. The oTotalOnTime will reflect only the total time that iVariable has been on. While iVariable is still TRUE, oInProgress will also be TRUE and oDone will be FALSE. Once iVariable is FALSE, oInProgress will be FALSE and oDone will be TRUE.

If the iEN00 input goes off, oTotalOnTime stops counting and the Kollmorgen UDFB execution stops. To restart the timer turn iEN00 on again. This will reset oTotalOnTime to zero and counting will begin once iVariable is also on.




Figure 1-141: FB_ElapseTime




Figure 1-142: MFB_ElapseTime – Time Diagram

6.2.0.5.1 Arguments

6.2.0.5.1.1 Input

iEN00	Description	Enable for the block
	Data type	Boolean
	Range	FALSE or TRUE
	Unit	N/A
	Default	FALSE

iVariable	Description	The variable to be tracked
	Data type	Boolean
	Range	FALSE or TRUE
	Unit	N/A
	Default	FALSE

6.2.0.5.1.2 Output

OK	Description	Function Block OK. This output follows the state on iEN00 input
	Data type	Boolean
	Range	FALSE or TRUE
	Unit	N/A
oTotalOnTime	Description	The amount of time the iVariable is turned on.
	Data type	Time
	Range	0ms - 24h
	Unit	ms
oTotalOnTime	Description	The amount of time the iVariable is turned on.
	Data type	Time
	Range	0ms - 24h
	Unit	ms
oInProgress	Description	The state of block's execution whether or not it is still keeping track of time
	Data type	Boolean
	Range	FALSE or TRUE
	Unit	N/A
oDone	Description	The state of block's execution whether or not it is completed
	Data type	Boolean
	Range	FALSE or TRUE
	Unit	N/A

6.2.0.5.2 Usage


- Enable the block by setting iEN00 to TRUE
- Either manually set iVariable to TRUE or have the application set this variable to TRUE
- Once oDone returns TRUE, read the oTotalOnTime to find out how long iVariable was on.

6.2.0.5.3 Example


6.2.0.5.3.1 Structured text

```
//Keep track of total time that IncrementTimer variable is TRUE while
EnableTimer variable is true
//Timer will be reset when EnableTimer variable is false
Inst_FB_ElapseTime( EnableTimer, IncrementTimer );
TotalOnTime := Inst_FB_ElapseTime.oTotalOnTime;
```

6.2.0.5.3.2 Function Block Diagram



6.2.0.5.3.3 Free Form Ladder Diagram



6.2.0.6 PipeNetwork_FFLD Pipe Network ✓

6.2.0.6.1 Description

This function is used to call the PNCode Function Block in FFLD POU's. It starts and initializes the Pipe Network, based on the command specified by cmdID. Internally this function calls the Function Block PNCode.

This is a special function that should only be used in Pipe Network applications that contain FFLD POU's that call PNCode. Calling this function instead of PNCode in FFLD POU's will eliminate the following compile error that occurs after modifying the Pipe Network using the Pipe Network editor.

```
Controller:PLC:Main: NW1(1,14): PNCode: Invalid block height
```

NOTE

The compile error is generated because the number of outputs on PNCode can vary. This occurs after modifying the original Pipe Network using the Pipe Network editor. The new PNCode Function Block is not automatically updated in any FFLD POU, reflecting the new outputs. You need to manually update each PNCode Function Block call in any FFLD POU to correct this problem.




Figure 1-143: PipeNetwork_FFLD

See also: [Design Motion with Pipe Network](#), [Initialize and Start up a Pipe Network](#), [PLCopen 2-Axes Template with FFLD](#)

6.2.0.6.2 Arguments

6.2.0.6.2.1 Inputs

En	Description	Request to initialize the Pipe Network
	Data type	BOOL
	Range	0, 1
	Unit	N/A
	Default	—
cmdID	Description	Commands used to start and initialize the Pipe Network <ul style="list-style-type: none"> • MLPN_CREATE_OBJECTS - Create Pipe Network • MLPN_POWER_ON - Power on all axes • MLPN_POWER_OFF - Power off all axes • MLPN_ACTIVATE - Activate the pipes • MLPN_CONNECT - Connect the axes to the pipes • MLPN_DEACTIVATE - Deactivate the pipes
	Data type	DINT
	Range	N/A
	Unit	N/A
	Default	—

6.2.0.6.2.2 Outputs

OK	Description	Returns TRUE when the function has completed
	Data type	BOOL
	Unit	N/A

6.2.0.6.3 Usage


- This is a special function that should only be used in Pipe Network applications that contain FFLD POU's that call PNCode.
- To use this Function, PipeNetwork must be declared as a global variable in the dictionary.

TIP

The Pipe Network FFLD Application Template is a good example of how to use this Function. See [Pipe Network 2-Axes Template with FFLD only](#).

6.2.0.6.4 Example

6.2.0.6.4.1 FFLD



6.2.0.7 ProfilesCode_FFLD

6.2.0.7.1 Description

This function is used to call the Profiles Code Function Block in FFLD POU. Internally this function calls the Function Block ProfilesCode.

This is a special function which should only be used in applications that contain FFLD POU that call ProfilesCode. Calling this function instead of ProfilesCode in FFLD POU will eliminate the following compile error that occurs after adding a new Profile to the project tree.

```
Controller:PLC:Main:NW1(1,14):ProfilesCode:Invalid block height
```

The compile error is generated because the number of outputs on ProfilesCode can vary. This occurs after adding a new profile to the project tree. The ProfilesCode Function Block is not automatically updated in any FFLD POU, reflecting the new outputs. You needed to manually update each ProfilesCode Function Block call in any FFLD POU to correct this problem. If you use this new Function instead, you no longer need to manually update each ProfilesCode Function Block in FFLD.




Figure 1-144: ProfilesCode_FFLD

6.2.0.7.2 Arguments

6.2.0.7.2.1 Inputs

En	Description	Request to initialize the Pipe Network
	Data type	BOOL
	Range	0,1
	Unit	N/A
	Default	—
cmdID	Description	Commands used to start and initialize the Pipe Network <ul style="list-style-type: none"> • MLPR_CREATE_PROFILES - Creation and initialization of profiles.
	Data type	DINT
	Range	N/A
	Unit	N/A
	Default	—

6.2.0.7.2.2 Outputs

OK	Description	Returns TRUE when the function has completed
	Data type	BOOL
	Unit	N/A

6.2.0.7.3 Usage


- This is a special function that should only be used in applications that contain FFLD POUs that call ProfilesCode.
- To use this function, Profiles must be declared as a global variable in the dictionary.

TIP

The Pipe Network and PLCopen 2 Axis FFLD Application Templates are two examples of how to use this function. See [Pipe Network 2-Axes Template with FFLD only](#) and [PLCopen 2-Axes Template with FFLD](#).


6.2.0.7.4 Example

6.2.0.7.4.1 FFLD



6.2.0.8 FB_TemperaturePID

- This function block provides PID temperature control with auto tuning.



The TemperaturePID user-defined function block

6.2.0.8.1 Arguments

6.2.0.8.1.1 Inputs

iEN	BOOL	Enable function
iREFTEMP	LREAL	Reference temperature [°C]
iTEMP	LREAL	Actual temperature [°C]
iSTART	BOOL	Start PID or auto tuning
iMODE	BOOL	FALSE-automatic, TRUE-tuning
iKP	LREAL	PID Proportional Gain
iKI	LREAL	PID Integral Gain


iKD	LREAL	PID Derivative Gain
iTC1S	BOOL	Sampling Time is 1s
iTC5S	BOOL	Sampling Time is 5s
iPROGCYCLE	LREAL	Execution time of the function [ms]

6.2.0.8.1.2 Outputs

oOK	BOOL	Function enabled
oCHECKSTABLE	BOOL	TRUE when checking if ambient temperature is stable
oTUNESTART	BOOL	Tuning is started
oTUNEOK	BOOL	Tuning is completed
oTAU	LREAL	System Time Constant[s]
oPWM	BOOL	PWM command for heater
oERR	BOOL	Function error
oERRID	INT	Function ID error (in case of oERR=TRUE)
oPOWER	LREAL	% of power requested from heater (100%=full power)
oTICK	BOOL	Pulse every sampling time

6.2.0.8.2 Usage

6.2.0.8.2.1 Tuning Process



Tuning consists of three steps.

1. Check if the ambient temperature is stable: the measured **delta_temp=Tmax-Tmin** must be lower than **0.1*Tmax**.
 This step takes 10 cycles (10*iTC5s or 10*iTC1s).
 The tuning fails (oERR=TRUE, oERRID=1) if the ambient temperature is greater than **0.1*Tmax**, otherwise **Tamb=(Tmax+Tmin)/2**.

2. Start tuning Phase1: output **oPWM** is kept TRUE until the final measured temperature **iTEMP** gets over **iREFTEMP/2**. After that **oPWM** is kept LOW.
3. Start tuning Phase2: with **oPWM** kept LOW the temperature gets down until the final value is lower than $[(iREFTEMP/2 - T_{amb}) * 0.368 + T_{amb}]$.

After, PID gains are calculated as:

```
Kp=10
Ki=0.14
delta_time = time to complete Phase2


Kd=SQRT(delta_time)*7
```

The tuning is completed.


TIP

oTAU may be useful for setting the proper sampling time (1s or 5s).

6.2.0.8.2.2 Start PID Controller



Upon starting the PID controller, the output **oPWM** is modulated 5 times within the sampling time (blue line is **oTICK**, green line is **oPWM**) and each pulse length depends on output **oPOWER** (100%=full length).




6.2.0.8.3 Example

6.2.0.8.3.1 ST


```
//Run PID function with determined proportional, integral, and derivative
gains
//send PWM output to command heater
udfbThPID( TRUE, 90, Temp_mes, TRUE, FALSE, KP, KI, KD, FALSE, TRUE, 1 );
```

```
Tau_Calculated := udfbThPID.oTAU;
PWM_CMD := udfbThPID.oPWM;
Power := udfbThPID.oPOWER;
Tick := udfbThPID.oTICK;
```

6.2.0.8.3.2 FBD



6.2.0.8.3.3 FFLD



6.2.0.9 MLFB_DriveFault Pipe Network ✓

6.2.0.9.1 Description

This function block returns the fault status, fault number and fault description of the requested axis which is mapped to a Kollmorgen drive such as S300, S700, AKD, AKD2G, and AKT2G Stepper.

The FAULT output returns TRUE when the selected drive goes into a fault state. The fault number and description depend on the drive type mapped to the axis.

- If the drive is an AKD or AKD2G then the fault number is the same number as reported on the display of the AKD/AKD2G drive.
- If the drive is an AKT2G Stepper, then the fault number represents the drive status word which is a bitmask that represents the various error conditions.

NOTE

This function blocks requires "FB_S700FltRpt" (→ p. 781), "MCFB_AKDFault" (→ p. 717), and "MCFB_AKDFaultLookup" (→ p. 719) subprograms imported to project to compile and function




Figure 1-145: MCFB_DriveFault

6.2.0.9.2 Arguments

6.2.0.9.2.1 Input

EN	Description	ENABLES the Kollmorgen UDFB (used in FFLD editor only)
	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A
	Default	—
AxisID	Description	ID of Axis block of Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	N/A
	Default	—

6.2.0.9.2.2 Output

FAULT	Description	TRUE if the selected drive currently has a Fault
	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A

FaultNumber	Description	<p>If the axis is:</p> <p>S300/S700: Three-digit fault identifier. See the article S300 & S700 Errors and Warnings on KDN for a full list of fault codes.</p> <p>AKD: Three-digit fault identifier. See the AKD Fault and Warning Messages for a full list of fault codes.</p> <p>AKD2G: Four-digit fault identifier. See the AKD2G Faults and Warnings View for a full list of fault codes.</p> <p>AKT2G Stepper: Drive Status word (bitmask). See following table.</p> <table border="1"> <thead> <tr> <th>Bit</th> <th>Description</th> <th>Cause</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Saturated</td> <td>Drive stage operates with maximum duty cycle</td> </tr> <tr> <td>1</td> <td>Over temperature</td> <td>Internal temperature is higher than 80o C</td> </tr> <tr> <td>2</td> <td>Torque overload.</td> <td>Motor current is higher than the rated current</td> </tr> <tr> <td>3</td> <td>Under voltage.</td> <td>Motor supply voltage is 20% lower than the configured nominal voltage (warning), or Motor supply voltage is less than 8 V</td> </tr> <tr> <td>4</td> <td>Over voltage.</td> <td>Motor supply voltage is 10% higher than the configured nominal voltage</td> </tr> <tr> <td>5</td> <td>Short circuit A.</td> <td>Short circuit in motor coil A</td> </tr> <tr> <td>6</td> <td>Short circuit B</td> <td>Short circuit in motor coil B</td> </tr> <tr> <td>7</td> <td>No control power</td> <td>Control voltage at the power contacts is less than 12 V</td> </tr> <tr> <td>8</td> <td>Misc. error</td> <td>Terminal initialization failed, or supply voltage is less than 8 V, or internal terminal temperature is higher than 100°C</td> </tr> <tr> <td>9</td> <td>Configuration error</td> <td>CoE change has not yet been adopted into the current configuration</td> </tr> </tbody> </table>	Bit	Description	Cause	0	Saturated	Drive stage operates with maximum duty cycle	1	Over temperature	Internal temperature is higher than 80o C	2	Torque overload.	Motor current is higher than the rated current	3	Under voltage.	Motor supply voltage is 20% lower than the configured nominal voltage (warning), or Motor supply voltage is less than 8 V	4	Over voltage.	Motor supply voltage is 10% higher than the configured nominal voltage	5	Short circuit A.	Short circuit in motor coil A	6	Short circuit B	Short circuit in motor coil B	7	No control power	Control voltage at the power contacts is less than 12 V	8	Misc. error	Terminal initialization failed, or supply voltage is less than 8 V, or internal terminal temperature is higher than 100°C	9	Configuration error	CoE change has not yet been adopted into the current configuration
		Bit	Description	Cause																															
		0	Saturated	Drive stage operates with maximum duty cycle																															
		1	Over temperature	Internal temperature is higher than 80o C																															
		2	Torque overload.	Motor current is higher than the rated current																															
		3	Under voltage.	Motor supply voltage is 20% lower than the configured nominal voltage (warning), or Motor supply voltage is less than 8 V																															
		4	Over voltage.	Motor supply voltage is 10% higher than the configured nominal voltage																															
		5	Short circuit A.	Short circuit in motor coil A																															
		6	Short circuit B	Short circuit in motor coil B																															
		7	No control power	Control voltage at the power contacts is less than 12 V																															
8	Misc. error	Terminal initialization failed, or supply voltage is less than 8 V, or internal terminal temperature is higher than 100°C																																	
9	Configuration error	CoE change has not yet been adopted into the current configuration																																	
Data type	DINT																																		
Range																																			
Unit	N/A																																		
Fault Description	Description	Description of the Fault																																	
	Dsata type	STRING																																	
	Range	N/A																																	
	Unit	N/A																																	

6.2.0.9.3 Usage

Typical usage for this UDFB is:

- Provide drive fault information that the application program uses to determine next steps such as perform a machine-controlled stop or perform an immediate disable of the servo drives.
- In the application program send output fault information from this UDFB to the HMI for review by the machine operator.

Related Functions


- ["FB_S700FltRpt"](#) (→ p. 781)
- ["MCFB_AKDFaultLookup"](#) (→ p. 719)

6.2.0.9.4 Example

6.2.0.9.4.1 Structured Text

```
//Execute and Read the Function Block
Inst_MLFB_DriveFault(PipeNetwork.AXIS1);
Axis1Fault := Inst_MLFB_DriveFault.FAULT;
Axis1FaultNumber := Inst_MLFB_DriveFault.FaultNumber;
Axis1FaultDescription := Inst_MLFB_DriveFault.FaultDescription;
```

6.2.0.9.4.2 Ladder Diagram



6.2.0.9.4.3 Function Block Diagram



6.2.0.10 MLFB_ECATRstart Pipe Network ✓

6.2.0.10.1 Description

This function block reinitializes the EtherCAT network and the motion engine. This function blocks also clears motion engine errors, motion bus driver errors and EtherCAT network errors before reinitializing the motion engine, if requested to do so.




Figure 1-146: MLFB_ECATRstart

6.2.0.10.2 Arguments

6.2.0.10.2.1 Input

iEN	Description	ENABLES the Kollmorgen UDFB
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A
	Default	—
iRSTERR	Description	Clears the motion engine and EtherCAT network errors in case of any faults
	Data type	BOOL
	Range	[1, 256]
	Unit	[0, 1]
	Default	—

6.2.0.10.2.2 Output

oOK	Description	Function block activated status
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A
oDONE	Description	Execution Complete
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A
oERR	Description	TRUE if the system initialization fails.
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A

6.2.0.10.3 Usage

The typical use for this UDFB is to allow the EtherCAT and motion engines to restart without having to restart the entire project. Examples:

- EtherCAT network wire is replaced or accidentally disconnected
- Axis setup Parameters defined by CreateAxis and/or InitAxis function need to be changed while the application is running.

Related Functions

- ["ClearCtrlErrors"](#) (→ p. 572)
- ["MLMotionInit"](#) (→ p. 414)
- ["MLMotionRstErr"](#) (→ p. 416)
- ["MLMotionStart"](#) (→ p. 417)


6.2.0.10.4 Examples

6.2.0.10.4.1 Structured Text


```

Inst_MLFB_ECATRestart( Restart, ResetErrors );
IF Inst_MLFB_ECATRestart.oDONE THEN
    RestartComplte:=1;
End_IF;
    
```

6.2.0.10.4.2 Ladder Diagram




6.2.0.10.4.3 Function Block Diagram



6.2.0.11 MLFB_HomeFindHomeInput Pipe Network ✓

6.2.0.11.1 Description



The motor starts to move according to the direction setting. The home position has been found as soon as the home-switch becomes active during a motion in direction of the direction setting. The command position of the drive will immediately be set to the position value and the motor ramps down to velocity 0. The hardware limit switches are monitored during the homing procedure. The drive behaves as follows in case that a hardware limit switch is active before the home-switch has been activated: The motor changes the direction until the home switch is crossed. The motor ramps down to zero velocity and reverses direction again after crossing the home-switch. The home-switch will now be activated according to the direction setting and the home-position has been found. The command position of the drive will immediately be set to the position value and the motor ramps down to zero velocity.

6.2.0.11.2 Arguments

6.2.0.11.2.1 Input

ibExecute	Description	Start homing, edge-triggered
	Data type	BOOL
iAxisID	Description	ID of Axis block of Pipe Network
	Data type	DINT
iPosition	Description	Reference position

	Data type	LREAL
ibDirection	Description	0=positive, 1=negative
	Data type	BOOL
iVelocity	Description	Reference speed
	Data type	LREAL
iAcceleration	Description	Reference acceleration
	Data type	LREAL
iDeceleration	Description	Reference deceleration
	Data type	LREAL
ibHomeInput	Description	Home input, high-active
	Data type	BOOL
ibPosLimitSwitch	Description	Positive limit switch, high-active
	Data type	BOOL
ibNegLimitSwitch	Description	Negative limit switch, high-active
	Data type	BOOL
iTimeout	Description	Time monitoring (T#0ms: off)
	Data type	TIME

6.2.0.11.2.2 Output

obDone	Description	Done bit												
	Data type	BOOL												
obActive	Description	Active bit												
	Data type	BOOL												
obError	Description	Error bit												
	Data type	BOOL												
oErrorID	Description	Error identifier, see list here												
		<table border="1"> <thead> <tr> <th>ErrorID</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Axis in error</td> </tr> <tr> <td>2</td> <td>Axis not enabled</td> </tr> <tr> <td>3</td> <td>Timeout expired</td> </tr> <tr> <td>4</td> <td>SDO read/write error</td> </tr> <tr> <td>5</td> <td>Input parameter out of range</td> </tr> </tbody> </table>	ErrorID	Description	1	Axis in error	2	Axis not enabled	3	Timeout expired	4	SDO read/write error	5	Input parameter out of range
ErrorID	Description													
1	Axis in error													
2	Axis not enabled													
3	Timeout expired													
4	SDO read/write error													
5	Input parameter out of range													
	Data type	DINT												

6.2.0.11.3 Example


6.2.0.11.3.1 ST

```


//Call homing function on Axis1 with preset velocity, accel, and decel
values
//Start in negative direction, change if limit switch seen before home
switch
//after seeing home switch, set axis position to zero
Inst_MLFB_HomeFindHomeInput( StartHomeRoutine,
    PipeNetwork.AXIS1,
    0,
    TRUE,
    100,
    1000,
    1000,
    HomeDigitalInput,
    PositiveLimitSwitch,
    NegativeLimitSwitch,
    T#30s );

HomeDone := Inst_MLFB_HomeFindHomeInput.obDone;
    
```

6.2.0.11.3.2 Function Block Diagram




6.2.0.11.3.3 FFLD



6.2.0.12 MLFB_HomeFindHomeInputThenZeroAngle Pipe Network ✓

6.2.0.12.1 Description



Similar to the Find Home Limit method, the find input home then find zero angle. Mode follows the same steps, but upon completion of the move, it continues to move to find the zero angle reference of the motor.

6.2.0.12.2 Arguments

6.2.0.12.2.1 Input

ibExecute	Description	Start homing, edge-triggered
	Data type	BOOL
iAxisID	Description	ID of Axis block of Pipe Network
	Data type	DINT
iPosition	Description	Reference position
	Data type	LREAL
ibDirection	Description	0=positive, 1=negative
	Data type	BOOL
iVelocity	Description	Reference speed
	Data type	LREAL
iAcceleration	Description	Reference acceleration
	Data type	LREAL
iDeceleration	Description	Reference deceleration
	Data type	LREAL
ibHomeInput	Description	Home input, high-active
	Data type	BOOL
ibPosLimitSwitch	Description	Positive limit switch, high-active
	Data type	BOOL
ibNegLimitSwitch	Description	Negative limit switch, high-active
	Data type	BOOL
iTimeout	Description	Time monitoring (T#0ms: off)
	Data type	TIME

6.2.0.12.2.2 Output

obDone	Description	Done bit												
	Data type	BOOL												
obActive	Description	Active bit												
	Data type	BOOL												
obError	Description	Error bit												
	Data type	BOOL												
oErrorID	Description	Error identifier, see list here												
		<table border="1"> <thead> <tr> <th>ErrorID</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Axis in error</td> </tr> <tr> <td>2</td> <td>Axis not enabled</td> </tr> <tr> <td>3</td> <td>Timeout expired</td> </tr> <tr> <td>4</td> <td>SDO read/write error</td> </tr> <tr> <td>5</td> <td>Input parameter out of range</td> </tr> </tbody> </table>	ErrorID	Description	1	Axis in error	2	Axis not enabled	3	Timeout expired	4	SDO read/write error	5	Input parameter out of range
ErrorID	Description													
1	Axis in error													
2	Axis not enabled													
3	Timeout expired													
4	SDO read/write error													
5	Input parameter out of range													
	Data type	DINT												

6.2.0.12.3 Example


6.2.0.12.3.1 ST

```


//Call homing function on Axis1 with preset velocity, accel, and decel
values
//Start in negative direction, change if limit switch seen before home
switch
//after seeing home switch and moving to zero angle, set axis position to
zero
Inst_MLFB_HomeFindHomeInputThenZeroAngle( StartHomeRoutine,
    PipeNetwork.AXIS1,
    0,
    TRUE,
    100,
    1000,
    1000,
    HomeDigitalInput,
    PositiveLimitSwitch,
    NegativeLimitSwitch,
    T#30s );

HomeDone := Inst_MLFB_HomeFindHomeInputThenZeroAngle.obDone;
    
```

6.2.0.12.3.2 Function Block Diagram




6.2.0.12.3.3 FFLD



6.2.0.13 MLFB_HomeFindLimitInput Pipe Network ✓

6.2.0.13.1 Description



The find limit input mode moves to a limit input. This method can be used if you have a positive or negative limit switch available that you want to establish as a home reference point.

6.2.0.13.2 Arguments

6.2.0.13.2.1 Input

ibExecute	Description	Start homing, edge-triggered
	Data type	BOOL
iAxisID	Description	ID of Axis block of Pipe Network
	Data type	DINT
iPosition	Description	Reference position

	Data type	LREAL
ibDirection	Description	0=positive, 1=negative
	Data type	BOOL
iVelocity	Description	Reference speed
	Data type	LREAL
iAcceleration	Description	Reference acceleration
	Data type	LREAL
iDeceleration	Description	Reference deceleration
	Data type	LREAL
ibLimitSwitch	Description	Pos. or neg. limit switch, high-active (depends on ibDirection)
	Data type	BOOL
iTimeout	Description	Time monitoring (T#0ms: off)
	Data type	TIME

6.2.0.13.2.2 Output

obDone	Description	Done bit												
	Data type	BOOL												
obActive	Description	Active bit												
	Data type	BOOL												
obError	Description	Error bit												
	Data type	BOOL												
oErrorID	Description	Error identifier, see list here												
		<table border="1"> <thead> <tr> <th>ErrorID</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Axis in error</td> </tr> <tr> <td>2</td> <td>Axis not enabled</td> </tr> <tr> <td>3</td> <td>Timeout expired</td> </tr> <tr> <td>4</td> <td>SDO read/write error</td> </tr> <tr> <td>5</td> <td>Input parameter out of range</td> </tr> </tbody> </table>	ErrorID	Description	1	Axis in error	2	Axis not enabled	3	Timeout expired	4	SDO read/write error	5	Input parameter out of range
ErrorID	Description													
1	Axis in error													
2	Axis not enabled													
3	Timeout expired													
4	SDO read/write error													
5	Input parameter out of range													
	Data type	DINT												

6.2.0.13.3 Example

6.2.0.13.3.1 ST


```
//Call homing function on Axis1 with preset velocity, accel, and decel
values
//Start in negative direction and stop when axis hits limit switch or
```

```


times out
//after seeing limit switch, set axis position to zero
Inst_MLFB_HomeFindLimitInput( StartHomeRoutine,
    PipeNetwork.AXIS1,
    0,
    TRUE,
    100,
    1000,
    1000,
    HomeDigitalInput,
    T#30s );

HomeDone := Inst_MLFB_HomeFindLimitInput.obDone;
    
```

6.2.0.13.3.2 Function Block Diagram




6.2.0.13.3.3 FFLD



6.2.0.14 MLFB_HomeFindLimitInputThenZeroAngle Pipe Network ✓

6.2.0.14.1 Description



Similar to the Find Input Limit method, the find input limit then find zero angle. Mode follows the same steps, but upon completion of the move, it continues to move to find the zero angle reference of the motor.

6.2.0.14.2 Arguments

6.2.0.14.2.1 Input

ibExecute	Description	Start homing, edge-triggered
	Data type	BOOL
iAxisID	Description	ID of Axis block of Pipe Network
	Data type	BOOL
iPosition	Description	Reference position
	Data type	BOOL
ibDirection	Description	0=positive, 1=negative
	Data type	BOOL
iVelocity	Description	Reference speed
	Data type	BOOL
iAcceleration	Description	Reference acceleration
	Data type	BOOL
iDeceleration	Description	Reference deceleration
	Data type	BOOL
ibLimitSwitch	Description	Pos. or neg. limit switch, high-active (depends on ibDirection)
	Data type	BOOL
iTimeout	Description	Time monitoring (T#0ms: off)
	Data type	BOOL

6.2.0.14.2.2 Output

obDone	Description	Done bit
	Data type	BOOL
obActive	Description	Active bit
	Data type	BOOL
obError	Description	Error bit
	Data type	BOOL
oErrorID	Description	Error identifier, see list here

ErrorID	Description
1	Axis in error
2	Axis not enabled
3	Timeout expired
4	SDO read/write error
5	Input parameter out of range

Data type DINT

6.2.0.14.3 Example

6.2.0.14.3.1 ST


```
//Call homing function on Axis1 with preset velocity, accel, and decel values
//Start in negative direction and stop when axis hits limit switch or times out
//after seeing limit switch, moves to zero angle and set axis position to zero
Inst_MLFB_HomeFindLimitInputThenZeroAngle( StartHomeRoutine,
PipeNetwork.AXIS1,
0,
```

```


TRUE,
100,
1000,
1000,
HomeDigitalInput,
T#30s );

HomeDone := Inst_MLFB_HomeFindLimitInputThenZeroAngle.obDone;
    
```

6.2.0.14.3.2 Function Block Diagram




6.2.0.14.3.3 FFLD



6.2.0.15 MLFB_HomeFindZeroAngle Pipe Network ✓

6.2.0.15.1 Description



1. Start Position
2. End Position (Zero degrees)

Figure 1-147: Mode to find the zero angle reference of the motor.

NOTE

This function block is only applicable to motors with Resolver or SFD feedback.

6.2.0.15.2 Arguments

6.2.0.15.2.1 Input

ibExecute	Description	Start homing, edge-triggered
	Data type	BOOL
iAxisID	Description	ID of Axis block of Pipe Network
	Data type	DINT
iPosition	Description	Reference position
	Data type	LREAL
iDirectionType	Description	0=positive, 1=negative, 2=shortest
	Data type	DINT
iVelocity	Description	Reference speed
	Data type	LREAL
iAcceleration	Description	Reference acceleration
	Data type	LREAL
iDeceleration	Description	Reference deceleration
	Data type	LREAL
iTimeout	Description	Time monitoring (T#0ms: off)
	Data type	TIME

6.2.0.15.2.2 Output

obDone	Description	Done bit												
	Data type	BOOL												
obActive	Description	Active bit												
	Data type	BOOL												
obError	Description	Error bit												
	Data type	BOOL												
oErrorID	Description	Error identifier, see list here												
		<table border="1"> <thead> <tr> <th>ErrorID</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Axis in error</td> </tr> <tr> <td>2</td> <td>Axis not enabled</td> </tr> <tr> <td>3</td> <td>Timeout expired</td> </tr> <tr> <td>4</td> <td>SDO read/write error</td> </tr> <tr> <td>5</td> <td>Input parameter out of range</td> </tr> </tbody> </table>	ErrorID	Description	1	Axis in error	2	Axis not enabled	3	Timeout expired	4	SDO read/write error	5	Input parameter out of range
ErrorID	Description													
1	Axis in error													
2	Axis not enabled													
3	Timeout expired													
4	SDO read/write error													
5	Input parameter out of range													
	Data type	DINT												

6.2.0.15.3 Example


6.2.0.15.3.1 ST

```


//Call homing function on Axis1 with preset velocity, accel, and decel
//values
//Start in negative direction and go to zero angle or time out
//after reaching zero angle set axis position to zero
Inst_MLFB_HomeFindZeroAngle( StartHomeRoutine,
PipeNetwork.AXIS1,
0,
1,
100,
1000,
1000,
T#30s );

HomeDone := Inst_MLFB_HomeFindZeroAngle.obDone;
    
```

6.2.0.15.3.2 Function Block Diagram




6.2.0.15.3.3 FFLD



6.2.0.16 MLFB_HomeMoveUntilPosErrExceeded Pipe Network ✓

6.2.0.16.1 Description



When executed, the motor will move to the hard stop with a definable peak current. When the position error exceeds, the home Position is set.

6.2.0.16.2 Arguments

6.2.0.16.2.1 Input

ibExecute	Description	Start homing, edge-triggered
	Data type	BOOL
iAxisID	Description	ID of Axis block of Pipe Network
	Data type	DINT
iPosition	Description	Reference position
	Data type	LREAL
ibDirection	Description	0=positive, 1=negative
	Data type	BOOL
iVelocity	Description	Reference speed
	Data type	LREAL
iAcceleration	Description	Reference acceleration
	Data type	LREAL
iDeceleration	Description	Reference deceleration
	Data type	LREAL
iMaxPositionError	Description	Maximum position error
	Data type	LREAL
iPeakCurrent	Description	Peak current in mA
	Data type	DINT
iTimeout	Description	Time monitoring (T#0ms: off)
	Data type	TIME

6.2.0.16.2.2 Output

obDone	Description	Done bit
	Data type	BOOL
obActive	Description	Active bit
	Data type	BOOL
obError	Description	Error bit
	Data type	BOOL
oErrorID	Description	Error identifier, see list here

ErrorID	Description
1	Axis in error
2	Axis not enabled
3	Timeout expired
4	SDO read/write error
5	Input parameter out of range

Data type DINT

6.2.0.16.3 Example

6.2.0.16.3.1 ST


```
//Call homing function on Axis1 with preset velocity, accel, and decel
values
//Start in negative direction and go until position error exceeds input
value or time out
//afterwards set axis position to zero
//function block temporarily writes new max current value to 2 Amp while
home routine active
Inst_MLFB_HomeMoveUntilPosErrExceeded( StartHomeRoutine,
```

```


PipeNetwork.AXIS1,
0,
1,
100,
1000,
1000,
MaxPosError,
2000,
T#30s );

HomeDone := Inst_MLFB_HomeMoveUntilPosErrExceeded.obDone;
    
```

6.2.0.16.3.2 Function Block Diagram




6.2.0.16.3.3 FFLD



6.2.0.17 MLFB_HomeMoveUntilPosErrExceededThenZeroAngle Pipe Network

6.2.0.17.1 Description



Similar to the Move Until Position Error Exceeded method, the move until position error exceeded then find zero angle. Mode follows the same steps, but upon completion of the move, it continues to move to find the zero angle reference of the motor.

6.2.0.17.2 Arguments

6.2.0.17.2.1 Input

ibExecute	Description	Start homing, edge-triggered
	Data type	BOOL
iAxisID	Description	ID of Axis block of Pipe Network
	Data type	DINT
iPosition	Description	Reference position
	Data type	LREAL
ibDirection	Description	0=positive, 1=negative
	Data type	BOOL
iVelocity	Description	Reference speed
	Data type	LREAL
iAcceleration	Description	Reference acceleration
	Data type	LREAL
iDeceleration	Description	Reference deceleration
	Data type	LREAL
iMaxPositionError	Description	Maximum position error
	Data type	LREAL
iPeakCurrent	Description	Peak current in mA
	Data type	DINT
iTimeout	Description	Time monitoring (T#0ms: off)
	Data type	TIME

6.2.0.17.2.2 Output

obDone	Description	Done bit
	Data type	BOOL
obActive	Description	Active bit
	Data type	BOOL
obError	Description	Error bit
	Data type	BOOL

oErrorID	Description	Error identifier, see list here												
		<table border="1"> <thead> <tr> <th>ErrorID</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Axis in error</td> </tr> <tr> <td>2</td> <td>Axis not enabled</td> </tr> <tr> <td>3</td> <td>Timeout expired</td> </tr> <tr> <td>4</td> <td>SDO read/write error</td> </tr> <tr> <td>5</td> <td>Input parameter out of range</td> </tr> </tbody> </table>	ErrorID	Description	1	Axis in error	2	Axis not enabled	3	Timeout expired	4	SDO read/write error	5	Input parameter out of range
ErrorID	Description													
1	Axis in error													
2	Axis not enabled													
3	Timeout expired													
4	SDO read/write error													
5	Input parameter out of range													
	Data type	DINT												

6.2.0.17.3 Example

6.2.0.17.3.1 ST


```

//Call homing function on Axis1 with preset velocity, accel, and decel
values
//Start in negative direction and go until position error exceeds input
value or time out
//afterterwards moves to zero angle and sets axis position to zero
//function block temporarily writes new max current value to 2 Amp while
home routine active
Inst_MLFB_HomeMoveUntilPosErrExceededThenZeroAngle( StartHomeRoutine,
  PipeNetwork.AXIS1,
  0,
  1,
  100,
  1000,
  1000,
  MaxPosError,
  2000,
  T#30s );


HomeDone := Inst_MLFB_HomeMoveUntilPosErrExceededThenZeroAngle.obDone;

```

6.2.0.17.3.2 Function Block Diagram




6.2.0.17.3.3 FFLD



6.2.0.18 MLFB_HomeUsingCurrentPosition Pipe Network ✓

6.2.0.18.1 Description



Using the current position is the most basic homing method. This method simply uses the current position of the motor as the home point reference.

You can use this parameter to set the value of the home position other than zero. This allows you to offset your home reference away from zero.

6.2.0.18.2 Arguments

6.2.0.18.2.1 Input

ibExecute	Description Data type	Start homing, edge-triggered BOOL
iAxisID	Description Data type	ID of Axis block of Pipe Network DINT
iPosition	Description Data type	Reference position LREAL

6.2.0.18.2.2 Output

obDone	Description Data type	Done bit BOOL
obActive	Description Data type	Active bit BOOL
obError	Description Data type	Error bit BOOL

oErrorID Description Error identifier, see list here

ErrorID	Description
1	Axis in error
2	Axis not enabled
3	Timeout expired
4	SDO read/write error
5	Input parameter out of range


Data type DINT

6.2.0.18.3 Example


6.2.0.18.3.1 ST

```
//No movement, set current axis position to position input in this case
zero
Inst_MLFB_HomeUsingCurrentPosition( StartHomeRoutine, PipeNetwork.AXIS1,
0 );
HomeDone := Inst_MLFB_HomeUsingCurrentPosition.obDone;
```

6.2.0.18.3.2 Function Block Diagram



6.2.0.18.3.3 FFLD



6.2.0.19 MLFB_HomeFindHomeFastInput Pipe Network ✓

6.2.0.19.1 Description

This function block performs a single-axis home to a limit switch connected to a High Speed Input. The motor starts to move according to the direction setting. The home position has been found as soon as the fast input selected is triggered on the edge selected.

An absolute move is made to the triggered position, and then the position value is set. The hardware limit switches are monitored during the homing procedure.

The drive behaves as follows in case that a hardware limit switch is active before the home-switch has been activated: The motor changes the direction until the home switch is crossed.

The following figure shows the function block I/O:




Figure 1-148: MLFB HomeFindHomeFastInput

6.2.0.19.2 Arguments

6.2.0.19.2.1 Input

ibExecute	Description	Request the homing step procedure at rising edge
	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A
	Default	—
iAxisID	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	[1 , 256]
	Unit	N/A
	Default	—
iPosition	Description	Offset Position Applied After Home Switch is found
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

ibDirection	Description	Define the axis homing direction						
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>clockwise rotation</td> </tr> <tr> <td>1</td> <td>counterclockwise rotation</td> </tr> </tbody> </table>	Value	Description	0	clockwise rotation	1	counterclockwise rotation
	Value	Description						
	0	clockwise rotation						
	1	counterclockwise rotation						
Data type	BOOL							
Range	[0, 1]							
Unit	N/A							
	Default	—						
iVelocity	Description	Commanded velocity for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec						
	Default	—						
iAcceleration	Description	Commanded acceleration for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec ²						
	Default	—						
iDeceleration	Description	Commanded deceleration for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec ²						
	Default	—						
ibHomeSwitchMode	Description	Limit switch state to complete homing						
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Rising edge of switch</td> </tr> <tr> <td>1</td> <td>Falling edge of switch</td> </tr> </tbody> </table>	Value	Description	0	Rising edge of switch	1	Falling edge of switch
	Value	Description						
	0	Rising edge of switch						
	1	Falling edge of switch						
Data type	BOOL							
Range	[0, 1]							
Unit	N/A							
	Default	—						
ibPosLimitSwitch	Description	The positive direction limit switch input I/O point						

	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						
ibNegLimitSwitch	Description	The negative direction limit switch input I/O point						
	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						
iTimeout	Description	Maximum time for homing move to complete. If exceeded the homing procedure will error out. 0= no time limit						
	Data type	TIME						
	Range	—						
	Unit	sec						
	Default	—						
ibFastInputNumber	Description	Limit switch state to complete homing.						
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Fast Input Number 1</td> </tr> <tr> <td>1</td> <td>Fast Input Number 2</td> </tr> </tbody> </table>	Value	Description	0	Fast Input Number 1	1	Fast Input Number 2
Value	Description							
0	Fast Input Number 1							
1	Fast Input Number 2							
	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						
iCycleTime	Description	Ethercat Cycle Time 250, 500 or 1000						
	Data type	LREAL						
	Range	—						
	Unit	microseconds						
	Default	—						

6.2.0.19.2.2 Output


obDone	Description	Indicates the move completed successfully. The Command Position has reached the endpoint
	Data type	BOOL

	Unit	N/A												
obActive	Description	Indicates this move is the active move												
	Data type	BOOL												
	Unit	N/A												
obError	Description	Indicates an invalid input was specified or the move was terminated due to an error												
	Data type	BOOL												
	Unit	N/A												
oErrorID	Description	Indicates the error if Error output is set to TRUE												
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Axis in Error State</td> </tr> <tr> <td>2</td> <td>Axis is Not Enabled</td> </tr> <tr> <td>3</td> <td>Timeout Exceeded</td> </tr> <tr> <td>4</td> <td>SDO Read/Write Error</td> </tr> <tr> <td>5</td> <td>Input Parameter out of Range</td> </tr> </tbody> </table>	Value	Description	1	Axis in Error State	2	Axis is Not Enabled	3	Timeout Exceeded	4	SDO Read/Write Error	5	Input Parameter out of Range
Value	Description													
1	Axis in Error State													
2	Axis is Not Enabled													
3	Timeout Exceeded													
4	SDO Read/Write Error													
5	Input Parameter out of Range													
	Data type	DINT												
	Unit	N/A												

6.2.0.19.3 Usage

This homing procedure performs a homing function searching for sensor using only High Speed Input Switches. (A High Speed Limit Switch has 1 "Off" (or "On") area).

- Home is commanded by user in the desired homing direction at the selected Velocity
- If LimitSwitch is found 'On' on rising 'Execute', then the process is started in the opposite direction as specified, LimitSwitch is search for 'Off' (or On, depending on LimitSwitchMode setting) Edge (released), and process is restarted again in original direction. This ensures that the end conditions are always the same
- The Timeout can cause an error if exceeded



6.2.0.19.4 Related Functions

[MLFB_HomeFindHomeFastInputModulo](#)

[MLFB_HomeFindLimitFastInput](#)

[MLFB_HomeFindLimitFastInputModulo](#)

6.2.0.19.5 Example

6.2.0.19.5.1 Structured Text


```
Direction:= 0;
Position:=1000;
Velocity:=1000;
Acceleration:=10000;
Deceleration:=10000;
SwitchMode:=0;
Timeout:=T#100;
FastInputNumber:=0;
CycleTime:=1000;

inst_fbHomeFindHomeFastInput(True, Axis1, Position, Direction,
Velocity, Acceleration, Deceleration, HomeSwitchMode,
PosLimitSwitch, NegLimitSwitch, Timeout, FastInputNumber,
CycleTime);


HomeComplete :=inst_fbHomeFindHomeFastInput.Done;
HomeActive :=inst_fbHomeFindHomeFastInput.Active;
HomeError :=inst_fbHomeFindHomeFastInput.Error;
HomeErrorID :=inst_fbHomeFindHomeFastInput.ErrorID;

(* PosLimitSwitch and NegLimitSwtch are declared I/O points *)
```

6.2.0.19.5.2 Ladder Diagram



6.2.0.19.5.3 Function Block Diagram



6.2.0.20 MLFB_HomeFindHomeFastInputModulo Pipe Network ✓

6.2.0.20.1 Description

This Application Specific Function function block performs a single-axis home to a limit switch connected to a High Speed Input. The motor starts to move according to the direction setting. The home position has been found as soon as the fast input selected is triggered on the edge selected.

An absolute move is made to the triggered position, and then the position value is set. The hardware limit switches are monitored during the homing procedure.

The drive behaves as follows in case that a hardware limit switch is active before the home-switch has been activated: The motor changes the direction until the home switch is crossed. This function is to be used when the axis is set-up in Modulo mode.

The following figure shows the function block I/O:




Figure 1-149: MLFB HomeFindHomeFastInputModulo

6.2.0.20.2 Arguments

6.2.0.20.2.1 Input

ibExecute	Description	Request the homing step procedure at rising edge
	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A
	Default	—
iAxisID	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	[1 , 256]
	Unit	N/A
	Default	—
iPosition	Description	Offset Position Applied After Home Switch is found
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

ibDirection	Description	Define the axis homing direction						
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>clockwise rotation</td> </tr> <tr> <td>1</td> <td>counterclockwise rotation</td> </tr> </tbody> </table>	Value	Description	0	clockwise rotation	1	counterclockwise rotation
	Value	Description						
	0	clockwise rotation						
	1	counterclockwise rotation						
Data type	BOOL							
Range	[0, 1]							
Unit	N/A							
	Default	—						
iVelocity	Description	Commanded velocity for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec						
	Default	—						
iAcceleration	Description	Commanded acceleration for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec ²						
	Default	—						
iDeceleration	Description	Commanded deceleration for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec ²						
	Default	—						
ibLimitSwitchMode	Description	Limit switch state to complete homing						
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Rising edge of switch</td> </tr> <tr> <td>1</td> <td>Falling edge of switch</td> </tr> </tbody> </table>	Value	Description	0	Rising edge of switch	1	Falling edge of switch
	Value	Description						
	0	Rising edge of switch						
	1	Falling edge of switch						
Data type	BOOL							
Range	[0, 1]							
Unit	N/A							
	Default	—						
ibPosLimitSwitch	Description	The positive direction limit switch input I/O point						

	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						
ibNegLimitSwitch	Description	The negative direction limit switch input I/O point						
	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						
iTimeout	Description	Maximum time for homing move to complete. If exceeded the homing procedure will error out. 0= no time limit						
	Data type	TIME						
	Range	—						
	Unit	sec						
	Default	—						
ibFastInputNumber	Description	Limit switch state to complete homing.						
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Fast Input Number 1</td> </tr> <tr> <td>1</td> <td>Fast Input Number 2</td> </tr> </tbody> </table>	Value	Description	0	Fast Input Number 1	1	Fast Input Number 2
Value	Description							
0	Fast Input Number 1							
1	Fast Input Number 2							
	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						
iCycleTime	Description	Ethercat Cycle Time 250, 500 or 1000						
	Data type	LREAL						
	Range	—						
	Unit	microseconds						
	Default	—						

6.2.0.20.2.2 Output


obDone	Description	Indicates the move completed successfully. The Command Position has reached the endpoint
	Data type	BOOL

	Unit	N/A												
obActive	Description	Indicates this move is the active move												
	Data type	BOOL												
	Unit	N/A												
obError	Description	Indicates an invalid input was specified or the move was terminated due to an error												
	Data type	BOOL												
	Unit	N/A												
oErrorID	Description	Indicates the error if Error output is set to TRUE												
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Axis in Error State</td> </tr> <tr> <td>2</td> <td>Axis is Not Enabled</td> </tr> <tr> <td>3</td> <td>Timeout Exceeded</td> </tr> <tr> <td>4</td> <td>SDO Read/Write Error</td> </tr> <tr> <td>5</td> <td>Input Parameter out of Range</td> </tr> </tbody> </table>	Value	Description	1	Axis in Error State	2	Axis is Not Enabled	3	Timeout Exceeded	4	SDO Read/Write Error	5	Input Parameter out of Range
Value	Description													
1	Axis in Error State													
2	Axis is Not Enabled													
3	Timeout Exceeded													
4	SDO Read/Write Error													
5	Input Parameter out of Range													
	Data type	DINT												
	Unit	N/A												

6.2.0.20.3 Usage

This homing procedure performs a homing function searching for sensor using only High Speed Input Switches. (A High Speed Limit Switch has 1 "Off" (or "On") area).

- Home is commanded by user in the desired homing direction at the selected Velocity
- If LimitSwitch is found 'On' on rising 'Execute', then the process is started in the opposite direction as specified, LimitSwitch is search for 'Off' (or On, depending on LimitSwitchMode setting) Edge (released), and process is restarted again in original direction. This ensures that the end conditions are always the same
- The Timeout can cause an error if exceeded



6.2.0.20.4 Related Functions

[MLFB_HomeFindHomeFastInput](#)

[MLFB_HomeFindLimitFastInput](#)

[MLFB_HomeFindLimitFastInputModulo](#)

6.2.0.20.5 Example

6.2.0.20.5.1 Structured Text


```
Direction:= 0;
Position:=1000;
Velocity:=1000;
Acceleration:=10000;
Deceleration:=10000;
SwitchMode:=0;
Timeout:=T#100;
FastInputNumber:=0;
CycleTime:=1000;

inst_fbHomeFindHomeFastInputModulo(True, Axis1, Position,
Direction, Velocity, Acceleration, Deceleration, PosLimitSwitch,
NegLimitSwitch, Timeout, FastInputNumber, CycleTime);


HomeComplete :=inst_fbHomeFindHomeFastInputModulo.Done;
HomeActive :=inst_fbHomeFindHomeFastInputModulo.Active;
HomeError :=inst_fbHomeFindHomeFastInputModulo.Error;
HomeErrorID :=inst_fbHomeFindHomeFastInputModulo.ErrorID;

(* PosLimitSwitch and NegLimitSwtch are declared I/O points *)
```

6.2.0.20.5.2 Ladder Diagram



6.2.0.20.5.3 Function Block Diagram



6.2.0.21 MLFB_HomeFindLimitFastInput Pipe Network ✓

6.2.0.21.1 Description

This function block performs a single-axis home to a limit switch connected to a High Speed Input. The motor starts to move according to the direction setting. The home position has been found as soon as the fast input selected is triggered on the edge selected.

An absolute move is made to the triggered position, and then the position value is set.

The following figure shows the function block I/O:




Figure 1-150: MLFB HomeFindLimitFastInput

6.2.0.21.2 Arguments

6.2.0.21.2.1 Input

ibExecute	Description	Request the homing step procedure at rising edge
	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A
	Default	—
iAxisID	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	[1 , 256]
	Unit	N/A
	Default	—
iPosition	Description	Offset Position Applied After Home Switch is found
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
ibDirection	Description	Define the axis homing direction
	Value	Description
	0	clockwise rotation
	1	counterclockwise rotation

	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						
iVelocity	Description	Commanded velocity for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec						
	Default	—						
iAcceleration	Description	Commanded acceleration for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec ²						
	Default	—						
ibLimitSwitchMode	Description	Limit switch state to complete homing						
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Rising edge of switch</td> </tr> <tr> <td>1</td> <td>Falling edge of switch</td> </tr> </tbody> </table>	Value	Description	0	Rising edge of switch	1	Falling edge of switch
Value	Description							
0	Rising edge of switch							
1	Falling edge of switch							
	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						
ibFastInputNumber	Description	Limit switch state to complete homing.						
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Fast Input Number 1</td> </tr> <tr> <td>1</td> <td>Fast Input Number 2</td> </tr> </tbody> </table>	Value	Description	0	Fast Input Number 1	1	Fast Input Number 2
Value	Description							
0	Fast Input Number 1							
1	Fast Input Number 2							
	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						
iCycleTime	Description	Ethercat Cycle Time 250, 500 or 1000						
	Data type	LREAL						

Range	—
Unit	microseconds
Default	—


6.2.0.21.2.2 Output

obDone	Description	Indicates the move completed successfully. The Command Position has reached the endpoint												
	Data type	BOOL												
	Unit	N/A												
obActive	Description	Indicates this move is the active move												
	Data type	BOOL												
	Unit	N/A												
obError	Description	Indicates an invalid input was specified or the move was terminated due to an error												
	Data type	BOOL												
	Unit	N/A												
oErrorID	Description	Indicates the error if Error output is set to TRUE												
	Data type	DINT												
	Unit	N/A												
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Axis in Error State</td> </tr> <tr> <td>2</td> <td>Axis is Not Enabled</td> </tr> <tr> <td>3</td> <td>Timeout Exceeded</td> </tr> <tr> <td>4</td> <td>SDO Read/Write Error</td> </tr> <tr> <td>5</td> <td>Input Parameter out of Range</td> </tr> </tbody> </table>	Value	Description	1	Axis in Error State	2	Axis is Not Enabled	3	Timeout Exceeded	4	SDO Read/Write Error	5	Input Parameter out of Range
Value	Description													
1	Axis in Error State													
2	Axis is Not Enabled													
3	Timeout Exceeded													
4	SDO Read/Write Error													
5	Input Parameter out of Range													

6.2.0.21.3 Usage

This homing procedure performs a homing function searching for sensor using only High Speed Input Switches. (A High Speed Limit Switch has 1 "Off" (or "On") area).

- Home is commanded by user in the desired homing direction at the selected Velocity.
- The Timeout can cause an error if exceeded



6.2.0.21.4 Related Functions

[MLFB_HomeFindHomeFastInput](#)

[MLFB_HomeFindHomeFastInputModulo](#)

[MLFB_HomeFindLimitFastInputModulo](#)

6.2.0.21.5 Example


6.2.0.21.5.1 Structured Text

```
Direction:= 0;
Position:=1000;
Velocity:=1000;
Acceleration:=10000;
Deceleration:=10000;
SwitchMode:=0;
Timeout:=T#100;
FastInputNumber:=0;
CycleTime:=1000;


inst_fbHomeFindLimitFastInput(True, Axis1, Position, Direction,
Velocity, Acceleration, Deceleration, LimitSwitchMode, Timeout,
FastInputNumber, CycleTime);

HomeComplete :=inst_fbHomeFindLimitFastInput.Done;
HomeActive :=inst_fbHomeFindLimitFastInput.Active;
HomeError :=inst_fbHomeFindLimitFastInput.Error;
HomeErrorID :=inst_fbHomeFindLimitFastInput.ErrorID;
```

6.2.0.21.5.2 Ladder Diagram



6.2.0.21.5.3 Function Block Diagram



6.2.0.22 MLFB_HomeFindLimitFastInputModulo Pipe Network ✓

6.2.0.22.1 Description

This function block performs a single-axis home to a limit switch connected to a High Speed Input. The motor starts to move according to the direction setting. The home position has been found as soon as the fast input selected is triggered on the edge selected.

An absolute move is made to the triggered position, and then the position value is set. This function is to be used when the axis is set-up in Modulo mode.

The following figure shows the function block I/O:




Figure 1-151: MLFB HomeFindLimitFastInputModule

6.2.0.22.2 Arguments

6.2.0.22.2.1 Input

ibExecute	Description	Request the homing step procedure at rising edge						
	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						
iAxisID	Description	Name of a declared instance of the AXIS_REF library function						
	Data type	AXIS_REF						
	Range	[1 , 256]						
	Unit	N/A						
	Default	—						
iPosition	Description	Offset Position Applied After Home Switch is found						
	Data type	LREAL						
	Range	—						
	Unit	User unit						
ibDirection	Description	Define the axis homing direction						
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>clockwise rotation</td> </tr> <tr> <td>1</td> <td>counterclockwise rotation</td> </tr> </tbody> </table>	Value	Description	0	clockwise rotation	1	counterclockwise rotation
	Value	Description						
	0	clockwise rotation						
	1	counterclockwise rotation						
Data type	BOOL							
Range	[0 , 1]							
Unit	N/A							
iVelocity	Description	Commanded velocity for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec						
	Default	—						

iAcceleration	Description	Commanded acceleration for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec ²						
iDeceleration	Default	—						
	Description	Commanded deceleration for the homing move						
	Data type	LREAL						
	Range	—						
ibLimitSwitchMode	Unit	User unit/sec ²						
	Default	—						
	Description	Limit switch state to complete homing						
	<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Rising edge of switch</td> </tr> <tr> <td>1</td> <td>Falling edge of switch</td> </tr> </tbody> </table>		Value	Description	0	Rising edge of switch	1	Falling edge of switch
Value	Description							
0	Rising edge of switch							
1	Falling edge of switch							
iTimeout	Data type	BOOL						
	Range	[0, 1]						
	Unit	N/A						
	Default	—						
ibFastInputNumber	Description	Maximum time for homing move to complete. If exceeded the homing procedure will error out. 0= no time limit						
	Data type	TIME						
	Range	—						
	Unit	sec						
ibFastInputNumber	Default	—						
	Description	Limit switch state to complete homing.						
	<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Fast Input Number 1</td> </tr> <tr> <td>1</td> <td>Fast Input Number 2</td> </tr> </tbody> </table>		Value	Description	0	Fast Input Number 1	1	Fast Input Number 2
	Value	Description						
0	Fast Input Number 1							
1	Fast Input Number 2							
Data type	BOOL							
iCycleTime	Range	[0, 1]						
	Unit	N/A						
	Default	—						
	Description	Ethercat Cycle Time 250, 500 or 1000						
iCycleTime	Data type	LREAL						
	Range	—						
	Unit	microseconds						
	Default	—						

6.2.0.22.2.2 Output


obDone	Description	Indicates the move completed successfully. The Command Position has reached the endpoint
	Data type	BOOL
	Unit	N/A
obActive	Description	Indicates this move is the active move
	Data type	BOOL
	Unit	N/A
obError	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
	Unit	N/A

oErrorID	Description	Indicates the error if Error output is set to TRUE	
		Value	Description
		1	Axis in Error State
		2	Axis is Not Enabled
		3	Timeout Exceeded
		4	SDO Read/Write Error
		5	Input Parameter out of Range
	Data type	DINT	
	Unit	N/A	

6.2.0.22.3 Usage

This homing procedure performs a homing function searching for sensor using only High Speed Input Switches. (A High Speed Limit Switch has 1 "Off" (or "On") area).

- Home is commanded by user in the desired homing direction at the selected Velocity.
- The Timeout can cause an error if exceeded



6.2.0.22.4 Related Functions

- [MLFB_HomeFindHomeFastInput](#)
- [MLFB_HomeFindHomeFastInputModulo](#)
- [MLFB_HomeFindLimitFastInput](#)

6.2.0.22.5 Example

6.2.0.22.5.1 Structured Text

```

Direction:= 0;
Position:=1000;
Velocity:=1000;
Acceleration:=10000;
Deceleration:=10000;
SwitchMode:=0;
Timeout:=T#100;
FastInputNumber:=0;
CycleTime:=1000;

```

```

inst_fbHomeFindLimitFastInputModulo(True, Axis1, Position,
Direction, Velocity, Acceleration, Deceleration,
LimitSwitchMode, Timeout, FastInputNumber, CycleTime);


```

```


HomeComplete :=inst_fbHomeFindLimitFastInputModulo.Done;
HomeActive :=inst_fbHomeFindLimitFastInputModulo.Active;
HomeError :=inst_fbHomeFindLimitFastInputModulo.Error;
HomeErrorID :=inst_fbHomeFindLimitFastInputModulo.ErrorID;

```

6.2.0.22.5.2 Ladder Diagram



6.2.0.22.5.3 Function Block Diagram



6.2.0.23 MLFB_Jog



Function - defined to jog an axis in the selected direction at a defined speed.

The En input (FFLD editor only) must be high. Typically wired to the rail. The AxisID selects the axis to jog. The JogPlus and JogMinus inputs select the direction the motion will occur in. Only one of these inputs should be enabled at a given time. If both are selected the motion will stop. If other motion is active when the jog is requested that motion will be aborted and the jog will start.

The following figure shows the function I/O




Figure 1-152: Kollmorgen UDFB Jog for PipeNetwork

6.2.0.23.1 Arguments

6.2.0.23.1.1 Input

En	Description	Enables execution (FFLD only)
	Data type	BOOL
	Range	—
	Unit	N/A
	Default	—
AxisID	Description	ID Name of the Axis
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

JogPlus	Description	Enables a Jog in the plus direction
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A
	Default	—
JogMinus	Description	Enables a Jog in the Minus direction
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A
	Default	—
Speed	Description	Rate at which the axis will move
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—

6.2.0.23.1.2 Output

InMotion	Description	Jogging is active when TRUE
	Data type	BOOL
	Range	N/A

6.2.0.23.2 Usage

This function is used to command motion in a designated direction at a defined rate. This may be used where continuous motion required as in a conveyor system, or in a setup mode for manually jogging the axis. Motion will start when the JogPlus or JogMinus input is true. It will stop when the input goes false. This function is used with the Pipe Network motion engine.

6.2.0.23.3 Related Functions


[MLAxisMoveVel](#)

6.2.0.23.4 Example


6.2.0.23.4.1 Structured Text

```
//Jog Axis1 at 6000 user units a second when JogPlus or JogMinus
variables are TRUE
//Stop motion on falling edge of either variable
MLFB_Jog( PipeNetwork.AXIS1, JogPlus, JogMinus, 6000 );
```

6.2.0.23.4.2 Ladder Diagram



6.2.0.23.4.3 Function Block Diagram



6.2.0.24 MLFB_PlsPosFw Pipe Network ✓

6.2.0.24.1 Description

This function block should be used in the command position path with ascending position. A dedicated comparator pipe block is needed. The Boolean output oPLS is set to TRUE if the position of the comparator has crossed the start position and is set to FALSE if the position has crossed the end position. The function block is executed cyclically. The modulo position is considered. The function block has the possibility to compensate a delay time of the connected device, e. g. glue nozzles.

6.2.0.24.2 Arguments

6.2.0.24.2.1 Input


ibExecute	Description	Enable PLS
	Data type	BOOL
iDedicatedCmpID	Description	ID of dedicated comparator
	Data type	DINT
iStartPos	Description	Start position of PLS
	Data type	LREAL
iEndPos	Description	End position of PLS
	Data type	LREAL
iDelayTime	Description	Delay time for compensation
	Data type	TIME
ibForce	Description	Force PLS
	Data type	BOOL

6.2.0.24.2.2 Output

oPLS	Description	Position limit switch
	Data type	BOOL

6.2.0.24.3 Example


6.2.0.24.4 Timing




6.2.0.24.4.1 ST

```
//PLSOutput is True when chosen comparator is between 180 and 270 with a
T#2ms delay
//Can also force the output to be true with ForceOutput variable
Inst_MLFB_PlsPosFw( EnablePLS, PipeNetwork.COMPARATOR, 180, 270, T#2ms,
ForceOutput );
PLSOutput := Inst_MLFB_PlsPosFw.oPLS;
```

6.2.0.24.4.2 FBD



6.2.0.24.4.3 FFLD



6.2.0.25 MLFB_PlsPosFwBw Pipe Network ✓

6.2.0.25.1 Description

This function block can be used in the command or actual position path, e.g. sampler pipe with noisy position, in both directions. Any modulo pipe block is needed, which can also be used for another instance of this UDFB. The Boolean output oPLS is set to TRUE if the position of the comparator has crossed the start position and is set to FALSE if the position has crossed the end position. The function block is executed cyclically. The modulo position is considered. The function block has the possibility to compensate a delay time of the connected device, e.g. glue nozzles. It is also possible to define a hysteresis for switching on and off of the PLS.

6.2.0.25.2 Arguments

6.2.0.25.2.1 Input


ibExecute	Description	Enable PLS
	Data type	BOOL
iAnyModuloBlkID	Description	Any modulo pipe network block ID
	Data type	DINT
iStartPos	Description	Start position of PLS
	Data type	LREAL
iEndPos	Description	End position of PLS
	Data type	LREAL
iDelayTime	Description	Delay time for compensation
	Data type	TIME
iHysteresis	Description	Hysteresis
	Data type	LREAL
ibForce	Description	Force PLS
	Data type	BOOL

6.2.0.25.2.2 Output


oPLS	Description	Position limit switch
	Data type	BOOL

6.2.0.25.3 Example

6.2.0.25.4 Timing



6.2.0.25.5 Hysteresis




6.2.0.25.5.1 ST

```
//PLSOutput is True when chosen comparator is between 180 and 270 with a
T#2ms delay
//Can also force the output to be true with ForceOutput variable
//Hysteresis is on for 3 user units in case direction changes around
```


```

start point
Inst_MLFB_PlsPosFwBw( EnablePLS, PipeNetwork.COMPARATOR, 180, 270, T#2ms,
3, ForceOutput );
PLSOutput := Inst_MLFB_PlsPosFwBW.oPLS;
    
```

6.2.0.25.5.2 FBD



6.2.0.25.5.3 FFLD



6.2.0.26 MLFB_PlsTimeFw Pipe Network ✓

6.2.0.26.1 Description

This function block should be used in the command position path with ascending position. A dedicated comparator pipe block is needed. The Boolean output oPLS is set to TRUE if the position of the comparator has crossed the start position and a timer with iOnTime is started. When the timer has expired the output is set to FALSE. The function block is executed cyclically. The modulo position is considered. The function block has the possibility to compensate a delay time of the connected device, e .g. glue nozzles.

6.2.0.26.2 Arguments

6.2.0.26.2.1 Input

ibExecute	Description	Enable PLS
	Data type	BOOL
iDedicatedCmpID	Description	ID of dedicated comparator
	Data type	DINT
iStartPos	Description	Start position of PLS
	Data type	LREAL
iOnTime	Description	Time PLS is on


	Data type	TIME
iDelayTime	Description	Delay time for compensation
	Data type	TIME
ibForce	Description	Force PLS
	Data type	BOOL

6.2.0.26.2.2 Output

oPLS	Description	Position limit switch
	Data type	BOOL

6.2.0.26.3 Example


6.2.0.26.4 Timing




6.2.0.26.4.1 ST

```
//PLSOutput is True when chosen comparator passes 180 for 3 seconds a
T#2ms delay
//Can also force the output to be true with ForceOuput variable
Inst_MLFB_PlsTimeFw( EnablePLS, PipeNetwork.COMPARATOR, 180, T#3s, T#2ms,
ForceOutput );
PLSOutput := Inst_MLFB_PlsTimeFw.oPLS;
```

6.2.0.26.4.2 FBD



6.2.0.26.4.3 FFLD



6.2.0.27 MCFB_AKDFault



Function Block - Outputs AKD drive fault Information.

The FAULT output turns TRUE when the selected drive goes into a fault state. The fault number is the same number as reported on the display of the AKD drive. This function can be used with the PLCopen Motion engines.

TIP

This function block lists the **highest priority** fault as displayed on the AKD. The "FB_AKDFltRpt" (→ p. 778) function block lists faults in the order they occur.

This image shows the function block I/O:




Figure 1-153: MCFB_AKDFault

6.2.0.27.1 Arguments

6.2.0.27.1.1 Input

EN	Description	ENABLES the Kollmorgen UDFB (used in FFLD editor only)
	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function. For more details, About Axis Name and Number .
	Data type	AXIS_REF
	Range	[1, 256]
	Unit	N/A
	Default	—

6.2.0.27.1.2 Output

FAULT	Description	TRUE if selected drive currently has a Fault
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A
FaultNumber	Description	Three digit AKD Fault identifier
	Data type	DINT
	Range	[100, 999]
	Unit	N/A

6.2.0.27.2 Usage

Typical usage for this UDFB are:

- Provide drive fault information that the application program uses to determine next steps such as perform a machine controlled stop or perform an immediate disable of the servo drives.
- In the application program send output fault information from this UDFB to the HMI for review by the machine operator.

Related Functions

["MCFB_AKDFaultLookup"](#) (→ p. 719)

["FB_AKDFltRpt"](#) (→ p. 778)

["MC_ReadStatus"](#) (→ p. 295) (PLCopen Motion Engine)

6.2.0.27.3 Example

6.2.0.27.3.1 Structured Text


```

//Execute and Read the Function Block

Inst_MCFB_AKDFault( Axis1(*lib:AXIS_REF*) );
FaultDrive1 := Inst_MCFB_AKDFault.FAULT;
FaultDrive1Number := Inst_MCFB_AKDFault.FaultNumber;

FaultDrive1Description := MCFB_AKDFaultLookup( FaultDrive1Number(*DINT*)
);
    
```

6.2.0.27.3.2 Ladder Diagram



6.2.0.27.3.3 Function Block Diagram



6.2.0.28 MCFB_AKDFaultLookup PLCopen

6.2.0.28.1 Description

String message of the corresponding AKD drive fault number. The OK output turns TRUE when there is a match for the FaultNumber. The FaultDescription displays the corresponding text string. The FaultNumber is the same number as reported on the display of the AKD drive. This function can be used with the PLCopen Motion engines. The following figure shows the function I/O:




Figure 1-154: MCFB_AKDFaultLookup

6.2.0.28.2 Arguments

6.2.0.28.2.1 Input

EN	Description	ENABLES the Kollmorgen UDFB (used in FFLD editor only)
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A
	Default	—
FaultNumber	Description	The AKD drive fault number
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—

6.2.0.28.2.2 Output

OK	Description	TRUE if there is a match for the FaultNumber
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A
FaultDescription	Description	Description of the Fault
	Data type	STRING
	Range	N/A
	Unit	N/A

6.2.0.28.3 Usage

Typical usage for this UDFB are:

- Provide drive fault information that the application program uses to determine next steps such as perform a machine controlled stop or perform an immediate disable of the servo drives.
- In the application program send output fault information from this UDFB to the HMI for review by the machine operator.

6.2.0.28.4 Related Functions

"MCFB_AKDFault" (→ p. 717)

"FB_AKDFltRpt" (→ p. 778)

"MC_ReadStatus" (→ p. 295) (PLCopen Motion Engine)

6.2.0.28.5 Example

6.2.0.28.5.1 Structured Text


```

//Execute and Read the Function Block

Inst_MCFB_AKDFault( Axis1(*lib:AXIS_REF*) );
FaultDrive1 := Inst_MCFB_AKDFault.FAULT;
FaultDrive1Number := Inst_MCFB_AKDFault.FaultNumber;

FaultDrive1Description := MCFB_AKDFaultLookup( FaultDrive1Number(*DINT*)
);
    
```

6.2.0.28.5.2 Ladder Diagram



6.2.0.28.5.3 Function Block Diagram



6.2.0.29 MCFB_DriveFault PLCopen ✔

6.2.0.29.1 Description

This function block returns the fault status, fault number and fault description of the requested axis which is mapped to a Kollmorgen drive such as S300, S700, AKD, AKD2G, and AKT2G Stepper.

The FAULT output returns TRUE when the selected drive goes into a fault state. The fault number and description depend on the drive type mapped to the axis.

- If the drive is an AKD or AKD2G then the fault number is the same number as reported on the display of the AKD/AKD2G drive.
- If the drive is an AKT2G Stepper, then the fault number represents the drive status word which is a bitmask that represents the various error conditions.

NOTE

This function blocks requires "FB_S700FltRpt" (→ p. 781), "MCFB_AKDFault" (→ p. 717), and "MCFB_AKDFaultLookup" (→ p. 719) subprograms imported to project to compile and function




Figure 1-155: MCFB_DriveFault

6.2.0.29.2 Arguments

6.2.0.29.2.1 Input

EN	Description	ENABLES the Kollmorgen UDFB (used in FFLD editor only)
	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function. For more details see About Axis Name and Number .
	Data type	AXIS_REF Structure
	Range	[1, 256]
	Unit	N/A
	Default	—

6.2.0.29.2.2 Output

FAULT	Description	TRUE if the selected drive currently has a Fault
	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A

FaultNumber	Description	<p>If the axis is:</p> <p>S300/S700: Three-digit fault identifier. See the article S300 & S700 Errors and Warnings on KDN for a full list of fault codes.</p> <p>AKD: Three-digit fault identifier. See the AKD Fault and Warning Messages for a full list of fault codes.</p> <p>AKD2G: Four-digit fault identifier. See the AKD2G Faults and Warnings View for a full list of fault codes.</p> <p>AKT2G Stepper: Drive Status word (bitmask). See following table.</p> <table border="1"> <thead> <tr> <th>Bit</th> <th>Description</th> <th>Cause</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Saturated</td> <td>Drive stage operates with maximum duty cycle</td> </tr> <tr> <td>1</td> <td>Over temperature</td> <td>Internal temperature is higher than 80o C</td> </tr> <tr> <td>2</td> <td>Torque overload.</td> <td>Motor current is higher than the rated current</td> </tr> <tr> <td>3</td> <td>Under voltage.</td> <td>Motor supply voltage is 20% lower than the configured nominal voltage (warning), or Motor supply voltage is less than 8 V</td> </tr> <tr> <td>4</td> <td>Over voltage.</td> <td>Motor supply voltage is 10% higher than the configured nominal voltage</td> </tr> <tr> <td>5</td> <td>Short circuit A.</td> <td>Short circuit in motor coil A</td> </tr> <tr> <td>6</td> <td>Short circuit B</td> <td>Short circuit in motor coil B</td> </tr> <tr> <td>7</td> <td>No control power</td> <td>Control voltage at the power contacts is less than 12 V</td> </tr> <tr> <td>8</td> <td>Misc. error</td> <td>Terminal initialization failed, or supply voltage is less than 8 V, or internal terminal temperature is higher than 100°C</td> </tr> <tr> <td>9</td> <td>Configuration error</td> <td>CoE change has not yet been adopted into the current configuration</td> </tr> </tbody> </table>	Bit	Description	Cause	0	Saturated	Drive stage operates with maximum duty cycle	1	Over temperature	Internal temperature is higher than 80o C	2	Torque overload.	Motor current is higher than the rated current	3	Under voltage.	Motor supply voltage is 20% lower than the configured nominal voltage (warning), or Motor supply voltage is less than 8 V	4	Over voltage.	Motor supply voltage is 10% higher than the configured nominal voltage	5	Short circuit A.	Short circuit in motor coil A	6	Short circuit B	Short circuit in motor coil B	7	No control power	Control voltage at the power contacts is less than 12 V	8	Misc. error	Terminal initialization failed, or supply voltage is less than 8 V, or internal terminal temperature is higher than 100°C	9	Configuration error	CoE change has not yet been adopted into the current configuration
		Bit	Description	Cause																															
		0	Saturated	Drive stage operates with maximum duty cycle																															
		1	Over temperature	Internal temperature is higher than 80o C																															
		2	Torque overload.	Motor current is higher than the rated current																															
		3	Under voltage.	Motor supply voltage is 20% lower than the configured nominal voltage (warning), or Motor supply voltage is less than 8 V																															
		4	Over voltage.	Motor supply voltage is 10% higher than the configured nominal voltage																															
		5	Short circuit A.	Short circuit in motor coil A																															
		6	Short circuit B	Short circuit in motor coil B																															
		7	No control power	Control voltage at the power contacts is less than 12 V																															
8	Misc. error	Terminal initialization failed, or supply voltage is less than 8 V, or internal terminal temperature is higher than 100°C																																	
9	Configuration error	CoE change has not yet been adopted into the current configuration																																	
Data type	DINT																																		
Range																																			
Unit	N/A																																		
Fault Description	Description	Description of the Fault																																	
	Data type	STRING																																	
	Range	N/A																																	
	Unit	N/A																																	

6.2.0.29.3 Usage

Typical usage for this UDFB is:

- Provide drive fault information that the application program uses to determine next steps such as perform a machine-controlled stop or perform an immediate disable of the servo drives.
- In the application program send output fault information from this UDFB to the HMI for review by the machine operator.

Related Functions


- "MCFB_AKDFault" (→ p. 717)
- "MCFB_AKDFaultLookup" (→ p. 719)
- "FB_S700FltRpt" (→ p. 781)
- "MC_ReadStatus" (→ p. 295) (PLCopen Motion Engine)

6.2.0.29.4 Example


6.2.0.29.4.1 Structured Text

```
//Execute and Read the Function Block
Inst_MCFB_DriveFault( Axis1 );
Axis1Fault := Inst_MCFB_DriveFault.FAULT;
Axis1FaultNumber := Inst_MCFB_DriveFault.FaultNumber;
Axis1FaultDescription := Inst_MCFB_DriveFault.FaultDescription;
```

6.2.0.29.4.2 Ladder Diagram



6.2.0.29.4.3 Function Block Diagram



6.2.0.30 MCFB_ECATRstart PLCopen ✔

6.2.0.30.1 Description

This function block reinitializes the EtherCAT network and the motion engine. This function blocks also clears motion engine errors, motion bus driver errors and EtherCAT network errors before reinitializing the motion engine, if requested to do so.




Figure 1-156: MCFB_ECATRstart

6.2.0.30.2 Arguments

6.2.0.30.2.1 Input

iEN	Description	ENABLES the Kollmorgen UDFB
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A
	Default	—
iRSTERR	Description	Clears the motion engine and EtherCAT network errors in case of any faults
	Data type	BOOL
	Range	[1, 256]
	Unit	[0, 1]
	Default	—

6.2.0.30.2.2 Output

oOK	Description	Function block activated status
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A
oDONE	Description	Execution Complete
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A
oERR	Description	TRUE if the system initialization fails.
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A

6.2.0.30.3 Usage

The typical use for this UDFB is to allow the EtherCAT and motion engines to restart without having to restart the entire project. Examples:

- EtherCAT network wire is replaced or accidentally disconnected
- Axis setup Parameters defined by CreateAxis and/or InitAxis function need to be changed while the application is running.

Related Functions

- ["MLMotionInit"](#) (→ p. 414)
- ["MLMotionRstErr"](#) (→ p. 416)
- ["MLMotionStart"](#) (→ p. 417)
- ["ClearCtrlErrors"](#) (→ p. 572)


6.2.0.30.4 Examples

6.2.0.30.4.1 Structured Text


```

Inst_MCFB_ECAtRestart( Restart, ResetErrors );
IF Inst_MCFB_ECAtRestart.oDONE THEN
    RestartComplte:=1;
End_IF;
    
```

6.2.0.30.4.2 Ladder Diagram



6.2.0.30.4.3 Function Block Diagram



6.2.0.31 MCFB_StepAbsolutes PLCopen ✔

6.2.0.31.1 Description

This function block performs a static homing function by setting Actual Position to the position of an absolute encoder. No physical motion is performed in this mode. Equivalent to MC_SetPosition is performed with SetPosition coming from absolute encoder reading, but with the option of using the once per rev feedback value.

The following figure shows the function block I/O:




Figure 1-157: MCFB StepAbsolute

6.2.0.31.2 Arguments

6.2.0.31.2.1 Input

En	Description
	Enables execution (FFLD only)

	Data type	BOOL						
	Range	—						
	Unit	N/A						
	Default	—						
Execute	Description	Request the homing step procedure at rising edge						
	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						
AxisID	Description	Name of a declared instance of the AXIS_REF library function						
	Data type	AXIS_REF						
	Range	[1 , 256]						
	Unit	N/A						
	Default	—						
Mode	Description	Define the actual position assignment source						
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>use drive feedback position for actual position</td> </tr> <tr> <td>1</td> <td>use once per rev feedback position</td> </tr> </tbody> </table>	Value	Description	0	use drive feedback position for actual position	1	use once per rev feedback position
Value	Description							
0	use drive feedback position for actual position							
1	use once per rev feedback position							
	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						

6.2.0.31.2.2 Output

Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint
	Data type	BOOL
	Unit	N/A
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL
	Unit	N/A
Active	Description	Indicates this move is the active move

	Data type	BOOL
	Unit	N/A
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
	Unit	N/A
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
	Unit	N/A
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
	Unit	N/A
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT
	Unit	N/A

Value	Description
1	Desired SetPosition is outside of Rollover period

6.2.0.31.3 Related Functions

[MCFB_StepAbsSwitch](#)

[MCFB_StepRefPulse](#)

[MCFB_StepBlock](#)


[MCFB_StepLimitSwitch](#)

6.2.0.31.4 Example


6.2.0.31.4.1 Structured Text

```
//Write current once per rev feedback position to overall axis position
MCFB_StepAbsolute( ExecuteHome, Axis1, ModeHome );
```

6.2.0.31.4.2 Ladder Diagram



6.2.0.31.4.3 Function Block Diagram



6.2.0.32 MCFB_StepAbsSwitch PLCopen

6.2.0.32.1 Description

This function block performs a homing function by searching for an absolute positioned external physical switch. (An Absolute Switch has two "Off" (or "On") areas.

The following figure shows the function block I/O:




Figure 1-158: MCFB StepAbsSwitch

6.2.0.32.2 Arguments

6.2.0.32.2.1 Input

Execute	Description
	Request the homing step procedure at rising edge. Outputs are reset when execute input is false.
	Data type BOOL
	Range [0, 1]
	Unit N/A
	Default —

AxisID	Description	Name of a declared instance of the AXIS_REF library function										
	Data type	AXIS_REF										
	Range	[1 , 256]										
	Unit	N/A										
	Default	—										
Direction	Description	Define the axis homing direction										
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>clockwise rotation</td> </tr> <tr> <td>1</td> <td>counterclockwise rotation</td> </tr> <tr> <td>2</td> <td>clockwise if AbsoluteSwitch starts Off and negative if switch starts On</td> </tr> <tr> <td>3</td> <td>counter clockwise if AbsoluteSwitch starts On and positive if switch starts Off</td> </tr> </tbody> </table>	Value	Description	0	clockwise rotation	1	counterclockwise rotation	2	clockwise if AbsoluteSwitch starts Off and negative if switch starts On	3	counter clockwise if AbsoluteSwitch starts On and positive if switch starts Off
Value	Description											
0	clockwise rotation											
1	counterclockwise rotation											
2	clockwise if AbsoluteSwitch starts Off and negative if switch starts On											
3	counter clockwise if AbsoluteSwitch starts On and positive if switch starts Off											
	Data type	DINT										
	Range	[0 , 3]										
	Unit	N/A										
	Default	—										
SwitchMode	Description	Switch state to complete homing										
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>switch is on</td> </tr> <tr> <td>1</td> <td>switch if off</td> </tr> <tr> <td>2</td> <td>rising edge of switch</td> </tr> <tr> <td>3</td> <td>falling edge of switch</td> </tr> </tbody> </table>	Value	Description	0	switch is on	1	switch if off	2	rising edge of switch	3	falling edge of switch
Value	Description											
0	switch is on											
1	switch if off											
2	rising edge of switch											
3	falling edge of switch											
	Data type	DINT										
	Range	[0 , 3]										
	Unit	N/A										
	Default	—										
Velocity	Description	Commanded velocity for the homing move										
	Data type	LREAL										
	Range	—										
	Unit	User unit/sec										
	Default	—										
Acceleration	Description	Commanded acceleration for the homing move										

	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Commanded deceleration for the homing move
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Commanded jerk for the homing move (if zero, then trapezoidal acc/dec is used)
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—
TorqueLimit	Description	Maximum torque applied for the homing move entered in thousandths of maximum torque, e.g. "250" is 250/1000, or 25%.
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
TimeLimit	Description	Maximum time for homing move to complete. If exceeded the homing procedure will error out. 0= no time limit
	Data type	TIME
	Range	—
	Unit	sec
	Default	—
DistanceLimit	Description	Maximum distance for homing move to complete. If exceeded the homing procedure will error out. 0= no distance limit
	Data type	LREAL
	Range	—
	Unit	User unit

	Default	—														
AbsoluteSwitch	Description	The absolute switch input I/O point														
	Data type	BOOL														
	Range	[0 , 1]														
	Unit	N/A														
	Default	—														
PosLimitSwitch	Description	The positive direction limit switch input I/O point														
	Data type	BOOL														
	Range	[0 , 1]														
	Unit	N/A														
	Default	—														
NegLimitSwitch	Description	The negative direction limit switch input I/O point														
	Data type	BOOL														
	Range	[0 , 1]														
	Unit	N/A														
	Default	—														
SwitchMode	Description	Switch state to complete homing														
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>abort</td> </tr> <tr> <td>1</td> <td>buffer</td> </tr> <tr> <td>2</td> <td>Blend to active</td> </tr> <tr> <td>3</td> <td>blend to next</td> </tr> <tr> <td>4</td> <td>blend to low velocity</td> </tr> <tr> <td>5</td> <td>blend to high velocity</td> </tr> </tbody> </table>	Value	Description	0	abort	1	buffer	2	Blend to active	3	blend to next	4	blend to low velocity	5	blend to high velocity
	Value	Description														
	0	abort														
	1	buffer														
	2	Blend to active														
	3	blend to next														
	4	blend to low velocity														
5	blend to high velocity															
Data type	SINT															
Range	[0 , 5]															
Unit	N/A															
Default	—															

6.2.0.32.2.2 Output

Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint
	Data type	BOOL
	Unit	N/A






Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended														
	Data type	BOOL														
	Unit	N/A														
Active	Description	Indicates this move is the active move														
	Data type	BOOL														
	Unit	N/A														
CommandAborted	Description	Indicates the move was aborted														
	Data type	BOOL														
	Unit	N/A														
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error														
	Data type	BOOL														
	Unit	N/A														
ErrorID	Description	Indicates the error if Error output is set to TRUE														
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>TimeLimit exceeded</td> </tr> <tr> <td>2</td> <td>DistanceLimit exceeded</td> </tr> <tr> <td>3</td> <td>TorqueLimit exceeded</td> </tr> <tr> <td>4</td> <td>axis error stop state</td> </tr> <tr> <td>5</td> <td>axis not enabled</td> </tr> <tr> <td>6</td> <td>invalid inputs for Velocity-Acceleration-Deceleration</td> </tr> </tbody> </table>	Value	Description	1	TimeLimit exceeded	2	DistanceLimit exceeded	3	TorqueLimit exceeded	4	axis error stop state	5	axis not enabled	6	invalid inputs for Velocity-Acceleration-Deceleration
	Value	Description														
1	TimeLimit exceeded															
2	DistanceLimit exceeded															
3	TorqueLimit exceeded															
4	axis error stop state															
5	axis not enabled															
6	invalid inputs for Velocity-Acceleration-Deceleration															
Data type	INT															
Unit	N/A															

6.2.0.32.3 Usage



This physical layout has the risk that homing is started in the wrong direction (escaping the switch). To support such case, it implements a special behavior when Limit Switches are found (or the AbsSwitch itself is "On" at Execute):

- The homing is commanded in the most likely direction were the sensor can be found. In this example (-).
- The velocity is defined by the input.
- The torque is limited.
- Both Time and Distance Limits can cause an error if exceeded
- If any LimitSwitch is found during Homing (any of them), then a special process is started in the opposite direction, the AbsSwitch is searched to switch off (or On, depending on SwitchMode setting). The Edge (passed by), and homing process is restarted in the original direction and with the same conditions. This ensures that the end conditions are always same



- If the SwitchMode is either MC_SwitchNegative or MC_SwitchPositive, then the special process is also started in opposite direction depending from the switch state at 'execute'.
- The direction changes only when the specified Velocity is reached (InVelocity).
- This Function Block doesn't modify the actual position



An overlapping switch configuration is also possible. This has same the behavior as working on the limit switches:



If the input Direction is set to a fixed direction (MC_Positive or MC_Negative), then the initial switch state is ignored (used for example in rotary axis where only one sense of rotation is allowed):



6.2.0.32.4 Related Functions

[MCFB_StepAbsolute](#)

[MCFB_StepRefPulse](#)

[MCFB_StepBlock](#)

[MCFB_StepLimitSwitch](#)

6.2.0.32.5 Example

6.2.0.32.5.1 Structured Text

```


NegativeDirection :=1;
RisingEdge :=2;
Velocity :=10000.0;
TorqueLimit :=50.0;
TimeLimit :=T#10s;
DistanceLimit :=10000.0;

Inst_MCFB_StepAbsSwitch( True, Axis1, NegativeDirection,
RisingEdge, Velocity, 1000, 1000, 0, TorqueLimit, TimeLimit,
DistanceLimit, AbsoluteSwitch, PosLimitSwitch, NegLimitSwitch, 0
);


HomeComplete :=Inst_MCFB_StepAbsSwitch.Done;
HomeBusy :=Inst_MCFB_StepAbsSwitch.Busy;
HomeActive :=Inst_MCFB_StepAbsSwitch.Active;
HomeAborted :=Inst_MCFB_StepAbsSwitch.CommandAborted;
HomeError :=Inst_MCFB_StepAbsSwitch.Error;
HomeErrorID :=Inst_MCFB_StepAbsSwitch.ErrorID;

(* AbsoluteSwitch, PosLimitSwitch, NegLimitSwitch are declared
I/O points *)
    
```

6.2.0.32.5.2 Ladder Diagram



6.2.0.32.5.3 Function Block Diagram



6.2.0.33 MCFB_StepBlock PLCopen

6.2.0.33.1 Description

This function block performs homing against a physical object, mechanically blocking the movement. In this mode there is no limit switch or Reference Pulse. Adequate torque limits are required for not damaging mechanics during homing process. The StepBlock condition is that we have reached the torque limit and real velocity falls below 5% of demanded.

The following figure shows the function block I/O:




Figure 1-159: MCFB StepBlock

6.2.0.33.2 Arguments

6.2.0.33.2.1 Input

Execute	Description	Request the homing step procedure at rising edge. Outputs are reset when execute input is false.
	Data type	BOOL
	Range	[0 , 1]

	Unit	N/A						
	Default	—						
AxisID	Description	Name of a declared instance of the AXIS_REF library function						
	Data type	AXIS_REF						
	Range	[1 , 256]						
	Unit	N/A						
	Default	—						
Direction	Description	Define the axis homing direction						
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>clockwise rotation</td> </tr> <tr> <td>1</td> <td>counterclockwise rotation</td> </tr> </tbody> </table>	Value	Description	0	clockwise rotation	1	counterclockwise rotation
Value	Description							
0	clockwise rotation							
1	counterclockwise rotation							
	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						
Velocity	Description	Commanded velocity for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec						
	Default	—						
Acceleration	Description	Commanded acceleration for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec ²						
	Default	—						
Deceleration	Description	Commanded deceleration for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec ²						
	Default	—						
Jerk	Description	Commanded jerk for the homing move (if zero, then trapezoidal acc/dec is used)						

	Data type	LREAL														
	Range	—														
	Unit	User unit/sec ³														
	Default	—														
TorqueLimit	Description	Maximum torque applied for the homing move entered in thousandths of maximum torque, e.g. "250" is 250/1000, or 25%.														
	Data type	LREAL														
	Range	—														
	Unit	User unit														
	Default	—														
TimeLimit	Description	Maximum time for homing move to complete. If exceeded the homing procedure will error out. 0= no time limit														
	Data type	TIME														
	Range	—														
	Unit	sec														
	Default	—														
DistanceLimit	Description	Maximum distance for homing move to complete. If exceeded the homing procedure will error out. 0= no distance limit														
	Data type	LREAL														
	Range	—														
	Unit	User unit														
	Default	—														
BufferMode	Description	Define the homing move start action														
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>abort</td> </tr> <tr> <td>1</td> <td>buffer</td> </tr> <tr> <td>2</td> <td>Blend to active</td> </tr> <tr> <td>3</td> <td>blend to next</td> </tr> <tr> <td>4</td> <td>blend to low velocity</td> </tr> <tr> <td>5</td> <td>blend to high velocity</td> </tr> </tbody> </table>	Value	Description	0	abort	1	buffer	2	Blend to active	3	blend to next	4	blend to low velocity	5	blend to high velocity
Value	Description															
0	abort															
1	buffer															
2	Blend to active															
3	blend to next															
4	blend to low velocity															
5	blend to high velocity															
	Data type	SINT														
	Range	[0 , 5]														

Unit	N/A
Default	—


6.2.0.33.2.2 Output

Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint														
	Data type	BOOL														
	Unit	N/A														
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended														
	Data type	BOOL														
	Unit	N/A														
Active	Description	Indicates this move is the active move														
	Data type	BOOL														
	Unit	N/A														
CommandAborted	Description	Indicates the move was aborted														
	Data type	BOOL														
	Unit	N/A														
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error														
	Data type	BOOL														
	Unit	N/A														
ErrorID	Description	Indicates the error if Error output is set to TRUE														
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>TimeLimit exceeded</td> </tr> <tr> <td>2</td> <td>DistanceLimit exceeded</td> </tr> <tr> <td>3</td> <td></td> </tr> <tr> <td>4</td> <td>axis error stop state</td> </tr> <tr> <td>5</td> <td>axis not enabled</td> </tr> <tr> <td>6</td> <td>invalid inputs for Velocity-Acceleration-Deceleration</td> </tr> </tbody> </table>	Value	Description	1	TimeLimit exceeded	2	DistanceLimit exceeded	3		4	axis error stop state	5	axis not enabled	6	invalid inputs for Velocity-Acceleration-Deceleration
Value	Description															
1	TimeLimit exceeded															
2	DistanceLimit exceeded															
3																
4	axis error stop state															
5	axis not enabled															
6	invalid inputs for Velocity-Acceleration-Deceleration															
	Data type	INT														
	Unit	N/A														

6.2.0.33.3 Usage

Homing against a physical object, mechanically blocking the movement require adequate torque limits for not damaging mechanics during homing process. The StepBlock condition is that we have reached the torque limit and real velocity falls below 5% of demanded.

- Home is commanded by user in the desired homing direction at the selected Velocity
- Torque is limited.
- Time and Distance Limits can cause error if exceeded
- Process is finished when Torque is in limit condition and real velocity is below 5% of selected velocity.
- This Function Block doesn't modify actual position



6.2.0.33.4 Related Functions

[MCFB_StepAbsolute](#)

[MCFB_StepRefPulse](#)

[MCFB_StepAbsSwitch](#)

[MCFB_StepLimitSwitch](#)

6.2.0.33.5 Example

6.2.0.33.5.1 Structured Text


```

PositiveDirection :=0;
Velocity :=10000.0;
TorqueLimit :=50.0;
TimeLimit :=T#10s;
DistanceLimit :=10000.0;


Inst_MCFB_StepBlock( True, Axis1, PositiveDirection, Velocity,
1000, 1000, 0, TorqueLimit, TimeLimit, DistanceLimit, 0 );

HomeComplete :=Inst_MCFB_StepBlock.Done;
HomeBusy :=Inst_MCFB_StepBlock.Busy;
HomeActive :=Inst_MCFB_StepBlock.Active;
HomeAborted :=Inst_MCFB_StepBlock.CommandAborted;
HomeError :=Inst_MCFB_StepBlock.Error;
HomeErrorID :=Inst_MCFB_StepBlock.ErrorID;
    
```

6.2.0.33.5.2 Ladder Diagram



6.2.0.33.5.3 Function Block Diagram



6.2.0.34 MCFB_StepLimitSwitch PLCopen ✔

6.2.0.34.1 Description

This function block performs a single-axis home to a limit switch. In this case the limit switches (always active once moving part working area has been surpassed) are used for homing procedure.

The following figure shows the function block I/O:




Figure 1-160: MCFB StepLimitSwitch

6.2.0.34.2 Arguments

6.2.0.34.2.1 Input

Execute	Description	Request the homing step procedure at rising edge. Outputs are reset when execute input is false.
	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A
	Default	—
AxisID	Description	Name of a declared instance of the AXIS_REF library function

	Data type	AXIS_REF										
	Range	[1 , 256]										
	Unit	N/A										
	Default	—										
Direction	Description	Define the axis homing direction										
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>clockwise rotation</td> </tr> <tr> <td>1</td> <td>counterclockwise rotation</td> </tr> </tbody> </table>	Value	Description	0	clockwise rotation	1	counterclockwise rotation				
Value	Description											
0	clockwise rotation											
1	counterclockwise rotation											
	Data type	BOOL										
	Range	[0 , 1]										
	Unit	N/A										
	Default	—										
LimitSwitchMode	Description	Limit switch state to complete homing										
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>switch is on</td> </tr> <tr> <td>1</td> <td>switch if off</td> </tr> <tr> <td>2</td> <td>rising edge of switch</td> </tr> <tr> <td>3</td> <td>falling edge of switch</td> </tr> </tbody> </table>	Value	Description	0	switch is on	1	switch if off	2	rising edge of switch	3	falling edge of switch
Value	Description											
0	switch is on											
1	switch if off											
2	rising edge of switch											
3	falling edge of switch											
	Data type	DINT										
	Range	[0 , 3]										
	Unit	N/A										
	Default	—										
Velocity	Description	Commanded velocity for the homing move										
	Data type	LREAL										
	Range	—										
	Unit	User unit/sec										
	Default	—										
Acceleration	Description	Commanded acceleration for the homing move										
	Data type	LREAL										
	Range	—										
	Unit	User unit/sec ²										
	Default	—										
Deceleration	Description	Commanded deceleration for the homing move										

	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Commanded jerk for the homing move (if zero, then trapezoidal acc/dec is used)
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—
TorqueLimit	Description	Maximum torque applied for the homing move entered in thousandths of maximum torque, e.g. "250" is 250/1000, or 25%.
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
TimeLimit	Description	Maximum time for homing move to complete. If exceeded the homing procedure will error out. 0= no time limit
	Data type	TIME
	Range	—
	Unit	sec
	Default	—
DistanceLimit	Description	Maximum distance for homing move to complete. If exceeded the homing procedure will error out. 0= no distance limit
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
LimitSwitch	Description	The limit switch input I/O point
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A

	Default	—														
BufferMode	Description	Define the homing move start action														
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>abort</td> </tr> <tr> <td>1</td> <td>buffer</td> </tr> <tr> <td>2</td> <td>Blend to active</td> </tr> <tr> <td>3</td> <td>blend to next</td> </tr> <tr> <td>4</td> <td>blend to low velocity</td> </tr> <tr> <td>5</td> <td>blend to high velocity</td> </tr> </tbody> </table>	Value	Description	0	abort	1	buffer	2	Blend to active	3	blend to next	4	blend to low velocity	5	blend to high velocity
	Value	Description														
	0	abort														
	1	buffer														
	2	Blend to active														
	3	blend to next														
	4	blend to low velocity														
5	blend to high velocity															
Data type	SINT															
Range	[0 , 5]															
Unit	N/A															
Default	—															

6.2.0.34.2.2 Output


Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint
	Data type	BOOL
	Unit	N/A
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL
	Unit	N/A
Active	Description	Indicates this move is the active move
	Data type	BOOL
	Unit	N/A
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
	Unit	N/A
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
	Unit	N/A

ErrorID	Description	Indicates the error if Error output is set to TRUE	
		Value	Description
		1	TimeLimit exceeded
		2	DistanceLimit exceeded
		3	TorqueLimit exceeded
		4	axis error stop state
		5	axis not enabled
		6	invalid inputs for Velocity-Acceleration-Deceleration
	Data type	INT	
	Unit	N/A	

6.2.0.34.3 Usage

This homing procedure performs a homing function searching for sensor using only LimitSwitches. (A LimitSwitch has 1 "Off" (or "On") area).

- Home is commanded by user in the desired homing direction at the selected Velocity.
- If LimitSwitch is found 'On' on rising 'Execute', then the process is started in the opposite direction as specified, LimitSwitch is search for 'Off' (or On, depending on LimitSwitchMode setting) Edge (released), and process is restarted again in original direction. This ensures that the end conditions are always the same.
- The torque is limited.
- The Time and Distance Limits can cause error if exceeded
- The Direction changes only when the specified Velocity is reached, this ensures acceleration and deceleration spaces are fixed
- This Function Block doesn't modify actual position



6.2.0.34.4 Related Functions

[MCFB_StepAbsolute](#)

[MCFB_StepRefPulse](#)

[MCFB_StepBlock](#)

[MCFB_StepAbsSwitch](#)

6.2.0.34.5 Example

6.2.0.34.5.1 Structured Text

```


PositiveDirection :=0;
RisingEdge :=2;
Velocity :=10000.0;
TorqueLimit :=50.0;
TimeLimit :=T#10s;
DistanceLimit :=10000.0;

Inst_MCFB_StepLimitSwitch( True, Axis1, PositiveDirection,
RisingEdge, Velocity, 1000, 1000, 0, TorqueLimit, TimeLimit,
DistanceLimit, LimitSwitch, 0 );


HomeComplete :=Inst_MCFB_StepLimitSwitch.Done;
HomeBusy :=Inst_MCFB_StepLimitSwitch.Busy;
HomeActive :=Inst_MCFB_StepLimitSwitch.Active;
HomeAborted :=Inst_MCFB_StepLimitSwitch.CommandAborted;
HomeError :=Inst_MCFB_StepLimitSwitch.Error;
HomeErrorID :=Inst_MCFB_StepLimitSwitch.ErrorID;

(* LimitSwitch is a declared I/O point *)
    
```

6.2.0.34.5.2 Ladder Diagram



6.2.0.34.5.3 Function Block Diagram



6.2.0.35 MCFB_StepRefPulse PLCopen ✔

6.2.0.35.1 Description

This function block performs homing by searching for Zero pulse (also called Marker or reference pulse) in encoder. The reference pulse appears once per encoder revolution. The advantage in using Reference Pulse for homing is the higher accuracy and precision that can be achieved compared to traditional optical, mechanical or magnetic sensors.

The following figure shows the function block I/O:




Figure 1-161: MCFB StepRefPulse

6.2.0.35.2 Arguments

6.2.0.35.2.1 Input

Execute	Description	Request the homing step procedure at rising edge
	Data type	BOOL
	Range	[0 , 1]

	Unit	N/A										
	Default	—										
AxisID	Description	Name of a declared instance of the AXIS_REF library function										
	Data type	AXIS_REF										
	Range	[1 , 256]										
	Unit	N/A										
	Default	—										
Direction	Description	Define the axis homing direction										
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>clockwise rotation</td> </tr> <tr> <td>1</td> <td>counterclockwise rotation</td> </tr> </tbody> </table>	Value	Description	0	clockwise rotation	1	counterclockwise rotation				
Value	Description											
0	clockwise rotation											
1	counterclockwise rotation											
	Data type	BOOL										
	Range	[0 , 1]										
	Unit	N/A										
	Default	—										
SwitchMode	Description	Switch state to complete homing										
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>switch is on</td> </tr> <tr> <td>1</td> <td>switch if off</td> </tr> <tr> <td>2</td> <td>rising edge of switch</td> </tr> <tr> <td>3</td> <td>falling edge of switch</td> </tr> </tbody> </table>	Value	Description	0	switch is on	1	switch if off	2	rising edge of switch	3	falling edge of switch
Value	Description											
0	switch is on											
1	switch if off											
2	rising edge of switch											
3	falling edge of switch											
	Data type	DINT										
	Range	[0 , 3]										
	Unit	N/A										
	Default	—										
Velocity	Description	Commanded velocity for the homing move										
	Data type	LREAL										
	Range	—										
	Unit	User unit/sec										
	Default	—										
Acceleration	Description	Commanded acceleration for the homing move										
	Data type	LREAL										

	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Commanded deceleration for the homing move
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Commanded jerk for the homing move (if zero, then trapezoidal acc/dec is used)
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—
SetPosition	Description	Value of the absolute position to be set when the homing move is done
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
TorqueLimit	Description	Maximum torque applied for the homing move
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
TimeLimit	Description	Maximum time for homing move to complete. If exceeded the homing procedure will error out. 0= no time limit
	Data type	TIME
	Range	—
	Unit	sec
	Default	—

DistanceLimit	Description	Maximum distance for homing move to complete. If exceeded the homing procedure will error out. 0= no distance limit														
	Data type	LREAL														
	Range	—														
	Unit	User unit														
	Default	—														
BufferMode	Description	Define the homing move start action														
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>abort</td> </tr> <tr> <td>1</td> <td>buffer</td> </tr> <tr> <td>2</td> <td>Blend to active</td> </tr> <tr> <td>3</td> <td>blend to next</td> </tr> <tr> <td>4</td> <td>blend to low velocity</td> </tr> <tr> <td>5</td> <td>blend to high velocity</td> </tr> </tbody> </table>	Value	Description	0	abort	1	buffer	2	Blend to active	3	blend to next	4	blend to low velocity	5	blend to high velocity
	Value	Description														
	0	abort														
	1	buffer														
	2	Blend to active														
	3	blend to next														
	4	blend to low velocity														
5	blend to high velocity															
Data type	SINT															
Range	[0 , 5]															
Unit	N/A															
Default	—															

6.2.0.35.2.2 Output


Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint
	Data type	BOOL
	Unit	N/A
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL
	Unit	N/A
Active	Description	Indicates this move is the active move
	Data type	BOOL
	Unit	N/A
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
	Unit	N/A

Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
	Unit	N/A
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Value	Description
	1	TimeLimit exceeded
	2	DistanceLimit exceeded
	3	TorqueLimit exceeded
	4	axis error stop state
	5	axis not enabled
	6	invalid inputs for Velocity-Acceleration-Deceleration
	Data type	INT
	Unit	N/A


6.2.0.35.3 Usage

This function Block performs homing by searching for Zero pulse (also called Marker or reference pulse) in encoder. The reference pulse appears once per encoder revolution.

- Home is commanded by user in the desired homing direction at the programmed velocity.
- First occurrence of the Reference Pulse, Homing is finished
- Torque is limited. Time and Distance Limits can cause error if exceeded
- This Function modifies actual position and sets to the "SetPosition" input value at the end



It is common that a first approach is performed against a mechanical sensor at higher velocity, and after a Reference Pulse, at a lower velocity. This is a traditional 2-Step homing (Coarse by external Switch in reverse and Fine by Reference Pulse in forward).



6.2.0.35.4 Related Functions

- [MCFB_StepAbsolute](#)
- [MCFB_StepAbsSwitch](#)
- [MCFB_StepBlock](#)
- [MCFB_StepLimitSwitch](#)

6.2.0.35.5 Example

6.2.0.35.5.1 Structured Text


```

PositiveDirection :=0;
Velocity :=10000.0;
SetPosition :=0.0;
TorqueLimit :=50.0;
TimeLimit :=T#10s;
DistanceLimit :=10000.0;


Inst_MCFB_StepRefPulse( True, Axis1, PositiveDirection,
Velocity, 1000, 1000, 0, SetPosition, TorqueLimit, TimeLimit,
DistanceLimit, 0 );

HomeComplete :=Inst_MCFB_StepRefPulse.Done;
HomeBusy :=Inst_MCFB_StepRefPulse.Busy;
HomeActive :=Inst_MCFB_StepRefPulse.Active;
HomeAborted :=Inst_MCFB_StepRefPulse.CommandAborted;
HomeError :=Inst_MCFB_StepRefPulse.Error;
HomeErrorID :=Inst_MCFB_StepRefPulse.ErrorID;
    
```

6.2.0.35.5.2 Ladder Diagram



6.2.0.35.5.3 Function Block Diagram



6.2.0.36 MCFB_StepAbsSwitchFastInput PLCopen ✔

6.2.0.36.1 Description

This function block performs a homing function by searching for an absolute positioned external physical switch. The switch must be connected to one of the two fast inputs on the Axis' AKD drive. (An Absolute Switch has two "Off" (or "On") areas.

The following figure shows the function block I/O:




Figure 1-162: MCFB StepAbsSwitchFastInput

6.2.0.36.1.1 Input

Execute	Description	Request the homing step procedure at rising edge. Outputs are reset when execute input is false.						
	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						
AxisID	Description	Structure for specified Axis desired to home						
	Data type	AXIS_REF						
	Range	[1 , 256]						
	Unit	N/A						
	Default	—						
Direction	Description	Define the axis homing direction						
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>clockwise rotation</td> </tr> <tr> <td>1</td> <td>counterclockwise rotation</td> </tr> </tbody> </table>	Value	Description	0	clockwise rotation	1	counterclockwise rotation
Value	Description							
0	clockwise rotation							
1	counterclockwise rotation							
	Data type	BOOL						

	Range	[0 , 1]										
	Unit	N/A										
	Default	—										
SwitchMode	Description	Switch state to complete homing										
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>when rising edge of sensor</td> </tr> <tr> <td>1</td> <td>when falling edge</td> </tr> <tr> <td>2</td> <td>rising edge when traveling in positive direction but falling edge in negative direction</td> </tr> <tr> <td>3</td> <td>falling edge when traveling in negative direction but rising edge in positive direction</td> </tr> </tbody> </table>	Value	Description	0	when rising edge of sensor	1	when falling edge	2	rising edge when traveling in positive direction but falling edge in negative direction	3	falling edge when traveling in negative direction but rising edge in positive direction
Value	Description											
0	when rising edge of sensor											
1	when falling edge											
2	rising edge when traveling in positive direction but falling edge in negative direction											
3	falling edge when traveling in negative direction but rising edge in positive direction											
	Data type	DINT										
	Range	[0 , 3]										
	Unit	N/A										
	Default	—										
Velocity	Description	Commanded velocity for the homing move										
	Data type	LREAL										
	Range	—										
	Unit	User unit/sec										
	Default	—										
Acceleration	Description	Commanded acceleration for the homing move										
	Data type	LREAL										
	Range	—										
	Unit	User unit/sec ²										
	Default	—										
Deceleration	Description	Commanded deceleration for the homing move										
	Data type	LREAL										
	Range	—										
	Unit	User unit/sec ²										
	Default	—										
Jerk	Description	Commanded jerk for the homing move (if zero, then trapezoidal acc/dec is used)										
	Data type	LREAL										

	Range	—
	Unit	User unit/sec ³
	Default	—
TorqueLimit	Description	Maximum torque applied for the homing move entered in thousandths of maximum torque, e.g. "250" is 250/1000, or 25%.
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
TimeLimit	Description	Maximum time for homing move to complete. If exceeded the homing procedure will error out. 0= no time limit
	Data type	TIME
	Range	—
	Unit	sec
	Default	—
DistanceLimit	Description	Maximum distance for homing move to complete. If exceeded the homing procedure will error out. 0= no distance limit
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
FastInputNum	Description	0 for first fast input (X7 Pin 10), 1 for second fast input (X7 pin 9)
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A
	Default	—
PosLimitSwitch	Description	The positive direction limit switch input I/O point
	Data type	BOOL
	Range	[0, 1]
	Unit	N/A
	Default	—
NegLimitSwitch	Description	The negative direction limit switch input I/O point

	Data type	BOOL														
	Range	[0 , 1]														
	Unit	N/A														
	Default	—														
BufferMode	Description	Define the homing move start action														
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>abort</td> </tr> <tr> <td>1</td> <td>buffer</td> </tr> <tr> <td>2</td> <td>Blend to active</td> </tr> <tr> <td>3</td> <td>blend to next</td> </tr> <tr> <td>4</td> <td>blend to low velocity</td> </tr> <tr> <td>5</td> <td>blend to high velocity</td> </tr> </tbody> </table>	Value	Description	0	abort	1	buffer	2	Blend to active	3	blend to next	4	blend to low velocity	5	blend to high velocity
Value	Description															
0	abort															
1	buffer															
2	Blend to active															
3	blend to next															
4	blend to low velocity															
5	blend to high velocity															
	Data type	SINT														
	Range	[0 , 5]														
	Unit	N/A														
	Default	—														


6.2.0.36.1.2 Output


Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint
	Data type	BOOL
	Unit	N/A
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL
	Unit	N/A
Active	Description	Set when the function block is active
	Data type	BOOL
	Unit	N/A
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
	Unit	N/A
Error	Description	Signals that an error has occurred within the function block
	Data type	BOOL

	Unit	N/A														
ErrorID	Description	Indicates the error if Error output is set to TRUE														
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>TimeLimit exceeded</td> </tr> <tr> <td>2</td> <td>DistanceLimit exceeded</td> </tr> <tr> <td>3</td> <td>TorqueLimit exceeded</td> </tr> <tr> <td>4</td> <td>axis error stop state</td> </tr> <tr> <td>5</td> <td>axis not enabled</td> </tr> <tr> <td>6</td> <td>invalid inputs for Velocity-Accel-Decel</td> </tr> </tbody> </table>	Value	Description	1	TimeLimit exceeded	2	DistanceLimit exceeded	3	TorqueLimit exceeded	4	axis error stop state	5	axis not enabled	6	invalid inputs for Velocity-Accel-Decel
	Value	Description														
	1	TimeLimit exceeded														
	2	DistanceLimit exceeded														
	3	TorqueLimit exceeded														
	4	axis error stop state														
5	axis not enabled															
6	invalid inputs for Velocity-Accel-Decel															
Data type	INT															
Unit	N/A															
TriggerPosition	Data type	LREAL														
	Range	-														
	Unit	User units														
	Default	-														

6.2.0.36.2 Usage

- The homing is commanded in the most likely direction were the sensor can be found. In this example (-).
- If any LimitSwitch is found during Homing (any of them), then a special process is started in the opposite direction, the AbsSwitch is searched to switch off (or On, depending on SwitchMode setting). The Edge (passed by), and homing process is restarted in the original direction and with the same conditions. This ensures that the end conditions are always same.





6.2.0.36.3 Related Functions

[MCFB_StepLimitSwitchFastInput](#)

6.2.0.36.4 Example

6.2.0.36.4.1 Structured Text

```
Execute_1 :=1;
```

(*Positive_Switch and Negative_Switch are physical hardware in Dictionary. *)

```
Inst_MC_StepAbsSwitchFastInput( Execute_1, Axis1, 0, 0,  
10000.0,Acceleration:=10000.0, 10000.0, 0, 0, 0, 0, 0, Positive_  
Switch , Negative_Switch , 0)
```

```
HomeComplete := Inst_MC_StepAbsSwitchFastInput.Done;
```

```
HomeBusy := Inst_MC_StepAbsSwitchFastInput.Busy;
```

```
HomeActive := Inst_MC_StepAbsSwitchFastInput.Active;
```


```
HomeAborted := Inst_MC_StepAbsSwitchFastInput.CommandAborted;
```

```
HomeError := Inst_MC_StepAbsSwitchFastInput.Error;
```


```
HomeErrorID := Inst_MC_StepAbsSwitchFastInput.ErrorID;
```

```
HomeTriggerPosition := Inst_MC_  
StepAbsSwitchFastInput.TriggerPosition;
```

6.2.0.36.4.2 FBD



6.2.0.36.4.3 Ladder Diagram



(* PosLimitSwitch, NegLimitSwitch are declared I/O points *)

6.2.0.37 MCFB_StepLimitSwitchFastInput PLCopen

6.2.0.37.1 Description

This function block performs a homing function by searching for an external physical switch. The switch must be connected to one of the two fast inputs on the Axis' AKD drive. The Axis will move and when a fast input is triggered, the triggered axis will then perform an absolute move to the latched position.

The following figure shows the function block I/O:




Figure 1-163: MCFB StepLimitSwitchFastInput

6.2.0.37.1.1 Input

Execute	Description	Request the homing step procedure at rising edge. Outputs are reset when execute input is false.						
	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						
AxisID	Description	Structure for specified Axis desired to home						
	Data type	AXIS_REF						
	Range	[1 , 256]						
	Unit	N/A						
	Default	—						
Direction	Description	Define the axis homing direction						
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>clockwise rotation</td> </tr> <tr> <td>1</td> <td>counterclockwise rotation</td> </tr> </tbody> </table>	Value	Description	0	clockwise rotation	1	counterclockwise rotation
Value	Description							
0	clockwise rotation							
1	counterclockwise rotation							
	Data type	BOOL						
	Range	[0 , 1]						
	Unit	N/A						
	Default	—						

LimitSwitchMode	Description	Limit switch state to complete homing						
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>when rising edge of sensor</td> </tr> <tr> <td>1</td> <td>when falling edge</td> </tr> </tbody> </table>	Value	Description	0	when rising edge of sensor	1	when falling edge
	Value	Description						
	0	when rising edge of sensor						
1	when falling edge							
Data type	DINT							
Range	[0, 1]							
	Unit	N/A						
	Default	—						
Velocity	Description	Commanded velocity for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec						
	Default	—						
Acceleration	Description	Commanded acceleration for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec ²						
	Default	—						
Deceleration	Description	Commanded deceleration for the homing move						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec ²						
	Default	—						
Jerk	Description	Commanded jerk for the homing move (if zero, then trapezoidal acc/dec is used)						
	Data type	LREAL						
	Range	—						
	Unit	User unit/sec ³						
	Default	—						
TorqueLimit	Description	Maximum torque applied for the homing move						
	Data type	LREAL						
	Range	—						


	Unit	User unit entered in thousandths of maximum torque, e.g. "250" is 250/1000, or 25%.														
	Default	—														
TimeLimit	Description	Maximum time for homing move to complete. If exceeded the homing procedure will error out. 0= no time limit														
	Data type	TIME														
	Range	—														
	Unit	sec														
	Default	—														
DistanceLimit	Description	Maximum distance for homing move to complete. If exceeded the homing procedure will error out. 0= no distance limit														
	Data type	LREAL														
	Range	—														
	Unit	User unit														
	Default	—														
FastInputNum	Description	0 for first fast input (X7 Pin 10), 1 for second fast input (X7 pin 9)														
	Data type	BOOL														
	Range	[0 , 1]														
	Unit	N/A														
	Default	—														
BufferMode	Description	Define the homing move start action														
		<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>abort</td> </tr> <tr> <td>1</td> <td>buffer</td> </tr> <tr> <td>2</td> <td>Blend to active</td> </tr> <tr> <td>3</td> <td>blend to next</td> </tr> <tr> <td>4</td> <td>blend to low velocity</td> </tr> <tr> <td>5</td> <td>blend to high velocity</td> </tr> </tbody> </table>	Value	Description	0	abort	1	buffer	2	Blend to active	3	blend to next	4	blend to low velocity	5	blend to high velocity
Value	Description															
0	abort															
1	buffer															
2	Blend to active															
3	blend to next															
4	blend to low velocity															
5	blend to high velocity															
	Data type	SINT														
	Range	[0 , 5]														
	Unit	N/A														
	Default	—														

6.2.0.37.1.2 Output

Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint	
	Data type	BOOL	
	Unit	N/A	
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended	
	Data type	BOOL	
	Unit	N/A	
Active	Description	Set when the function block is active	
	Data type	BOOL	
	Unit	N/A	
CommandAborted	Description	Indicates the move was aborted	
	Data type	BOOL	
	Unit	N/A	
Error	Description	Signals that an error has occurred within the function block	
	Data type	BOOL	
	Unit	N/A	
ErrorID	Description	Indicates the error if Error output is set to TRUE	
		Value	Description
		1	TimeLimit exceeded
		2	DistanceLimit exceeded
		3	TorqueLimit exceeded
		4	axis error stop state
		5	axis not enabled
		6	invalid inputs for Velocity-Accel-Decel
Data type	INT		
Unit	N/A		

6.2.0.37.2 Usage

The homing is commanded in the most likely direction were the sensor can be found. In this example (-).



6.2.0.37.3 Related Functions

[MCFB_StepAbsSwitchFastInput](#)

6.2.0.37.4 Example

6.2.0.37.4.1 Structured Text


```

Execute_1 :=1;


Inst_MCFB_StepLimitSwitchFastInput( Execute_1, Axis1, 0, 0, 10000.0,
10000.0, 10000.0, 0, 0, 0, 0, 0, 0);

HomeComplete := Inst_MCFB_StepLimitSwitchFastInput.Done;
HomeBusy := Inst_MCFB_StepLimitSwitchFastInput.Busy;
HomeActive := Inst_MCFB_StepLimitSwitchFastInput.Active;
HomeAborted := Inst_MCFB_StepLimitSwitchFastInput.CommandAborted;
HomeError := Inst_MCFB_StepLimitSwitchFastInput.Error;
HomeErrorID := Inst_MCFB_StepLimitSwitchFastInput.ErrorID;
    
```

6.2.0.37.4.2 FBD



6.2.0.37.4.3 Ladder Diagram



6.2.0.38 MCFB_Jog PLCopen

This function block is defined to jog an axis in the selected direction at a defined speed. The En input (FFLD editor only) must be high. Typically wired to the rail.

The AxisID selects the axis to jog. The JogPlus and JogMinus inputs select the direction the motion will occur in. Only one of these inputs should be enabled at a given time. If both are selected the motion will stop. If other motion is active when the jog is requested that motion will be aborted and the jog will start.

The following figure shows the function block I/O




Figure 1-164: Jog for PLCopen

6.2.0.38.1 Arguments

6.2.0.38.1.1 Input

En	Description
	Enables execution (FFLD only)
	Data type BOOL

	Range	—
	Unit	N/A
	Default	—
AxisID	Description	ID Name of the Axis
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
JogPlus	Description	Enables a Jog in the plus direction
	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A
	Default	—
JogMinus	Description	Enables a Jog in the Minus direction
	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A
	Default	—
Speed	Description	Rate at which the axis will move
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—
Accel Decel	Description	Linear Acc/Dec rate
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—

6.2.0.38.1.2 Output

InMotion	Description	Jogging is active when TRUE
	Data type	BOOL
	Unit	N/A

6.2.0.38.2 Usage

This function Block is used to command motion in a designated direction at a defined rate. This may be used where continuous motion required as in a conveyor system, or in a setup mode for manually jogging the axis. Motion will start when the JogPlus or JogMinus input is true. It will stop when the input goes false.

6.2.0.38.3 Related Functions


[MC_MoveVelocity](#)

6.2.0.38.4 Example


6.2.0.38.4.1 Structured Text

```
InMotion := Inst_Jog_PLCopen(Axis1, Switch_1, Switch_2, 600,
10000);
```

6.2.0.38.4.2 Ladder Diagram



6.2.0.38.4.3 Function Block Diagram



6.2.0.39 MCFB_GearedWebTension PLCopen ✔

This Kollmorgen UDFB facilitates dancer and tension control in an electronic geared master/slave machine design. This is done by using the analog feedback from a LVDT, tension transducer, potentiometer, encoder, resolver or some other similar device. The analog feedback value is compared to a pre-determined analog set-point. The difference or error is used in a PID algorithm with the summed output driving changes to the master/slave gearing relationship. This results in the slave axis either speeding up or slowing down to maintain desired tension.

The following figure shows the function block I/O.




Figure 1-165: MCFB_GearedWebTension Function Block I/O

6.2.0.39.1 Arguments

6.2.0.39.1.1 Inputs

Enable	Description	Enables execution
	Data Type	BOOL
	Range	[0,1]
	Unit	N/A
	Default	-
MasterID	Description	Identifies the master axis
	Data Type	AXIS_REF
	Range	
	Unit	N/A
	Default	-
SlaveID	Description	Identifies the slave axis
	Data Type	AXIS_REF
	Range	
	Unit	N/A
	Default	-

RatioNumerator	Description	Numerator of the master/slave ratio
	Data Type	DINT
	Range	[-2147483648 to +2147483647]
	Unit	N/A
	Default	-
RatioDenominator	Description	Denominator of the master/slave ratio
	Data Type	DINT
	Range	[-2147483648 to +2147483647]
	Unit	N/A
	Default	-
Acceleration	Description	Trapezoidal: acceleration rate, S-Curve: maximum acceleration
	Data Type	LREAL
	Range	[-1.7E308 to 1.7E308 and -1.7E-308 to 1.7E-308 (14 to 15 significant digits of accuracy)]
	Unit	N/A
	Default	-
Deceleration	Description	Trapezoidal: deceleration rate, S-Curve: not used
	Data Type	LREAL
	Range	[-1.7E308 to 1.7E308 and -1.7E-308 to 1.7E-308 (14 to 15 significant digits of accuracy)]
	Unit	N/A
	Default	-
Jerk	Description	Trapezoidal: 0, S-Curve: constant jerk
	Data Type	LREAL
	Range	[-1.7E308 to 1.7E308 and -1.7E-308 to 1.7E-308 (14 to 15 significant digits of accuracy)]
	Unit	N/A
	Default	-
Kp	Description	Proportional gain
	Data Type	LREAL
	Range	[-1.7E308 to 1.7E308 and -1.7E-308 to 1.7E-308 (14 to 15 significant digits of accuracy)]
	Unit	N/A

	Default	-
Ti	Description	Integral gain
	Data Type	LREAL
	Range	[-1.7E308 to 1.7E308 and -1.7E-308 to 1.7E-308 (14 to 15 significant digits of accuracy)]
	Unit	N/A
	Default	-
Td	Description	Derivative gain
	Data Type	LREAL
	Range	[-1.7E308 to 1.7E308 and -1.7E-308 to 1.7E-308 (14 to 15 significant digits of accuracy)]
	Unit	N/A
	Default	-
DeviceFBValue	Description	Analog input
	Data Type	DINT
	Range	[-2147483648 to +2147483647]
	Unit	N/A
	Default	-
DeviceSetPoint	Description	Analog set point
	Data Type	DINT
	Range	[-2147483648 to +2147483647]
	Unit	N/A
	Default	-
ErrorDB	Description	Maximum or minimum error between DeviceFBValue and DeviceSetPoint before a change will take place.
	Data Type	LREAL
	Range	[-1.7E308 to 1.7E308 and -1.7E-308 to 1.7E-308 (14 to 15 significant digits of accuracy)]
	Unit	N/A
	Default	-
RatioLimitPercent	Description	Maximum and minimum master/slave ratio window
	Data Type	LREAL
	Range	[-1.7E308 to 1.7E308 and -1.7E-308 to 1.7E-308 (14 to 15 significant digits of accuracy)]

	Unit	N/A
	Default	-
ErrorCalcMode	Description	Not set: DeviceFBValue-DeviceSetPoint, Set: DeviceSetPoint-DeviceFBValue
	Data Type	BOOL
	Range	[0,1]
	Unit	N/A
	Default	-

6.2.0.39.1.2 Output

OK	Description	The output will have power flow after the enable input has been energized.
	Data Type	BOOL
	Range	[0,1]
	Unit	N/A
NewRatio	Description	New master/slave ratio
	Data Type	REAL
	Range	[-3.4E38 to 3.4E38 and -3.4E-38 to 3.4E-38 (6 to 7 significant digits of accuracy)]
	Unit	N/A
Error	Description	Function block error
	Data Type	BOOL
	Range	[0,1]
	Unit	N/A
ErrorID	Description	Function block error value
	Data Type	INT
	Range	[-32768 to +32767]
	Unit	N/A

6.2.0.39.2 Usage

This Kollmorgen UDFB is used in conjunction with the main ladder MC_GearIn function and it is assumed that the master/slave move is active. Internal to the Kollmorgen UDFB is another call to the MC_GearIn function therefore the MasterID, SlaveID, RatioNumerator, RatioDenominator, Acceleration, Deceleration, and Jerk inputs are the same values as the main ladder MC_GearIn function input values, both with the Buffer input of 0. This assures that the initial starting master/slave ratio will transition to the new Kollmorgen UDFB ratio smoothly.

This Kollmorgen UDFB will change the master/slave ratio that was defined by the MC_GearIn function based on the error between the analog input and the analog set-point. The magnitude of

the ratio and the rate of the ratio change is defined by the Kp, Ti, Td PID gain values. The new ratio calculated is output at the NewRatio output.

The RatioLimitPercent input is the maximum and minimum theoretical new ratio that can be changed. This provides a +/- window limit around the running ratio to prevent unwanted motion in the event of a web break or analog feedback failure.

6.2.0.39.2.1 Example 1

NOTE

This example assumes that the analog feedback device is located *after* (or downstream in the process) the feedroll axis.

RatioNumerator = 1
 RatioDemominator = 2 Therefore the master/slave starting ratio is 0.5000000
 ErrorCaclMode = 0
 DeviceFBValue = 6
 DeviceSetPoint = 4 Therefore error $6 - 4 = 2$
 Kp = 0.005
 Ti = 0
 Td = 0

From the equation:

New RatioDemominator = (RatioDemoninator - Kp * error)

Therefore the new RatioDenominator = $(2 - 0.005 * 2) = 1.99$

Thus the new master/slave running ratio is $1 / 1.99 = 0.502512562$

Since the master/slave ratio is greater than the previous ratio the slave axis is going faster and the tension is reduced.

6.2.0.39.2.2 Example 2

NOTE

This example assumes that the analog feedback device is located *before* (or upstream in the process) the feedroll axis.

This is the same example as example 1 with the exception of the ErrorCaclMode input Boolean set.

RatioNumerator = 1
 RatioDemominator = 2 Therefore the master/slave starting ratio is 0.5000000
 ErrorCaclMode = 1
 DeviceFBValue = 6
 DeviceSetPoint = 4 Therefore error is $4 - 6 = -2$
 Kp = 0.005
 Ti = 0
 Td = 0

From the equation:

New RatioDemominator = (RatioDemoninator - (Kp * error))


Therefore the new RatioDenominator = $(2 + 0.005 * 2) = 2.01$

Thus the new master/slave running ratio is $1 / 2.01 = 0.497512437$

Since the master/slave ratio is less than the previous ratio the slave axis is going slower and the tension is reduced.

6.2.0.39.2.3 PID Function in KAS:

There is a PID function in KAS that could be used for the PID control section in the Kollmorgen UDFB.



6.2.0.39.2.4 Programming tips:

The First Order Digital Filter Kollmorgen UDFB can be used to decrease excess dither on the analog input. The filtered analog value is then used at the DeviceFBValue input of the MCFB_GearedWebTension Kollmorgen UDFB .

The assumption is a MC_GearIn function block is first called in the main ladder and these initial values are then used at the inputs for the Kollmorgen UDFB. The resolution of the initial MC_GearIn the RatioNumerator and RatioDenominator inputs are directly related to the resolution of the calculated master/slave ratio (from the Kollmorgen UDFB inputs) and may need to be scaled accordingly.

6.2.0.40 Example 1

No scaling

Initial MC_GearIn input RatioNumerator = 2

Initial MC_GearIn input RatioDenominator = 1 then initial Master/Slave ratio = 2

Kollmorgen UDFB input RatioNumerator = 2

Kollmorgen UDFB input RatioDenominator = 1 then Kollmorgen UDFB Master/Slave ratio = 2

Kollmorgen UDFB input DeviceFBValue = 4

Kollmorgen UDFB input DeviceFBSetpoint = 3 then Device PID error = 1 assume KP = 1, Ti and Td =0

New Kollmorgen UDFB RatioNumerator = Current RatioNumerator - PID error = 2 - 1 = 1 then new Kollmorgen UDFB Master/Slave ratio = 1

Resolution = Master/Slave ratio:PID Error ratio = 1:1

The resolution is so coarse that a change of 1 for the error output of the PID creates a Master/Slave ratio change of 1. This results is a significant change to the slave velocity that will probably cause excess slack or web breakage.

6.2.0.41 Example 2

Scaling value = 1000

Initial MC_GearIn input RatioNumerator = 2

Initial MC_GearIn input RatioDenominator = 1 then initial Master/Slave ratio = 2

Kollmorgen UDFB input RatioNumerator = 2000

Kollmorgen UDFB input RatioDenominator = 1000 then Kollmorgen UDFB Master/Slave ratio = 2

Kollmorgen UDFB input DeviceFBValue = 4

Kollmorgen UDFB input DeviceFBSetpoint = 3 then Device PID error = 1 assume KP = 1, Ti and Td =0

New Kollmorgen UDFB RatioNumerator = Current RatioNumerator - PID error = 2000- 1 =1999

then new Kollmorgen UDFB Master/Slave ratio = 1999

Resolution = Master/Slave ratio:PID Error ratio = 2000:1


This resolution is much finer than example 1 so for a change of 1 for the error output of the PID this creates a Master/Slave ratio change of 1999. This results in a slower rate of change to the slave velocity that is more suited to good tension in a machine process.

6.2.0.41.1 Related Functions


"FB_FirstOrderDigitalFilter" (→ p. 643)

6.2.0.41.2 Example

6.2.0.41.2.1 Ladder Example



6.2.0.41.2.2 Function Block Diagram Example



6.2.0.41.2.3 Structured Text Example

```

Inst_MCFB_GearedWebTension
( DInput_1 FALSE , Axis1, Axis2, UDFBRatioNumerator 0 , UDFBRatioDenominator 0 ,
500.0, 500.0, 0.0,1.0, 0.0,0.0, AnalogInputValue 0.0 , 3.0, 0.0, 50.0, NeverSet FALSE );
WebTensionOk FALSE :=Inst_MCFB_GearedWebTension.OK FALSE ;
NewGearRatio 0.0 :=Inst_MCFB_GearedWebTension.NewRatio 0.0 ;
WebTensionError FALSE :=Inst_MCFB_GearedWebTension.Error FALSE ;
WebTensionErrorID 0 :=Inst_MCFB_GearedWebTension.ErrorID 0 ;
    
```

6.2.0.42 FB_Cylinder



- This function block can be used to control a cylinder and the Limit Switches.

There are two inputs InA and InB to set the direction of the movement and the belonging LimSwitches LsA and LsB.

If InA is set to TRUE the output DirA is set to TRUE and after a time value defined by CtrlTime the LsA has to become TRUE otherwise a fault FaultLsA appears. Just as in direction B.

If both LsA and LsB are TRUE then a Fault depending of the output is set. If both InA and InB are given (e.g. to stop the cylinder movement) no limit switch is controlled.

All faults can be reset by input iResetFault.

6.2.0.42.1 Arguments

6.2.0.42.1.1 Input

iInA	Description	Set direction A
	Data type	BOOL
iInB	Description	Set direction B
	Data type	BOOL
iLsA	Description	Limit Switch at End of direction A
	Data type	BOOL
iLsB	Description	Limit Switch at End of direction B
	Data type	BOOL

iCtrlTime	Description	Max Time till Lim.Sw. has to be reached
	Data type	TIME
iResetFault	Description	Reset Fault (Is set to FALSE by UDFB!)
	Data type	BOOL

6.2.0.42.1.2 Output


oDirA	Description	Direction A
	Data type	BOOL
oDirB	Description	Direction B
	Data type	BOOL
oFaultLsA	Description	Fault of Lim.Sw. at End direction A
	Data type	BOOL
oFaultLsB	Description	Fault of Lim.Sw. at End direction B
	Data type	BOOL

6.2.0.42.2 Usage

The signal flow is valid for both directions (A and B)

If oDirA AND oDirB are active there is no Fault Control.

The Fault can be reset by iRestFault = True.




6.2.0.42.3 Example

6.2.0.42.3.1 ST


```
//Electric Cylinder with limit switch controls
Inst_FB_Cylinder( dirA, dirB, LimitSwitchA, LimitSwitchB, CtrlTime,
ResetFault );
A := Inst_FB_Cylinder.oDirA;
```

```
B := Inst_FB_Cylinder.oDirB;
FaultLimitSwitchA := Inst_FB_Cylinder.oFaultLsA;
FaultLimitSwitchB := Inst_FB_Cylinder.oFaultLsB;
```

6.2.0.42.3.2 Function Block Diagram



6.2.0.42.3.3 FFLD



6.2.0.43 FB_AKDFltRpt

PLCopen ✓
Pipe Network ✓

- Outputs AKD drive fault Information.

The oFAULT output turns TRUE when the selected drive goes into a fault state. This function block outputs the total number of faults in the AKD drive fault history variable (Pre-Defined Error Field Object 1003h), and the fault number and message for the last 3 drive faults.

Each fault has two outputs: the fault number and a fault message. The fault number is the same number as reported on the display of the AKD drive. The fault message provides a short description of the fault. For example if the first fault is a feedback error with a F401 displayed on the front of the drive, the output of this FB are:

- **oFirstFaultNumber** = 401
- **oFirstFaultMessage** = Failed To Set Feedback Type

The **iResetfaultHistory** Input resets the faults reported by the FB.

The **oDriveNotUsed** outputs a 1 (True) if the axis is configured to Simulated in the ProjectEthercat setup screen.

TIP

This function block lists the *earliest occurring* fault first. This may not be the same fault as is being reported on an AKD's display, which is based on priority. The "MCFB_AKDFault" (→ p. 717) function block may be preferred as it reports the same error as displayed on the drive.

This function Block can be used with either the PipeNetwork or PLCopen Motion engines. The following figure shows the function block I/O:




Figure 1-166: AKDFltRpt

6.2.0.43.1 Arguments

6.2.0.43.1.1 Input

EN	Description	ENABLES the Kollmorgen UDFB (used in FFLD editor only)
	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A
	Default	—
iEtherCat_ID	Description	EtherCAT address desired AKD Drive ex. 1001 or AKD_1
	Data type	INT
	Range	—
	Unit	N/A
	Default	—
iRstFltHist	Description	When input is TRUE, clears all Faults saved to drives history
	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A
	Default	—

6.2.0.43.1.2 Output

oFAULT	Description	TRUE if selected drive currently has a Fault
	Data type	BOOL
	Unit	N/A
oNumberFaults	Description	Number of faults saved in the Drive's history

	Data type	DINT
	Range	[0 , 10]
	Unit	N/A
oFirstFaultNumber	Description	Three digit AKD Fault identifier
	Data type	DINT
	Range	[100 , 999]
	Unit	N/A
oFirstFaultMessage	Description	Description of the Fault
	Data type	STRING
	Unit	N/A
oSecondFaultNumber	Description	Three digit AKD Fault identifier.
	Data type	DINT
	Range	[100 , 999]
	Unit	N/A
oSecondFaultMessage	Description	Description of the Fault
	Data type	STRING
	Unit	N/A
oThirdFaultNumber	Description	Three digit AKD Fault identifier
	Data type	DINT
	Range	[100 , 999]
	Unit	N/A
oThirdFaultMessage	Description	Description of the Fault
	Data type	STRING
	Unit	N/A
oDriveNotUsed	Description	Is this Drive Real (0) on Simulated (1)
	Data type	BOOL
	Unit	N/A

6.2.0.43.2 Usage

Typical usage for this UDFB are:

- Provide drive fault information that the application program uses to determine next steps such as perform a machine controlled stop or perform an immediate disable of the servo drives.
- In the application program send output fault information from this UDFB to the HMI for review by the machine operator.

6.2.0.43.3 Related Functions

"MC_ReadStatus" (→ p. 295) (PLCopen Motion Engine)

"MLAxisStatus" (→ p. 96) (Pipe Network Motion Engine)

"MCFB_AKDFault" (→ p. 717)

6.2.0.43.4 Example


6.2.0.43.4.1 Structured Text

```
//Execute the Function Block
l_AKDFltRpt (1001, resetFaultHistST);


//Read Function Block Outputs
AKD1_Fault:= A1_AKDFltRpt.oFault;
AKD1_NumFault:= A1_AKDFltRpt.oNumberFaults;
AKD1_FirstFaultNumber:= A1_AKDFltRpt.oFirstFaultNumber;
AKD1_FirstFaultMessage:= A1_AKDFltRpt.oFirstFaultMessage;
AKD1_SecondFaultNumber:= A1_AKDFltRpt.oSecondFaultNumber;
AKD1_SecondFaultMessage:= A1_AKDFltRpt.oSecondFaultMessage;
AKD1_ThirdFaultNumber:= A1_AKDFltRpt.oThirdFaultNumber;
AKD1_ThirdFaultMessage:= A1_AKDFltRpt.oThirdFaultMessage;
;
```

NOTE
A1_FaultReporting is an instance of the FB_S700FltRpt function block.

6.2.0.43.4.2 Ladder Diagram



6.2.0.43.4.3 Function Block Diagram



6.2.0.44 FB_S700FltRpt



- Outputs S700 drive fault Information.

The oFAULT output turns TRUE when the selected drive goes into a fault state. This function block outputs the total number of faults in the S700 drive fault history variable (FLTHIST), and the fault number and message for the last 3 drive faults.

Each fault has two outputs: the fault number and a fault message. The fault number is the same number as reported on the display of the S700 drive. The fault message provides a short description of the fault. For example if the first fault is a feedback error with a F04 is displayed on the front of the drive, the output of this FB are:

- **oFirstFaultNumber** = 04
- **oFirstFaultMessage** = Feedback Error

The **iResetfaultHistory** Input resets the faults reported by the FB.

The **oDriveNotUsed** outputs a 1 (True) if the axis is configured to Simulated in the ProjectEthercat setup screen.

This function Block can be used with either the PipeNetwork or PLCopen Motion engines.

The following figure shows the function block I/O:




Figure 1-167: S700FltRpt

6.2.0.44.1 Arguments

6.2.0.44.1.1 Input

EN	Description	ENABLES the Kollmorgen UDFB (used in FFLD editor only)
	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A
	Default	—
iEtherCat_ID	Description	EtherCAT address desired AKD Drive ex. 1001 or AKD_1
	Data type	DINT
	Range	—
	Unit	N/A
	Default	—
iRstFltHist	Description	When input is TRUE, clears all Faults saved to drives history
	Data type	BOOL
	Range	[0 , 1]
	Unit	N/A

Default —

6.2.0.44.1.2 Output

oFAULT	Description	TRUE if selected drive currently has a Fault
	Data type	BOOL
	Unit	N/A
oNumberFaults	Description	Number of faults saved in the Drive's history
	Data type	DINT
	Range	[0 , 10]
	Unit	N/A
oFirstFaultNumber	Description	Two digit S700 drive Fault identifier
	Data type	DINT
	Range	[00 , 32]
	Unit	N/A
oFirstFaultMessage	Description	Description of the Fault
	Data type	STRING
	Unit	N/A
oSecondFaultNumber	Description	Two digit S700 drive Fault identifier
	Data type	DINT
	Range	[00 , 32]
	Unit	N/A
oSecondFaultMessage	Description	Description of the Fault
	Data type	STRING
	Unit	N/A
oThirdFaultNumber	Description	Two digit S700 drive Fault identifier
	Data type	DINT
	Range	[00 , 32]
	Unit	N/A
oThirdFaultMessage	Description	Description of the Fault
	Data type	STRING
	Unit	N/A
oDriveNotUsed	Description	Is this Drive Real (0) on Simulated (1)
	Data type	BOOL
	Unit	N/A

6.2.0.44.2 Usage

Typical usage for this UDFB are:

- Provide drive fault information that the application program uses to determine next steps such as perform a machine controlled stop or perform an immediate disable of the servo drives.
- In the application program send output fault information from this UDFB to the HMI for review by the machine operator.

6.2.0.44.3 Related Functions

[MC_ReadStatus](#) (PLCopen Motion Engine)

[MLAxisStatus](#) (Pipe Network Motion Engine)

6.2.0.44.4 Example

6.2.0.44.4.1 Structured Text

```


//Execute the Function Block
A1_FaultReporting (1001, 0);

//Read Function Block Outputs
A1_Fault:= A1_FaultReporting.oFault;
A1_NumFault:= A1_FaultReporting.oNumberFaults;
A1_FirstFaultNumber:= A1_FaultReporting.oFirstFaultNumber;
A1_FirstFaultMessage:= A1_FaultReporting.oFirstFaultMessage;
A1_SecondFaultNumber:= A1_FaultReporting.oSecondFaultNumber;
A1_SecondFaultMessage:= A1_FaultReporting.oSecondFaultMessage;
A1_ThirdFaultNumber:= A1_FaultReporting.oThirdFaultNumber;
A1_ThirdFaultMessage:= A1_FaultReporting.oThirdFaultMessage;
A1_Simulated:= A1_FaultReporting.oDriveNotUsed;
    
```


NOTE

A1_FaultReporting is an instance of the FB_S700FltRpt function block.

6.2.0.44.4.2 Ladder Diagram



6.2.0.44.4.3 Function Block Diagram



6.2.0.45 FB_AxisPLsPosModulo



- This function block can be used for any position of a modulo axis in both directions. The Boolean output oPLS is set to TRUE if the position has crossed the start position and is set to FALSE if the position has crossed the end position. The function block is executed cyclically. The function block has the possibility to compensate a delay time of the connected device, e.g. glue nozzles. It is also possible to define a hysteresis for switching on and off of the PLS.

6.2.0.45.1 Arguments

6.2.0.45.1.1 Input


ibExecute	Description	Enable PLS
	Data type	BOOL
iPosition	Description	Any position of a modulo axis
	Data type	LREAL
iModuloPosition	Description	Modulo position of axis
	Data type	LREAL
iStartPos	Description	Start position of PLS
	Data type	LREAL
iEndPos	Description	End position of PLS
	Data type	LREAL
iDelayTime	Description	Delay time for compensation
	Data type	TIME
iHysteresis	Description	Hysteresis
	Data type	LREAL
ibForce	Description	Force PLS
	Data type	BOOL

6.2.0.45.1.2 Output


oPLS	Description	Position limit switch
	Data type	BOOL

6.2.0.45.2 Example

6.2.0.45.3 Timing



6.2.0.45.4 Hysteresis




6.2.0.45.4.1 ST

```
//PLSOutput is True when position input is between 180 and 270 with a
T#2ms delay
//Can also force the output to be true with ForceOuput variable
//Hysteresis is on for 3 user units in case direction changes around
start point


Inst_FB_AxisPlsPosModulo( EnablePLS, ActualPosition, ModuloPosition, 180,
270, T#2ms, 3, ForcePLS );

PLSOutput := Inst_FB_AxisPlsPosModulo.oPLS;
```

6.2.0.45.4.2 Function Block Diagram



6.2.0.45.4.3 FFLD



6.2.0.46 FB_AxisPlsPosNoModulo

PLCopen ✓

Pipe Network ✓

- This function block can be used for any position of a non-modulo axis in both directions. The Boolean output oPLS is set to TRUE if the position has crossed the start position and is set to FALSE if the position has crossed the end position. The function block has the possibility to compensate a delay time of the connected device, e .g. glue nozzles. It is also possible to define a hysteresis for switching on and off of the PLS.

6.2.0.46.1 Arguments

6.2.0.46.1.1 Input


ibExecute	Description	Enable PLS
	Data type	BOOL
iPosition	Description	Any position of a none-modulo axis
	Data type	LREAL
iStartPos	Description	Start position of PLS
	Data type	LREAL
iEndPos	Description	End position of PLS
	Data type	LREAL
iDelayTime	Description	Delay time for compensation
	Data type	TIME
iHysteresis	Description	Hysteresis
	Data type	LREAL
ibForce	Description	Force PLS
	Data type	BOOL

6.2.0.46.1.2 Output


oPLS	Description	Position limit switch
	Data type	BOOL

6.2.0.46.2 Example

6.2.0.46.3 Timing



6.2.0.46.4 Hysteresis




6.2.0.46.4.1 ST

```
//PLSOutput is True when position input is between 180 and 270 with a
T#2ms delay
//Can also force the output to be true with ForceOutput variable
//Hysteresis is on for 3 user units in case direction changes around
start point


Inst_FB_AxisPlsPosNoModulo( EnablePLS, ActualPosition, 180, 270, T#2ms,
3, ForcePLS );

PLSOutput := Inst_FB_AxisPlsPosNoModulo.oPLS;
```

6.2.0.46.4.2 FBD



6.2.0.46.4.3 FFLD



Appendix A: Index

A

Abort Camming	330
Abort Gearing	350, 354
actual position	
pipe network	105
actual velocity	289
Adapter, E/IP	566
AKDFaultLookup	
PLCopen	717, 719
AKDFltRpt	778
ASCII	521
AXIS_GROUP_REF	453
AxisPlsPosModulo	785
AxisPlsPosNoModulo	787

C

Cam	
Aborting	330
Coordinated Motion	
Group Control items	424
Info items	460
List of Function Blocks	421
Motion items	479
Reference items	516
copyrights	2
curve	
synchronizer	233
cycle	
missed	521

D

debug	
EtherCAT	549
delay compensation	250
disclaimer	2
DriveFault	
PipeNetwork	666
PLCopen	720
DriveParamRead	522
DriveParamStrRead	527
DriveParamWrite	530

E

ECAT Restart	
PLCopen	723
ECATGetObjVal	547
ECATReadData	549
ECATReadSdo	551
ECATWCStatus	555
ECATWriteData	556
ECATWriteSdo	558

ECERR_DEVICE_ERROR	536
ECERR_INVALID_ARRAY_SIZE	536
EIP	566
endian	631, 636
EtherCAT	
image	549, 556
timeout	525, 529, 533, 565
EtherCAT library	520
EtherCAT library function	
DriveParamRead	522
DriveParamStrRead	527
DriveParamWrite	530
ECATGetObjVal	547
ECATReadData	549
ECATReadSdo	551
ECATWCStatus	555
ECATWriteData	556
ECATWriteSdo	558
F	
falling edge	246
fast input	55, 251
fbCylinder	776
feed-forward	
torque-	138
feedback position	46, 105
FSoE	562
FSoEParamsInit	562
G	
Gear	
Aborting	350, 354
generator position	105
GetCtrlPerf	577
H	
HomeFindHomeFastInput	688
HomeFindHomeFastInputModulo	694
HomeFindHomeInput	671
HomeFindHomeInputThenZeroAngle	674
HomeFindLimitFastInput	700
HomeFindLimitFastInputModulo	705
HomeFindLimitInput	676
HomeFindLimitInputThenZeroAngle	678
HomeFindZeroAngle	680
HomeMoveUntilPosErrExceeded	682
HomeMoveUntilPosErrExceededThenZeroAngle	684
HomeUsingCurrentPosition	687
homing	372
I	
image EtherCAT	549, 556

J**Jog**

Pipe Network	710
PLCopen	766

K

Kollmorgen UDFB	643, 650, 658
AKDFaultLookup	717, 719
AKDFltRpt	778
AxisPlsPosModulo	785
AxisPlsPosNoModulo	787
DriveFault	666, 720
ECATRestart	669, 723
fbCylinder	776
HomeFindHomeFastInput	688
HomeFindHomeFastInputModulo	694
HomeFindHomeInput	671
HomeFindHomeInputThenZeroAngle	674
HomeFindLimitFastInput	700
HomeFindLimitFastInputModulo	705
HomeFindLimitInput	676
HomeFindLimitInputThenZeroAngle	678
HomeFindZeroAngle	680
HomeMoveUntilPosErrExceeded	682
HomeMoveUntilPosErrExceededThenZeroAngle	684
HomeUsingCurrentPosition	687
Jog	710, 766
PlsPosFw	712
PlsPosFwBw	713
PlsTimeFw	715
S700FltRpt	781
ScaleInput	653
ScaleOutput	656
StepAbsolute	725
StepAbsSwitch	728
StepAbsSwitchFastInput	753
StepBlock	735
StepLimitSwitch	741
StepLimitSwitchFastInput	760
StepRefPulse	747
TemperaturePID	663

L

latency	255
----------------------	------------

M

Mark-to-Machine	376
Mark-to-Mark	376
MC_AbortTrigger	277
MC_AddSuperAxis	392
MC_AxisSetDefaults	480
MC_CamIn	330
MC_CamOut	338
MC_CamResumePos	341
MC_CamStartPos	343
MC_CamTbiSelect	347

MC_ClearFaults	258
MC_CreateAxesGrp	427
MC_CreatePLCAxis	259
MC_ErrorDescription	271, 396
MC_EStop	263
MC_GearIn	350
MC_GearInPos	354
MC_GearOut	360
MC_GrpDisable	430
MC_GrpEnable	432
MC_GrpHalt	483
MC_GrpReadActAcc	461
MC_GrpReadActPos	463
MC_GrpReadActVel	466
MC_GrpReadBoolPar	434
MC_GrpReadCmdPos	469
MC_GrpReadCmdVel	471
MC_GrpReadError	474
MC_GrpReadStatus	475
MC_GrpReset	438
MC_GrpSetOverride	486
MC_GrpSetPos	516
MC_GrpStop	440
MC_GrpWriteBoolPar	443
MC_Halt	301
MC_InitAxesGrp	447
MC_InitAxis	264
MC_InitAxisFeedback	267
MC_MachRegist	376
MC_MarkRegist	384
MC_MoveAbsolute	304
MC_MoveAdditive	309
MC_MoveCircAbs	488
MC_MoveCircRel	494
MC_MoveDirAbs	500
MC_MoveDirRel	503
MC_MoveLinAbs	506
MC_MoveLinRel	511
MC_MoveRelative	313
MC_MoveSuperimp	317
MC_MoveVelocity	321
MC_Phasing	362
MC_Power	269
MC_ReadActPos	286
MC_ReadActVel	288
MC_ReadAxisErr	290
MC_ReadBoolPar	292
MC_ReadParam	293
MC_ReadStatus	295
MC_Reference	368
MC_RemSuperAxis	394
MC_ResetError	273
MC_SetKinTra	452
MC_SetOverride	328
MC_SetPos	373
MC_SetPosition	376
MC_Stop	274
MC_StopRegist	390
MC_SyncSlaves	366
MC_TouchProbe	279

MC_UngroupAllAxes	455
MC_WriteBoolPar	297
MC_WriteParam	299
missing PLC cycles	521
MLAxisAbs	47
MLAxisActualPos	82
MLAxisAdd	51
MLAxisClrErrors	94
MLAxisGenStatus	85
MLAxisPowerOff	79
MLAxisPowerOn	79
MLAxisRefPos	57
MLAxisRun	77
MLAxisSetZero	106
MLCNVConECAT	135
MLPNAxisCreate	107
MLPrfGetIRatio	116
MLPrfGetORatio	119
MLPrfSetIRatio	121
MLPrfSetORatio	124
MLProfileRelease	410
MLSmpConPLCAxis	227
MLSmpConPNAxis	228
MLTrigGetPos	252
MLTrigGetTime	254
Modulo calculation, MLTrigReadPos	251
motion library	20
adder	20
Axis	45
Block	33
CAM Profile	110
Comparator	125
Convertor	134
Delay	143
Derivator	144
Gear	149
Integrator	164
Master	167
Phaser	193, 521-522
Pipe	38
PMP	201
Sampler	223
State Machine	413
Synchronizer	233
Trigger	242
motion library function	
MC_AbortTrigger	277
MC_CamIn	330
MC_CamOut	338
MC_CamTblSelect	347
MC_ClearFaults	258
MC_CreatePLCAxis	259
MC_EStop	263
MC_GearIn	350
MC_GearInPos	354
MC_GearOut	360
MC_Halt	301
MC_InitAxis	264
MC_InitAxisFeedback	267
MC_MachRegist	376

MC_MarkRegist	384
MC_MoveAbsolute	304
MC_MoveAdditive	309
MC_MoveRelative	313
MC_MoveSuperimp	317
MC_MoveVelocity	321
MC_Phasing	362
MC_Power	269
MC_ReadActPos	286
MC_ReadActVel	288
MC_ReadAxisErr	290
MC_ReadBoolPar	292
MC_ReadParam	293
MC_ReadStatus	295
MC_Reference	368
MC_ResetError	273
MC_SetKinTra	452
MC_SetOverride	328
MC_SetPos	373
MC_SetPosition	376
MC_Stop	274
MC_StopRegist	390
MC_SyncSlaves	366
MC_TouchProbe	279
MC_WriteBoolPar	297
MC_WriteParam	299
MLAxisAbs	47
MLAxisAdd	51
P	
phasing	
synchronizer pipe block	233
pipe position	105
PlsPosFw	712
PlsPosFwBw	713
PlsTimeFw	715
position	
actual position	105
feedback position	46, 105
generator position	105
pipe position	105
reference position	47, 105, 125
Position	
Zero Offset	105
R	
reference position	47, 105, 125
registration	274, 376, 384
rising edge	246
robot	452, 457
S	
S-curve	213
S700FltRpt	781
ScaleInput	653
ScaleOutput	656
servo axis	264

state machine	
motion	414
stats	521-522
StepAbsolute	725
StepAbsSwitch	728
StepAbsSwitchFastInput	753
StepBlock	735
StepLimitSwitch	741
StepLimitSwitchFastInput	760
StepRefPulse	747
SuperimposedCmdPos	392, 394
T	
TCP/IP	606
TCP/IP, functions	606
TemperaturePID	663
timeout	
EtherCAT	525, 529, 533, 565
torque feed-forward	138
trademarks	2
U	
UDFB	
INOUT	643
out	643
UDP Functions;udpAddrMake	622
UDP Functions;udpClose	624
UDP Functions;udpCreate	625
UDP Functions;udpIsValid	626
UDP Functions;udpRcvFrom	627
UDP Functions;udpRcvFromArray	629
UDP Functions;udpSendTo	633
UDP Functions;udpSendToArray	634
V	
Velocity, current	338, 360
Z	
Zero Offset	
Pipe Network	105

--- / ---

7 Support and Services

About KOLLMORGEN

Kollmorgen is a leading provider of motion systems and components for machine builders. Through world-class knowledge in motion, industry-leading quality and deep expertise in linking and integrating standard and custom products, Kollmorgen delivers breakthrough solutions that are unmatched in performance, reliability and ease-of-use, giving machine builders an irrefutable marketplace advantage.



Join the [Kollmorgen Developer Network](#) for product support. Ask the community questions, search the knowledge base for answers, get downloads, and suggest improvements.

North America KOLLMORGEN

201 West Rock Road
Radford, VA 24141, USA

Web: www.kollmorgen.com
Mail: support@kollmorgen.com
Tel.: +1 - 540 - 633 - 3545
Fax: +1 - 540 - 639 - 4162

Europe KOLLMORGEN Europe GmbH

Pempelfurtstr. 1
40880 Ratingen, Germany

Web: www.kollmorgen.com
Mail: technik@kollmorgen.com
Tel.: +49 - 2102 - 9394 - 0
Fax: +49 - 2102 - 9394 - 3155

South America KOLLMORGEN

Avenida João Paulo Ablas, 2970
Jardim da Glória, Cotia - SP
CEP 06711-250, Brazil

Web: www.kollmorgen.com
Mail: contato@kollmorgen.com
Tel.: +55 11 4615-6300

China and SEA KOLLMORGEN

Room 302, Building 5, Lihpao Plaza,
88 Shenbin Road, Minhang District,
Shanghai, China.

Web: www.kollmorgen.cn
Mail: sales.china@kollmorgen.com
Tel.: +86 - 400 668 2802
Fax: +86 - 21 6248 5367